



ATV Illustrated Parts Manual

ATV 500 MF


2005

MASSEY FERGUSON

TABLE OF CONTENTS

FRONT BODY PANEL ASSEMBLY	3
REAR BODY PANEL ASSEMBLY	4
TAILLIGHT ASSEMBLY	5
DECALS	6
FRAME AND RELATED PARTS	7
SEAT ASSEMBLY	8
STEERING POST ASSEMBLY	9
HANDLEBAR ASSEMBLY	10
FRONT SUSPENSION ASSEMBLY	11
REAR SUSPENSION ASSEMBLY	12
WHEEL AND TIRE ASSEMBLY	13
AUXILIARY BRAKE ASSEMBLY	14
HYDRAULIC HAND BRAKE ASSEMBLY	15
HYDRAULIC BRAKE ASSEMBLY	16
GAS TANK ASSEMBLY	17
REVERSE SHIFT LEVER ASSEMBLY	18
AIR INTAKE ASSEMBLY	19
BATTERY ASSEMBLY	20
ENGINE AND EXHAUST	21
COOLING ASSEMBLY	22
CASE/BELT COOLING ASSEMBLY	23
DRIVE TRAIN ASSEMBLY	24
FRONT DRIVE GEARCASE ASSEMBLY	25
REAR DRIVE GEARCASE ASSEMBLY	26
WIRING HARNESS ASSEMBLY	27
CARBURETOR	28
CYLINDER HEAD ASSEMBLY	29
CYLINDER ASSEMBLY	30
CRANKCASE ASSEMBLY	31
CLUTCH/V-BELT/MAGNETO COVER ASSEMBLY	32
CRANKSHAFT ASSEMBLY	33
STARTER CLUTCH ASSEMBLY	34
CRANK BALANCER ASSEMBLY	35
CAMSHAFT/VALVE ASSEMBLY	36
CAM CHAIN ASSEMBLY	37
RECOIL STARTER ASSEMBLY	38
OIL FILTER/PUMP ASSEMBLY	39
WATER PUMP ASSEMBLY	40
TRANSMISSION ASSEMBLY	41
SECONDARY TRANSMISSION ASSEMBLY	42
SECONDARY DRIVE ASSEMBLY	43
GEAR SHIFTING ASSEMBLY	44
STARTER MOTOR ASSEMBLY	45
MAGNETO ASSEMBLY	46
CONTROL SWITCH HOUSING ASSEMBLY	47
THROTTLE CASE ASSEMBLY	48
RELATED ITEMS	49



■ **NOTE:** The illustrations used in this Parts Manual are for reference to replacement part numbers only and are not to be used for assembly. For assembly procedures, use an Arctic Cat Service Manual. Underlined part numbers are new for the 2005 model year.



FRONT BODY PANEL ASSEMBLY

0739-662


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	<u>0541-272</u>	1	Rack – Front – Assembly (inc. 2-5)	15	<u>0470-513</u>	1	Cover, Storage Box
2	0411-576	1	● Decal, Warning – Front Rack Load	16	<u>1406-573</u>	1	Box, Storage
3	0411-592	4	● Bushing, Rack	17	<u>0470-514</u>	1	Lid, Storage Box
4	0441-556	6	● Bushing, Rack	18	1406-599	1	Latch, Storage Box
5	<u>1441-049</u>	2	● Plug, Rack	19	<u>1406-313</u>	1	Panel, Side – Right
6	8468-830	4	Screw, Machine		<u>1406-314</u>	1	Panel, Side – Left
7	0423-463	4	Spacer	20	<u>1406-354</u>	1	Panel, Splash – Right
8	0423-465	4	Grommet		<u>1406-355</u>	1	Panel, Splash – Left
9	8432-802	4	Nut, Lock	21	0423-342	4	Screw, Self-Tapping
10	<u>1406-606</u>	1	Panel, Fender – Front	22	0423-101	4	Screw, Body
	<u>1406-605</u>	1	Panel, Fender – Front (Green)	23	0123-788	AR	Cable Tie – 7.5 in.
	<u>1406-607</u>	1	Panel, Fender – Front (Cat Green)	24	<u>0411-818</u>	1	Decal, Reflector – Amber – Right
11	<u>1406-358</u>	1	Cover, Access		<u>0411-819</u>	1	Decal, Reflector – Amber – Left
12	<u>0423-535</u>	2	Rivet, Reinstallable	25	0423-355	2	Screw, Shoulder
13	0623-362	10	Rivet, Reinstallable	26	8050-222	2	Washer
14	<u>1406-484</u>	1	Cover, Steering Post	27	8424-602	2	Nut, Lock
Homologated ATV's				30	AC008-792	1	Holder anti theft device
28	AC000-790	1	Anti theft device	31	AC008-795	1	Star screw
29	AC000-793	1	Bracket anti theft device				



REAR BODY PANEL ASSEMBLY

0739-665


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	<u>0541-275</u>	1	Rack – Rear – Assembly (inc. 2-5)	11	0423-355	2	Screw, Shoulder
	<u>0541-285</u>	1	Rack – Rear – Assembly (inc. 2-5) (LE)	12	8050-222	2	Washer
2	<u>0411-814</u>	1	● Decal, “Arctic Cat”	13	8424-602	2	Nut
	<u>0411-947</u>	1	● Decal, “Arctic Cat” (LE)	14	<u>0411-820</u>	1	Decal, Reflector – Red - Right
3	0411-648	1	● Decal, Warning – Rear Rack Load		<u>0411-821</u>	1	Decal, Reflector – Red – Left
4	0441-592	4	● Bushing, Rack	15	0423-101	2	Screw, Body
5	0441-556	8	● Bushing, Rack	16	<u>0423-540</u>	22	Nut, Lock
6	8468-830	4	Screw, Machine	17	0623-362	2	Rivet, Reinstallable
7	0423-463	4	Spacer	18	<u>1406-356</u>	1	Footwell – Right
8	0423-465	4	Grommet		<u>1406-357</u>	1	Footwell – Left
9	8432-802	4	Nut, Lock	19	8468-616	16	Screw, Machine
10	<u>1406-284</u>	1	Panel, Fender – Rear	20	0423-355	6	Screw, Shoulder
	<u>1406-603</u>	1	Panel, Fender – Rear (Green)	21	<u>1506-125</u>	2	Footpeg
	<u>1406-604</u>	1	Panel, Fender – Rear (Cat Green)	22	<u>0412-296</u>	1	Shield, Heat
Homologated ATV's							
23	0470-404	2	Grommet				



TAILLIGHT ASSEMBLY

0739-667


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	0509-022	1	Taillight Assembly (inc. 2-4)	4	0409-057	1	● Socket, Taillight
2	0509-025	1	● Housing, Taillight	5	0623-301	2	Screw, Self-Tapping
3	0409-056	1	● Bulb, Taillight	6	8053-212	2	Washer, Lock – External Tooth
Homologated ATV's				11	AC000-223	2	Bracket, indicator
7	AC000-079	1	Taillight new	12	AC000-231	1	Bracket, rear light
8	AC000-139	2	reflector				
9	AC000-145	1	Indicator, left				
10	AC000-146	1	Indicator, right				



DECALS

0739-676

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	0411-666	1	Decal, Warning – Reverse/Pre-Ride	10	<u>0411-872</u>	1	Decal, Side – Lower Right
2	<u>0411-835</u>	1	Decal, Warning – Turn/Hill		<u>0411-873</u>	1	Decal, Side – Lower Left
3	0411-426	1	Decal, Warning – Clutch Cover		<u>0411-870</u>	1	Decal, Side – Lower Right (Green)
4	<u>0411-844</u>	1	Decal, Instrument Pod		<u>0411-871</u>	1	Decal, Side – Lower Left (Green)
	<u>0411-843</u>	1	Decal, Instrument Pod		<u>0411-874</u>	1	Decal, Side – Lower Right
	<u>0411-845</u>	1	Decal, Instrument Pod		<u>0411-875</u>	1	Decal, Side – Lower Left
5	<u>0411-964</u>	1	Decal, Crest	11	0411-430	1	Decal, Warning – Tire Pressure
6	<u>0411-840</u>	1	Decal, Front	12	0411-435	1	Decal, Passenger
	<u>0411-839</u>	1	Decal, Front (Green)	13	<u>0411-890</u>	1	Decal, Rear – Right
	<u>0411-841</u>	1	Decal, Front (Cat Green)		<u>0411-891</u>	1	Decal, Rear – Left
7	0411-401	1	Decal, Warning – Age		<u>0411-888</u>	1	Decal, Rear – Right (Green)
8	<u>0411-966</u>	1	Decal, Warning – Differential Lock		<u>0411-889</u>	1	Decal, Rear – Left (Green)
9	<u>0411-854</u>	1	Decal, Side – Upper Right		<u>0411-892</u>	1	Decal, Rear – Right (Cat Green)
	<u>0411-855</u>	1	Decal, Side – Upper Left		<u>0411-893</u>	1	Decal, Rear – Left (Cat Green)
	<u>0411-852</u>	1	Decal, Side – Upper Right (Green)	14	0411-267	1	Decal, Warning – Towing
	<u>0411-853</u>	1	Decal, Side – Upper Left (Green)	15	0411-218	1	Decal, Warning – General
	<u>0411-856</u>	1	Decal, Side – Upper Right (Cat Green)	16	<u>0411-965</u>	1	Decal, “Speedrack”
	<u>0411-857</u>	1	Decal, Side – Upper Left				
Homologated ATV's							
17	0411-949	1	Decal head	20	0411-956	1	Decal side MF RH
18	0411-952	1	Decal 500 MF LH	21	0411-957	1	Decal side MF LH
19	0411-953	1	Decal 500 MF RH				




FRAME AND RELATED PARTS

0739-649

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	<u>1506-460</u>	1	Frame, Main	16	1406-420	1	Grille, Bumper – Lower
2	0409-032	1	Headlight Assembly – Right (inc. 3-6)	17	8468-830	4	Screw, Machine
	0409-031	1	Headlight Assembly – Left (inc. 3-6)	18	8408-812	2	Screw, Cap
3	0409-045	4	● Bulb, Headlight	19	0506-653	2	Channel, Bumper
4	8410-860	2	● Screw, Cap	20	8408-816	8	Screw, Cap
5	0406-945	2	● Bracket, Headlight	21	8424-602	2	Nut, Flange
6	0423-375	2	● Nut, Flange	22	<u>1506-506</u>	1	Footrest – Right
7	8424-802	18	Nut, Flange		<u>1506-507</u>	1	Footrest – Left
8	8409-020	8	Screw, Cap	23	<u>1506-508</u>	1	Footrest, Passenger – Right
					<u>1506-509</u>	1	Footrest, Passenger – Left
9	0506-544	1	Bumper	24	0423-412	8	Screw, Machine
10	0406-130	2	Cap, Bumper	25	<u>1406-643</u>	8	Mount, Rubber
11	0406-832	1	Grille, Upper	26	<u>1406-641</u>	1	Rod, Support – Right
12	0423-361	2	Screw, Machine		<u>1406-642</u>	1	Rod, Support – Left
13	1441-006	1	Plate, Skid	27	8408-825	2	Screw, Cap
	<u>1441-008</u>	1	Plate, Skid (Green)	28	8050-282	2	Washer
	<u>1441-007</u>	1	Plate, Skid (Cat Green)	29	0406-289	1	Pad, Frame – Rear
14	1406-176	1	Panel, Belly	30	1506-067	1	Foam, Frame
15	0423-101	AR	Screw, Body				
Homologated ATV's				39	AC000-752	1	Mirror right
31	AC000-034	1	Orifice headlight, r	40	AC000-145	1	Indicator, left
32	AC000-035	1	Orifice headlight, l	41	AC000-146	1	Indicator, right
33	AC000-063	1	Embleme MF	42	AC000-753	1	Mirror mounting left
34	AC000-068	1	Grill plastic MF	43	AC000-754	1	Mirror mounting right
35	AC000-242	2	Headlight assy., MF (incl. 36, 37)				
36	● AC000-077	1	Headlight MF	44	ÂC000-158	1	horn
37	● AC000-227	1	Harness headlight 2005				
38	AC000-751	1	Mirror left				

0739-690


8



STEERING POST ASSEMBLY

0739-774


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	8408-860	4	Screw, Cap	11	0423-073	1	Washer
2	0405-035	4	Cap, Steering Adjuster	12	8409-020	1	Screw, Cap
3	0423-505	2	Screw, Shoulder	13	0505-408	2	Tie Rod – Assembly (inc. 14-18)
4	0405-166	1	Cap. Housing	14	0405-083	2	● Ball Joint, Tie Rod – Left
5	0405-138	1	Housing, Lower	15	0423-013	2	● Nut – Left
6	0405-139	1	Housing, Upper	16	0405-107	2	● Tie Rod
7	0505-451	1	Post, Steering	17	8420-002	2	● Nut – Right
8	8408-816	2	Screw, Cap	18	0405-082	2	● Ball Joint, Tie Rod – Right
9	0602-233	1	Flange, Bearing	19	0423-157	4	Nut, Top Lock
10	0405-052	1	Bearing w/Inverted Oil Seal	20	0623-175	4	Pin, Cotter



HANDLEBAR ASSEMBLY

0739-775


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	<u>0505-448</u>	1	Tube, Handlebar	10	<u>1506-592</u>	1	Bracket, Mounting – Instrument Pod
2	<u>0405-148</u>	2	Plug, Handlebar	11	<u>0405-171</u>	1	Instrument Pod
3	<u>0405-149</u>	2	End Cap, Handlebar		<u>0405-172</u>	1	Instrument Pod (Green)
4	8050-247	2	Washer		<u>0405-173</u>	1	Instrument Pod (Cat Green)
5	8477-845	2	Screw, Machine	12	0623-362	2	Rivet, Reinstallable
6	<u>0405-147</u>	2	Grip, Handlebar	13	0423-356	1	Screw, Shoulder
7	0409-013	1	Cover, Key	14	<u>0420-054</u>	1	Gauge, Digital
8	3430-040	1	Switch, Ignition – Assembly (inc. 9)	15	8424-602	1	Nut, Flange
9	3409-007	1	● Key, Ignition – Blank (C Series)	16	0423-448	2	Grommet
	3409-011	1	● Key, Ignition – Blank (D Series)	17	<u>0502-527</u>	1	Control, Differential Lock (inc.18)
	3409-012	1	● Key, Ignition – Blank (E Series)	18	<u>0502-613</u>	1	● Clamp, Differential Lock Control-Kit
	3409-013	1	● Key, Ignition – Blank (F Series)	19	<u>0487-030</u>	1	Cable, Differential Lock
Homologated ATV's				21	● AC000-151	2	Control indicator
20	AC005-024 – 026	1	Pod speed assy. (incl. 21) (No depends on the colour)				
20a	AC005-024		Pod red				
20b	AC005-025		Pod green				
20c	AC005-026		Pod lime green				



FRONT SUSPENSION ASSEMBLY

0739-603


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	1603-889	2	Retainer, Spring	15	0403-115	8	● Bushing
2	0403-127	2	Shock Absorber - Front (inc. 3-4)	16	0403-114	4	● Collar
3	0604-310	8	● Bushing, Shock Absorber	17	<u>0505-446</u>	1	Knuckle - Assembly - Right (inc. 18-20)
4	0403-028	4	● Sleeve, Shock		<u>0505-447</u>	1	Knuckle - Assembly - Left (inc. 18-20)
5	0403-102	2	Cam, Spring Adjuster	18	<u>0505-444</u>	1	● Knuckle, Steering - Right
6	0403-129	2	Spring, Shock Absorber - Platinum		<u>0505-445</u>	1	● Knuckle, Steering - Left
	0403-128	2	Spring, Shock Absorber - Black (Green)	19	1402-027	2	● Bearing, Wheel Hub
7	8409-040	4	Screw, Cap	20	0423-423	2	● Ring, Retaining
8	8428-002	10	Nut, Lock	21	8409-030	4	Screw, Cap
9	<u>0503-272</u>	1	A-Arm, Upper Right - Platinum (inc. 10-13)	22	0423-334	2	Screw, Cap
	<u>0503-273</u>	1	A-Arm, Upper Left - Platinum (inc. 10-13)	23	8409-075	4	Screw, Cap
	0503-196	1	A-Arm, Upper Right - Black (inc. 10-13) (Green)	24	<u>0502-542</u>	1	Axle, Drive - Front - Right (inc. 25-26)
	0503-197	1	A-Arm, Upper Left - Black (inc. 10-13) (Green)		<u>0502-547</u>	1	Axle, Drive - Front - Left (inc. 25-26)
10	0403-081	4	● Bushing	25	0441-400	2	● Clip, Retaining
11	0403-080	2	● Collar	26	0436-276	2	● Repair Kit, Boot - Front Axle
12	0423-009	4	● Clip, Ball Joint	27	<u>0441-752</u>	1	Guard, Boot - Axle - Right
13	0405-115	4	● Ball Joint - Front		<u>0441-753</u>	1	Guard, Boot - Axle - Left
14	<u>0503-268</u>	1	A-Arm, Lower Right - Platinum (inc. 12-13 and 15-16)		<u>1441-002</u>	1	Guard, Boot - Axle - Right (Green)
	<u>0503-269</u>	1	A-Arm, Lower Left - Platinum (inc. 12-13 and 15-16)		<u>1441-003</u>	1	Guard, Boot - Axle - Left (Green)
	0503-220	1	A-Arm, Lower Right - Black (inc. 12-13 and 15-16) (Green)		<u>0441-756</u>	1	Guard, Boot - Axle - Right (Cat Green)
	0503-221	1	A-Arm, Lower Left - Black (inc. 12-13 and 15-16) (Green)		<u>0441-757</u>	1	Guard, Boot - Axle - Left (Cat Green)
				28	0423-101	4	Screw, Body
				29	0441-587	1	Wrench, Spanner



REAR SUSPENSION ASSEMBLY

0739-463

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	0504-312	1	Knuckle, Right Rear - Assembly (inc. 2-6)	13	<u>0441-754</u>	1	Guard, Boot - Right
	0504-313	1	Knuckle, Left Rear - Assembly (inc. 2-6)		<u>0441-755</u>	1	Guard, Boot - Left
2	0504-311	1	● Knuckle - Right		<u>1441-004</u>	1	Guard, Boot - Right (Green)
	0504-310	1	● Knuckle - Left		<u>1441-005</u>	1	Guard, Boot - Left (Green)
3	1402-027	2	● Bearing, Wheel Hub		<u>0441-758</u>	1	Guard, Boot - Right (Cat Green)
4	0423-423	2	● Ring, Retaining		<u>0441-759</u>	1	Guard, Boot - Left (Cat Green)
5	0403-038	4	● Collar, Suspension Bushing	14	0423-101	6	Screw, Body
6	0403-032	8	● Bushing, Suspension	15	1406-071	1	Guard, Boot - Right
7	<u>0504-326</u>	1	A-Arm, Rear - Lower Right - Platinum (inc. 8-9)		1406-072	1	Guard, Boot - Left
	<u>0504-327</u>	1	A-Arm, Rear - Lower Left - Platinum (inc. 8-9)	16	0502-596	2	Axle, Drive (inc. 17-18)
	0504-320	1	A-Arm, Rear - Lower Right - Black (inc. 8-9) (Green)	17	0441-400	2	● Clip, Retaining
	0504-321	1	A-Arm, Rear - Lower Left - Black (inc. 8-9) (Green)	18	0436-276	2	● Repair Kit, Boot - Rear Axle
8	0403-115	16	● Bushing	19	8409-075	8	Screw, Cap
9	0403-114	8	● Collar	20	1603-889	2	Retainer, Spring
10	8428-002	14	Nut, Lock	21	0404-074	2	Spring, Suspension - Platinum
11	8409-000	4	Screw, Cap		0404-065	2	Spring, Suspension - Black (Green)
12	<u>0504-330</u>	1	A-Arm, Rear - Upper Right - Platinum (inc. 8-9)	22	<u>0404-085</u>	2	Shock Absorber - Rear (inc. 23-24)
	<u>0504-331</u>	1	A-Arm, Rear - Upper Left - Platinum (inc. 8-9)	23	0604-310	8	● Bushing, Shock Absorber
	0504-318	1	A-Arm, Rear - Upper Right - Black (inc. 8-9) (Green)	24	0403-028	2	● Sleeve, Shock Absorber
	0504-319	1	A-Arm, Rear - Upper Left - Black (inc. 8-9) (Green)	25	0404-057	2	Cam, Spring Adjuster
				26	8409-040	2	Screw, Cap
				27	0423-087	2	Washer
				28	8408-820	2	Screw, Cap
				29	0441-587	1	Wrench, Spanner



15



16



17




17

WHEEL AND TIRE ASSEMBLY

0739-534


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	0423-029	12	Screw, Machine	9	1402-100	2	Tire – Front
2	<u>1402-225</u>	3	Disc, Brake	10	0402-064	4	Stem, Valve (inc. 11)
3	0502-599	2	Hub, Wheel-Front (inc. 4)	11	0402-140	4	● Cap, Valve Stem
4	0402-974	16	● Stud, Wheel Hub	12	0502-601	1	Hub, Wheel – Rear – Left (inc. 4)
5	0423-407	4	Pin, Cotter		0502-599	1	Hub, Wheel – Rear – Right (inc. 4)
6	0423-394	4	Nut, Castle	13	1402-115	2	Wheel – Rear – Platinum
7	1402-127	2	Wheel – Front – Platinum		0402-858	2	Wheel – Rear – Gray (Green)
	0402-856	2	Wheel – Front – Gray (Green)	14	1402-137	2	Tire – Rear
8	0423-408	16	Nut, Mounting Wheel				
Homologated ATV's				17	0502-505	1	Wheel, gray RH 25x11-12
15	0502-464	1	Wheel, gray RH 25x8-12	18	0502-506	1	Wheel, gray LH 25x11-12
16	0502-465	1	Wheel, gray LH 25x8-12				



AUXILIARY BRAKE ASSEMBLY

0739-792 *Not a Servie Part


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	<u>0502-656</u>	1	Lever, Brake	19	0123-788	1	Cable Tie 7,5 in.
2	<u>1602-213</u>	2	O-Ring	20	1402-200	1	Hose, Brake
3	<u>0502-713</u>	1	Spring, Brake Lever	21	0423-413	2	Bolt, Banjo Fitting
4	<u>8422-002</u>	1	Nut	22	0423-178	4	Washer, Crush
5	<u>0402-575</u>	1	Pin, Clevis	23	8408-825	4	Screw, Cap
6	<u>0402-583</u>	1	Washer	24	<u>0502-457</u>	1	Caliper, Brake (inc. 25-35)
7	<u>0402-584</u>	1	Pin, Cotter	25	*	1	● Housing, Caliper
8	<u>0502-665</u>	1	Brake Assembly (inc. 9-16)	26	0402-495	1	● Pin, Brake Caliper
9	<u>0402-580</u>	1	● Actuator, Push Rod	27	<u>1402-126</u>	2	● Pad, Brake
10	<u>0402-592</u>	2	● Nut, Jam	28	0423-495	1	● Pin, Cotter
11	*	1	● Master, Cylinder	29	0402-493	1	● Cap, Bleed Valve
12	<u>1402-277</u>	1	● Fitting, Banjo	30	<u>1402-123</u>	1	● Valve, Bleed
13	<u>1402-278</u>	1	● Bolt, Banjo Fitting	31	<u>1402-125</u>	2	● Piston
14	<u>0423-525</u>	2	● Clamp, Hose	32	0402-980	2	● O-Ring, Brake Caliper
15	<u>1402-266</u>	1	● Hose, Brake Reservoir	33	*	1	● O-Ring
16	<u>1402-257</u>	1	● Reservoir, Brake	34	*	1	● Plug
17	<u>8424-602</u>	1	Nut, Flanged	35	*	1	● Ring, Retaining
18	<u>8476-616</u>	1	Screw, Machine				
Homologated ATV's							
36	AC000-252	1	Brake hose				
37	AC000-254	1	Sealing screw				



HYDRAULIC HAND BRAKE ASSEMBLY

0739-479


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	<u>0502-703</u>	1	Brake Assembly (inc.2-10)	6	<u>0502-704</u>	1	● Master Cylinder Assembly – Kit
2	0502-566	1	● Screw, Reservoir Cover – Kit	7	<u>0502-634</u>	1	● Lever Assembly – Kit (inc. 8-9)
3	<u>0502-706</u>	1	● Cover, Reservoir – Kit	8	<u>0502-635</u>	1	● ● Lock, Brake Lever – Kit
4	0502-568	1	● Screw, Master Cylinder Clamp – Kit	9	0502-580	1	● ● Lever Pin – Kit
5	<u>0502-705</u>	1	● Clamp, Master Cylinder – kit	10	0502-564	1	● Switch, Brake – Kit
Homologated ATV's							
11	AC000-032	1	Protection ball				



HYDRAULIC BRAKE ASSEMBLY

0739-796


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	0502-627	1	Hose, Brake – Assembly	6	0502-606	3	● ● Piston/Seal Set (inc. 7)
2	8476-625	1	Screw, Cap	7	0502-607	3	● ● ● Seal Set
3	8408-820	6	Screw, Cap	8	0502-609	3	● ● Valve, Bleed
4	0502-602	1	Caliper, Brake – Right Front (inc. 5-11)	9	0502-608	3	● O-Ring, Guide – Set
	0502-610	2	Caliper, Brake – Left Front and Right Rear (inc. 5-11)	10	0502-605	3	● Bracket Assembly
5	0502-603	1	● Housing, Caliper – Assembly – Right Front (inc. 6-8)	11	0502-604	3	● Pad, Brake – Set
	0502-611	2	● Housing, Caliper – Assembly – Left Front and Right Rear (inc. 6-8)	12	0423-178	8	Washer, Crush
				13	0423-413	4	Bolt, Banjo Fitting



GAS TANK ASSEMBLY

0739-695


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	<u>0570-096</u>	1	Tank, Gas Assembly (inc. 2-6)	10	8476-620	2	Screw, Machine
2	0470-438	1	● Cap, Gas Tank (inc. 3)	11	8422-602	2	Nut, Lock
3	0109-733	1	● ● Gasket, Tank Cap	12	<u>1623-233</u>	2	Clamp, Hose
4	<u>0570-098</u>	1	● Sender, Fuel Level (inc. 5-6)	13	<u>0470-527</u>	1	Fitting, Straight
5	<u>0470-521</u>	1	● ● Seal, Fuel Level Sender	14	0423-460	2	Grommet
6	<u>0470-475</u>	1	● ● Filter, Fuel	15	0570-081	1	Shield, Gas Tank (inc. 16-17)
7	0423-461	6	Clamp, Hose	16	0470-499	1	● Shield, Heat
8	<u>0410-070</u>	AR	Hose, Gasline – 25 ft	17	0470-498	1	● Shield, Heat
9	<u>0470-519</u>	1	Pump, Fuel	18	8408-816	2	Screw, Cap



REVERSE SHIFT LEVER ASSEMBLY

0739-701


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	0402-843	1	Handle, Reverse Shift Lever	11	0423-299	2	O-Ring
2	0423-345	1	Clip, Push	12	8408-812	1	Screw, Cap
3	<u>1402-110</u>	1	Plate, Shift	13	0423-087	1	Washer
4	0423-357	4	Nut, Stamped	14	0623-294	2	Nut
5	<u>0502-659</u>	1	Lever, Reverse Shift	15	<u>1402-270</u>	1	End, Rod
6	0502-410	1	Spring, Reverse Shift Lever	16	<u>0502-669</u>	1	Linkage, Shift
7	<u>0502-742</u>	1	Axle, Reverse Shift Lever	17	0423-091	1	Bushing, Shift Linkage
8	8424-602	1	Nut	18	8050-242	1	Washer
9	0423-182	2	O-Ring	19	0423-169	1	E-Ring
10	0402-675	1	Axle, Pivot				



AIR INTAKE ASSEMBLY

0736-899


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	<u>0413-091</u>	1	Diverter, Air – Bottom	11	<u>0423-455</u>	4	Clip, Spring
2	<u>0413-093</u>	1	Diverter, Air – Top	12	<u>0470-525</u>	1	Boot, Carburetor
3	<u>0470-442</u>	6	Valve, Drain	13	<u>0423-554</u>	1	Clamp, Boot
4	<u>0423-380</u>	2	Clamp, Boot	14	<u>0470-516</u>	1	Screen, Air Filter
5	<u>0470-529</u>	1	Boot, Air Intake	15	<u>0470-494</u>	1	Filter, Air
6	<u>1406-747</u>	1	Shroud, Splash	16	<u>0470-495</u>	1	Seal, Air Intake Cover
7	<u>0623-362</u>	2	Rivet, Reinstallable	17	<u>0470-530</u>	1	Cover, Air Intake
8	<u>0423-342</u>	4	Screw, Self-Tapping	18	<u>0410-079</u>	1	Hose, Vent – Crankcase
9	<u>0423-454</u>	2	Clip, Mounting – Air Intake	19	<u>0423-045</u>	2	Clamp, Hose
10	<u>0470-515</u>	1	Housing, Air Intake				



BATTERY ASSEMBLY

0739-740 *Not Illustrated


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	<u>5990-839</u>	1	Battery Cover/Tool Tray Assembly (inc. 2-3)	6	0645-152	1	● Clamp, Hose
2	1406-507	1	● Cover, Battery	7	0645-263	1	● Hose, Battery Vent
3	0406-288	2	● Pad, Battery	8	0645-151	1	● Label, Warning – Battery
*	0444-122	1	Kit, Tool	9	0123-903	4	Cable Tie – 11,5 in.
4	0745-045	1	Battery Assembly (inc. 5-8)	10	8476-616	1	Screw, Machine
5	0645-045	6	● Cap, Battery				



ENGINE AND EXHAUST

0739-711


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	0462-029	1	Engine	15	<u>0412-261</u>	1	● Shield, Exhaust Pipe – Inner – Middle
2	0423-405	2	Screw, Cap	16	<u>0412-262</u>	1	● Shield, Exhaust Pipe – Outer – Middle
3	0423-426	4	Washer, Engine	17	<u>0412-264</u>	1	● Shield, Exhaust Pipe – Outer – Rear
4	0423-042	2	Spacer	18	<u>0412-263</u>	1	● Shield, Exhaust Pipe – Inner Rear
5	8428-002	2	Nut, Lock	19	<u>0423-524</u>	5	● Tie, Band
6	8408-816	2	Screw, Cap	20	<u>0512-181</u>	1	● Pipe, Exhaust
7	<u>1506-632</u>	1	Bracket, Engine – Right	21	<u>0412-215</u>	2	Bushing, Exhaust Pipe
	<u>1506-633</u>	1	Bracket, Engine – Left	22	<u>0512-209</u>	1	Clamp, Muffler
8	8408-860	1	Screw, Cap	23	<u>0412-183</u>	1	Seal, Muffler
9	8424-802	3	Nut	24	<u>0512-180</u>	1	Muffler
10	0412-007	1	Seal, Exhaust	25	<u>0412-253</u>	2	Bushing, Muffler
11	8408-820	2	Screw, Cap	26	<u>0423-476</u>	2	Screw, Shoulder
12	<u>0512-214</u>	1	Pipe, Exhaust – Assembly (inc. 13-20)	27	<u>0412-242</u>	1	Cover, Muffler
13	<u>0412-260</u>	1	● Shield, Exhaust Pipe – Outer – Front	28	8477-610	4	Screw, Machine
14	<u>0412-259</u>	1	● Shield, Exhaust Pipe – Inner - Front				
Homologated ATV's							
29	AC000-706	1	Exhaust ACE6				



COOLING ASSEMBLY

0739-654


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	0413-038	1	Radiator Assembly (inc. 2-14)	12	0123-397	1	● Clamp, Cable
2	0413-043	1	● Radiator	13	0413-045	1	● Sender, Temperature - Coolant
3	0413-007	1	● Screen, Radiator	14	0423-390	1	● O-Ring
4	0413-002	1	● Cap, Radiator	15	0423-484	2	Screw, Shoulder
5	0423-030	2	● Grommet	16	0623-038	2	Nut w/Washer
6	0610-016	AR	● Hose – 25 ft	17	0423-028	2	Bushing, Stem
7	0413-009	4	● Screw, Thumb	18	0410-002	1	Hose, Coolant – Upper
8	0413-046	2	● Shroud, Fan	19	0410-022	1	Hose, Coolant – Crossover
9	0413-044	1	● Fan, Cooling	20	0410-041	1	Hose, Coolant – Lower
10	8475-512	8	● Screw, Machine	21	0423-496	2	Clamp, Hose
11	0423-351	1	● Clamp, Wire	22	0623-751	1	Cable, Tie



CASE/BELT COOLING ASSEMBLY

0739-713


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	<u>0513-010</u>	1	Duct, Belt Cooling – Front	6	0470-442	1	Valve, Drain
2	0423-380	4	Clamp, Duct	7	0413-055	1	Boot, Duct – Rear
3	<u>0413-092</u>	1	Boot, Air-In	8	<u>0413-094</u>	1	Duct, Belt Cooling – Rear
4	3402-449	2	Clamp, Boot	9	0123-903	1	Cable, Tie – 11,5 in
5	0413-049	1	Boot, Duct - Front				



DRIVE TRAIN ASSEMBLY

0739-743

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	0402-147	2	Bladder, Gearcase	11	0410-049	AR	Hose, Vent
2	0423-315	4	Clamp, Fitting	12	0623-101	1	Clip, Routing – Snap-In
3	8428-002	4	Nut, Lock	13	0470-462	1	Fitting, Vent
4	0423-426	8	Washer	14	0423-393	2	Clamp, Boot
5	0423-404	4	Screw, Cap	15	0402-985	2	Boot
6	<u>0502-444</u>	1	Gearcase, Front	16	0423-411	2	Clamp, Boot
7	0402-966	1	Boot, Shaft	17	0673-618	2	Bumper, Propeller Shaft
8	0502-500	1	Plate, Cable	18	<u>1402-233</u>	1	Shaft, Propeller
9	0423-396	3	Screw, Self-Tapping	19	8408-820	4	Screw, Cap
10	<u>0502-642</u>	1	Gearcase, Rear	20	0402-950	1	Flange, Output




FRONT DRIVE GEARCASE ASSEMBLY

(Complete Assembly p/n 0502-444)

0739-579

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	0502-385	1	Shaft, Propeller - Assembly (inc. 2-6)	33	1402-210	1	Plug, Magnetic (inc. one No. 34)
2	0423-411	1	● Clamp, Boot	34	0423-153	2	● O-Ring
3	0402-985	1	● Boot, Propeller Shaft	35	0423-149	1	O-Ring
4	0423-393	1	● Clamp, Boot	36	0402-393	1	Bearing
5	1402-045	1	● Shaft, Output	37	0402-405	AR	Shim
6	0502-407	1	● Shaft, Input		0402-406	AR	Shim
7	1402-011	1	Seal		0402-407	AR	Shim
8	0423-423	1	Ring, Retaining		0402-408	AR	Shim
9	0502-347	1	Bracket, Actuator		0402-409	AR	Shim
10	0502-579	1	Actuator (inc. 11)	38	0502-411	1	Gear, Ring - 36T
11	0423-498	1	● O-Ring	39	1402-074	AR	Shim
12	0423-396	3	Screw, Self-Tapping		1402-075	AR	Shim
13	1402-043	1	Bearing		1402-076	AR	Shim
14	0423-118	11	Screw, Self-Tapping		1402-077	AR	Shim
15	0502-528	1	Housing, Pinion		1402-078	AR	Shim
16	0402-947	1	Gasket, Flange	40	0502-434	1	Cover, Gearcase (inc. one No. 34, 41-56, and one No. 57)
17	0402-997	1	Shaft, Selector	41	1402-063	1	● Bearing
18	0402-998	1	Fork, Selector	42	0502-413	1	● Flange, Bearing
19	0402-417	1	Shaft, Shuttle	43	1402-079	1	● Pin, Parallel
20	0423-402	1	Ring, Retaining	44	1402-042	1	● Collar, Sliding
21	0423-147	1	O-Ring	45	1402-064	1	● Fork
22	0402-999	1	Spring, Return	46	1402-068	2	● Ring, Retaining
23	0423-417	1	Ring, Retaining	47	1402-067	1	● Spring
24	0402-357	1	Collar, Lock	48	1402-104	1	● Fitting
25	0402-413	1	Coupler, Drive	49	0402-419	1	● Switch, Indicator
26	0502-123	1	Gear, Pinion - Assembly - 10T (inc. 27-29)	50	1402-063	1	● Spring
27	0402-336	1	● Collar, Retaining	51	1402-065	1	● Shaft, Lock
28	0402-327	1	● Bearing	52	1402-066	1	● Seal
29	0402-424	AR	● Shim	53	0423-133	1	● O-Ring
	0402-425	AR	● Shim	54	0423-132	1	● Washer
	0402-426	AR	● Shim	55	0423-424	1	● Ring, Retaining
	0402-427	AR	● Shim	56	1402-211	1	● Plug, Oil Level (inc. one No. 34)
	0402-428	AR	● Shim	57	0402-394	2	● Seal
30	0402-328	1	Bearing	58	0402-333	1	Plug, Fill (inc. 59)
31	0402-411	1	Pin, Dowel	59	0423-154	1	● O-Ring
32	0502-514	1	Housing, Gearcase				




REAR DRIVE GEARCASE ASSEMBLY

(Complete Assembly p/n 0502-642)

0739-580


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	0502-352	1	Housing, Gearcase	15	0423-153	1	● O-Ring
2	0402-393	2	Bearing	16	0402-328	1	Bearing
3	0402-394	2	Seal	17	0502-123	1	Gear, Pinion – Assembly – 10 T (inc. 18-20)
4	1402-032	1	Gear, Ring – 36T	18	0402-424	AR	● Shim
5	0402-405	AR	Shim		0402-425	AR	● Shim
	0402-406	AR	Shim		0402-426	AR	● Shim
	0402-407	AR	Shim		0402-427	AR	● Shim
	0402-408	AR	Shim		0402-428	AR	● Shim
	0402-409	AR	Shim	19	0402-327	1	● Bearing
6	0402-326	1	Button, Thrust	20	0402-336	1	● Collar, Retaining
7	0402-429	AR	Shim	21	0402-411	1	Pin, Dowel
	0402-430	AR	Shim	22	0402-331	1	Collar, Lock
	0402-431	AR	Shim	23	0402-982	1	Washer, Wave
	0402-432	AR	Shim	24	0402-981	1	Collar, Shaft
	0402-433	AR	Shim	25	0402-947	1	Gasket, Flange
8	0423-149	1	O-Ring	26	0502-529	1	Housing, Piston
9	0502-346	1	Cover, Gearcase	27	0423-417	1	Ring, Retaining
10	0402-333	1	Plug, Fill (inc. 11)	28	1402-043	1	Bearing
11	0423-154	1	● O-Ring	29	0423-423	1	Ring, Retaining
12	1402-102	1	Fitting	30	1402-011	1	Seal
13	0423-118	11	Screw, Self-Tapping	31	0502-407	1	Shaft, Input
14	0402-450	1	Plug, Magnetic (inc. 15)				



WIRING HARNESS ASSEMBLY

0739-716

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	<u>0486-158</u>	1	Harness, Main (inc. 2-7 and two No. 8)	19	0123-010	4	Nut, Expansion
2	0530-008	1	● Cover, Fuse Box	20	3530-039	1	CDI Unit
3	0430-037	1	● Holder, Fuse	21	<u>0412-291</u>	1	Shield, Heat
4	0430-034	3	● Diode	22	0409-009	1	Switch, Brake – Assembly
5	0430-033	3	● Relay	23	0402-991	1	Retainer, Switch
6	0430-032	4	● Fuse – 10 Amp	24	8476-630	2	Screw, Machine
	0430-031	3	● Fuse – 15 Amp	25	3530-028	1	Regulator, Voltage
	0430-030	2	● Fuse – 30 Amp	26	8476-616	1	Screw, Machine
7	<u>0411-828</u>	1	● Decal, Fuse Block	27	0509-011	1	Diode Assembly
8	0123-788	AR	● Cable Tie – 7,5 in.	28	0123-903	AR	Cable Tie – 11,5 in.
9	<u>0445-044</u>	1	Cable, Solenoid/Starter	29	0445-022	2	Receptacle, 12V (inc. 30)
10	0623-038	7	Nut w/Washer	30	0445-034	1	● Nut, Retainer
11	0645-327	1	Boot, Terminal	31	8476-620	1	Screw, Machine
12	<u>0445-046</u>	1	Cable, Battery/Solenoid (inc. one No. 13)	32	3530-027	1	Coil, Ignition – Assembly
13	0645-019	2	● Boot, Terminal	33	3430-009	1	Seal, High Tension Wire
14	<u>0445-036</u>	1	Solenoid	34	3430-007	1	Cap, Spark Plug
15	8476-625	2	Screw, Machine	35	3430-008	1	Seal, Spark Plug
16	<u>0445-045</u>	1	Cable, Battery/Ground	36	0623-966	1	Screw, Self-Tapping
17	0623-121	4	Screw, Machine	37	8053-212	1	Washer, Lock – Ext.l Tooth
18	<u>1406-600</u>	1	Tray, Electrical				
Homologated ATV's							
38	AC000-226	1	Harness 2005				




CARBURETOR

(Complete Assembly p/n 0470-533)

0739-656 *Not a Service Part **Optional


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	5507-001	1	Cover, Top	19	*	1	● O-Ring
2	5507-002	4	Screw, Top Cover	20	5507-027	1	Screw, Idle Adjust
3	5507-085	1	Spring	21	5507-028	1	Washer
4	5507-099	1	Piston, Vacuum	22	5507-029	1	Spring
5	5507-005	1	Seat, Spring	23	5507-115	1	Plate
6	5507-184	1	Jet, Needle	24	5507-117	1	Screw
7	5507-007	1	Needle Jet	25	5507-113	1	Choke, Electric
8	5507-047	1	Holder, Needle Jet	26	5507-114	1	Cover, Electric Choke
9	5507-043	1	Main Jet – 142	27	5507-065	1	Chamber, Float – Assembly (inc. 28-34)
	5507-044	1	Main Jet – 140**	28	5507-067	1	● O-Ring, Float Chamber
	5507-041	1	Main Jet – 147**	29	5507-050	1	● Screw, Drain
	5507-086	1	Main Jet – 148**	30	5507-032	1	● Spring
	5507-009	1	Main Jet – 150**	31	5507-031	1	● Diaphragm Assembly
10	5507-101	1	Slow Jet	32	*	1	● Housing, Pump
11	5507-112	1	Starter Jet – 85	33	5507-034	1	● U-Ring
12	5507-183	1	Valve, Float – Set (inc.13)	34	5507-035	3	● Screw
13	*	1	● Clip	35	5507-017	4	Screw
14	5507-039	1	Float Set (inc. 15)	36	0487-021	1	Cable, Throttle
15	*	1	● Pin, Float	37	5507-036	1	Cover
16	5507-111	1	Screw, Pilot Air – Set (inc. 17-19)	38	5507-037	1	Screw
17	*	1	● Spring	39	0410-056	1	Hose, Vent
18	*	1	● Washer				



CYLINDER HEAD ASSEMBLY

0739959 *Not Illustrated


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3402-098	1	Head, Cylinder – Assembly (inc.2 –5)	17	3003-290	4	Gasket
2	3423-043	2	● Pin, Dowel	18	3402-010	4	Gasket, Head Nut
3	3402-099	4	● Guide, Valve	19	0217-632	1	Spark Plug (NGK CR6E)
4	3423-006	4	● Screw, Cap	20	3402-100	2	Cap, Inspection
5	3008-376	2	● Screw, Cap	21	3402-101	2	O-Ring
6	3402-362	1	Gasket, Cylinder Head	22	3004-341	5	Screw, Cap
7	3423-088	2	Pin, Dowel	23	3423-383	1	Bolt, Stud
8	3423-015	2	Screw, Cap	24	3402-035	1	Plug, Cylinder Head
9	3423-016	2	Screw, Cap	25	0570-092	1	Manifold, Intake
10	3423-089	2	Bolt, Stud	26	0470-531	1	O-Ring
11	3423-087	2	Bolt, Stud	27	8476-620	2	Screw, Machine
12	3423-203	1	Bolt, Stud	28	0423-317	1	Clamp
13	3423-007	2	Screw, Cap	29	3530-038	1	Switch, Water Temperature – Assembly
14	3004-376	4	Screw, Cap	30	3413-004	1	Cover, Thermostat
15	3004-488	5	Nut	31	3413-012	1	Thermostat
16	3004-326	1	Nut	*	3402-048	1	Plug, Frost



CYLINDER ASSEMBLY

0732-301


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3402-707	1	Cylinder	5	3423-088	2	Pin, Dowel
2	3423-384	2	Bolt, Stud	6	3413-013	1	Union, Water, Hose
3	3004-488	2	Nut	7	3423-121	1	Screw, Cap
4	3402-365	1	Gasket, Cylinder	8	3423-058	1	O-Ring



CRANKCASE ASSEMBLY

0737-757


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3402-708	1	Crankcase Assembly (inc. two No. 2 & 13-14)	12	3423-387	1	● Bolt
2	3423-088	4	● Pin, Dowel	13	3423-388	1	● Bolt
3	3004-822	1	● Pin, Dowel	14	3423-308	1	● Bolt
4	3423-091	4	● Bolt	15	3402-439	1	Housing, Secondary Shaft Bearing
5	3423-119	3	● Bolt	16	3423-506	3	Bolt
6	3423-092	3	● Bolt	17	3402-437	1	Pipe, Breather
7	3004-880	4	● Bolt	18	3423-389	1	Bolt, Breather Pipe
8	3005-332	1	● Bolt	19	3402-214	1	Plug, Oil Pressure
9	3423-385	1	● Bolt	20	3402-012	1	Gasket, Oil Pressure Plug
10	3402-436	2	● Gasket	21	3402-438	1	Stick, Oil Level
11	3423-386	1	● Plug	22	3423-055	1	O-Ring, Oil Level Stick



CLUTCH/V-BELT/MAGNETO COVER ASSEMBLY

0737-759


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3402-710	1	Cover, V-Belt	12	3402-445	1	Plate, Air Intake
2	3402-711	1	Damper, V-Belt Cover	13	3402-699	1	Cushion, Air Intake Plate
3	3402-712	2	Damper, V-Belt Cover	14	3402-714	1	Cover, Magneto
4	3402-713	1	Plate, V-Belt Cover	15	3402-715	1	Gasket, Magneto Cover
5	3423-435	7	Screw	16	3402-041	1	Plug, Oil Filter
6	3423-088	6	Pin, Dowel	17	3402-013	1	Gasket, Oil Filler Plug
7	3402-443	1	Gasket, V-Belt Cover	18	3423-098	26	Bolt
8	3402-444	1	Gasket, Drain Plug	19	3423-092	2	Bolt
9	3004-705	1	Plug, Drain	20	3004-756	2	Bolt
10	3402-709	1	Cover, Clutch	21	3423-091	14	Bolt
11	3402-441	1	Gasket, Clutch Cover	22	3423-119	2	Bolt



CRANKSHAFT ASSEMBLY

0737-077

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3402-883	1	Crankshaft Assembly (inc. 2-7)	9	3402-054	1	Bearing – Left
2	3402-376	1	● Rod, Connecting	10	3402-188	1	Retainer, Oil Seal – Left
3	3402-377	1	● Pin, Crank	11	3402-788	1	Piston Set (inc. 12-14)
4	3402-717	1	● Bearing	12	3402-719	1	● Piston
5	3423-351	2	● Washer	13	3402-720	1	● Ring, Piston – Set
6	3402-834	1	● Crankshaft – Right	14	3423-344	2	● Circlip, Piston Set
7	3402-705	1	● Crankshaft – Left	15	3402-375	1	Pin, Piston
8	3402-058	1	Bearing – Right	16	3423-018	3	Screw




STARTER CLUTCH ASSEMBLY

0735-612

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3402-813	1	Gear, Starter Idler – No.1	6	3402-457	1	Clutch, Starter – Set (inc. 7)
2	3423-331	1	Pin	7	3402-063	1	● Bearing
3	3402-349	1	Gear, Starter Idler – No.2	8	3423-104	1	Washer
4	3423-396	1	Spacer, Starter Idler	9	3423-509	6	Screw, Cap
5	3423-397	1	Gear No. 2 Pin				

0737-762


35



CAMSHAFT/VALVE ASSEMBLY

0737-800


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3402-723	1	Camshaft	11	3402-148	4	Seat, Spring
2	3402-352	1	Sprocket	12	3402-078	4	Seal. Oil
3	3423-047	1	Pin	13	3402-140	1	Shaft, Rocker Arm
4	3423-073	1	Washer	14	3402-141	1	Shaft, Rocker Arm
5	3423-013	2	Bolt	15	3423-031	2	Washer
6	3423-071	1	C-Ring	16	3402-040	2	Plug, Shaft
7	3402-805	1	Arm, Valve Rocker – Intake (inc. two No. 8-9)	17	3402-012	2	Gasket
8	3423-075	4	● Screw	18	3402-725	2	Valve, Intake
9	3423-076	4	● Nut	19	3402-143	2	Valve, Exhaust
10	3402-139	1	Arm, Valve Rocker – Exhaust (inc. two No. 8-9)	20	3402-726	4	Spring, Valve
				21	3423-541	4	Retainer, Spring
				22	3402-147	8	Cotter, Valve



CAM CHAIN ASSEMBLY

0732-308


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3402-353	1	Chain, Cam	6	3402-136	1	Adjuster, Tensioner – Assembly
2	3402-355	1	Guide, Chain	7	3402-137	1	Gasket
3	3402-356	1	Tensioner, Chain	8	3004-475	2	Screw, Cap
4	3423-074	1	Bolt	9	3003-290	2	Gasket
5	3003-188	1	Washer				



RECOIL STARTER ASSEMBLY

0737-764


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3445-003	1	Starter, Recoil – Assembly (inc. 2-6)	8	3004-491	1	Nut
2	3445-011	1	● Rope Assembly	9	3445-029	1	Cup, Starter
3	3445-007	1	● Spring, Spiral	10	3423-053	1	O-Ring
4	3445-004	1	● Reel	11	3423-063	1	O-Ring
5	3445-016	1	● Ratchet Assembly	12	3402-119	1	Spacer
6	3004-488	1	● Nut	13	3402-070	1	Seal, Oil
7	3423-428	4	Screw, Cap	14	3402-051	1	Bearing



OIL FILTER/PUMP ASSEMBLY

0737-765


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3402-727	1	Pump, Oil	9	3402-157	1	Cap, Oil Strainer
2	3402-463	1	Gear, Driven	10	3423-077	1	O-Ring
3	3423-046	1	Pin	11	3004-756	4	Screw, Cap
4	3423-443	1	Washer	12	0436-146	1	Filter, Oil
5	3423-184	1	Circlip	13	3402-036	1	Plug, Drain
6	3423-510	3	Screw, Cap	14	3402-012	1	Gasket, Drain Plug
7	3402-156	1	Strainer, Oil	15	3402-154	1	Valve, Oil Relief – Assembly
8	0693-389	2	Screw, Cap	16	3402-158	1	Union, Oil Filter



WATER PUMP ASSEMBLY

0737-766


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3402-464	1	Pump, Water – Assembly (inc. 2-11)	12	3423-308	2	Screw, Cap
2	3423-343	1	● Screw, Cap	13	3402-026	1	Gear, Driven
3	3003-188	1	● Gasket	14	3402-466	1	Shaft, Driven Gear
4	3423-402	1	● O-Ring	15	3423-046	1	Pin, Driven Gear
5	3413-014	1	● Impeller/Shaft	16	3423-184	2	Circlip, Driven Gear
6	3005-909	1	● Seal, Mechanical	17	3402-467	1	Bearing, Shaft
7	3402-465	1	● Seal, Oil	18	3423-405	1	Circlip, Shaft Bearing
8	3003-615	1	● Bearing	19	3402-390	1	Gear, Water Pump Drive
9	3423-403	1	● E-Ring	20	3423-110	1	Pin, Drive Gear
10	3423-404	1	● O-Ring	21	3423-189	1	Circlip, Drive Gear
11	3003-484	2	● Screw				



TRANSMISSION ASSEMBLY

0737-771


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3402-750	1	Face, Fixed Drive	18	3423-514	2	Nut
2	3402-751	1	Face, Movable Drive	19	3402-757	1	V-Belt
3	3402-470	2	Seal, Movable Drive Face	20	3402-758	1	Housing, Clutch
4	3402-471	1	Spacer, Movable Drive Face	21	3402-544	1	Spacer, Fixed Drive Face
5	3402-752	1	Face, Fixed Driven	22	3402-808	1	Seal, Clutch Housing – Center
6	3402-753	1	Face, Movable Driven	23	3402-488	1	Seal, Clutch Housing – Left
7	3402-474	1	Spring, Movable Driven Face	24	3446-003	1	Clutch, One Way
8	3402-475	2	O-Ring, Movable Driven Face	25	3402-760	1	Shoe, Clutch – Assembly
9	3402-476	2	Seal, Movable Driven Face	26	3446-031	2	Retainer, Bearing
10	3402-477	4	Pin, Movable Driven Face	27	3423-435	2	Screw, Bearing Retainer
11	3402-478	4	Spacer, Movable Driven Face	28	3402-567	1	Bearing
12	3402-755	1	Plate, Movable Driven Face	29	3402-729	1	Bearing
13	3402-756	1	Sleeve, Movable Driven Face	30	3423-353	1	O-Ring
14	3402-481	4	Damper, Movable Drive Face	31	3402-761	2	Seal, Clutch Housing – Right
15	3423-406	1	Nut, Driven Pulley	32	3423-501	1	Nut
16	3402-482	1	Holder, Movable Driven Face Spring	33	3402-730	1	Retainer, Bearing
17	3402-483	8	Roller, Movable Drive Face	34	3423-018	2	Screw



SECONDARY TRANSMISSION ASSEMBLY

0738-705


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3402-045	2	Bearing, Shaft	23	3423-557	1	Circlip
2	3402-381	1	Washer, Drive Gear No. 2 - Right	24	3446-289	1	Gasket
3	3402-497	1	Gear, Drive - No. 2	25	3006-547	2	Pin
4	3423-066	2	Circlip	26	3446-355	1	Housing, Speedometer Sensor
5	3402-821	1	Dog, Reverse Driven Gear	27	3003-290	2	Gasket
6	3402-825	1	Spacer, Reverse Driven Gear	28	3423-091	2	Bolt
7	3423-263	2	Washer	29	3402-838	1	Sensor, Speedometer
8	3402-494	3	Bushing	30	3423-226	1	Bolt
9	3402-498	3	Bearing	31	3402-735	1	Bearing, Shaft
10	3402-822	1	Gear, Reverse Driven	32	3402-835	1	Shaft, Output
11	3423-266	1	Washer, Lock	33	3402-502	1	Bearing, Output Shaft
12	3402-820	1	Countershaft	34	3402-534	1	Gear, Driven - No. 2
13	3423-262	1	Washer, Lock	35	3446-031	2	Retainer, Bearing
14	3402-668	1	Gear, Driven - Low	36	3423-435	2	Screw, Bearing Retainer
15	3423-554	2	Washer, Driven Gear	37	3402-537	1	Seal, Driveshaft - Left
16	3402-824	1	Dog, Sliding	38	3402-499	1	Bearing, Driveshaft - Right
17	3402-733	1	Gear, Driven - High	39	3402-731	1	Driveshaft
18	3423-412	1	Washer, Drive Gear - Left	40	3003-261	1	Bearing, Driveshaft - Left
19	3402-836	1	Seal, Countershaft - Left	41	3402-195	2	Washer, Reverse Idle Gear
20	3423-518	1	Circlip	42	3402-503	1	Gear, Reverse Idle
21	3402-837	1	Rotor	43	3446-103	1	Bushing, Reverse Idle Gear
22	3423-556	1	Washer	44	3402-507	1	Shaft, Reverse Idle



SECONDARY DRIVE ASSEMBLY

0738-922


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3402-744	1	Yoke, Propeller Shaft Joint	11	3402-740	1	Shaft, Secondary Driven – Front
2	3402-562	1	Joint, Universal – Set (inc. 3)	12	3446-035	1	Shim, Secondary Drive Gear – Set
3	3423-479	4	● Circlip	13	3402-738	1	Gear, Secondary Drive
4	3423-025	2	Nut, Rear Output Joint	14	3005-372	1	Washer
5	3423-028	2	Washer, Rear Output Flange	15	3423-023	1	Nut
6	3402-742	1	Yoke, Drive Output – Front (inc. 7)	16	3402-515	1	Bearing, Driven Gear
7	3402-743	1	● Plate, Output Yoke	17	3402-739	1	Gear, Secondary Driven
8	3402-072	2	Seal, Oil – Driven Shaft	18	3423-340	2	Circlip, Secondary Driven Gear
9	3402-067	2	Bearing, Driven Shaft	19	3423-072	1	Ring, Driven Bearing
10	3402-017	AR	Shim, 25 x 34 x 0,60 mm	20	3423-415	1	Washer, Driven Shaft
	3402-018	AR	Shim, 25 x 34 x 0,65 mm	21	3402-513	1	Shaft, Secondary Driven - Rear
	3402-019	AR	Shim, 25 x 34 x 0,70 mm	22	3402-514	1	Flange, Output Joint – Rear
	3402-020	AR	Shim, 25 x 34 x 0,75 mm				
	3402-021	AR	Shim, 25 x 34 x 0,80 mm				
	3402-022	AR	Shim, 25 x 34 x 0,85 mm				
	3402-023	AR	Shim, 25 x 34 x 0,90 mm				
	3402-024	AR	Shim, 25 x 34 x 0,95 mm				
	3402-025	AR	Shim, 25 x 34 x 1,00 mm				
	3402-028	AR	Shim, 25 x 34 x 1,05 mm				
	3402-029	AR	Shim, 25 x 34 x 1,10 mm				
	3402-030	AR	Shim, 25 x 34 x 1,15 mm				
	3402-031	AR	Shim, 25 x 34 x 1,20 mm				



GEAR SHIFTING ASSEMBLY

0737-777


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3423-418	2	Bolt	17	3402-642	1	Plate, Gear Shift Cam
2	3530-042	1	Base, Gear Shift – Assembly	18	3004-376	1	Bolt, Gear Shift Cam Plate
3	3423-044	2	Contact	19	3423-358	2	Circlip, Sub-Gear Shift Shaft
4	3402-087	2	Spring	20	3402-747	1	Shaft, Sub-Gear Shift
5	3423-421	1	Washer, Shift Shaft	21	1691-043	2	Washer, Sub-Gear Shift Shaft
6	3423-191	4	Circlip, Cam Spring	22	3402-076	1	Seal, Sub-Gear Shift Shaft
7	3402-826	1	Shaft, Gear Shift (inc. 8)	23	3402-434	1	Arm, Select
8	3423-114	1	● Pin	24	3004-341	1	Bolt, Select Arm
9	3402-382	2	Washer, Cam Spring	25	3423-141	1	Washer, Cam Stopper
10	3446-280	2	Spring, Cam	26	3402-746	2	Stopper, Cam
11	3402-827	1	Cam, Reverse	27	3446-048	1	Support, Cam Stopper
12	3423-416	1	C-Ring, Cam	28	3423-511	1	Spring, Cam Stopper
13	3446-353	2	Fork, Shift	29	3423-438	2	Washer, Cam Stopper Spring
14	3402-828	1	Cam, Gear Shift	30	3004-488	1	Nut, Cam Stopper Spring
15	3402-381	2	Washer, Shift Shaft	31	3446-266	1	Shaft, Shift Fork
16	3423-446	1	Washer, Gear Shift Cam Plate	32	3402-829	1	Bearing



STARTER MOTOR ASSEMBLY

0737-779


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3545-015	1	Motor, Starter Assembly (inc. 2-9)	7	3436-001	1	● Washer Set
2	3008-094	1	● Terminal Set, Brush	8	3008-553	2	● O-Ring
3	3008-095	1	● Holder Set, Brush	9	3423-085	2	● Through-Bolt
4	3008-096	4	● Spring, Brush	10	3423-162	2	Screw, Cap
5	3008-164	1	● O-Ring	11	3423-195	1	Nut
6	3423-084	1	● O-Ring				



MAGNETO ASSEMBLY


0737-780

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3430-058	1	Stator Assembly	5	3423-086	1	Nut
2	3430-046	1	Rotor/Flywheel	6	3423-005	3	Bolt
3	3423-162	3	Bolt	7	3430-006	1	Clamp – No. 1
4	0691-785	1	Key	8	3430-005	1	Clamp – No. 2



CONTROL SWITCH HOUSING ASSEMBLY

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	0509-014	1	Switch, Control – Assembly (inc. 2-3)	3	0409-028	1	● Screw, Cap
2	0409-027	1	● Screw	4	3409-019	1	Cover, Choke Lever
5	AC000-018	1	Switch combi 2005				



THROTTLE CASE ASSEMBLY

0738-414

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	0509-012	1	Case, Throttle – Assembly (inc. 2-9)	6	3423-014	1	● Screw
2	3409-001	1	● Lever	7	3423-327	1	● Nut
3	3004-533	1	● Screw, Cap	8	3423-199	2	● Screw
4	3004-447	1	● Washer, Lock	9	0409-048	1	● Cover, Throttle Case w/Switch
5	3003-030	1	● Washer				

RELATED ITEMS

2005 ATV 500 FIS (Automatic Transmission)

Red (Model No.)
Green (Model No.)
Cat Green (Model No.)

0436-479	Articulating Spool mount	2257-180	Manual, Illustrated Parts
0436-548	Articulating Spool Receiver Mount Adapter	2257-034	Manual Operator's (E)
0436-679	Bag, Fender – Black	2257-172	Manuel d'utilisation (F)
0436-660	Bag, Rack, Front – Black	0436-626	Rack Basket
0436-480	Bar, Utility/Gun Rack	0436-647	Rack, Extension, 4 in. (Front)
0436-619	Brush Guard/Bumper	0436-646	Rack, Extension, 8 in. (Rear)
0436-462	Bucket Holder	0436-629	Rapid Blind (Break-Up)
0436-620	Bumper (Rear)	0436-630	Rapid Blind (Shadow Grass)
0436-464	Camp Stove Cradle	0436-628	Rapid Shack (Blue Ice)
0436-454	Cargo Box	0436-511	Rod Holder – Adjustable
0436-625	Cargo Box Quick-Release Kit	0436-635	Snowplow Attachment Kit
0436-459	Carryall (9 x 12)	0436-228	Snowplow Blade, 50 in. – Straight
0436-460	Carryall (11 x 17)	0436-287	Snowplow Blade, 50 in. – One Way
0436-652	Carryall (14 x 27)	0436-296	Snowplow Blade, 60 in. – Straight
0436-476	Chain Saw Lock	0436-360	Snowplow Blade, 60 in. – One Way
0436-477	Cord Reel	0436-636	Snowplow Push Frame
0436-664	Cover, Black and Green	0436-471	Speedclamp, Double
0436-668	Cover, Timber Camo	0436-624	Sprayer System
0436-005	Engine Oil – 10W40	0436-508	Sprayer Boom (120 in.)
0436-003	Engine Oil – 5W30	0436-465	Table, Expansion
0436-466	Fender Box	1402-028	Tire, Titan AT589 (25x8-12, Mud & Snow)
0436-538	Gear Cradle	0402-563	Tire, Titan AT586 (25x10-12, Mud & Snow)
0436-007	Gear Lube (Diff) – 80W90	0436-478	Tool Caddy
0436-501	Grease, High-Performance	0436-297	Tool Holder – Double
0436-627	Gun Scabbard Kit	0436-263	Tool Holder – Single
0436-706	Gun Scabbard Mount	0436-468	Tree Stand/Bow Case Holder
0436-505	Hand Guards – Black	0436-655	Winch, 2500 lb
0436-352	Hand/Thumb Warmers	0436-623	Windshield Clear w/Black Accent
0436-639	Ice Auger Holder	0436-470	Workbase (8 in.)
0436-463	Light Bar		

■ **NOTE:** For a complete list of related items, refer to the current accessory catalog.

