

2014 ARCTIC CAT[®]

ILLUSTRATED PARTS MANUAL



550 EFT

Model Number A2014IB04EETP

ARCTIC CAT[®]
SHARE OUR PASSION.™

www.arcticcat.com


TABLE OF CONTENTS

2014 ATV 550 EFT

(Model No. A2014IBO4EETP)

FRONT RACK, BODY PANEL, AND HEADLIGHT ASSEMBLIES	1
REAR RACK, BODY PANEL, AND FOOTWELL ASSEMBLIES	2
FRAME AND RELATED PARTS	3
WINCH ASSEMBLY	4
LICENSE PLATE HOLDER ASSEMBLY	5
SEAT ASSEMBLY	6
STEERING ASSEMBLY	7
HANDLEBAR ASSEMBLY	8
INSTRUMENT POD ASSEMBLY	9
FRONT SUSPENSION ASSEMBLY	10
REAR SUSPENSION ASSEMBLY	11
WHEEL AND TIRE ASSEMBLY	12
HYDRAULIC BRAKE ASSEMBLY	13
PARKING BRAKE ASSEMBLY	14
GAS TANK ASSEMBLY	15
SHIFT LEVER ASSEMBLY	16
AIR INTAKE ASSEMBLY	17
ENGINE AND EXHAUST	18
COOLING ASSEMBLY	19
CASE/BELT COOLING ASSEMBLY	20
DRIVE TRAIN ASSEMBLY	21
FRONT DRIVE GEARCASE ASSEMBLY	22
REAR DRIVE GEARCASE ASSEMBLY	23
WIRING HARNESS ASSEMBLY	24
BATTERY AND STARTER ASSEMBLY	25
THROTTLE BODY ASSEMBLY	26
CYLINDER ASSEMBLY	27
CYLINDER HEAD AND CAMSHAFT/VALVE ASSEMBLY	28
CAM CHAIN ASSEMBLY	29
CRANKCASE ASSEMBLY	30
CRANKSHAFT AND PISTON ASSEMBLY	31
CLUTCH/V-BELT/MAGNETO COVER ASSEMBLY	32
STARTER CLUTCH ASSEMBLY	33
CRANK BALANCER ASSEMBLY	34
OIL FILTER/PUMP ASSEMBLY	35
WATER PUMP ASSEMBLY	36
TRANSMISSION ASSEMBLY	37
SECONDARY TRANSMISSION ASSEMBLY	38
GEAR SHIFTING ASSEMBLY	39
SECONDARY DRIVE ASSEMBLY	40
MAGNETO ASSEMBLY	41


■ **NOTE:** The illustrations used in this Parts Manual are for reference to replacement part numbers only and are not to be used for assembly. For assembly procedures, use an Arctic Cat Service Manual. For a complete list of related items, refer to the current accessory catalog.



FRONT RACK, BODY PANEL, AND HEADLIGHT ASSEMBLIES

0747-725


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	2506-106		1	Rack, Front - Assembly (inc. 2-3)	23	8050-217		8	Washer
2	0411-576		1	● Decal, Warning - Load	24	0423-447		4	Grommet
3	0441-592		4	● Bushing	25	2406-300		1	Panel, Side - Lower - Right
4	8410-835		4	Screw, Cap		2406-419		1	Panel, Side - Lower - Left
5	0423-669		4	Spacer	26	0423-678		8	Grommet
6	0423-465		4	Grommet	27	1406-358		1	Cover, Access
7	8432-802		4	Nut, Lock	28	0423-535		2	Rivet, Reinstallable
8	0423-654		2	Screw, Shoulder	29	0623-362		4	Rivet, Reinstallable
9	8050-222		2	Washer	30	1406-484		1	Cover, Steering Post
10	8427-602		2	Nut, Lock	31	0470-513		1	Cover, Storage Box
11	0509-036		1	Headlight Assembly - Right (inc. 12-18)	32	1406-573		1	Box, Storage
	0509-037		1	Headlight Assembly - Left (inc. 12-18)	33	2506-234		1	Lid, Storage Box w/Latch (inc. 34-35)
12	0409-102		2	● Socket, Position Bulb	34	1406-599		1	● Latch, Storage Box
13	0409-101		2	● Bulb, Position	35	0470-514		1	● Lid, Storage Box
14	0409-099		2	● Bulb, Turn Signal	36	0423-101		2	Screw, Shoulder
15	0409-100		2	● Socket, Turn Signal Bulb	37	2406-523		1	Panel, Fender - Black
16	0409-096		2	● Bulb, Headlight	38	0411-818		1	Decal, Reflector - Right - Amber
17	0409-097		2	● Retainer, Spring		0411-819		1	Decal, Reflector - Left - Amber
18	0409-098		2	● Boot, Rubber	39	1411-725		1	Decal, "Arctic Cat"
19	0423-514		2	Stud, Adjuster - Headlight	40	3411-965	X	2	Decal, "550 EFI"
20	0423-522		2	Spring, Adjuster	41	3411-966	X	1	Decal, Side - Upper Right
21	0423-513		2	Knob, Adjuster		3411-967	X	1	Decal, Side - Upper Left
22	0623-785		4	Screw, Self-Tapping					



REAR RACK, BODY PANEL, AND FOOTWELL ASSEMBLIES

0747-922


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	2506-125		1	Rack, Rear - Assembly (inc. 2-3)	17	1411-725		1	Decal, "Arctic Cat"
2	0411-648		1	● Decal, Warning - Load	18	0423-101		2	Screw, Shoulder
3	0441-592		4	● Bushing, Rack	19	1406-356		1	Footwell - Right
4	8410-835		4	Screw, Cap		2406-429		1	Footwell - Left
5	0423-669		4	Spacer	20	0423-419		18	Screw, Machine
6	0423-465		4	Grommet	21	1506-125		2	Footpeg
7	8432-802		4	Nut, Lock	22	0423-355		4	Screw, Shoulder
8	0423-654		2	Screw, Shoulder	23	8476-516		6	Screw, Machine
9	8050-222		2	Washer	24	0409-112		1	Bezel, Taillight - Right
10	8427-602		26	Nut, Lock		0409-113		1	Bezel, Taillight - Left
11	0411-965		2	Decal, "Speedrack"	25	3313-392		1	Taillight Assembly - Right (inc. 26-28)
12	2506-885		1	Panel, Fender - Black		3313-393		1	Taillight Assembly - Left (inc. 26-28)
13	1411-592		1	Decal, Reflector - Right - Red	26	3313-506		2	● Bulb, Turn Signal
	1411-593		1	Decal, Reflector - Left - Red	27	3303-849		2	● Bulb, Taillight
14	0470-658		1	Foil, Protective	28	3313-509		1	● Harness, Taillight - Right
15	2411-609		1	Decal, Warning - Tire Pressure		3313-507		1	● Harness, Taillight - Left
16	0412-582		1	Foil, Protective	29	3304-061		6	Clip, U-Nut



FRAME AND RELATED PARTS

0746-696


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	4506-550		1	Frame, Main	17	0623-038		3	Nut w/Washer
2	2416-401		1	Clip, Routing	18	2406-321		1	Bracket, Mounting - Horn
3	0706-371	AR		Trim - 3 ft	19	8477-616		2	Screw, Machine
4	1506-596		2	Channel, Mounting - Bumper	20	0430-053		1	Horn, Electric - 12V
5	8409-020		4	Screw, Cap	21	8477-620		1	Screw, Machine
6	1506-562		1	Bracket, Mounting - Bumper - Right	22	2416-162		1	Bracket, Support - Right
7	1506-563		1	Bracket, Mounting - Bumper - Left	23	2416-163		1	Bracket, Support - Left
8	8408-816		6	Screw, Cap	24	8424-802		4	Nut
9	1506-855		1	Bumper, Front	25	8409-016		4	Screw, Cap
10	1406-360		1	Fascia, Bumper - Front	26	1506-380		1	Footrest - Right
11	0423-419		2	Screw, Machine	27	1506-379		1	Footrest - Left
12	0423-101		12	Screw, Shoulder	28	2506-423		2	Rod, Support
13	1406-030		1	Panel, Belly	29	1411-077		1	Decal, Warning - Towing
14	8409-025		2	Screw, Cap	30	0541-857		1	Mount, Ball Hitch (inc. 29-30)
15	2516-852		1	Brace, A-Arm		0423-690		1	● Nut, Lock
16	0423-744		2	Nut, Lock		0423-693		1	● Screw, Cap
	0406-289		2	Pad, Foam					



WINCH ASSEMBLY

0745-322

Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	1441-657		1	Winch (inc. 2-3)	16	0445-069		1	Cable, Winch/Solenoid - Blue
2	1411-826		1	● Decal, Warning	17	0445-087		1	Cable, Solenoid/Battery - Red
3	0441-061		1	● Cable, Winch	18	1441-112		1	Cable, Solenoid/Battery - Black
4	8051-246		4	Washer, Lock	19	0409-066		1	Solenoid
5	8408-820		4	Screw, Cap	20	8476-625		2	Screw, Machine
6	0441-403		1	Roller, Winch (inc. 7)	21	0505-552		1	Switch, Winch - Assembly (inc. 22-27)
7	0411-474		1	● Decal, Warning - Pinch Point	22	1441-428		1	● Connector, Harness
8	8468-820		2	Screw, Machine	23	0505-551		1	● Bracket, Winch Switch
9	0623-175		1	Pin, Cotter	24	8052-093		2	● Washer, Internal Tooth Lock
10	1441-833		1	Hook, Winch	25	8009-243		2	● Screw, Machine
11	1441-781		1	Strap	26	0486-276		1	● Harness, Adapter - Solenoid
12	1441-834		1	Pin	27	8053-212		1	● Washer, External Tooth Lock
13	0645-019		3	Boot, Terminal	28	0123-788		AR	Tie, Cable - 8 in.
14	0623-038		8	Nut w/Washer		0123-903		AR	Tie, Cable - 11.5 in.
15	0445-068		1	Cable, Winch/Solenoid - Yellow					




LICENSE PLATE HOLDER ASSEMBLY

0743-236

Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	2506-914		1	Mount, License Plate	5	0123-950		2	Screw, Self-Tapping
2	3304-772		1	Light, License Plate Assembly (inc. 3-4)	6	8432-802		2	Nut, Lock
3	3305-399		2	● Screw, Self-Tapping	7	8050-247		2	Washer
4	3303-847		1	● Bulb	8	8468-820		2	Screw, Machine


6



STEERING ASSEMBLY

0747-925


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	8408-835		4	Screw, Cap	15	0405-052		1	Bearing w/Inverted Oil Seal
2	0405-035		2	Cap, Steering Adjuster	16	0423-073		1	Washer
3	0505-484		1	Cap, Housing	17	8409-020		1	Screw, Cap
4	0405-260		1	Housing, Upper	18	0505-872	X	2	Tie Rod - Assembly (inc. 19-25)
5	0405-259		1	Housing, Lower	19	0505-875	X	2	● End, Tie Rod - Left-Hand Thread - Kit (inc. one No. 20-22)
6	0505-493		1	Post, Steering	20	0423-013		2	●● Nut - Left-Hand Thread
7	0423-505		2	Screw, Shoulder	21	0623-175		4	●● Pin, Cotter
8	8408-820		2	Screw, Cap	22	0423-157		4	●● Nut, Lock
9	0505-713		1	Steering Lock Assembly (inc. 10-13)	23	0405-281		2	● Tie Rod
10	2406-354		1	● Lock	24	0505-874	X	2	● End, Tie Rod - Right-Hand Thread - Kit (inc. one No. 20-22 and 25)
11	2406-349		1	● Bracket, Mounting - Lock	25	8420-002		2	●● Nut - Right-Hand Thread
12	1423-058		1	● Spring					
13	2506-173		1	● Latch					
14	0602-233		1	Flange, Bearing					



HANDLEBAR ASSEMBLY

0745-005


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0505-522		1	Handlebar	13	3423-014		1	● Screw, Machine
2	0405-218		2	Plug, Handlebar	14	3423-327		1	● Nut
3	0405-147		2	Grip, Handlebar	15	3423-199		2	● Screw, Machine
4	0405-149		2	End Cap, Handlebar	16	0411-966		1	Decal, Warning - Differential Lock
5	8050-247		2	Washer	17	2406-630		1	Mirror - Right (inc. 18-21)
6	8477-845		2	Screw, Machine		2406-631		1	Mirror - Left (inc. 18-21)
7	0509-054		1	Case, Throttle - Assembly (inc. 8-15)	18	0423-985		2	● Cover
8	0409-141		1	● Cover, Throttle Case w/Switch	19	0423-986		2	● Nut, Adjuster
9	3007-392		1	● Screw, Cap	20	0423-987		2	● Washer, Lock
10	3004-447		1	● Washer, Lock	21	0423-988		2	● Nut
11	3003-030		1	● Washer	22	0409-081		1	Switch, Control - Assembly
12	0409-133		1	● Lever, Throttle	23	1411-865		1	Decal, Warning - Brake Lever Lock



INSTRUMENT POD ASSEMBLY

0746-654


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0430-090	1	1	Switch, Ignition - Assembly (inc. 2-4)	6	9611-751	1	1	Decal, "Arctic Cat"
2	0430-050	1	1	● Nut, Retaining	7	0641-897	1	1	Outlet, Accessory - 12V
3	0430-042	1	1	● Key, Ignition (Y Series - Left-Side Cut)	8	0405-276	1	1	Instrument Pod - Black
	0430-043	1	1	● Key, Ignition (Z Series - Right-Side Cut)	9	0420-065	1	1	Bracket, Retaining
4	0430-054	1	1	● Cover, Key	10	0423-493	2	2	Nut w/Washer
5	0520-161	1	1	Gauge, LCD	11	2506-470	1	1	Bracket, Mounting - Instrument Pod
					12	0423-535	2	2	Rivet, Reinstallable



FRONT SUSPENSION ASSEMBLY

0745-247


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0403-209		2	Shock Absorber (inc. 2)	17	0403-208		8	● Bushing
2	0403-182		4	● Bushing	18	0403-214		4	● Axle
3	0403-288		2	Cam, Spring Adjuster	19	8409-075		4	Screw, Cap
4	0503-353		2	Spring, Suspension - Black	20	1502-800		1	Axle, Drive - Right (inc. 21-24)
5	1603-889		2	Retainer, Spring	21	1502-799		1	Axle, Drive - Locking - Left (inc. 21-24)
6	8409-040		4	Screw, Cap	22	1436-419		2	● Repair Kit, Boot (inc. 22)
7	0423-744		10	Nut, Lock	23	1441-988		2	● Clip, Retaining
8	0503-416		1	A-Arm, Upper Right - Black (inc. 9-12)	24	1402-885		4	● Pin, Detent
9	0503-417		1	A-Arm, Upper Left - Black (inc. 9-12)	25	1402-889		2	● Clip, Retaining
10	0403-080		2	● Bushing	26	0505-576		1	Knuckle - Assembly - Right (inc. 26-27)
11	0423-009		4	● Ring, Retaining	27	0505-577		1	Knuckle - Assembly - Left (inc. 26-27)
12	0405-483		4	● Ball Joint	28	0423-423		2	● Ring, Retaining
13	0423-946		4	Screw, Self-Tapping	29	1402-809		2	● Bearing
14	1502-594		2	Clamp, Routing	30	0423-998		4	Screw, Shoulder
15	0423-334		2	Screw, Cap	29	1406-034		1	Guard, Boot - Right - Black
16	0503-376		1	A-Arm, Lower Right - Black (inc. 17-18 and two No. 11-12)	30	1406-035		1	Guard, Boot - Left - Black
	0503-377		1	A-Arm, Lower Left - Black (inc. 17-18 and two No. 11-12)		0423-545		4	Screw, Shoulder



REAR SUSPENSION ASSEMBLY

0745-252


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0404-158		2	Shock Absorber (inc. 2-4)	16	0504-572		1	A-Arm, Rear - Lower Right - Black (inc. 13-14)
2	0403-182		2	● Bushing		0504-573		1	A-Arm, Rear - Lower Left - Black (inc. 13-14)
3	0603-955		4	● Bushing	17	1502-798		2	Axle, Drive (inc. 18-21)
4	1603-219		2	● Sleeve	18	1436-419		2	● Repair Kit, Boot (inc. 19)
5	1603-889		2	Retainer, Spring	19	1441-988		2	● Clip, Retaining
6	0504-536		2	Spring, Suspension - Black	20	1402-884		4	● Pin, Detent
7	0404-057		2	Cam, Spring Adjuster	21	1402-890		2	● Clip, Retaining
8	8409-040		1	Screw, Cap - Right	22	0504-616		1	Knuckle, Right - Assembly (inc. 23-26)
	8409-050		1	Screw, Cap - Left		0504-549		1	Knuckle, Left - Assembly (inc. 23-26)
9	0423-744		14	Nut, Lock	23	0423-423		2	● Ring, Retaining
10	0423-087		2	Washer	24	1402-809		2	● Bearing
11	8408-820		2	Screw, Cap	25	0403-213		4	● Axle
12	0504-582		1	A-Arm, Rear - Upper Right - Black (inc. 13-14)	26	0403-206		8	● Bushing
	0504-583		1	A-Arm, Rear - Upper Left - Black (inc. 13-14)	27	8409-000		4	Screw, Cap
13	0403-208		16	● Bushing	28	0423-545		4	Screw, Shoulder
14	0403-214		8	● Axle	29	1406-068		1	Guard, Boot - Rear - Right - Black
15	8409-075		8	Screw, Cap		1406-069		1	Guard, Boot - Rear - Left - Black



WHEEL AND TIRE ASSEMBLY

0743-964


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0423-557		12	Screw, Shoulder	8	1402-780		2	Wheel - Front - Black
2	1436-164		3	Disc, Brake		1402-781		2	Wheel - Rear - Black
3	1502-462		2	Hub, Wheel - Front (inc. 4)	9	0423-408		16	Nut, Lug
4	0402-974		16	● Stud	10	2402-096		2	Tire - Front
5	1502-462		1	Hub, Wheel - Rear - Right (inc. 4)		2402-097		2	Tire - Rear
	1502-464		1	Hub, Wheel - Rear - Left (inc. 4)	11	0402-064		4	Stem, Valve (inc. 12)
6	0423-607		4	Nut, Castle	12	0402-140		4	● Cap, Valve Stem
7	0423-407		4	Pin, Cotter					



HYDRAULIC BRAKE ASSEMBLY

0747-101


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	1436-422		1	Caliper, Brake - Right Front (inc. 2-9)	19	8050-217		1	Washer
	1436-423		1	Caliper, Brake - Left Front (inc. 2-9)	20	1402-377		1	Pin, Clevis
	1436-423		1	Caliper, Brake - Rear (inc. 2-9)	21	8408-816		1	Screw, Cap
2	1436-160		1	● Housing, Caliper - Assembly - Right Front (inc. 3-6)	22	8050-252		1	Washer
	1436-161		1	● Housing, Caliper - Assembly - Left Front (inc. 3-6)	23	1602-213		2	O-Ring
	1436-161		1	● Housing, Caliper - Assembly - Rear (inc. 3-6)	24	0502-807		1	Spring, Brake Lever
3	8408-821		6	●● Screw, Cap	25	1502-063		1	Lever, Brake
4	0502-606		3	●●● Piston/Seal Set (inc. 5)	26	8408-625		2	Screw, Cap
5	0502-607		3	●●●● Seal Set	27	1502-179		1	Bracket, Switch
6	0502-609		3	●● Valve, Bleed	28	0502-785		1	Spring, Brake Switch
7	0502-608		3	● O-Ring, Guide - Set	29	1402-592		1	Hose, Brakeline
8	0502-605		3	● Bracket Assembly	30	0502-914		1	Brake Assembly (inc. 31-39)
9	1502-694		3	● Pad, Brake - Set	31	0502-566		1	● Screw, Machine - Kit
10	0423-178		13	Washer, Crush	32	0502-868		1	● Cover, Reservoir
11	0423-413		5	Bolt, Banjo-Fitting	33	0502-568		1	● Screw, Machine - Kit
12	8476-625		1	Screw, Machine	34	0502-869		1	● Clamp, Master Cylinder
13	8427-602		1	Nut, Lock	35	0502-704		1	● Master Cylinder Assembly
14	1502-148		1	Hose, Brakeline - Assembly	36	0502-866		1	● Lever Assembly - Kit (inc. 37-38)
15	0423-610		1	Bolt, Banjo-Fitting - Double	37	0502-867		1	●● Lock, Brake Lever - Kit
16	1402-593		1	Hose, Brakeline	38	0502-580		1	●● Lever Pin - Kit
17	1502-147		1	Brake Assembly	39	0502-564		1	● Switch, Brake
18	0117-868		1	Pin, Cotter	40	1502-115		2	Clip, Brakeline Hose
					41	0123-788	AR		Tie, Cable - 8 in.
					42	5639-848	AR		Fluid, Brake - 12 oz



PARKING BRAKE ASSEMBLY

0743-214


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	1502-265		1	Lever, Parking Brake - Assembly (inc. 2-6)	6	0487-054		1	● Cable, Brake - Rear
2	1502-429		1	● Lever, Parking Brake - Kit	7	1502-865		1	Mechanical Brake Assembly (inc. 8)
3	1502-432		1	● Clamp, Handlebar - Kit	8	1402-602		2	● Pad, Brake
4	1502-430		1	● Adjuster, Thumb Nut - Kit	9	8408-826		2	Screw, Cap
5	1502-431		1	● Lock, Parking Brake Lever - Kit	10	0402-379		1	Wire Form, Cable



GAS TANK ASSEMBLY

0747-102


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0570-307		1	Tank, Gas - Assembly (inc. 2-5)	12	0470-988		1	Filter, In-Line
2	0470-438		1	● Cap, Gas Tank (inc. 3)	13	0123-788		AR	Tie, Cable - 8 in.
3	0109-733		1	●● Gasket, Gas Tank Cap	14	0410-070		AR	Hose, Gasline - 25 ft
4	0423-898		6	● Screw, Self-Tapping	15	0423-732		2	Screw, Shoulder
5	2670-042		1	● Plate, Retaining	16	0623-038		1	Nut w/Washer
6	0570-322		1	Pump, Fuel - Assembly (inc. 7-8)	17	0423-460		1	Grommet
7	2670-235		1	● Float	18	0423-806		1	Grommet
8	0470-838		1	● Seal	19	0470-710		1	Shield, Heat - Gas Tank - Rear
9	0570-317		1	Hose, Gasline - Assembly	20	0623-797		4	Screw, Self-Tapping
10	0423-688		AR	Clamp, Hose	21	0470-709		1	Shield, Heat - Gas Tank - Front
11	0470-980		1	Bracket, Filter Mounting					



SHIFT LEVER ASSEMBLY

0745-123


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0402-843		1	Knob, Shift	13	0423-087		1	Washer
2	0423-345		1	Clip, Retaining	14	8408-812		1	Screw, Cap
3	1402-576		1	Plate, Shift	15	8424-802		1	Nut
4	2406-345		1	Shield, Shift Plate	16	1402-621		1	Pin, Mounting
5	0423-357		4	Nut, Stamped	17	0423-091		2	Bushing
6	1502-977		1	Lever, Shift	18	0623-094		2	Washer
7	2402-117		1	Spring, Shift Lever	19	0423-169		2	E-Ring
8	1502-332		1	Actuator, Shift	20	1502-200		1	Linkage, Shift - Assembly (inc. 21-23)
9	8424-602		1	Nut	21	0123-917		1	+ Nut, Hex - Left-Hand Thread
10	0423-182		2	O-Ring	22	1402-619		1	+ Coupler
11	0402-675		1	Axle, Pivot	23	0623-294		1	+ Nut, Hex - Right-Hand Thread
12	0423-299		2	O-Ring					



AIR INTAKE ASSEMBLY

0745-077


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0470-877		1	Cover, Intake	12	0470-442		1	Valve, Drain
2	0470-560		1	Screen, Air Filter	13	0410-172		1	Hose, Vent
3	0470-558		1	Filter, Air	14	1623-281		2	Clamp, Hose
4	0470-728		1	Housing, Intake	15	0470-896		1	Hose
5	0423-455		4	Clip, Spring	16	1623-289		2	Clamp
6	0470-749		1	Duct, Engine Intake	17	0423-554		1	Clamp
7	0423-763		1	Grommet	18	0470-511		1	Boot
8	0570-215		1	Resonator	19	0430-055		1	Sensor, Air Temperature (inc. 20)
9	0470-729		1	Boot	20	5507-224		1	+ O-Ring
10	0423-342		4	Screw, Self-Tapping	21	2406-604		1	Panel, Shield
11	0423-019		2	Clamp	22	0623-362		2	Rivet, Reinstallable



ENGINE AND EXHAUST

0746-135


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0800-141		1	Engine, A550H	17	0412-349		1	● Shield, Exhaust Pipe - Inner - Front
2	0411-426		1	Decal, Warning - Clutch Cover	18	0512-570		1	● Shield, Exhaust Pipe - Inner - Rear
3	8428-002		2	Nut, Lock	19	0512-569		1	● Shield, Exhaust Pipe - Outer - Rear
4	0801-129		3	Mount, Rubber - Engine	20	0423-317		3	● Clamp
5	0423-451		1	Screw, Cap	21	0512-571		1	● Shield Heat
6	0801-122		1	Mount, Rubber - Engine	22	0423-832		1	● Clamp
7	0423-405		1	Screw, Cap	23	0412-375		1	Seal, Exhaust
8	0512-577		1	Valve, Air	24	0612-668		2	Spring, Extension
9	0412-573		1	Bracket, Retaining	25	0412-577		3	Bushing
10	0123-903	AR		Tie, Cable - 11.5 in.	26	1506-732		1	Channel, Muffler Support
11	0412-574		1	Hose	27	0512-592		1	Muffler - Assembly (inc. 28-30)
12	8408-820		2	Screw, Cap	28	8408-616		3	● Screw, Cap
13	0412-338		1	Gasket, Exhaust	29	0512-219		1	● Arrester, Spark - Assembly
14	0512-521		1	Pipe, Exhaust - Assembly (inc. 15-22)	30	0412-313		1	● Gasket, Spark Arrester
15	0412-348		1	● Shield, Exhaust Pipe - Outer - Front	31	0412-373		1	Cover, Muffler
16	0512-530		1	● Pipe, Exhaust	32	8477-610		3	Screw, Machine



COOLING ASSEMBLY

0745-858


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0413-256		1	Radiator Assembly (inc. 2-13)	11	0413-123		1	● Fan, Cooling
2	0413-255		1	● Cap	12	0623-378		8	● Screw, Self-Tapping
3	0413-205		1	● Radiator	13	0423-030		2	● Grommet
4	0413-195		1	● Plug, Drain	14	0423-484		2	Screw, Shoulder
5	1602-213		1	● O-Ring	15	0623-038		2	Nut w/Washer
6	0413-007		1	● Screen	16	0423-028		2	Bushing, Stem
7	8475-512		4	● Screw, Machine	17	0423-496		6	Clamp, Hose
8	0423-351		1	● Clamp, Wire	18	0410-229		1	Hose, Coolant - Lower
9	0610-016	AR		● Hose - 25 ft	19	0410-022		1	Hose, Coolant - Crossover
	0610-015	AR		● Hose - 100 ft	20	0410-002		1	Hose, Coolant - Upper
10	0413-203		1	● Shroud, Fan	21	0123-903	AR		Tie, Cable - 11.5 in.



CASE/BELT COOLING ASSEMBLY

0744-433


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0423-550		2	Clamp	8	0423-730		1	Clamp
2	0423-342		4	Screw, Self-Tapping	9	0413-206		1	Boot, Duct - Air Out - Rear
3	0413-252		1	Boot, Duct - Air Intake - Front	10	0470-824		1	Duct, Air Out - Rear
4	0423-019		2	Clamp					(inc. three No. 11 and 12-13)
5	0413-250		1	Duct, Air Intake - Front - Lower	11	0623-784		4	● Screw, Self-Tapping
6	0470-750		1	Duct, Air Intake - Front - Upper	12	0470-778		1	● Duct
7	0470-729		1	Cup, Air Intake	13	0470-825		1	● Duct



DRIVE TRAIN ASSEMBLY

0745-861


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	2502-089	X	1	Gearcase, Front	9	0402-950		1	Flange, Output
2	1402-620		2	Bladder, Gearcase	10	8408-820		4	Screw, Cap
3	0423-315		2	Clamp, Hose	11	0423-393		2	Clamp
4	8428-002		4	Nut, Lock	12	0402-985		2	Boot
5	0423-426		8	Washer	13	0423-411		2	Clamp
6	0423-404		4	Screw, Cap	14	0673-618		2	Bumper, Propeller Shaft
7	0402-966		1	Boot, Shaft	15	1402-233		1	Shaft, Propeller
8	1402-026		2	Spring	16	2502-090	X	1	Gearcase, Rear



FRONT DRIVE GEARCASE ASSEMBLY

0745-863


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
-	2502-089	X	1	Complete Front Drive Gearcase Assembly	32	0402-328		1	Bearing
1	1502-083		1	Shaft, Propeller - Assembly (inc. 2-6)	33	0402-411		1	Pin, Dowel
2	0423-411		1	● Clamp	34	1402-210		1	Plug, Magnetic (inc. one No. 35)
3	0402-985		1	● Boot, Propeller Shaft	35	0423-153		2	● O-Ring
4	0423-393		1	● Clamp	36	0423-149		1	O-Ring
5	1402-045		1	● Shaft, Output	37	0402-393		1	Bearing
6	1502-085		1	● Shaft, Input	38	0402-405		AR	Shim, 41 x 49 x 1.3 mm
7	1402-011		1	Seal		0402-406		AR	Shim, 41 x 49 x 1.4 mm
8	0423-423		1	Ring, Retaining		0402-407		AR	Shim, 41 x 49 x 1.5 mm
9	1502-237		1	Bracket, Actuator		0402-408		AR	Shim, 41 x 49 x 1.6 mm
10	1502-909		1	Actuator (inc. 11)		0402-409		AR	Shim, 41 x 49 x 1.7 mm
11	1402-981		1	● O-Ring	39	1502-860		1	Gear, Ring - 36T
12	0423-892		1	O-Ring	40	1402-074		AR	Shim, 61 x 69 x 1.3 mm
13	0423-396		3	Screw, Self-Tapping		1402-075		AR	Shim, 61 x 69 x 1.4 mm
14	1402-043		1	Bearing		1402-076		AR	Shim, 61 x 69 x 1.5 mm
15	0423-118		11	Screw, Self-Tapping		1402-077		AR	Shim, 61 x 69 x 1.6 mm
16	0502-528		1	Housing, Pinion		1402-078		AR	Shim, 61 x 69 x 1.7 mm
17	0402-947		1	Gasket, Flange	41	2502-104	X	1	Cover, Gearcase (inc. one No. 35, 42-52, and one No. 53)
18	0423-417		1	Ring, Retaining	42	1402-053		1	● Bearing
19	0402-997		1	Shaft, Selector	43	0502-413		1	● Flange, Bearing
20	0423-402		1	Ring, Retaining	44	1402-079		1	● Pin, Parallel
21	0402-998		1	Fork, Selector	45	1402-042		1	● Collar, Sliding
22	0402-417		1	Shaft, Shuttle	46	1402-054		1	● Fork
23	0423-147		1	O-Ring	47	1402-058		2	● Ring, Retaining
24	0402-999		1	Spring, Return	48	1402-057		1	● Spring
25	0402-413		1	Coupler, Drive	49	1402-063		1	● Spring
26	1423-067		1	Ring, Retaining	50	1402-656		1	● Shaft, Lock
27	1502-863		1	Gear, Pinion - Assembly - 10T (inc. 28-29)	51	1402-211		1	● Plug, Oil Level (inc. one No. 35)
28	1402-977		1	● Collar, Retaining	52	1402-056		1	● Seal
29	0402-327		1	● Bearing	53	2402-150	X	2	● Seal
30	1502-856		1	Housing, Gearcase	54	0402-333		1	Plug, Fill (inc. 55)
31	2402-160	X	1	Fitting, Elbow	55	0423-154		1	● O-Ring



REAR DRIVE GEARCASE ASSEMBLY

0745-864


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
-	2502-090	X	1	Complete Rear Drive Gearcase Assembly	12	0402-333		1	Plug, Magnetic (inc. 13)
1	1502-896		1	Housing, Gearcase	13	0423-154		1	● O-Ring
2	2402-162	X	1	Fitting, Elbow	14	1402-211		1	Plug, Oil Level (inc. one No. 15)
3	2402-150	X	2	Seal	15	0423-153		2	● O-Ring
4	0402-393		2	Bearing	16	1402-210		1	Plug, Fill (inc. one No. 15)
5	1402-032		1	Gear, Ring - 36T	17	0402-411		1	Pin, Dowel
6	0402-405	AR		Shim, 41 x 49 x 1.3 mm	18	0402-328		1	Bearing
	0402-406	AR		Shim, 41 x 49 x 1.4 mm	19	1502-863		1	Gear, Pinion - Assembly - 10T (inc. 20-21)
	0402-407	AR		Shim, 41 x 49 x 1.5 mm	20	0402-327		1	● Bearing
	0402-408	AR		Shim, 41 x 49 x 1.6 mm	21	1402-977		1	● Collar, Retaining
	0402-409	AR		Shim, 41 x 49 x 1.7 mm	22	1423-067		1	Ring, Retaining
7	0423-149		1	O-Ring	23	0402-982		1	Washer, Wave
8	1502-897		1	Cover, Gearcase	24	0402-981		1	Collar, Shaft
9	0402-429	AR		Shim, 6.3 x 18 x 1.3 mm	25	0402-947		1	Gasket, Flange
	0402-430	AR		Shim, 6.3 x 18 x 1.4 mm	26	0502-529		1	Housing, Pinion
	0402-431	AR		Shim, 6.3 x 18 x 1.5 mm	27	0423-417		1	Ring, Retaining
	0402-432	AR		Shim, 6.3 x 18 x 1.6 mm	28	1402-043		1	Bearing
	0402-433	AR		Shim, 6.3 x 18 x 1.7 mm	29	0423-423		1	Ring, Retaining
10	0402-326		1	Button, Thrust	30	1402-011		1	Seal
11	0423-118		11	Screw, Self-Tapping	31	1502-085		1	Shaft, Input



WIRING HARNESS ASSEMBLY

0745-328


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0486-348		1	Harness, Main (inc. 2-10)	16	0824-043		1	Coil, Ignition
2	0486-164		1	● Tether, Accessory Connector	17	0824-049		1	Cap, Spark Plug
3	0430-085		1	● Cover, Fuse Block	18	8476-620		2	Screw, Machine
4	0430-045		5	● Relay (4-Pin) - 20 Amp	19	0623-038		2	Nut w/Washer
5	0430-034		1	● Diode	20	0824-037		1	Regulator, Voltage
6	0430-037		1	● Holder, Fuse	21	8476-625		2	Screw, Machine
7	0430-032		5	● Fuse - 10 Amp	22	0423-493		2	Nut w/Washer
	0430-031		4	● Fuse - 15 Amp	23	0409-064		1	Sensor, Tilt
	0430-030		2	● Fuse - 30 Amp	24	0123-802		2	Washer
8	2411-080		1	● Decal, Fuse Block	25	8468-425		2	Screw, Machine
9	0430-086		1	● Seal	26	0409-089		1	Switch, Brake - Assembly
10	0430-097		1	● Cover, Diagnostics Connector	27	0430-076		1	Cushion, ECM
11	0430-049		1	Flasher	28	0530-040		1	ECM
12	1436-416		1	Repair Kit, Connector - Tilt Sensor	29	0623-362		3	Rivet, Reinstallable
13	1436-417		1	Repair Kit, Connector - Idle Speed Control	30	2406-643		1	Tray, Electrical
14	1436-415		1	Repair Kit, Connector - LCD Gauge	31	0123-788		AR	Tie, Cable - 8 in.
15	1436-424		AR	Repair Kit, Connector - Headlight/Turn Signal/Position		0123-903		AR	Tie, Cable - 11.5 in.
					32	8476-516		1	Screw, Machine
					33	8427-502		1	Nut, Lock



BATTERY AND STARTER ASSEMBLY

0746-852


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	5993-040		1	Battery Cover/Tool Tray Assembly (inc. 2-4)	10	0445-063		1	Cable, Battery/Ground
2	4406-136		1	● Cover, Battery	11	0445-062		1	Cable, Battery/Solenoid
3	0444-122		1	● Kit, Tool	12	0645-327		1	Boot, Terminal
4	0417-016		1	● Pad, Battery	13	0623-038		5	Nut w/Washer
5	8476-620		2	Screw, Machine	14	0445-064		1	Cable, Solenoid/Starter (inc. 15)
6	0645-480		1	Battery Assembly (inc. 7-8)	15	0645-019		1	● Boot, Terminal
7	0445-082		1	● Kit, Hardware	16	0445-058		1	Solenoid
8	0645-430		1	● Decal, Warning	17	8476-625		4	Screw, Machine
9	0417-012		1	Foam, Battery	18	0825-024	X	1	Motor, Starter - Assembly



THROTTLE BODY ASSEMBLY

0742-670


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0470-753		1	Throttle - Assembly (inc. 2-19)	11	0470-762		1	● Injector, Fuel
2	-		1	● Throttle Body - Not a Service Part	12	0470-768		1	● Seal
3	0430-072		1	● Sensor, Throttle Position	13	5507-227		1	● Bracket, MAP Sensor
4	5507-234		1	● O-Ring	14	5507-117		2	● Screw, Machine
5	5507-231		1	● Screw, Machine	15	0430-073		1	● Sensor, MAP
6	0430-074		1	● Valve, ISC	16	5507-232		1	● O-Ring
7	5507-233		1	● O-Ring	17	5507-229		1	● Plate, ISC Valve
8	5507-238		1	● Screw, Machine	18	5507-223		1	● Cover
9	0470-687		1	● Rail, Fuel	19	5507-037		1	● Screw, Machine
10	0470-767		1	● O-Ring	20	0487-057		1	Cable, Throttle



CYLINDER ASSEMBLY

0744-071


Ref	Part No.	New Qty	Description	Ref	Part No.	New Qty	Description
1	0804-051	1	Cylinder	6	0804-047	1	Union, Coolant Hose
2	0827-002	4	Bolt, Stud	7	8468-612	1	Screw, Machine
3	8424-604	4	Nut	8	0830-007	1	O-Ring
4	0830-084	1	Gasket, Base	9	0830-097	1	Gasket, Cylinder Head
5	0829-002	4	Pin, Dowel				



CYLINDER HEAD AND CAMSHAFT/VALVE ASSEMBLY

0745-901


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0808-227	X	1	Head, Cylinder - Assembly (inc. 2-17)	23	0830-147		4	Washer
2	0829-062		2	● Pin, Dowel	24	0808-077		1	Plug, Cylinder Head
3	0831-092		2	● Plug, Shaft	25	0826-007		6	Screw, Cap
4	0809-319	X	1	● Arm, Valve Rocker - Exhaust (inc. two No. 5-6)	26	0808-003		2	Cap, Inspection
5	0809-240		4	●● Screw, Adjuster	27	0830-004		2	O-Ring
6	0827-059		4	●● Nut	28	0826-034		2	Screw, Cap
7	0809-318	X	1	● Arm, Valve Rocker - Intake (inc. two No. 5-6)	29	0828-004		1	Plate, Retainer
8	0809-241		1	● Shaft, Rocker Arm - Intake	30	0809-212		1	Sprocket
9	0809-242		1	● Shaft, Rocker Arm - Exhaust	31	0809-245		1	Camshaft
10	0809-233		8	● Cotter, Valve	32	0809-003		1	C-Ring
11	0809-232		4	● Retainer, Spring	33	0829-049		1	Pin, Dowel
12	0809-231		4	● Spring, Valve	34	0217-799		1	Spark Plug - CPR8E
13	0830-186		4	● Seal, Oil	35	0470-668		1	Flange, Intake Manifold
14	0809-230		4	● Seat, Spring - Valve	36	0830-090		1	O-Ring
15	0809-228		2	● Valve, Intake	37	0826-008		2	Screw, Machine
16	0809-229		2	● Valve, Exhaust	38	0437-069		1	Boot (inc. 39)
17	0826-149		4	● Screw, Cap	39	1423-041		1	● Clamp
18	0830-155		4	Gasket	40	0808-008		1	Cover, Thermostat
19	0826-002		2	Screw, Cap	41	0808-078		1	Thermostat
20	0826-005		2	Screw, Cap	42	0808-124		1	Sensor, Engine Coolant Temperature
21	0826-006		2	Screw, Cap	43	0827-031		1	Bolt, Stud
22	0808-037		4	Screw, Cap	44	8424-804		1	Nut
					45	0827-030		2	Bolt, Stud
					46	8424-604		2	Nut



CAM CHAIN ASSEMBLY

0732-308


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0810-001	1	1	Chain, Cam	7	0830-018	1	1	Gasket
2	0810-002	1	1	Guide, Chain	8	8468-625	2	2	Screw, Machine
3	0810-003	1	1	Tensioner, Chain	9	0830-107	2	2	Gasket
4	0826-036	1	1	Pivot, Tensioner	10	8400-610	1	1	Screw, Cap
5	0830-025	1	1	Washer, Crush	11	0828-129	1	1	Washer
6	0810-004	1	1	Adjuster, Tensioner - Assembly					



CRANKCASE ASSEMBLY

0743-953


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0801-151		1	Crankcase Assembly (inc. 2-15)	19	8468-645		3	Screw, Machine
2	0812-064		2	● Plug	20	8468-655		3	Screw, Machine
3	0801-002		1	● Plug	21	8468-675		2	Screw, Machine
4	0832-043		1	● Bearing	22	8412-860		1	Screw, Cap
5	0832-005		2	● Bearing	23	0826-017		1	Screw, Cap
6	0832-049		1	● Bearing	24	0830-008		2	Gasket
7	0832-050		3	● Bearing	25	0826-019		1	Screw, Cap
8	0832-042		1	● Bearing	26	0826-018		1	Screw, Cap
9	0832-048		1	● Bearing	27	8468-695		1	Screw, Machine
10	0832-077		1	● Bearing	28	8468-680		1	Screw, Machine
11	0822-052		1	● Seal, Countershaft	29	0801-029		1	Housing, Secondary Shaft (inc. one No. 7)
12	0826-100		4	● Screw, Machine	30	0826-105		3	Screw, Cap
13	0822-010		4	● Retainer, Bearing	31	0826-038		1	Screw, Cap
14	0801-028		1	● Pipe, Breather	32	0801-069		1	Pipe, Breather
15	0830-035		1	● Seal, Driveshaft	33	0801-179		1	Stick, Oil Level
16	8412-850		4	Screw, Cap	34	0830-010		1	O-Ring
17	0829-003		1	Pin, Dowel					
18	0829-002		5	Pin, Dowel					



CRANKSHAFT AND PISTON ASSEMBLY

0739-932


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0805-325	1	1	Crankshaft Assembly	4	0831-001	2	2	● Circlip, Piston Pin
2	0805-064	1	1	Piston Set (inc. 3-6)	5	-	1	1	● Piston - Not a Service Part
3	0805-065	1	1	● Ring, Piston - Set	6	0805-012	1	1	● Pin, Piston



CLUTCH/V-BELT/MAGNETO COVER ASSEMBLY

0746-612

Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0806-089		1	Cover, V-Belt	19	0802-071		1	● Clamp, Routing
2	0829-002		6	Pin, Dowel	20	8470-510		2	Screw, Machine
3	0830-013		1	Washer, Crush	21	0826-155		1	Plug
4	8408-812		1	Screw, Cap	22	0830-015		1	Washer, Crush
5	0832-060		1	Bearing	23	1623-984		1	Clamp, Routing
6	0831-078		1	Ring, Retaining	24	8468-675		2	Screw, Machine
7	0830-174		1	Gasket, V-Belt Cover	25	8468-640		26	Screw, Machine
8	0806-086		1	Cover, Clutch	26	8468-625		2	Screw, Machine
9	8468-645		14	Screw, Machine	27	1602-981		1	Bearing
10	8468-655		2	Screw, Machine	28	0830-158		1	Seal
11	0826-029		5	Screw, Machine	29	0805-008		1	Retainer, Seal
12	0806-048		1	Plate, Air Intake	30	0826-031		3	Screw, Machine
13	0830-188		1	Seal	31	0830-108		1	O-Ring
14	0832-009		1	Bearing	32	0820-061		1	Bushing
15	0822-010		2	Retainer, Bearing	33	0827-008		1	Nut
16	0830-116		1	Gasket, Clutch Cover	34	0820-062		1	Cover, Magneto
17	0830-128		1	Gasket, Magneto Cover	35	8468-616		4	Screw, Machine
18	0806-127		1	Cover, Magneto - Assembly (inc. 19)					




STARTER CLUTCH ASSEMBLY

0739-940

Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0815-001	1		Gear, Starter Idler - No. 1	6	0815-004	1		Gear, Starter Clutch (inc. 7)
2	0829-031	1		Shaft, Starter Gear	7	0832-079	1		● Bearing
3	0815-002	1		Gear, Starter Idler - No. 2	8	0802-035	1		Clutch, Starter
4	0815-003	1		Spacer, Starter Idler Gear No. 2	9	0826-069	6		Screw, Machine
5	0829-032	1		Shaft, Starter Gear	10	0828-094	1		Washer

0739-941

Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0826-033		1	Screw, Cap	5	0811-004		1	Spacer
2	0828-003		1	Washer	6	0811-034		1	Gear, Driven
3	0811-003		1	Gear, Oil Pump Drive	7	0829-006		1	Key
4	0829-007		1	Pin, Dowel	8	0805-304		1	Balancer, Crank




OIL FILTER/PUMP ASSEMBLY

0744-012

Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0812-023	1		Pump, Oil	9	0812-034	1		Filter, Oil
2	0812-083	1		Gear, Driven	10	0812-053	1		Cap, Oil Strainer
3	0829-009	1		Pin	11	8468-625	4		Screw, Machine
4	0828-007	1		Washer	12	0812-007	1		Valve, Oil-Relief - Assembly
5	0831-002	1		Ring, Retaining	13	0812-006	1		Plug, Drain
6	0826-039	3		Screw, Machine	14	0830-017	1		Gasket, Drain Plug
7	0812-057	1		Strainer, Oil	15	0812-066	1		Union, Filter
8	0826-040	2		Screw, Machine					


0739-945									
Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0813-001		1	Pump, Water - Assembly (inc. 2)	7	0832-046		1	Bearing, Shaft
2	0830-029		1	● O-Ring	8	0831-004		1	Ring, Retaining
3	0813-004		1	Gear, Driven	9	0811-003		1	Gear, Water Pump Drive
4	0813-005		1	Shaft, Driven Gear	10	0829-007		1	Pin, Alignment
5	0829-009		1	Pin, Driven Gear	11	0831-005		1	Ring, Retaining
6	0831-002		2	Ring, Retaining	12	8468-665		2	Screw, Machine



TRANSMISSION ASSEMBLY

0747-926


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0823-432	X	1	Pulley, Driven - Assembly (inc. 2-8)	15	0823-164		8	Roller
2	0823-456	X	1	● Pulley, Driven - Uncalibrated (inc. 3-6)	16	0823-271		1	Spacer
3	0823-454	X	3	●● Shoe, Cam	17	0823-273		1	Face, Movable Drive
4	0823-177		3	●● Screw, Machine	18	0823-013		1	Belt, Drive
5	0823-383	X	1	●● Key	19	0823-272		1	Face, Fixed Drive
6	0823-455	X	1	●● Ring, Snap - External	20	0823-131		1	Shroud, Drive Face
7	0823-453		1	● Cam	21	0623-914		6	Screw, Self-Tapping
8	0823-377		1	● Spring - Black	22	0823-015		1	Spacer, Fixed Drive Face
9	0623-929		1	Washer	23	0470-531		1	O-Ring
10	8413-241		1	Screw, Cap	24	0821-002		1	Housing, Clutch - Assembly
11	0827-010		1	Nut	25	0830-189		1	Seal
12	0828-106		1	Washer	26	0827-011		1	Nut
13	0823-276		1	Plate, Movable Drive Face	27	0823-018		1	Clutch, One-Way
14	0823-277		4	Damper, Movable Drive Face	28	0823-484	X	1	Clutch, Centrifugal - 6 Plate



SECONDARY TRANSMISSION ASSEMBLY

0746-671


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0828-101		2	Washer, Thrust	13	0822-137		1	● Gear, Driven - Low
2	0822-092		1	Gear, Reverse Idle (inc. 3)	14	0822-138		1	● Gear Select, Sliding
3	-		1	● Bushing - Not Serviced Individually	15	0822-075		1	● Shim
4	0822-080		1	Shaft, Reverse Idle	16	0822-139		1	● Gear, Driven - High
5	0822-076		1	Driveshaft	17	0829-059		1	● Washer, Thrust
6	0822-133		1	Countershaft Assembly (inc. 7-17)	18	0829-023		2	Pin, Dowel
7	0822-134		1	● Countershaft	19	0830-129		1	Gasket
8	0822-135		1	● Gear Select, Reverse	20	0822-130		1	Housing, Speedometer Sensor
9	0831-091		2	● Ring, Retaining	21	0830-107		2	Gasket
10	0828-099		3	● Washer, Spline	22	8468-645		2	Screw, Machine
11	0832-061		3	● Bearing	23	0824-042		1	Sensor, Speedometer
12	0822-136		1	● Gear, Reverse Driven	24	8468-620		1	Screw, Machine



GEAR SHIFTING ASSEMBLY

0745-773


Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0828-036		2	Washer	13	0828-131		1	Spacer
2	0831-010		2	Ring, Retaining	14	0828-037		1	Washer
3	0818-007		1	Shaft, Sub-Gear Shift	15	0818-089		1	Plate, Gear Shift Cam
4	0830-044		1	Seal, Sub-Gear Shift Shaft	16	0826-006		1	Screw, Cap
5	0818-014		1	Arm, Select	17	0828-038		1	Washer
6	8468-620		1	Screw, Machine	18	0818-002		1	Stopper, Cam
7	8470-520		2	Screw, Machine	19	0818-004		1	Support, Cam Stopper
8	0409-090		1	Switch, Gear Position	20	0818-090		1	Spring
9	0818-013		2	Contact	21	0828-035		1	Washer
10	0818-017		2	Spring	22	8424-602		1	Nut
11	0828-040		1	Washer	23	0818-072		2	Fork, Shift
12	0818-075		1	Shaft, Gear Shift - Assembly	24	0818-006		1	Shaft, Shift Fork



SECONDARY DRIVE ASSEMBLY

0747-788

Ref	Part No.	New	Qty	Description	Ref	Part No.	New	Qty	Description
1	0819-063		1	Yoke, Propeller Shaft Joint	10	0819-115		1	Shaft, Secondary Driven - Front
2	1402-164		1	Joint, Universal - Set (inc. 3)	11	0832-016		1	Bearing
3	0423-450		4	● Ring, Retaining	12	0822-106		1	Gear, Secondary Driven
4	0827-013		2	Nut	13	0819-011		1	Ring, Driven Bearing
5	0828-020		2	Washer	14	0819-053		1	Shaft, Secondary Driven - Rear
6	0819-061		1	Yoke, Drive Output	15	0819-005		1	Flange, Output Joint
7	0830-043		2	Seal, Oil	16	0822-067		1	Shaft, Output
8	0832-017		2	Bearing	17	0822-009		1	Gear, Driven
9	0828-021	AR		Shim, 25 x 34 x 0.25 mm	18	0822-127		1	Gear, Secondary Drive
	0828-022	AR		Shim, 25 x 34 x 0.30 mm	19	0828-019		1	Washer, Thrust
	0828-023	AR		Shim, 25 x 34 x 0.70 mm	20	0827-012		1	Nut
	0828-024	AR		Shim, 25 x 34 x 0.90 mm					
	0828-025	AR		Shim, 25 x 34 x 0.95 mm					
	0828-026	AR		Shim, 25 x 34 x 1.00 mm					
	0828-027	AR		Shim, 25 x 34 x 1.05 mm					
	0828-028	AR		Shim, 25 x 34 x 1.10 mm					
	0828-029	AR		Shim, 25 x 34 x 1.15 mm					



MAGNETO ASSEMBLY

0746-613

Ref	Part No.	New Qty	Description	Ref	Part No.	New Qty	Description
1	0802-048	1	Rotor/Flywheel	5	0802-041	1	Stator - Assembly
2	0829-012	1	Key	6	8470-510	1	Screw, Machine
3	0827-014	1	Nut	7	0802-015	1	Clamp - No. 1
4	8409-632	3	Screw, Cap				

