


2015 ATV 400 4X4 EFT GREEN

Contents

AIR INTAKE ASSEMBLY [94347]	1
BATTERY AND STARTER ASSEMBLY [94352]	3
CAM CHAIN ASSEMBLY [90862]	4
CARBURETOR [100407]	5
CASE/BELT COOLING ASSEMBLY [94316]	7
CLUTCH/V-BELT/MAGNETO COVER ASSEMBLY [96215]	8
CRANK BALANCER ASSEMBLY [90867]	10
CRANKCASE ASSEMBLY [300617]	11
CRANKSHAFT AND PISTON ASSEMBLY [94355]	13
CYLINDER ASSEMBLY [92885]	14
CYLINDER HEAD AND CAMSHAFT/VALVE ASSEMBLY [100394]	15
DRIVE TRAIN ASSEMBLY [100713]	17
ENGINE AND EXHAUST [98410]	19
FRAME AND RELATED PARTS [96060]	21
FRONT DRIVE GEARCASE ASSEMBLY [100409]	23
FRONT RACK, BODY PANEL, AND HEADLIGHT ASSEMBLIES [300618]	25
FRONT SUSPENSION ASSEMBLY [100404]	27
GAS TANK ASSEMBLY [100391]	29
GEAR SHIFTING ASSEMBLY [98402]	30
HANDLEBAR ASSEMBLY [100403]	32
HYDRAULIC BRAKE ASSEMBLY [300615]	34
INSTRUMENT POD ASSEMBLY [300614]	36
LICENSE PLATE HOLDER ASSEMBLY [96062]	37
MAGNETO ASSEMBLY [98403]	38
OIL COOLER ASSEMBLY [300616]	39
OIL PUMP AND STRAINER ASSEMBLY [92889]	41
PARKING BRAKE ASSEMBLY [96050]	43
REAR BODY, RACK, AND TAILLIGHT ASSEMBLY [300619]	44
REAR DRIVE GEARCASE ASSEMBLY [97672]	46
REAR SUSPENSION ASSEMBLY [100389]	48
REED VALVE ASSEMBLY [100395]	50
SEAT ASSEMBLY [95049]	52
SECONDARY DRIVE ASSEMBLY [94327]	53
SECONDARY TRANSMISSION ASSEMBLY [92890]	55
SHIFT LEVER ASSEMBLY [100376]	57
STARTER CLUTCH ASSEMBLY [92888]	58
STEERING ASSEMBLY [300613]	59
TRANSMISSION ASSEMBLY [94357]	61
WHEEL AND TIRE ASSEMBLY [100390]	62
WINCH ASSEMBLY [300583]	63
WIRING HARNESS ASSEMBLY [100406]	64


AIR INTAKE ASSEMBLY [94347]



Item	Part No.	Qty	Name	Context	Footnote
1	3313-395	1	Filter, Air - Assembly	(inc. 2-13)	
.2	8408-850	3	Screw, Cap		
.3	0470-442	1	VALVE, AIR CLEANER		
.4	3313-705	1	Clamp		
.5	3313-375	3	Latch		
.6	3313-376	1	Cover, Air Filter		
.7	3313-853	3	Spacer		
.8	3313-378	1	Element, Air Filter		
.9	3313-446	1	Gasket, Air Filter		
.10	3313-377	1	Housing, Air Filter		
.11	0402-678	3	SPRING,SHIFT,LEVER		
.12	8050-222	3	Washer		
.13	3303-269	3	Nut		
14	3305-448	2	Clip, Retaining		
15	0423-380	5	CLAMP,HOSE-WORM-50-70mm x 9mm BLK		
16	3313-816	1	Boot, Air Intake		
17	3313-817	2	Clamp		
18	3313-275	1	Boot, Air Intake		
19	3313-063	1	Boot, Air Intake		
20	3313-274	1	Boot, Air Intake		


Item	Part No.	Qty	Name	Context	Footnote
21	3313-397	1	Hose, Oil Catch	(inc. 22)	
22	3304-167	2	Clamp		
23	3313-224	1	Housing, Air Intake		
24	3313-356	1	Bracket, Mounting - Air Intake Housing		
25	3304-409	2	BOLT WASHER 5*12		
26	3313-362	1	SHIELD,RH		
27	3313-706	1	Clamp		
28	3313-543	1	Pipe, Drain		
29	3313-551	1	Boot, Air Intake - Carburetor		

BATTERY AND STARTER ASSEMBLY [94352]




Item	Part No.	Qty	Name	Context	Footnote
1	0745-045	1	BATTERY PKG (0645-165)	(inc. 2-5)	
2	0645-045	6	Cap, Battery		
3	0645-152	1	Clamp, Hose		
4	0645-263	1	Hose, Battery		
5	0645-151	1	Decal, Warning		
6	3313-525	1	Cable, Battery/Ground		
7	3313-526	1	Cable, Battery/Solenoid		
8	3313-527	1	Cable, Solenoid/Starter	(inc. 9)	
9		1	Boot, Terminal		Part Number not Available
10	3304-011	1	Nut w/Washer		
11	3305-954	1	Motor, Starter - Assembly	(inc. 12)	
12	3304-104	1	O-Ring		
13	3305-946	2	Screw, Cap		
14	3304-654	3	NUT FLANGE 6MM		
15	3313-464	1	Solenoid	(inc. 16)	
16	3304-212	1	Fuse - 30 Amp		
17	3305-703	2	Screw, Machine		
18	3313-467	1	Bracket, Mounting - Solenoid		
19	3304-431	2	NUT LOCK		

CAM CHAIN ASSEMBLY [90862]



Item	Part No.	Qty	Name	Context	Footnote
1	0810-005	1	Chain, Cam		
2	0810-006	1	Guide, Chain		
3	0810-007	1	Tensioner, Chain		
4	0826-133	1	Pivot, Tensioner		
5	0830-150	1	Washer		
6	0810-054	1	Adjuster, Tensioner - Assembly	(inc. 7-9)	
7	0810-056	1	Spring		
8	0810-061	1	Plug		
9	0810-062	1	Washer		
10	0830-060	1	Gasket		
11	3303-360	2	Screw, Cap		


CARBURETOR [100407]



Item	Part No.	Qty	Name	Context	Footnote
Not Shown	0470-856	1	Complete Carburetor Assembly		
1	5507-001	1	Cover, Top		
2	5507-002	4	SCREW, TOP COVER		
3	5507-066	1	SPRING		
4	5507-005	1	Seat, Spring		
5	5507-110	1	Jet Needle		
6	5507-004	1	PISTON, VACUUM		
7	5507-027	1	Screw, Idle Adjust		
8	5507-028	1	Washer		
9	5507-029	1	Spring		
10	5507-115	1	Plate		
11	5507-117	1	SCREW		
12	5507-180	1	Choke, Electric		
13	5507-114	1	Cover, Electric Choke		
14	5507-067	1	O-RING, FLOAT CHAMBER		
15	5507-107	1	Valve, Float - Set		
16	5507-039	1	Float Set		


Item	Part No.	Qty	Name	Context	Footnote
17	5507-007	1	Needle Jet		
18	5507-047	1	HOLDER, NEEDLE- JET		
19	5507-125	1	Main Jet - 120		
20	5507-097	1	STARTER JET 75		
21	5507-246	1	JET,SLOW #38		
22	5507-017	4	SCREW		
23	5507-032	1	Spring		
24	5507-197	1	DIAPHRAGM		
25	5507-198	1	PUMP HOUSING		
26	5507-034	1	U-Ring		
27	5507-035	3	Screw, Machine		
28	5507-050	1	SCREW, DRAIN		
29	5507-111	1	Screw, Pilot - Set		
30	5507-036	1	Cover		
31	5507-037	1	SCREW(TOP COVER)		
32	3313-476	1	Hose, Vent		
33	3306-275	1	Cable, Throttle		

CASE/BELT COOLING ASSEMBLY [94316]



Item	Part No.	Qty	Name	Context	Footnote
1	3313-064	1	Duct, Belt - Air Out		
2	0423-342	4	SCREW,SELF TAPPING-.1875 X .75		
3	0423-551	2	Clamp		
4	3313-782	2	Boot, Duct		
5	0423-550	2	Clamp		
6	3313-065	1	Duct, Belt - Air In		


CLUTCH/V-BELT/MAGNETO COVER ASSEMBLY [96215]



Item	Part No.	Qty	Name	Context	Footnote
1	0806-026	1	Cover, Clutch		
2	0830-055	1	Gasket		
3	0830-157	1	Seal		
4	0832-071	1	Bearing		
5	0822-104	2	Retainer, Bearing		
6	0826-144	5	SCREW,PPH,M6X1X12		
7	0806-103	1	Plate, Air Intake		
8	3303-386	18	BOLT FLANGE SH 6*35		
9	0806-027	1	Cover, Drive Belt		
10	0830-056	1	Gasket		
11	0829-046	6	Pin, Dowel		
12	0832-023	1	Bearing		
13	3303-347	1	Ring, Retaining		
14	3303-365	2	Screw, Cap		
15	3303-591	3	Washer		


Item	Part No.	Qty	Name	Context	Footnote
16	3304-903	22	Screw, Cap		
17	0826-066	1	Screw, Cap		
18	3304-191	2	BOLT FLANGE SH 6*50		
19	0826-068	1	Screw, Cap		
20	0806-028	1	Cover, Magneto		
21	0830-057	1	Gasket		
22	0832-053	1	Bearing		
23	0806-099	1	Plug		
24	0830-141	1	Washer, Crush		
25	0806-029	1	Stick, Oil Level	(inc. 26)	
26	3304-102	1	O-RING 18*3		
27	0837-015	1	KIT,SEAL		
28	0830-153	1	O-Ring		
29	0805-178	1	Retainer, Oil Seal		
30	0826-145	3	Screw, Machine		
31	0820-066	1	COVER,MAGNETO-OUTER		
32	3303-617	4	BOLT FLANGE SH 6*18		

CRANK BALANCER ASSEMBLY [90867]



Item	Part No.	Qty	Name	Context	Footnote
1	0811-005	1	Balancer, Crank		
2	0829-037	1	Key		
3	3304-144	1	Pin, Alignment		
4	0811-006	1	Gear, Driven		
5	0811-009	1	Gear, Oil Pump Drive		
6	0828-091	1	Washer		
7	0826-118	1	Screw, Cap		


CRANKCASE ASSEMBLY [300617]



Item	Part No.	Qty	Name	Context	Footnote
1	0801-021	1	CRANK CASE COMP RIGHT	(inc. 2-4)	
2	0829-050	2	Pin, Dowel		
3	3307-048	1	Screw, Cap		
4	3304-607	4	Bolt, Flange		
5	0826-064	3	Screw, Cap		
6	3303-387	10	Screw, Cap		
7	0826-065	3	Screw, Cap		
8	0829-046	2	Pin, Dowel		
9	0832-087	1	Bearing		
10	3304-198	1	Bearing		
11	0832-074	1	Bearing		
12	0826-144	6	SCREW,PPH,M6X1X12		
13	0822-104	2	Retainer, Bearing		
14	3304-195	1	Bearing		
15	3304-699	1	BRG BALL RADIAL 6204		
16	0832-022	2	Bearing		
17	0832-020	1	Bearing		
18	0832-019	1	Bearing		
19	0801-027	1	Tube, Vent - Crankcase		
20	0830-066	1	Seal		


Item	Part No.	Qty	Name	Context	Footnote
21	0801-018	1	Plate, Oil Guide - Right		
22	0801-019	1	Plate, Oil Guide - Left		
23	0830-058	1	Seal		
24	0805-018	1	Retainer		
25	0826-145	3	Screw, Machine		
26	0830-143	1	WASHER,COMPRESSION 14 X 19 X 1.35		
27	0835-004	1	Plug, Oil Pressure		
28	0812-066	1	Union, Oil Filter		
29	0812-034	1	Filter, Oil		
30	3313-721	2	Bolt, Stud		

CRANKSHAFT AND PISTON ASSEMBLY [94355]




Item	Part No.	Qty	Name	Context	Footnote
1	0805-013	1	Crankshaft Assembly		
2	0805-169	1	Piston Set	(inc. 3-5)	
3	0805-170	1	Ring, Piston - Set		
4	0805-023	1	Pin, Piston		
5	0831-060	2	Circlip		
6	0820-064	1	Bushing		
7	3303-333	1	NUT FLANGE 10MM		

CYLINDER ASSEMBLY [92885]



Item	Part No.	Qty	Name	Context	Footnote
1	0804-042	1	Cylinder		
2	0830-050	1	Gasket, Cylinder Head		
3	0830-053	1	Gasket, Cylinder		
4	0829-046	2	Pin, Dowel		
5	3304-654	2	NUT FLANGE 6MM		


CYLINDER HEAD AND CAMSHAFT/VALVE ASSEMBLY [100394]



Item	Part No.	Qty	Name	Context	Footnote
1	0808-185	1	Head, Cylinder		
2	3303-341	2	Pin, Dowel		
3	0826-115	4	Screw, Cap		
4	0830-155	4	SEAL,FASTENER		
5	3304-918	2	Screw, Cap		
6	3303-386	2	BOLT FLANGE SH 6*35		
7	3304-903	1	Screw, Cap		
8	0826-136	1	Screw, Cap		
9	3303-384	2	BOLT FLANGE SH 6*25		
10	3306-787	1	PLUG HEAD		
11	0830-139	2	O-Ring		
12	3303-383	4	BOLT FLANGE SH 6*20		
13	0808-111	1	Cap, Inspection		
14	0217-705	1	SPARK PLUG(NGK CR8E)		NGK CR8E
15	3323-228	1	Manifold, Intake	(inc. 16)	

Item	Part No.	Qty	Name	Context	Footnote
.16	3323-145	1	O-Ring		
17	3304-189	2	BOLT FLANGE SH 6*20		
18	3306-151	1	Insert, Intake Manifold		
19	0423-380	1	CLAMP,HOSE-WORM-50-70mm x 9mm BLK		
20	0809-287	1	Camshaft		
21	0809-165	1	C-Ring		
22	0809-166	1	Sprocket		
23	0829-036	1	Pin, Alignment		
24	0828-086	1	Plate, Retainer		
25	0826-154	2	Screw, Cap		
26	0809-145	1	Arm, Valve Rocker - Intake		
27	3304-007	4	SCREW TAPPET ADJUSTING		
28	3304-026	4	NUT TAPPET ADJUSTING		
29	0809-149	1	Arm, Valve Rocker - Exhaust		
30	0809-151	2	Shaft, Rocker Arm		
31	0830-143	2	WASHER,COMPRESSION 14 X 19 X 1.35		
32	0831-053	2	Plug, Shaft		
33	3303-044	8	Cotter, Valve		
34	0809-142	4	Retainer, Spring		
35	0809-140	4	Spring, Valve		
36	0809-190	4	Seal, Oil		
37	0809-141	4	Seat, Spring		
38	0809-188	2	Valve, Intake		
39	0809-189	2	Valve, Exhaust		
40	0826-062	2	Screw, Cap		
41	0826-061	2	Screw, Cap		
42	0828-044	4	Washer		
43	0827-019	2	Bolt, Stud		
44	3303-332	2	Nut		
45	0829-013	2	Pin, Dowel		
46	3303-656	1	BOLT SEALING 12MM		


DRIVE TRAIN ASSEMBLY [100713]



Item	Part No.	Qty	Name	Context	Footnote
1	3313-796	2	Bladder, Gearcase		
2	3323-149	1	Clamp, Hose		
3	3323-150	2	Fitting, Vent		
4	3313-684	4	Clamp, Hose		
5	0410-070	AR	Hose, Gasline - 25 ft		
6	3304-031	4	NUT U 10MM		
7	3305-787	4	Screw, Cap		
8	3306-265	1	Complete Front Drive Gearcase Assembly		
9	3313-783	4	Bumper, Propeller Shaft		
10	3313-784	1	Shaft, Propeller		
11	3313-776	4	Clamp		
12	3313-825	1	Boot, Coupler		
13	3313-774	2	Flange, Output		
14	3304-565	8	BOLT FLANGE 8*20		
15	0402-985	2	BOOT, COUPLER (TBX)		
16	3313-777	2	Clamp		
17	3313-773	1	Shaft, Propeller		
18	3306-023	1	Gearcase, Rear		
19	3323-152	1	Clip, Routing		
20	3303-349	1	Clamp, Hose		

Item	Part No.	Qty	Name	Context	Footnote
21	0123-788	AR	Tie, Cable - 8 in.		


ENGINE AND EXHAUST [98410]



Item	Part No.	Qty	Name	Context	Footnote
1	3313-862	1	Engine	(inc. 2-3)	
.2	0801-092	3	Mount, Rubber - Engine		
.3	0801-144	1	Mount, Rubber - Engine		
4	3323-174	2	Screw, Cap		
5	3304-031	2	NUT U 10MM		
6	0411-426	1	Decal, Warning - Clutch		
7	3313-432	1	Switch, Temperature - Fan		
8	0830-180	2	O-Ring		
9	3313-431	1	Switch, Temperature - Light		
10	3313-692	1	Pipe, Exhaust - Assembly	(inc. 11-13)	
.11	3313-693	1	Pipe, Exhaust		
.12	3313-025	1	Shield, Exhaust		
.13	0423-317	2	CLAMP, HOSE -32/50 (NORMA 962)		
14	3304-565	2	BOLT FLANGE 8*20		
15	0412-007	1	SEAL, EXHAUST PIPE		

Item	Part No.	Qty	Name	Context	Footnote
16	0612-668	2	Spring		
17	0612-188	1	GASKET,EXH.-TAIL PIPE		
18	3313-709	1	Muffler - Assembly	(inc. 19-21)	
19	3323-116	1	Gasket, Spark Arrester		
20	3313-047	1	Arrester, Spark - Assembly		
21	3305-344	2	BOLT FLANGE 6*16		
22	3313-264	3	Bushing		
23	3313-026	1	Cover, Muffler		
24	3313-711	3	Screw, Cap		


FRAME AND RELATED PARTS [96060]



Item	Part No.	Qty	Name	Context	Footnote
1	3306-424	1	Frame, Main		
2	3306-332	1	Bumper - Front		
3	3304-543	12	BOLT FLANGE 8*16		
4	3304-587	4	BOLT WASHER 6*16		
5	3306-352	1	Fascia, Bumper		
6	3304-766	1	Turn Signal - Right - Assembly	(inc. 7, one No. 8, and 9)	
6	3304-813	1	Turn Signal - Left - Assembly	(inc. 7, one No. 8, and 9)	
.7	3304-822	1	Lens - Right		
.7	3304-823	1	Lens - Left		
.8	3304-825	2	Bulb		
.9	3305-359	1	Harness - Right		
.9	3305-360	1	Harness - Left		
10	3304-645	4	SCREW TAPPING 5*12		
11	3304-586	2	BOLT WASHER 6*20		
12	3303-267	2	Clip, U-Nut		

Item	Part No.	Qty	Name	Context	Footnote
13	3306-372	1	Relay, Turn Signal		
14	3305-344	2	BOLT FLANGE 6*16		
15	3313-577	1	Bracket, Mounting - Electrical		
16	3304-544	1	Screw, Cap		
17	3304-553	1	BOLT FLANGE 6*12		
18	3313-576	1	Horn, Electric - 12V		
19	3305-395	2	Screw, Machine		
20	3305-392	1	Lock, Steering		
21	3313-351	2	Footrest		
22	3313-755	1	PLATE SKID		
23	0423-545	10	SCREW,BODY-SELF TAP #12 X 3/4 A Z&B		
24	3313-596	1	Shield, Gearcase	(inc. 25)	
25	3306-582	1	Foil, Protective		
26	3306-329	2	Cushion		
27	1411-077	1	Decal, Warning - Towing		
28	0541-857	1	Mount, Ball Hitch	(inc. 29-30)	
29	0423-690	1	Nut, Lock		
30	0423-693	1	Screw, Cap		


FRONT DRIVE GEARCASE ASSEMBLY [100409]



Item	Part No.	Qty	Name	Context	Footnote
Not Shown	3306-265	1	Complete Front Drive Gearcase Assembly		
1	3306-047	1	Shaft, Input		
2	3323-239	1	Seal		
3	3306-046	1	Ring, Retaining		
4	3323-241	1	Bracket, Actuator		
5	3306-264	1	Actuator		
6	3313-792	1	O-Ring		
7	3313-797	3	Screw, Self-Tapping		
8	3323-240	1	Bearing		
9	3303-615	11	Screw, Self-Tapping		
10	3323-238	1	Housing, Pinion		
11	3323-234	1	Gasket, Flange		
12	3306-045	1	Ring, Retaining		
13	3323-235	1	Shaft, Selector		
14	3313-791	1	Ring, Retaining		
15	3323-236	1	Fork, Selector		
16	3323-233	1	Shaft, Shuttle		
17	3313-790	1	O-Ring		
18	3313-789	1	Spring, Return		

Item	Part No.	Qty	Name	Context	Footnote
19	3313-788	1	Collar, Lock		
20	3323-232	1	Coupler, Drive		
21	3306-039	1	Gear, Pinion - Assembly - 11T	(inc. 22-23)	
.22	0402-336	1	Collar, Retaining		
.23	3306-040	1	Bearing		
24	3313-793	1	Housing, Gearcase		
25	3306-038	1	Bearing		
26	3306-048	1	Pin, Dowel		
27	3306-027	1	Plug, Magnetic	(inc. one No. 28)	
.28	0423-153	2	O-Ring		
29	3306-030	1	O-Ring		
30	3306-801	2	Bearing		
31	3306-132	AR	Shim, 41 x 49 x 1.0 mm		
31	3306-133	AR	Shim, 41 x 49 x 1.1 mm		
31	3306-134	AR	Shim, 41 x 49 x 1.2 mm		
31	3306-135	AR	Shim, 41 x 49 x 1.3 mm		
31	3306-136	AR	Shim, 41 x 49 x 1.4 mm		
31	3306-137	AR	Shim, 41 x 49 x 1.5 mm		
31	3306-138	AR	Shim, 41 x 49 x 1.6 mm		
31	3306-139	AR	Shim, 41 x 49 x 1.7 mm		
32	3313-794	1	Gear, Ring - 34T		
33	3313-795	1	Cover, Gearcase		
34	3306-034	1	Fitting, Elbow		
35	3306-036	1	Plug, Oil Level	(inc. one No. 28)	
36	2402-240	2	SEAL, 48X84X9 FKM		
37	3306-035	1	Plug, Fill	(inc. 38)	
.38	0423-154	1	O-Ring		


FRONT RACK, BODY PANEL, AND HEADLIGHT ASSEMBLIES [300618]



Item	Part No.	Qty	Name	Context	Footnote
1	3306-330	1	Rack, Front - Assembly	(inc. 2)	
.2	1411-681	1	Decal, Warning - Load		
3	3313-522	2	Screw, Cap		
4	3313-713	2	Screw, Cap		
5	0423-669	4	Spacer		
6	0423-465	4	Grommet		
7	3304-668	4	Nut, Lock		
8	3313-469	1	Tube, Mounting		
9	3306-268	1	Headlight - Assembly - Right	(inc. 10, one No. 11, one No. 12, and one No. 13)	
.10	3306-270	1	Lens, Headlight - Right		
9	3306-269	1	Headlight - Assembly - Left	(inc. 10, one No. 11, one No. 12, and one No. 13)	
.10	3306-271	1	Lens, Headlight - Left		
.11	3303-847	2	Bulb		
.12	3303-846	2	BULB HEAD LIGHT		
.13	3306-272	2	Harness, Headlight		
14	3304-061	4	NUT CLIP 5MM		
15	3304-029	4	BOLT WASH 5*16		
16	3304-157	2	Clamp, Routing		
17	3304-586	2	BOLT WASHER 6*20		

Item	Part No.	Qty	Name	Context	Footnote
18	3303-267	2	Clip, U-Nut		
19	3313-752	1	PANEL,SIDE-RH		
20	0423-678	10	Grommet		
21	3313-753	1	Panel, Side - Lower - Left		
22	3306-404	1	Cover, Access - Black		
23	3303-592	6	Clip, Retaining		
24	3306-397	1	Cover, Gas Tank - Green		
25	3304-057	2	CLIP FENDER		
26	3313-756	1	Panel, Splash - Front - Right		
26	3313-861	1	Panel, Splash - Front - Left		
27	3313-754	1	Shield, Linkage		
28	3304-650	3	SCREW TAPPING 5*16 (CIRCLE HEAD)		
29	3305-783	2	Screw, Cap		
30	3306-400	1	Panel, Fender - Front - Green		
31	3304-774	2	Nut, Lock		
32	3313-359	2	REFLECTOR,FRONT (OVAL)		
33	1411-804	1	DECAL,WARNING-AGE (16)		
34	3304-806	1	Decal, Warning - General		
35	4411-346	1	Decal, Side - Upper Right		
35	4411-347	1	Decal, Side - Upper Left		
36	2411-465	1	Decal, "Arctic Cat"		

FRONT SUSPENSION ASSEMBLY [100404]



Item	Part No.	Qty	Name	Context	Footnote
1	3306-865	2	Shock/Spring Assembly - Black		
2	3303-376	4	SCREW,CAP-HFH M10X1.25X40		
3	3304-031	10	NUT U 10MM		
4	3306-866	1	A-Arm, Upper Right - Black	(inc. 5-9)	
4	3306-867	1	A-Arm, Upper Left - Black	(inc. 5-9)	
.5	3313-111	2	SLEEVE,SUSPENSION		
.6	3313-112	12	Bushing		
.7	3313-113	12	Seal		
.8	0423-009	4	CLIP,BALL JOINT		
.9	0405-483	4	BALLJOINT-ASSY (DOUBLE STAKE)		
10	3313-430	2	Screw, Cap		
11	3304-183	4	SCREW,CAP-HFH M10X1.25X85		
12	3313-082	1	A-Arm, Lower Right - Black	(inc. 6-9 and 13)	

Comments for Part Num. 3313-082

3313-112 BUSHING-SUSPENSION, This a-arm requires qty 4.


12	3313-083	1	A-Arm, Lower Left - Black	(inc. 6-9 and 13)	
----	----------	---	---------------------------	-------------------	--

Comments for Part Num. 3313-083

3313-112 BUSHING-SUSPENSION, This a-arm requires qty 4.


Item	Part No.	Qty	Name	Context	Footnote
.13	3313-107	4	Axle		
14	3313-831	2	HALF SHAFT,FRONT	(inc. 15-17)	
.15	3313-560	2	DIFF SIDE BOOT SERVICE KIT(IN BOARD)	(inc. 16)	
16	0423-845	2	CLIP,RETAINING-INBOARD		
17	3306-425	2	Repair Kit, Boot - Drive Axle - Outbound		
18	3323-130	1	Knuckle - Assembly - Right	(inc. 19-20)	
18	3323-131	1	Knuckle - Assembly - Left	(inc. 19-20)	
.19	1402-809	2	Bearing		
.20	0423-423	2	Ring, Retaining		
21	3323-127	4	Screw, Cap		

GAS TANK ASSEMBLY [100391]



Item	Part No.	Qty	Name	Context	Footnote
1	3306-241	1	Tank, Gas - Assembly		
2	3306-297	1	Cap, Gas Tank	(inc. 3)	
3	3306-298	1	Gasket, Gas Tank Cap		
4	3306-300	6	BOLT WASHER 5*16		
5	3306-299	1	Plate, Retaining		
6	3313-852	1	Sensor, Fuel Level		
7	3313-845	1	Seal		
8	0423-732	1	Screw, Shoulder		
9	0423-460	2	Grommet		
10	3313-833	1	Shield, Heat		
11	3307-118	1	Screw, Machine		
12	3313-287	1	Knob, Gas Tank Valve		
13	3306-897	1	Valve, Gas Tank		
14	3304-431	2	NUT LOCK		
15	3313-685	1	Hose, Gasline	(inc. 16)	
16	3313-684	2	Clamp, Hose		


GEAR SHIFTING ASSEMBLY [98402]



Item	Part No.	Qty	Name	Context	Footnote
1	0818-126	1	DRUM ASSY, GEAR SHIFT	(inc. 2-8 and two No. 9)	
2	0818-125	1	SHIFT SHAFT		
3	3304-439	1	Pin, Dowel		
4	0818-060	2	Spring		
5	0818-116	1	Cam, Reverse		
6	3304-147	4	CIR CLIP EX 25MM		
7	0831-016	1	C-Ring		
8	0818-117	1	Cam, Gear Shift		
9	0828-079	3	Washer		
10	3303-252	2	Screw, Machine		
11	3306-395	1	Switch, Gear Position		
12	0818-073	1	Spacer, Speed Sensor		
13	0828-081	1	Washer, Thrust		
14	0828-080	1	Washer, Thrust		
15	0818-061	1	Plate, Gear Shift Cam		
16	3304-569	1	Screw, Cap		
17	0828-084	2	Washer		
18	0831-056	2	Ring, Retaining		
19	0818-113	1	Shaft, Sub-Gear Shift	(inc. 18)	

Item	Part No.	Qty	Name	Context	Footnote
20	0830-179	1	Seal		
21	3304-551	1	BOLT FLANGE 6*22		
22	1623-984	1	CLAMP,WIRE - 76.14MM LG W/6.25 HOLE		Optional
23	3306-316	1	Arm, Select		
24	0828-083	1	Washer		
25	0818-084	1	Stopper, Cam		
26	0818-062	1	Support, Cam Stopper		
27	0818-020	1	Spring		
28	0828-082	1	Washer		
29	3304-654	1	NUT FLANGE 6MM		
30	0818-021	1	Shaft, Shift Fork		
31	0818-088	2	Fork, Shift		


HANDLEBAR ASSEMBLY [100403]



Item	Part No.	Qty	Name	Context	Footnote
1	3313-580	1	Handlebar		
2	0405-148	2	PLUG,HANDLE BAR		
3	0405-147	2	Grip, Handlebar		
4	0405-149	2	End Cap, Handlebar		
5	8050-247	2	Washer		
6	8477-845	2	Screw, Machine		
7	3306-276	1	Case, Throttle - Assembly	(inc. 8-17)	
8		1	Cover, Throttle Case w/Switch		Not Serviced Individually
9	3305-344	1	BOLT FLANGE 6*16		
10	3313-739	1	Washer		
11	3313-838	1	Arm, Throttle		
12	3313-839	1	Spring		
13	3313-740	1	Screw, Machine		
14	3305-832	1	Nut		
15	3313-741	2	Screw, Machine		
16	3313-841	1	Spacer		
17	3313-842	1	Lever		
18	1411-865	1	Decal, Brake Lever Lock		
19	3313-581	1	Switch, Control - Assembly		

Item	Part No.	Qty	Name	Context	Footnote
20	3304-803	1	Mirror Assembly - Right		
20	3304-816	1	Mirror Assembly - Left		
21	3303-839	AR	Tie, Cable		


HYDRAULIC BRAKE ASSEMBLY [300615]



Item	Part No.	Qty	Name	Context	Footnote
1	3307-069	6	Screw, Cap		
2	3323-230	1	Caliper, Brake	(inc. 3-9)	Front Right
2	3323-231	2	Caliper, Brake	(inc. 3-9)	Front Left & Rear Right
.3	1436-160	1	Housing, Caliper - Assembly	(inc. 4-6)	Front Right
.3	1436-161	2	Housing, Caliper - Assembly	(inc. 4-6)	Front Left & Rear Right
..4	0502-606	3	Piston/Seal Set	(inc. 5)	
...5	0502-607	3	Seal Set		
..6	0502-609	3	Valve, Bleed		
.7	0502-608	3	O-Ring, Guide - Set		
.8	0502-605	3	Bracket Assembly		
.9	1436-420	3	Pad, Brake - Set		
10	3307-067	5	Bolt, Banjo-Fitting		
11	3303-284	15	WASHER OIL BOLT **(1) C.98.06.01.		
12	3303-919	2	Clamp, Brake Hose		
13	3304-553	3	BOLT FLANGE 6*12		
14	3313-523	1	Bracket, Mounting - Brake Hose Assembly		
15	3305-789	1	Screw, Cap		
16	3313-750	1	ASSEMBLY,BRAKE HOSE(JUNCTION)		
17	3313-647	1	Hose, Brake		


Item	Part No.	Qty	Name	Context	Footnote
18	3313-316	1	Brake Assembly	(inc. 19-26)	
19	0502-566	1	Screw, Machine		
20	0502-868	1	Cover, Reservoir		
21	0502-568	1	Screw, Machine		
22	0502-869	1	Clamp, Handlebar		
23	0502-704	1	Master Cylinder Assembly		
24	1502-904	1	Lever Assembly - Kit	(inc. 25-26)	
25	1502-905	1	Lock, Brake Lever - Kit		
26	0502-580	1	Lever Pin - Kit		
27	3313-682	1	HOSE,BRAKE(JUNCTION-DIRM)		
28	3304-674	1	OIL BOLT 10*33		
29	3306-370	1	Brake Assembly		
30	3306-152	1	Pin, Clevis		
31	3304-050	1	Washer		
32	3304-141	1	Pin, Cotter		
33	3313-680	1	Switch, Brake		
34	3313-681	1	Hose, Brake		
35	0123-788	AR	Tie, Cable - 8 in.		
36	3304-189	2	BOLT FLANGE SH 6*20		
37	3304-543	1	BOLT FLANGE 8*16		
38	8050-252	1	Washer		
39	1602-213	2	O-Ring		
40	3313-156	1	LEVER,BRAKE-BLACK		

INSTRUMENT POD ASSEMBLY [300614]




Item	Part No.	Qty	Name	Context	Footnote
1	3313-677	1	Switch, Ignition - Assembly	(inc. 2-4)	
.2	0430-054	1	Cover, Key		
.3	3409-007	2	KEY, BLANK (C SERIES)		
.4	0430-050	1	Nut, Flange - Ignition Switch		
5	3313-468	1	Outlet, Accessory - 12V		
6	0520-160	1	Speedometer - Assembly		
7	3306-278	1	Pod, Instrument - Black		
8	4411-479	1	Decal - "AirCat"		
9	0420-065	1	CLAMP, PLASTIC-LCD GAUGE		
10	0423-493	2	Nut w/Washer		
11	3304-404	2	Screw, Cap		
12	3306-277	1	Bracket, Mounting - Pod	(inc. 13)	
.13	3303-239	1	Grommet		

LICENSE PLATE HOLDER ASSEMBLY [96062]




Item	Part No.	Qty	Name	Context	Footnote
1	2506-808	1	Holder, License Plate		
2	3304-772	1	Light, License Plate Assembly	(inc. 3-9)	
3	3305-369	1	Harness		
4	3303-847	1	Bulb		
5	3305-367	1	Base		
6	3305-366	1	Seal		
7	3305-368	1	Lens		
8	3305-365	1	Cover		
9	3305-399	2	Screw, Self-Tapping		
10	3304-651	2	Screw, Self-Tapping		
11	3304-668	4	Nut, Lock		
12	3313-606	4	Clamp		
13	3304-543	4	BOLT FLANGE 8*16		

MAGNETO ASSEMBLY [98403]



Item	Part No.	Qty	Name	Context	Footnote
1	3323-200	1	STATOR,IGNITION		
2	3323-164	1	FLYWHEEL,IGNITION		
3	3305-945	3	Screw, Cap		
4	0829-039	1	Key		
5	3306-705	1	Nut		
6	3303-308	3	Screw, Cap		
7	0802-003	1	Clamp, Routing		
8	0802-004	1	Clamp, Routing		


OIL COOLER ASSEMBLY [300616]



Item	Part No.	Qty	Name	Context	Footnote
1	3323-202	1	Cooler, Oil - Assembly	(inc. 2-3, three No. 4, and 5-6)	
2	3323-203	1	Cooler, Oil		
3	3323-204	1	Fan, Cooling - Assembly		
4	3304-654	5	NUT FLANGE 6MM		
5	3304-587	3	BOLT WASHER 6*16		
6	0423-030	2	Grommet		
7	3313-166	2	Screw, Shoulder		
8	0423-028	2	Bushing		
9	0423-098	2	Clamp, Hose		
10	0410-044	1	Hose, Oil		
11	3313-772	2	Clamp, Hose		
12	3313-771	1	Hose, Oil		
13	0830-172	2	O-Ring		
14	0812-060	1	Fitting, Oil		
15	3307-049	4	Screw, Cap		

Item	Part No.	Qty	Name	Context	Footnote
16	0812-059	1	Fitting, Oil		


OIL PUMP AND STRAINER ASSEMBLY [92889]



Item	Part No.	Qty	Name	Context	Footnote
1	0812-069	1	Pump, Oil		
2	0812-010	1	Gear, Driven		
3	0812-036	1	Pin, Driven Gear		
4	0828-007	1	Washer		
5	3304-146	1	Ring, Retaining		
6	0826-131	3	Screw, Machine		
7	0812-049	1	Strainer, Oil		
8	3313-722	2	Screw, Cap		
9	0812-038	1	Cap, Oil Strainer		
10	0830-159	1	O-Ring		
11	3303-384	4	BOLT FLANGE SH 6*25		
12	0829-033	2	Pin, Dowel		
13	0812-065	1	Plug, Drain		
14	0830-143	1	WASHER, COMPRESSION 14 X 19 X 1.35		
15	0812-067	1	Valve, Oil-Relief - Assembly	(inc. 16)	


Item	Part No.	Qty	Name	Context	Footnote
.16	0830-181	1	O-Ring		

PARKING BRAKE ASSEMBLY [96050]



Item	Part No.	Qty	Name	Context	Footnote
1	3306-356	1	Caliper	(inc. 2)	
2	3305-788	2	Pad, Brake - Set		
3	3305-784	2	Screw, Cap		
4	3306-351	1	Cable		
5	3313-650	1	Handle, Brake - Assembly	(inc. 6-15)	
6	3313-691	1	E-Ring		
7	3313-689	1	Lock, Brake Lever		
8	3313-690	1	Pin		
9	3313-686	1	Lever, Brake		
10	3313-687	1	Housing, Brake Lever		
11	3313-860	1	Switch, Brake		
12	3303-271	1	Nut		
13	3303-262	1	Nut		
14	3305-914	1	Screw, Shoulder		
15	3303-397	1	Screw, Machine		


REAR BODY, RACK, AND TAILLIGHT ASSEMBLY [300619]



Item	Part No.	Qty	Name	Context	Footnote
1	3306-759	1	Rack, Rear - Assembly	(inc. 2)	
.2	1411-682	1	Decal, Warning - Load		
3	8410-830	2	Screw, Cap		
4	0423-669	4	Spacer		
5	0423-465	4	Grommet		
6	3304-668	8	Nut, Lock		
7	3313-522	2	Screw, Cap		
8	3304-543	8	BOLT FLANGE 8*16		
9	3313-449	2	Tube, Mounting		
10	3313-352	1	Bracket, Mounting - Rear Rack - Right		
10	3313-353	1	Bracket, Mounting - Rear Rack - Left		
11	3306-410	1	Panel, Fender - Rear - Green		
12	4411-348	1	Decal, - "400"		
12	4411-349	1	Decal, - "400"		
13	3304-774	2	Nut, Lock		
14	3313-359	2	REFLECTOR,FRONT (OVAL)		
15	1411-893	1	Decal, Warning - Tire Pressure		
16	3313-674	1	Foil, Protective - Right		
17	3313-675	1	Foil, Protective - Left		
18	2411-465	1	Decal, "Arctic Cat"		

Item	Part No.	Qty	Name	Context	Footnote
19	3305-783	2	Screw, Cap		
20	3304-061	8	NUT CLIP 5MM		
21	3304-029	8	BOLT WASH 5*16		
22	3313-392	1	ASSY,TAILLIGHT-RH (ECE)	(inc. one No. 23, 24, and one No. 25)	
24	3313-392	1	ASSY,TAILLIGHT-RH (ECE)		
22	3313-393	1	ASSY,TAILLIGHT-LH (ECE)	(inc. one No. 23, 24, and one No. 25)	
23	3313-506	2	BULB,SIGNAL(12V 5W) (YELLOW)		
24	3313-393	1	ASSY,TAILLIGHT-LH (ECE)		
25	3303-849	2	BULB TAIL & STOP 12V21W/5W		
26	3313-760	1	Footwell - Front - Right		
26	3313-761	1	Footwell - Front - Left		
27	3305-703	18	Screw, Machine		
28	3304-431	22	NUT LOCK		
29	3304-586	4	BOLT WASHER 6*20		
30	5506-497	2	FOOTPEG,BLACK		
31	0423-545	2	SCREW,BODY-SELF TAP #12 X 3/4 A Z&B		
32	3313-762	1	Footwell - Rear - Right		
32	3313-763	1	Footwell - Rear - Left		
33	3305-852	4	Washer		

REAR DRIVE GEARCASE ASSEMBLY [97672]




Item	Part No.	Qty	Name	Context	Footnote
Not Shown	3306-023	1	Gearcase, Rear		
1	3306-024	1	Housing, Gearcase		
2	3306-801	2	Bearing		
3	2402-240	2	SEAL,48X84X9 FKM		
4	3306-029	1	Gear, Ring - 34T		
5	3306-132	AR	Shim, 41 x 49 x 1.0 mm		
5	3306-133	AR	Shim, 41 x 49 x 1.1 mm		
5	3306-134	AR	Shim, 41 x 49 x 1.2 mm		
5	3306-135	AR	Shim, 41 x 49 x 1.3 mm		
5	3306-136	AR	Shim, 41 x 49 x 1.4 mm		
5	3306-137	AR	Shim, 41 x 49 x 1.5 mm		
5	3306-138	AR	Shim, 41 x 49 x 1.6 mm		
5	3306-139	AR	Shim, 41 x 49 x 1.7 mm		
6	3306-031	1	Button, Thrust		
7	3306-124	AR	Shim, 6.3 x 18 x 1.0 mm		
7	3306-125	AR	Shim, 6.3 x 18 x 1.1 mm		
7	3306-126	AR	Shim, 6.3 x 18 x 1.2 mm		
7	3306-127	AR	Shim, 6.3 x 18 x 1.3 mm		
7	3306-128	AR	Shim, 6.3 x 18 x 1.4 mm		
7	3306-129	AR	Shim, 6.3 x 18 x 1.5 mm		

Item	Part No.	Qty	Name	Context	Footnote
7	3306-130	AR	Shim, 6.3 x 18 x 1.6 mm		
7	3306-131	AR	Shim, 6.3 x 18 x 1.7 mm		
8	3306-030	1	O-Ring		
9	3306-033	1	Cover, Gearcase		
10	3306-035	1	Plug, Fill	(inc. 11)	
.11	0423-154	1	O-Ring		
12	3306-034	1	Fitting, Elbow		
13	3303-615	11	Screw, Self-Tapping		
14	3306-027	1	Plug, Magnetic	(inc. one No. 15)	
.15	0423-153	2	O-Ring		
16	3306-038	1	Bearing		
17	3306-039	1	Gear, Pinion - Assembly - 11T	(inc. 18-19)	
.18	3306-040	1	Bearing		
.19	0402-336	1	Collar, Retaining		
20	3306-048	1	Pin, Dowel		
21	3306-042	1	Collar, Lock		
22	3306-043	1	Washer, Wave		
23	3306-044	1	Collar, Shaft		
24	3323-234	1	Gasket, Flange		
25	3306-049	1	Housing, Pinion		
26	3306-045	1	Ring, Retaining		
27	3323-240	1	Bearing		
28	3306-046	1	Ring, Retaining		
29	3323-239	1	Seal		
30	3306-047	1	Shaft, Input		
31	3306-036	1	Plug, Oil Level	(inc. one No. 15)	

Item	Part No.	Qty	Name	Context	Footnote
.13	3313-107	4	Axle		
14	3313-832	2	Axle, Drive	(inc. 15-17)	
.15	3313-560	2	DIFF SIDE BOOT SERVICE KIT(IN BOARD)	(inc. 16)	
.16	0423-845	2	CLIP,RETAINING-INBOARD		
.17	3306-425	2	Repair Kit, Boot - Drive Axle - Outbound		
18	3323-108	1	Knuckle - Assembly - Right	(inc. 19-22)	
18	3323-109	1	Knuckle - Assembly - Left	(inc. 19-22)	
.19	1402-809	2	Bearing		
.20	0423-423	2	Ring, Retaining		
.21	0403-283	8	Bushing, Suspension		
.22	0403-437	4	Collar, Suspension Bushing		


REED VALVE ASSEMBLY [100395]



Item	Part No.	Qty	Name	Context	Footnote
1	0808-186	1	Cap, Inspection - Reed Valve		
2	0808-187	1	Cover, Reed Valve		
3	3305-587	1	Valve, Reed		
4	0808-188	1	Body, Reed Valve		
5	3303-362	1	Screw, Cap		
6	0830-190	1	Gasket		
7	3313-595	1	Pipe, Air		
8	3303-363	2	Screw, Cap		
9	3303-732	1	Gasket		
10	3304-114	2	Bolt, Stud		
11	3304-654	2	NUT FLANGE 6MM		
12	3313-737	1	Duct, Air		
13	3304-167	1	Clamp		
14	3303-712	2	Clamp		
15	3313-734	1	Vacuum, Air - Assembly		


Item	Part No.	Qty	Name	Context	Footnote
16	3305-355	1	Mount, Air Vacuum		
17	3313-736	1	Duct, Air		
18	3313-735	1	Hose Assembly	(inc. 19)	
19	3304-161	2	Clamp, Hose		

SEAT ASSEMBLY [95049]



Item	Part No.	Qty	Name	Context	Footnote
1	3313-199	1	Seat Assembly	(inc. 2-5)	
2	3306-673	1	Bumper, Seat		
3	3306-458	6	BUMPER,SEAT		
4	1506-156	1	Latch, Seat		
5	1406-592	1	SPRING,LATCH		
6	3313-759	1	Retainer, Tool Kit		
7	3305-913	1	Kit, Tool		
8	1441-797	1	Wrench, Spanner		Optional


SECONDARY DRIVE ASSEMBLY [94327]



Item	Part No.	Qty	Name	Context	Footnote
1	3306-428	2	NUT		
2	3304-958	1	Washer		
3	0819-022	2	Flange, Output Joint		
4	0830-144	2	Seal, Oil		
5	0832-026	1	Bearing		
6	0819-020	1	Shaft, Secondary Driven		
7	0827-022	1	Nut		
8	0828-090	1	Washer		
9	0819-019	1	Gear, Secondary Driven		
10	0832-040	1	Bearing		
11	0819-070	1	C-Ring		
12	0819-021	1	Shaft, Secondary Driven		
13	3305-955	AR	Shim, 25 x 34 x 0.60 mm		
13	3305-956	AR	Shim, 25 x 34 x 0.65 mm		
13	3305-957	AR	Shim, 25 x 34 x 0.70 mm		
13	3305-958	AR	Shim, 25 x 34 x 0.75 mm		
13	3305-959	AR	Shim, 25 x 34 x 0.80 mm		
13	3305-960	AR	Shim, 25 x 34 x 0.85 mm		
13	3305-961	AR	Shim, 25 x 34 x 0.90 mm		

Item	Part No.	Qty	Name	Context	Footnote
13	3305-962	AR	Shim, 25 x 34 x 0.95 mm		
13	3305-963	AR	Shim, 25 x 34 x 1.00 mm		
13	3305-964	AR	Shim, 25 x 34 x 1.05 mm		
13	3305-965	AR	Shim, 25 x 34 x 1.10 mm		
13	0828-088	AR	Shim, 25 x 34 x 1.15 mm		
13	3305-966	AR	Shim, 25 x 34 x 1.20 mm		
13	3305-967	AR	Shim, 25 x 34 x 1.25 mm		
14	0832-041	1	Bearing		
15	3306-226	1	Washer		
16	0827-047	1	Nut		
17	3304-042	1	Washer, Thrust		
18	0819-018	1	Gear, Secondary Drive		
19	3306-009	AR	Shim, 30 x 48 x 0.60 mm		
19	3306-010	AR	Shim, 30 x 48 x 0.65 mm		
19	3306-011	AR	Shim, 30 x 48 x 0.70 mm		
19	3306-012	AR	Shim, 30 x 48 x 0.75 mm		
19	3306-013	AR	Shim, 30 x 48 x 0.80 mm		
19	3306-014	AR	Shim, 30 x 48 x 0.85 mm		
19	3306-015	AR	Shim, 30 x 48 x 0.90 mm		
19	3306-016	AR	Shim, 30 x 48 x 0.95 mm		
19	3306-017	AR	Shim, 30 x 48 x 1.00 mm		
19	3306-018	AR	Shim, 30 x 48 x 1.05 mm		
19	3306-019	AR	Shim, 30 x 48 x 1.10 mm		
19	3306-020	AR	Shim, 30 x 48 x 1.15 mm		
19	3306-021	AR	Shim, 30 x 48 x 1.20 mm		
19	3306-022	AR	Shim, 30 x 48 x 1.25 mm		


SECONDARY TRANSMISSION ASSEMBLY [92890]



Item	Part No.	Qty	Name	Context	Footnote
1	0828-081	1	Washer, Thrust		
2	0822-061	1	Gear, Reverse Idle		
3	0822-065	1	Bushing		
4	0822-064	1	Shaft, Reverse Idle		
5	0822-029	1	Spacer		
6	0822-022	1	Driveshaft		
7	0822-036	1	Countershaft Assembly	(inc. 8-18)	
8	0822-033	1	Gear Select, Reverse		
9	3304-147	4	CIR CLIP EX 25MM		
10	3304-045	3	Washer		
11	0822-062	3	Bushing		
12	0832-038	3	Bearing		
13	0822-032	1	Gear, Reverse Driven		
14	0822-063	1	Gear, Driven - Low		
15	0822-027	1	Gear Select, Sliding		
16	3304-044	2	WASHER THRUST 25MM		
17	0822-026	1	Gear, Driven - High		
18	0822-025	1	Countershaft		
19	0822-028	1	Gear, Drive		
20	0822-023	1	Shaft, Output		


Item	Part No.	Qty	Name	Context	Footnote
21	3303-395	2	Pin, Dowel		
22	0830-156	1	Gasket, Housing		
23	0822-105	1	Housing, Speedometer Sensor		
24	3303-382	1	BOLT FLANGE 6*16MM		
25	3313-172	1	Sensor, Speedometer		
26	0830-155	2	SEAL,FASTENER		
27	3303-387	2	Screw, Cap		
28	3304-198	1	Bearing		

SHIFT LEVER ASSEMBLY [100376]




Item	Part No.	Qty	Name	Context	Footnote
1	0402-843	1	KNOB,SHIFT		
2	0423-345	1	Clip, Retaining		
3	3313-317	1	Lever, Shift		
4	3304-544	1	Screw, Cap		
5	0423-087	1	Washer		
6	0423-299	2	O-RING,-016 (5/8X3/4X1/16)		
7	3306-317	1	Actuator, Shift		
8	0402-678	1	SPRING,SHIFT,LEVER		
9	0402-675	1	Axle, Pivot		
10	0423-182	2	O-RING,-008 (3/16X5/16X1/16)		
11	3304-654	1	NUT FLANGE 6MM		
12	3313-821	1	Screw, Cap		
13	3323-037	2	Bushing		
14	3305-396	1	Nut, Lock		
15	3306-319	1	Linkage, Shift - Assembly	(inc. 16-18)	
.16	3303-327	1	Nut, Hex - Right-Hand Thread		
.17	3313-278	1	Adjuster, Shift Linkage		
.18	3313-822	1	Nut, Hex - Left-Hand Thread		
19	3304-138	1	Washer		
20	3313-766	1	E-Ring		

STARTER CLUTCH ASSEMBLY [92888]



Item	Part No.	Qty	Name	Context	Footnote
1	0815-022	1	Gear, Starter Idler - No. 2		
2	0815-031	1	Gear, Starter Idler - No. 1		
3	0815-015	1	Pin, Starter Idler Gear No. 2		
4	0815-007	1	Pin, Starter Idler Gear No. 1		
5	0815-023	1	Gear, Starter Clutch	(inc. 6)	
6	0832-069	1	Bearing		
7	0802-044	1	CLUTCH, ONE WAY-W/ HUB ASSEMBLY	(inc. 8)	
8		1	Bearing		Not a Service Part
9	0826-120	6	Screw, Cap		


STEERING ASSEMBLY [300613]



Item	Part No.	Qty	Name	Context	Footnote
1	3307-066	4	Screw, Cap		
2	0405-035	2	Cap, Steering Adjuster		
3	0423-505	2	Screw, Shoulder		
4	0405-166	1	Cap, Housing		
5	3323-052	1	Housing - Upper		
6	3323-051	1	Housing - Lower		
7	3313-583	1	Post, Steering		
8	3304-565	2	BOLT FLANGE 8*20		
9	0602-233	1	Flange, Bearing		
10	0405-052	1	Bearing w/Inverted Oil Seal		
11	0423-073	1	Washer		
12	8408-820	1	Screw, Cap		
13	3306-722	2	Tie Rod - Assembly	(inc. 14-18)	
14	3306-725	2	End, Tie Rod - Left-Hand Thread		
15	3306-727	2	Nut - Left-Hand Thread		


Item	Part No.	Qty	Name	Context	Footnote
.16	3306-723	2	Tie Rod		
.17	3306-726	2	Nut - Right-Hand Thread		
.18	3306-724	2	End, Tie Rod - Right-Hand Thread		
19	3306-290	4	Nut		
20	3305-724	4	Pin, Cotter		

TRANSMISSION ASSEMBLY [94357]




Item	Part No.	Qty	Name	Context	Footnote
1	0823-328	1	Shoe, Clutch - Assembly		
2	0823-198	1	Clutch, One-Way		
3	0827-050	1	Nut		
4	0823-338	1	Housing, Clutch		
5	0470-531	1	O-Ring		
6	0823-058	1	Spacer		
7	0823-313	1	Face, Fixed Drive		
8	0823-228	1	Belt, Drive		
9	0823-324	1	Face, Movable Drive		
10	0823-210	8	Roller, Movable Drive Face		
11	0823-206	1	Spacer, Movable Drive Face		
12	0823-213	1	Plate, Movable Drive Face		
13	0823-214	4	Damper, Movable Drive Face		
14	3323-165	1	NUT FLANGE 16mm Z&Y		
15	0823-294	1	CLUTCH,DRIVEN-ASM	(inc. 16)	
16	0835-018	1	Key		
17	0827-058	1	Nut		

WHEEL AND TIRE ASSEMBLY [100390]




Item	Part No.	Qty	Name	Context	Footnote
1	0423-557	12	Screw, Shoulder w/Loctite		
2	1436-806	3	Disc, Brake		
3	1502-462	3	HUB - ASSEMBLY (W/DISC PEARCH)	(inc. four No. 4)	Both Front & Rear Right
4	0402-974	16	Stud, Wheel		
5	1502-464	1	HUB,ASSEMBLY (W/O DISC PEARCH)	(inc. four No. 4)	Rear Left
6	0423-607	4	Nut, Castle		
7	0423-407	4	Pin, Cotter		
8	3306-868	4	Wheel - Black		
9	0423-408	16	NUT,LUG-M10		
10	3306-419	2	Tire - Front		
10	3306-420	2	Tire - Rear		
11	3304-562	4	Stem, Valve		

WINCH ASSEMBLY [300583]



Item	Part No.	Qty	Name	Context	Footnote
1	2441-250	1	WINCH,ARCTIC 3000 (W/GASKET)	(inc. 2-5)	
2	2411-141	1	Decal, Warning - Tension		
3	2411-140	1	Decal, Warning - Operation		
4	1441-831	1	Cable, Winch		
5	0623-038	2	Nut w/Washer		
6	1441-862	1	Kit, Hardware		
7	0441-403	1	Roller, Winch	(inc. 8)	
8	0411-474	1	Decal, Warning - Pinch Point		
9	3306-383	1	Hook, Winch	(inc. 10)	
10	3306-385	1	Strap		
11	0123-788	AR	Tie, Cable - 8 in.		
11	0123-903	AR	Tie, Cable - 11.5 in.		
12	3306-382	1	Set, Winch Cable		
13	3306-638	1	Kit, Terminal Boot		
14	0409-066	1	Solenoid		
15	0541-622	1	Plate, Mounting - Winch		
16	3306-644	1	Switch, Winch - Assembly		

WIRING HARNESS ASSEMBLY [100406]



Item	Part No.	Qty	Name	Context	Footnote
1	0486-470	1	Harness, Main	(inc. 2-6)	
2	0530-008	1	Cover, Fuse Block		
3	0430-037	1	Holder, Fuse		
4	0430-033	3	Relay (5-Pin) - 30 Amp	(5-Pin) - 30 Amp	
5	0430-032	4	Fuse - 10 Amp		
5	0430-031	3	Fuse - 15 Amp		
5	3304-212	1	Fuse - 30 Amp		
6		1	Decal, Fuse Block		Not Serviced Individually
7	0423-345	2	Clip, Retaining		
8	3313-273	1	Tray, Electrical		
9	3313-659	1	CDI Unit		
10	3306-413	1	REG RECT COMP		
11	3305-344	2	BOLT FLANGE 6*16		
12	3304-654	6	NUT FLANGE 6MM		
13	3303-252	2	Screw, Machine		
14	3323-216	1	Coil, Ignition - Assembly	(inc. 15)	
15	3313-695	1	Cap, Spark Plug		
16	3303-289	AR	BAND OIL HANDLE		
17	3304-778	1	Control, Hazard		



The illustrations used in this Parts Manual are for reference to replacement part numbers only and are not to be used for assembly. For assembly procedures, use an Arctic Cat Service Manual. For a complete list of related items, refer to the current accessory catalog. Once printed, Arctic Cat does not guarantee the accuracy of the information contained in this manual. Our parts lists and illustrations are constantly revised to reflect part number changes, discrepancies, and enhancements.

®™ Trademarks of Arctic Cat Inc., Thief River Falls, MN 56701