

SECTION 4 - FUEL/LUBRICATION/COOLING

4


TABLE OF CONTENTS

Carburetor Specifications	4-2
Carburetor Schematics (400/500/650 H1).....	4-2
Throttle Body Assembly (700 EFI)	4-2
Carburetor (400/500/650 H1)	4-2
Electronic Fuel Injection (700 EFI)	4-7
Cleaning and Inspecting Carburetor (400/500/650 H1)	4-8
Throttle Cable Free-Play	4-9
Engine RPM (Idle)	4-9
Gas Tank	4-9
Gas/Vent Hoses	4-9
Electric Fuel Pump (700 EFI)	4-9
Vacuum Pulse Fuel Pump (400/500/650 H1)	4-9
Oil Flow Charts.....	4-10
Oil Filter/Oil Pump	4-11
Testing Oil Pump Pressure.....	4-11
Oil Cooler (400)	4-12
Oil Cooler (650 H1)	4-12
Liquid Cooling System (500/650 H1/700 EFI)	4-13
Radiator.....	4-13
Hoses/Thermostat (500/650 H1/700 EFI)	4-14
Fan	4-14
Servicing Water Pump (500 - Manual Transmission).....	4-14
Servicing Water Pump (500/650 H1/700 EFI - Automatic Transmission).....	4-15
Testing Electric Fuel Pump (700 EFI).....	4-18
Testing Vacuum Pulse Fuel Pump (400/500/650 H1)	4-20


Carburetor Specifications

ITEM	400	500	650 H1
Carburetor	Keihin CVK34	Keihin CVK36	Keihin CVK36
Main Jet	135	138	132
Slow Jet	38	40	40
Pilot Screw Setting (turns)	1 3/4	1 3/4	1 1/4
Jet Needle	NAZG	NFKG	NFKS
Idle RPM (engine warm)	1250-1350	1250-1350	1250-1350
Starter Jet	75	85	85
Float Arm Height	17 mm (0.7 in.)	17 mm (0.7 in.)	17 mm (0.7 in.)
Throttle Cable Free-Play (at lever)	3-6 mm (1/8-1/4 in.)	3-6 mm (1/8-1/4 in.)	3-6 mm (1/8-1/4 in.)

Carburetor Schematics (400/500/650 H1)



Throttle Body Assembly (700 EFI)



0741-277

Carburetor (400/500/650 H1)

WARNING

Whenever any maintenance or inspection is performed on the fuel system during which there may be fuel leakage, there should be no welding, smoking, open flames, etc., in the area.


REMOVING

1. Remove the seat.
2. As necessary to access the carburetor, remove the air-intake snorkel, the air cleaner housing cover, or the air cleaner housing.
3. Disconnect the gasoline hose from the carburetor to the fuel pump.
4. Loosen the flange clamps; then remove the carburetor from the intake pipe.
5. Remove the screw securing the throttle actuator cover to the carburetor; then remove the cover.




CC743

6. Remove the throttle cable from the actuator arm.



CC742

7. Loosen the outer jam nut securing the throttle cable to the carburetor body; then route the cable out of the way.



CC741

8. Disconnect the electric choke lead from the wiring harness.
9. Disconnect the vent hose; then remove the carburetor.


DISASSEMBLING

1. Remove the four Phillips-head screws securing the top cover; then remove the cover.




CH015D

2. Remove the vacuum piston assembly from the carburetor body. Account for a spring, spring seat, and the jet needle.




CC746

3. Remove the three screws securing the pump housing. Account for the diaphragm assembly, spring, and U-ring (in the housing).





CC748


4. Remove the Phillips-head screws securing the float chamber; then remove the chamber. Account for the O-ring.




■ **NOTE:** Note the locations of the jets, pilot screw, and holder for disassembling procedures.



5. Remove the float pin.




6. Lift the float assembly from the carburetor. Account for the float valve.



7. Secure the needle jet holder with a wrench; then remove the main jet.
8. Remove the needle jet holder; then remove the needle jet, slow jet, and the starter jet.


9. Remove the pilot screw. Account for a spring, washer, and an O-ring.



10. Unscrew and remove the idle adjust screw. Account for the spring and washer.

ASSEMBLING


1. Screw the idle adjust screw into the carburetor making sure the washer and spring are properly positioned.
2. Install the pilot screw, spring, washer, and O-ring.



CC758


■ **NOTE:** Turn the pilot screw clockwise until it is lightly seated; then turn it counterclockwise the recommended number of turns as an initial setting.

■ **NOTE:** Note the locations of the jets and holder during assembling procedures.



CC761A


3. Install the slow jet. Tighten securely.
4. Install the main jet into the needle jet holder and tighten securely; then install the needle jet and needle jet holder assembly into the carburetor and tighten securely.
5. Place the float assembly (with float valve) into position and secure to the carburetor with the float pin.




CC753

■ **NOTE:** Check float arm height by placing the carburetor on its side w/float contacting the needle; then measure with a caliper the height when the float arm is in contact with the needle valve. Float arm height should be 17 mm (0.7 in.).

6. Place the float chamber into position making sure the O-ring is properly positioned; then secure with the Phillips-head screws.




CC750



CC749

4

7. Place the U-ring into the pump housing. Position the spring and diaphragm assembly (lip toward the carburetor) onto the carburetor; then secure the assembly with the pump housing and three screws. Tighten securely.




CC748


CAUTION

It is important to press down on the pump housing until it contacts the carburetor to make sure the diaphragm lip is properly seated in the groove in the carburetor. If the diaphragm is not properly seated, leakage will occur.

8. Place the jet needle, spring seat, and spring into the vacuum piston; then place the assembly down into the carburetor.




9. Place the top cover into position; then secure with the Phillips-head screws. Tighten securely.




INSTALLING


1. Connect the gas and vent hoses onto the carburetor.
2. Connect the electric choke lead to the wiring harness.



3. Place the throttle cable into position and secure by tightening the outer jam nut.



4. Connect the throttle cable to the actuator arm.



5. Place the throttle actuator cover into position on the carburetor; then secure with the screw.



CC743

6. Position the carburetor in the air cleaner boot and intake pipe assembly; then secure with the clamps.
7. Connect the hose from the carburetor to the gas tank.
8. As necessary, secure the air-intake snorkel, the air cleaner housing cover, or the air cleaner housing.
9. Install the seat.

Electronic Fuel Injection (700 EFI)

⚠ WARNING

Whenever any maintenance or inspection is performed on the fuel system during which there may be fuel leakage, there should be no welding, smoking, open flames, etc., in the area.

TROUBLESHOOTING

1. Verify that the electric fuel pump is operating by listening for a “whirring” sound for several seconds after the ignition switch is turned to the ON position. If no sound can be heard, see Testing Electric Fuel Pump (700 EFI) in this section.
2. Check for a flashing EFI icon on the LCD display. If EFI is flashing, see ECU Error Codes (700 EFI) in Section 5.
3. Make sure there is sufficient, clean gas in the gas tank.
4. Verify that the battery is sufficiently charged to crank the engine over at normal speed.
5. Check the air filter housing and air filter for contamination. Clean or replace as necessary (see Section 2).


REMOVING

1. Turn the ignition switch to the OFF position; then remove the ignition switch key.

⚠ WARNING

Do not turn the ignition switch to the ON position with the hoses removed. Gasoline will be pumped by the electric fuel pump causing a safety hazard.

2. Disconnect the battery; then remove the seat.
3. Remove the storage compartment cover and air filter housing cover; then remove the air filter.
4. Loosen the clamp securing the air filter housing boot to the throttle body inlet; then remove the boot from the throttle body.




FI081B

5. Slowly disconnect the gasoline hose connector from the fuel rail.

⚠ WARNING

Gasoline may be under pressure. Place an absorbant towel under the connector to absorb any gasoline spray when disconnecting.




FI092A

6. Remove the screw securing the throttle actuator cover to the throttle body; then remove the cover.
7. Remove the throttle cable from the actuator arm.

4

8. Loosen the outer jam nut securing the throttle cable to the throttle body; then route the cable out of the way.
9. Remove the four electrical connectors from the throttle body components.



10. Remove the cap screws securing the intake pipe to the cylinder head and remove the throttle body assembly; then remove the intake pipe from the throttle body. Account for an O-ring.



11. Use tape to cover and seal the intake opening.

⚠ CAUTION

Any objects or liquid entering the intake opening will fall into the engine causing severe damage if the engine is turned over or started.

INSTALLING

1. Install the throttle body into the intake pipe and secure with the clamp. Tighten securely.
2. Place a new O-ring in the intake pipe; then position the pipe onto the engine and secure with two cap screws.
3. Connect the throttle cable to the throttle body and adjust throttle free-play (see Section 2); then connect the gasline hose.

4. Connect the four electrical connectors to the throttle body components.
5. Install the air filter housing boot and secure with the clamp; then install the air filter, air filter cover, storage compartment, and storage compartment cover.
6. Install the seat making sure it locks securely in place.

Cleaning and Inspecting Carburetor (400/500/650 H1)

■ NOTE: Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

⚠ WARNING

When drying components with compressed air, always wear safety glasses.

⚠ CAUTION

DO NOT place any non-metallic components in parts-cleaning solvent because damage or deterioration will result.

1. Place all metallic components in a wire basket and submerge in carburetor cleaner.
2. Soak for 30 minutes; then rinse with fresh parts-cleaning solvent.
3. Wash all non-metallic components with soap and water. Rinse thoroughly.
4. Dry all components with compressed air only making sure all holes, orifices, and channels are unobstructed.
5. Inspect the carburetor body for cracks, nicks, stripped threads, and any other imperfections in the casting.
6. Inspect the vacuum piston/diaphragm for cracks, imperfections in the casting, or cracks and tears in the rubber.
7. Inspect float for damage.
8. Inspect gasket and O-rings for distortion, tears, or noticeable damage.
9. Inspect tips of the jet needle, pilot screw, and the needle jet for wear, damage, or distortion.

10. Inspect the slow jet and main jet for obstructions or damage.

■ NOTE: If the slow jet is obstructed, the mixture will be extremely lean at idle and part-throttle operation.

11. Inspect the float valve for wear or damage.
12. Inspect the carburetor mounting flange for damage and tightness.

Throttle Cable Free-Play

To adjust throttle cable free-play, see Section 2.

Engine RPM (Idle) (Carbureted Models)

To adjust the idle RPM, see Section 2.

Gas Tank

⚠ WARNING

Whenever any maintenance or inspection is made on the fuel system during which there may be fuel leakage, there should be no welding, smoking, open flames, etc., in the area.

REMOVING

1. Remove the seat.
2. Remove the rear rack and fenders (see Section 8).
3. Disconnect the hose from the fuel pump to the carburetor/throttle body.
4. Remove the cap screws securing the gas tank to the frame.
5. Disconnect the fuel gauge connector; then remove the gas tank.

CLEANING AND INSPECTING

■ NOTE: Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Clean all gas tank components with parts-cleaning solvent.

2. Inspect all hoses for cracks or leaks.

3. Inspect tank cap and tank for leaks, holes, and damaged threads.

INSTALLING

1. Place the gas tank into position in the frame; then install the cap screws. Tighten securely.
2. Connect the gas hose from the carburetor/throttle body; then connect the fuel gauge connector.
3. Install the vent hose; then fill the gas tank with gasoline.
4. Start the engine and inspect for leakage.
5. Install the rear fenders and rack (see Section 8); then install the seat making sure it latches securely.

4

Gas/Vent Hoses

Replace the gas hose every two years. Damage from aging may not always be visible. Do not bend or obstruct the routing of the carburetor/throttle body vent hose. Make certain that the vent hose is securely connected to the carburetor/throttle body and the opposite end is always open.

Electric Fuel Pump (700 EFI)

The electric fuel pump and fuel level sensor are not serviceable components. If either fails, the fuel pump assembly must be replaced.


■ NOTE: To test the fuel pump, see Testing Electric Fuel Pump (700 EFI) in this section.

Vacuum Pulse Fuel Pump (400/500/650 H1)

The vacuum pulse fuel pump is not a serviceable component. If the pump fails, it must be replaced.


Oil Flow Charts

400/500 (Manual Transmission)




ATV-0111

400/500/650 H1 (Automatic Transmission)



ATV-1102

700 EFI



FI449



Oil Filter/Oil Pump

■ NOTE: Whenever internal engine components wear excessively or break and whenever oil is contaminated, the oil pump should be replaced. The oil pump is not a serviceable component.

Testing Oil Pump Pressure

■ NOTE: The engine must be warmed up to the specified temperature for this test.

1. Connect the Tachometer (p/n 0644-275) to the engine.
2. Connect the Oil Pressure Test Kit (p/n 0644-495) to the oil filter drain plug (400/500), in the oil pressure test port (700 EFI), or to the upper oil cooler hose at the engine (650 H1).



■ NOTE: Some oil seepage may occur when installing the oil pressure gauge. Wipe up oil residue with a cloth.

3. Start the engine and run at 3000 RPM. The oil pressure gauge must read as specified.

400 (Manual Transmission)
OIL PRESSURE
0.6-1.0 kg/cm ² (9-14 psi)
Oil Temperature - 60°C (140°F)
400 (Automatic Transmission)
OIL PRESSURE
1.1-1.5 kg/cm ² (16-21 psi)
Oil Temperature - 60°C (140°F)
500 (Manual Transmission)
OIL PRESSURE
1.2-1.6 kg/cm ² (17-23 psi)
Oil Temperature - 60°C (140°F)
500 (Automatic Transmission)
OIL PRESSURE
1.3-1.7 kg/cm ² (18-24 psi)
Oil Temperature - 60°C (140°F)
650 H1
OIL PRESSURE (From Oil Cooler)
1.40-2.46 kg/cm ² (15-25 psi)
Oil Temperature - 60°C (140°F)
700 EFI
OIL PRESSURE
1.4-1.8 kg/cm ² (20-26 psi)
Oil Temperature - 110°C (230°F)

■ NOTE: If the oil pressure is lower than specified, check for an oil leak, damaged oil seal, defective oil pump, or oil cooler.


4

■ **NOTE:** If the oil pressure is higher than specified, check for too heavy engine oil weight (see Section 2), clogged oil passage, clogged oil filter, or improper installation of the oil filter.

Oil Cooler (400)

KEY

1. Oil Cooler Assy
2. Oil Cooler
3. Screen
4. Thumb Screw
5. Shroud
6. Machine Screw
7. Fan
8. Drain Plug
9. O-Ring
10. Grommet
11. Nut w/Washer
12. Shoulder Screw
13. Bushing
14. Clamp
15. Hose
16. Fitting
17. O-Ring
18. Cap Screw
19. Fitting



0739-573

REMOVING

■ **NOTE:** It is not necessary to drain the engine oil for this procedure.

1. Remove the input and output hoses from the fittings on the cooler.

CAUTION

Elevate and secure the hoses to avoid oil spillage.

2. Remove the cap screws securing the oil cooler to the frame. Account for grommets.



AL651D

3. Remove the oil cooler from the frame.

INSTALLING

1. Place the cooler into position in the frame.
2. Secure the cooler to the frame with the cap screws and grommets.



AL651D

3. Install the hoses onto their respective fittings and secure with the clamps.

Oil Cooler (650 H1)

REMOVING

1. Disconnect the oil hoses from the oil cooler located on the back of the radiator.
2. Remove the radiator (see Radiator) in this section.
3. Remove the fan and fan shroud; then separate the oil cooler from the radiator.


INSTALLING

1. Place the oil cooler into position on the radiator and secure with the retainer brackets; then install the fan shroud and fan.
2. Install the radiator (see Radiator) in this section.
3. Connect the oil hoses to the oil cooler and tighten the clamps securely.
4. Warm up the engine and check for leaks; then shut off the engine and check for the proper oil level on the oil level stick. Add sufficient amount of oil to raise the level above the lower level mark.

Liquid Cooling System (500/650 H1/700 EFI)


The cooling system should be inspected daily for leakage and damage. Also, the coolant level should be checked periodically.

To check the cooling system, see Section 2.



CC863

Radiator



REMOVING

1. Drain the coolant at the engine.
2. Remove the front rack (see Section 8).
3. Remove the front bumper and front fender panel (see Section 8).
4. Remove the upper and lower coolant hoses.
5. Remove the cap screws and nuts securing the radiator to the frame.
6. Disconnect the fan wiring from the main wiring harness; then remove the radiator/fan assembly and account for the grommets and collars.
7. Remove the fan/fan shroud assembly from the radiator.

4


CLEANING AND INSPECTING

■ **NOTE:** Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Flush the radiator with water to remove any contaminants.
2. Inspect the radiator for leaks and damage.
3. Inspect all hoses for cracks and deterioration.
4. Inspect all fasteners and grommets for damage or wear.

INSTALLING

1. Position the fan/fan shroud assembly on the radiator; then secure with existing hardware.
2. Place the radiator with grommets and collars into position on the frame; then install the cap screws and nuts. Tighten securely.
3. Install the upper and lower coolant hoses; then secure with hose clamps.



AF734D

4. Install the front bumper and front fender panel (see Section 8).
5. Install the front rack (see Section 8).

6. Fill the cooling system with the recommended amount of antifreeze. Check for leakage.
7. Connect the fan wiring to the main wiring harness.

Hoses/THERMOSTAT (500/650 H1/700 EFI)

REMOVING

1. Drain approximately one qt of coolant from the cooling system.
2. Remove the two cap screws securing the thermostat housing to the cylinder head. Account for an O-ring and a thermostat.

INSPECTING

■ NOTE: Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Inspect the thermostat for corrosion, wear, or spring damage.
2. Using the following procedure, inspect the thermostat for proper operation.
 - A. Suspend the thermostat in a container filled with water.
 - B. Heat the water and monitor the temperature with a thermometer.
 - C. The thermostat should start to open at 73.5-76.5° C (164-170° F) on the 500/650 H1 and 80.5-83.5° C (177-182° F) on the 700 EFI.
 - D. If the thermostat does not open, it must be replaced.
3. Inspect all coolant hoses, connections, and clamps for deterioration, cracks, and wear.

■ NOTE: All coolant hoses and clamps should be replaced every four years or 4000 miles.

INSTALLING

1. Place the thermostat and O-ring into the thermostat housing; then secure the thermostat housing to the cylinder head with the two cap screws.
2. Install the crossover coolant hose onto the water pump and engine water inlet. Secure with the two hose clamps.

3. Slide the upper hose onto the thermostat housing and radiator. Secure with the two hose clamps.
4. Install the lower coolant hose onto the water pump housing and radiator. Secure with the two hose clamps.
5. Fill the cooling system with the recommended amount of antifreeze. Check for leakage.

FAN

REMOVING


1. Remove the radiator (see Radiator in this section).
2. Remove the fan assembly from the radiator.

INSTALLING

1. Position the fan assembly on the radiator; then secure with existing hardware.
- NOTE:** The fan wiring must be in the upper-right position.
2. Install the radiator (see Radiator in this section).

SERVICING WATER PUMP (500 - Manual Transmission)

REMOVING/DISASSEMBLING



0738-290

1. Drain the coolant.

2. Remove the three cap screws securing the water pump case. Note the position of the long cap screw and account for the O-ring.
3. Remove the impeller cap screw, washer, and gasket.
4. Remove the mechanical seal using this procedure.
 - A. Tap the tip of a small sheet metal screw into the inner-metal edge of the seal.
 - B. Grip the screw with a pair of vise-grip pliers and pull the seal out. Account for the pump drive seal.

CLEANING AND INSPECTING

■ **NOTE:** Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Clean all pump components in solvent.
2. Inspect the mechanical seal and pump drive seal for damage.

■ **NOTE:** If the mechanical seal and/or pump drive seal are damaged, they must be replaced as a set.

3. Inspect the impeller for corrosion or damage.

ASSEMBLING/INSTALLING

■ **NOTE:** Treat seals and O-rings with clean anti-freeze for initial lubrication.


1. Press the mechanical seal with pump drive seal into the impeller by hand.
2. Install the mechanical seal assembly onto the water pump shaft and secure with the cap screw, washer, and gasket. Tighten the cap screw securely.
3. Place the water pump case into position and secure with the three cap screws. Note the position of the long cap screw from removal.
4. Fill the cooling system with the recommended amount of antifreeze.

■ **NOTE:** While the cooling system is being filled, air pockets may develop; therefore, run the engine for five minutes after the initial fill, shut the engine off, and then fill the cooling system.

5. Check the entire cooling system for leakage.

Servicing Water Pump (500/650 H1/700 EFI - Automatic Transmission)

■ **NOTE:** When servicing the water pump, it will be necessary to install a new oil seal and a new mechanical seal.



0737-766

4

REMOVING


1. Remove the radiator cap; then remove the water pump drain and drain the coolant.




CC789

2. Drain the oil from the engine/transmission.
3. Remove the four torx-head cap screws securing the front and rear fenders to the footrest; then remove the four cap screws securing the footrest to the frame. Remove the footrest.


4. From inside the left-front wheel-well, remove the two torx-head cap screws securing the fender to the frame.




5. Compress the tabs on the coolant hose clamps and slide the clamps away from the hose ends approximately 51 mm (2 in.); then remove both hoses from the water pump.



6. Using an impact driver, loosen but do not remove the two Phillips-head cover screws.



7. Remove the two cap screws securing the water pump to the engine; then remove the water pump.



CC786A

DISASSEMBLING

1. Finish removing the two Phillips-head cap screws securing the cover to the bearing housing; then remove the cover. Account for the O-ring.
2. Remove the E-ring securing the impeller/shaft to the bearing housing; then remove the impeller/shaft.
3. Using Seal Removal Tool (p/n 0644-072), remove the mechanical seal and the oil seal from the bearing housing.



CC772


CLEANING AND INSPECTING

■ **NOTE:** Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Clean all oil-pump components in cleaning solvent.
2. Inspect the impeller/shaft for corrosion or damage.

ASSEMBLING

1. Place the new oil seal into the bearing housing; then using a seal driver, gently tap the seal down until it is fully seated.



CC778

2. Place the new mechanical seal into the bearing housing; then tap it down until it is fully seated.

■ NOTE: A large deep-well socket can be used to drive the seal down evenly.

3. Install the impeller/shaft assembly into the bearing housing; then secure with the E-ring.

■ NOTE: Make sure the E-ring is fully seated and the impeller rotates freely.

4. While holding the bearing housing assembly in position on the engine, slowly rotate the impeller until the impeller/shaft engages properly with its slot in the driven shaft.

■ NOTE: The bearing housing will be flush with the engine when the two shafts are properly engaged.


⚠ CAUTION

Failure to properly engage the two shafts could cause serious engine damage.


5. With the bearing housing assembly in position on the engine, place the cover (with O-ring installed) into position on the housing; then loosely secure with the two Phillips-head cap screws.

INSTALLING

1. Secure the water pump to the engine with the two cap screws tightened securely; then tighten the two Phillips-head cap screws securely.




CC786A



CC785A

4

2. Connect the two coolant hoses to the water pump and secure with the clamps.
3. From inside the left-front wheel-well, secure the fender to the frame with the two torx-head cap screws. Tighten securely.



CC788A


4. Place the footrest into position on the frame and loosely secure with four cap screws; then secure the front and rear fenders to the footrest with the four torx-head cap screws. Tighten the four torx-head cap screws securely; then tighten the remaining cap screws to specifications.
5. Fill the engine/transmission with the proper amount of recommended oil.
6. Fill the cooling system with the proper amount of recommended coolant.

■ **NOTE:** While the cooling system is being filled, air pockets may develop; therefore, run the engine for five minutes after the initial fill, shut the engine off, and then fill the cooling system.

7. Check the entire cooling system for leakage.

⚠ CAUTION

After operating the ATV for the initial 5-10 minutes, stop the engine, allow the engine to cool down, and check the coolant level. Add coolant as necessary.



Testing Electric Fuel Pump (700 EFI)

⚠ WARNING

Whenever any maintenance or inspection is made on the fuel system during which there may be fuel leakage, there should be no welding, smoking, open flames, etc., in the area.

⚠ AT THIS POINT

Prior to removing the electric fuel pump, the following check should be performed to determine that removal is necessary.

1. Turn the ignition switch ON and listen for a momentary "whirring" sound of the pump building pressure. If the sound is heard (10 seconds), no electrical checks are necessary. Turn the ignition switch OFF.
2. Disconnect the gasline hose from the throttle body; then install a suitable pressure gauge.

⚠ WARNING

Gasoline may be under pressure. Place an absorbant towel under the connector to absorb any gasoline spray when disconnecting.

3. Turn the ignition switch to the ON position. The fuel pressure should build until the pump shuts off. Pressure should read 3.0 kg-cm² (43 psi).
4. If the pump is not running, disconnect the fuel pump/tank sensor connector by reaching under the rear rack from behind.
5. Connect a multimeter to the power supply leads with the red tester lead to the red wire and the black tester lead to the black wire; then turn the ignition switch to the ON position. The meter should read battery voltage. If battery voltage is indicated and the fuel pump does not run, replace the pump assembly. If no battery voltage is indicated, check the ECU and the vehicle tilt sensor.

REMOVING

1. Remove the rear rack and fenders (see Section 8); then disconnect the power supply/ fuel gauge connector.
2. Remove the spring clamp; then remove the fuel hose.
3. Remove the screws securing the fuel pump to the gas tank; then make a reference mark on the fuel pump and tank.
4. Lift out the fuel pump assembly carefully tilting it forward to clear the voltage regulator; then guide the pump and float lever through the opening in the gas tank.

⚠ CAUTION

Take care not to damage the float or float arm or replacement of the entire assembly will be necessary.


5. Using duct tape or other suitable means, cover the fuel pump opening.

INSPECTING

AT THIS POINT

If the pump has failed earlier test and must be replaced, proceed to **INSTALLING**.


1. Inspect the fuel screen and blow clean with low pressure compressed air.
2. Move the float lever and check for free movement. The float assembly should return to the lower position without force. If not, replace the fuel pump assembly.
3. Test the fuel gauge tank sensor by connecting a multimeter (A) to the fuel sensor leads (B); then select OHMS. The multimeter should show 5 ohms at full fuel position (C) and 95 ohms at empty fuel position (D).



ATV2116

■ **NOTE:** If readings are erratic, clean the resistor wiper and resistor with clean alcohol and retest. If still not correct, replace the fuel gauge tank sensor.

4. To replace the fuel gauge tank sensor, use the following procedure.
 - A. Disconnect the two-wire connector (A); then press the fuel gauge tank sensor toward the top of the fuel pump to release it from the mounting slot (B).




FI460A

- B. Engage the tabs (C) of the fuel gauge tank sensor into the mounting slot (B) and press toward the bottom of the fuel pump to latch in place; then connect the two-wire connector (A).

INSTALLING

1. Mark the new fuel pump with a reference mark in the same location as the removed pump; then place the new gasket on the pump.
2. Remove the material covering the fuel pump opening; then carefully guide the fuel pump into position taking care not to damage the float or float lever.



KX190

4

3. Rotate the fuel pump until the match marks align; then install the mounting screws and tighten securely using a crisscross pattern.

■ **NOTE:** It is important to install the fuel pump with the correct orientation to ensure adequate float lever clearance.

4. Connect the wires, fuel hose, and spring clamp; then turn the ignition switch to the ON position. Note that the fuel pump runs momentarily and the fuel gauge indicates the proper fuel level.
5. With the transmission in neutral and brake lever lock engaged, start the engine and check for normal operation. Check for any fuel leaks.
6. Install any wire ties that were removed; then install the rear fenders, rack, and seat making sure the seat locks securely.

Testing Vacuum Pulse Fuel Pump (400/500/650 H1)

⚠ WARNING

Whenever any maintenance or inspection is made on the fuel system during which there may be fuel leakage, there should be no welding, smoking, open flames, etc., in the area.

☞ AT THIS POINT

Prior to removing the vacuum pulse fuel pump, the following check should be performed to determine that removal is necessary.

1. Disconnect the fuel pump/carburetor hose at the fuel pump; then connect a hose and suitable pressure gauge to the fuel pump output fitting.




CD815

2. Start the engine. Fuel pump pressure should read 0.18-0.25 kg/cm² (2.5-3.5 psi).

REMOVING

1. Remove the seat; then remove the three clamps securing the gas hoses and vacuum hose and disconnect the hoses.



CD766A

2. Remove the two machine screws and flange nuts securing the fuel pump to the electrical tray; then remove the pump.

INSTALLING

1. Place the fuel pump into position on the electrical tray; then secure with the machine screws and flange nuts. Tighten securely.
2. Connect two gas hoses and one vacuum hose; then secure with the clamps.



CD816

SECTION 5 - ELECTRICAL SYSTEM

TABLE OF CONTENTS

Specifications	5-2
Battery	5-2
RPM Limiter	5-2
Testing Electrical Components	5-2
Accessory Receptacle/Connector	5-3
Brakelight Switch (Auxiliary)	5-3
Brakelight Switch (Handlebar Control)	5-3
Oil Temperature and Cooling Fan Switches (400) ...	5-4
Coolant Temperature and Cooling Fan Switches (500/650 H1)	5-5
Cooling Fan Switch and Engine Coolant Temperature (ECT) Sensor (700 EFI)	5-5
Fan Motor	5-6
Fuse Block/Power Distribution Module	5-6
Fuses	5-7
Ignition Coil	5-7
EFI Sensors/Components (700 EFI)	5-8
Electronic Speedometer Speed Sensor	5-8
Ignition Switch	5-10
Handlebar Control Switches	5-10
Front Drive Selector Switch	5-11
Front Drive Selector Actuator	5-12
Differential Lock Switch	5-12
Magneto Coils (400/500/650 H1)	5-13
Stator Coil/Crankshaft Position (CKP) Sensor (700 EFI)	5-14
Starter Motor	5-15
Starter Relay	5-20
CDI Unit (400/TBX/500/650 H1)	5-20
Electronic Control Unit (ECU) (700 EFI)	5-20
Regulator/Rectifier	5-21
Neutral Start/Front Drive Actuator/Start-in-Gear/ Differential Lock/2WD Relays	5-21
Headlights	5-21
Taillight - Brakelight	5-21
Ignition Timing	5-22
ECU Error Codes (700 EFI)	5-22
Tilt Sensor (700 EFI)	5-23
Throttle Position Sensor (TPS) (700 EFI)	5-24

Specifications

400		
Ignition Timing	10° BTDC @ 1500 RPM	
Spark Plug Type	NGK CR7E	
Spark Plug Gap	0.7-0.8 mm (0.028-0.032 in.)	
Spark Plug Cap	8000-12,000 ohms	
Ignition Coil Resistance (primary)	Less than 1 ohm (terminal to ground)	
(secondary)	5200-7800 ohms (high tension - plug cap removed - to ground)	
Ignition Coil Peak Voltage (primary/ CDI)	250-375 DC volts (terminal to ground)	
MAGNETO		
Magneto Coil Resistance (trigger)	160-240 ohms (green to blue)	
(source)	Less than 1 ohm (yellow to white)	
(charging)	Less than 1 ohm (black to black)	
Magneto Coil Peak Voltage (trigger)	5.04-7.56 volts (green to blue)	
(source)	0.7-1.05 volts (yellow to white)	
Stator Coil Output (no load)	60 AC volts @ 5000 RPM (black to black)	

500/650 H1		
Ignition Timing	10° BTDC @ 1500 RPM	
Spark Plug Type	NGK CR6E	
Spark Plug Gap	0.7-0.8 mm (0.028-0.032 in.)	
Spark Plug Cap	8000-12,000 ohms (500) 4000 ohms (650 H1)	
Ignition Coil Resistance (primary)	Less than 1 ohm (terminal to ground)	
(secondary)	5200-7800 ohms (high tension - plug cap removed - to ground)	
Ignition Coil Peak Voltage (primary/ CDI)	140.0-215.0 DC volts - 500 142.4-213.6 DC volts - 650 H1 (terminal to ground)	
MAGNETO		
Magneto Coil Resistance (trigger)	160-240 ohms (green to blue)	
(source)	Less than 1 ohm (yellow to white)	
(charging)	Less than 1 ohm (black to black)	
Magneto Coil Peak Voltage (trigger)	4.2-6.3 volts (green to blue)	
(source)	0.40-0.62 volt (yellow to white)	
Stator Coil Output (no load)	60 AC volts @ 5000 RPM (black to black)	

700 EFI		
Ignition Timing	N/A	
Spark Plug Type	NGK CR6E	
Spark Plug Gap	0.7-0.8 mm (0.028-0.032 in.)	
Spark Plug Cap	8000-12,000 ohms	
Ignition Coil Resistance (primary)	Less than 1 ohm (terminal (+) to terminal (-))	
(secondary)	12k-19k ohms (high tension - plug cap to terminal (+))	
Ignition Coil Peak Voltage (ECU)	80 volts or more (wire (+) to ground)	
MAGNETO		
Stator Coil Resistance (crankshaft position sensor) (charging)	150-250 ohms (blue to white)	
	Less than 1 ohm (yellow to yellow)	
Crankshaft Position Sensor Peak Voltage	5.0 volts or more (blue to white)	
Stator Coil Output (no load)	75 AC volts @ 5000 RPM (yellow to yellow)	

Battery

For battery related information, see Section 2.

RPM Limiter

■ NOTE: The ATV is equipped with a CDI unit that retards ignition timing when maximum RPM is approached. When the RPM limiter is activated, it could be misinterpreted as a high-speed misfire.

Testing Electrical Components

All of the electrical tests should be made using the Fluke Model 73 Multimeter (p/n 0644-191) and when testing peak voltage, the Peak Voltage Reading Adapter (p/n 0644-307) must be used. If any other type of meter is used, readings may vary due to internal circuitry. When troubleshooting a specific component, always verify first that the fuse(s) are good, that the bulb(s) are good, that the connections are clean and tight, that the battery is fully charged, and that all appropriate switches are activated.

■ NOTE: For absolute accuracy, all tests should be made at room temperature of 68° F.

Accessory Receptacle/Connector

■ NOTE: This test procedure is for either the receptacle or the connector.

VOLTAGE

1. Turn the ignition switch to the ON position; then set the meter selector to the DC Voltage position.
2. Connect the red tester lead to the red/white wire or the positive connector; then connect the black tester lead to ground.
3. The meter must show battery voltage.

■ NOTE: If the meter shows no battery voltage, troubleshoot the battery, fuse, receptacle, connector, or the main wiring harness.

Brakelight Switch (Auxiliary)

The switch connector is the two-prong connector on the brake switch lead above the transmission.

■ NOTE: The ignition switch must be in the ON position.

VOLTAGE (Wiring Harness Side)

1. Set the meter selector to the DC Voltage position.
2. Connect the red tester to the orange wire; then connect the black tester lead to ground.



3. The meter must show battery voltage.

■ NOTE: If the meter shows no battery voltage, troubleshoot the battery, fuse, switch, or the main wiring harness.


■ NOTE: If the meter shows battery voltage, the main wiring harness is good; proceed to test the switch/component, the connector, and the switch wiring harness for resistance.

RESISTANCE (Switch Connector)

CAUTION

Always disconnect the battery when performing resistance tests to avoid damaging the multimeter.

1. Set the meter selector to the OHMS position.
2. Connect the red tester lead to one black wire; then connect the black tester lead to the other black wire.



3. When the brake pedal is depressed, the meter must show less than 1 ohm.

■ NOTE: If the meter shows more than 1 ohm of resistance, replace the switch.

Brakelight Switch (Handlebar Control)

To access the connector, remove the access panel.

■ NOTE: The ignition switch must be in the ON position.

VOLTAGE (Wiring Harness Connector)

1. Set the meter selector to the DC Voltage position.
2. Connect the red tester lead to the orange wire; then connect the black tester lead to ground.



AR622D

3. The meter must show battery voltage.

■ **NOTE:** If the meter shows no battery voltage, troubleshoot the battery, fuse, switch, or the main wiring harness.

■ **NOTE:** If the meter shows battery voltage, the main wiring harness is good; proceed to test the switch/component, the connector, and the switch wiring harness for resistance.

RESISTANCE (Switch Connector)

CAUTION

Always disconnect the battery when performing resistance tests to avoid damaging the multimeter.

■ **NOTE:** The brake lever must be compressed for this test. Also, the ignition switch must be in the OFF position.

1. Set the meter selector to the OHMS position.
2. Connect the red tester lead to one black wire; then connect the black tester lead to the other black wire.



AR621D

3. When the lever is compressed, the meter must show less than 1 ohm.


■ **NOTE:** If the meter shows more than 1 ohm of resistance, replace the switch.

Oil Temperature and Cooling Fan Switches (400)

■ **NOTE:** This model has an oil temperature switch and a cooling fan switch.

1. Connect the meter leads (selector in the OHMS position) to the switch contacts.
2. Suspend the switch and a thermometer in a container of oil; then heat the oil.

■ **NOTE:** Neither the switch nor the thermometer should be allowed to touch the bottom of the container or inaccurate readings will occur. Use wire holders to suspend switch and thermometer.




733-554C

3. On the oil temperature switch when the oil temperature reaches 160° C (320° F), the meter should read a closed circuit.
4. On the oil temperature switch, allow the oil to cool, and when the temperature is at (or just before) a temperature of 140° C (284° F), the meter should read an open circuit.
5. On the cooling fan switch when the temperature reaches 120° C (248° F), the meter should read a closed circuit.
6. On the cooling fan switch, allow the oil to cool, and when the temperature is at (or just before) a temperature of 110° C (230° F), the meter should read an open circuit.
7. If the readings are not as indicated, the switch must be replaced.
8. Apply thread tape to the threads of the switch; then install the switch and tighten securely.
9. Connect the switch leads.

Coolant Temperature and Cooling Fan Switches (500/650 H1)

1. Connect the meter leads (selector in the OHMS position) to the switch contacts.
2. Suspend the switch and a thermometer in a container of water; then heat the water.

■ NOTE: Neither the switch nor the thermometer should be allowed to touch the bottom of the container or inaccurate readings will occur. Use wire holders to suspend switch and thermometer.



3. On the coolant temperature switch when the water temperature reaches 112-118° C (234-244° F), the meter should read a closed circuit.
4. On the coolant temperature switch, allow the water to cool, and when the temperature is within a temperature range of 108-111° C (226-232° F), the meter should read an open circuit.
5. On the cooling fan switch when the temperature reaches 66-68° C (150-155° F), the meter should read a closed circuit.
6. On the cooling fan switch, allow the water to cool, and when the temperature is within a temperature range of 62-65° C (145-149° F), the meter should read an open circuit.
7. If the readings are not as indicated, the switch must be replaced.
8. Install the switch and tighten securely.
9. Connect the switch leads.

Cooling Fan Switch and Engine Coolant Temperature (ECT) Sensor (700 EFI)

1. Connect the meter leads (selector in OHMS position) to the switch/sensor terminals.

2. Suspend the switch/sensor and a thermometer in a container of water; then heat the water.

■ NOTE: Neither the switch/sensor nor the thermometer should be allowed to touch the bottom of the container or inaccurate readings will occur. Use wire holders to suspend the switch/sensor and thermometer.

3. On the cooling fan switch when the water temperature reaches approximately 93° C (199° F), the meter should read less than 1.0 ohm.
4. On the cooling fan switch, allow the water to cool and when the temperature reaches approximately 87° C (189° F), the meter should read an open circuit.
5. On the ECT sensor when the temperature reaches 20° C (68° F), the meter should read approximately 2.45k ohms.
6. On the ECT sensor when the temperature reaches 50° C (122° F), the meter should read approximately 800 ohms.
7. On the ECT sensor when the temperature reaches 80° C (176° F), the meter should read approximately 318 ohms.
8. On the ECT sensor when the temperature reaches 110° C (230° F), the meter should read approximately 142 ohms.
9. If the readings are not as indicated, the switch/sensor must be replaced.
10. Install the switch/sensor and tighten securely.
11. Connect the leads.

Fan Motor

The connector is the black two-prong one located behind the fan assembly.

■ NOTE: The ignition switch must be in the ON position.

VOLTAGE (Main Harness Connector to Fan Motor)

1. Set the meter selector to the DC Voltage position.
2. Connect the red tester lead to the black/red wire (500/650 H1/700 EFI) or the black/orange wire (400); then connect the black tester lead to ground.
3. The meter must show battery voltage.

■ NOTE: If the meter shows no battery voltage, troubleshoot the battery, fuse, motor, or the main wiring harness.

■ NOTE: If the meter shows battery voltage, the main wiring harness is good. The connector should be checked for resistance.

RESISTANCE (Fan Motor Connector)

⚠ CAUTION

Always disconnect the battery when performing resistance tests to avoid damaging the multimeter.

1. Set the meter selector to the OHMS position.
2. Connect the red tester lead to the blue wire; then connect the black tester lead to the black wire.



AR645D

3. The meter must show less than 1 ohm.

■ NOTE: If the meter shows more than 1 ohm of resistance, troubleshoot or replace the switch/component, the connector, or the switch wiring harness.

■ NOTE: To determine if the fan motor is good, connect the blue wire from the fan connector to a 12 volt DC power supply; then connect the black wire from the fan connector to ground. The fan should operate.

⚠ CAUTION

Care should be taken to keep clear of the fan blades.

Fuse Block/Power Distribution Module

The fuses are located in a power distribution module under the seat.

If there is any type of electrical system failure, always check the fuses first.

■ NOTE: The ignition switch must be in the LIGHTS position.

1. Remove all fuses from the distribution module.
2. Set the meter selector to the DC Voltage position.
3. Connect the black tester lead to ground.
4. Using the red tester lead, contact each end of the fuse holder connector terminals individually.
5. The meter must show battery voltage from one side of the connector terminal ends.

■ NOTE: Battery voltage will be indicated from only one side of the fuse holder connector terminal; the other side will show no voltage.

■ NOTE: When testing the HI fuse holder, the headlight dimmer switch must be in the HI position; when testing the LIGHTS fuse holder, the headlight dimmer switch can be in either position.

■ NOTE: If the meter shows no battery voltage, troubleshoot the battery, switches, distribution module, or the main wiring harness.


Fuses

CAUTION


Always disconnect the battery when performing resistance tests to avoid damaging the multimeter.

1. Set the meter selector to the OHMS position.
2. Connect the red tester lead to one spade end of the fuse; then connect the black tester lead to the other spade end.
3. The meter must show less than 1 ohm resistance. If the meter reads open, replace the fuse.

■ NOTE: Make sure the fuses are returned to their proper position according to amperage. Refer to the fuse block cover for fuse placement.




CF202A




CD882B

5



CF234A



FI066B

2. The meter reading must be within specification.

Secondary Winding


1. Remove the plug cap from the high tension lead; then connect the red tester lead to the high tension lead.

2. On the 400/650 H1, connect the black tester lead to either primary connector; on the 500/700 EFI, connect the black tester lead to the coil frame or to the primary connector.
3. The meter reading must be within specification.

■ NOTE: If the meter does not show as specified, replace ignition coil.

Spark Plug Cap

1. Connect the red tester lead to one end of the cap; then connect the black tester lead to the other end of the cap.



2. The meter reading must be within specification.

■ NOTE: If the meter does not read as specified, replace the spark plug cap.

PEAK VOLTAGE (400)

■ NOTE: All of the peak voltage tests should be made using the Fluke Model 73 Multimeter (p/n 0644-191) with Peak Voltage Reading Adapter (p/n 0644-307). If any other type of tester is used, readings may vary due to internal circuitry.

■ NOTE: The battery must be at full charge for these tests.

Primary/CDI

■ NOTE: The CDI is located beneath the seat and fender panel near the battery.

1. Set the meter selector to the DC Voltage position; then disconnect the blue/white primary wire from the coil.
2. Connect the red tester lead to the primary wire; then connect the black tester lead to ground.
3. Crank the engine over using the electric starter.
4. The meter reading must be within specification.

PEAK VOLTAGE (500/650 H1/700 EFI)

■ NOTE: All of the peak voltage tests should be made using the Fluke Model 73 Multimeter (p/n 0644-191) with Peak Voltage Reading Adapter (p/n 0644-307). If any other type of tester is used, readings may vary due to internal circuitry.

■ NOTE: The battery must be at full charge for these tests.

Primary/CDI (500/650 H1)/ ECU (700 EFI)

■ NOTE: The CDI/ECU is located beneath the seat near the battery.

1. Set the meter selector to the DC Voltage position; then disconnect the blue/white primary wire from the coil.
2. Connect the red tester lead to the primary wire; then connect the black tester lead to ground.
3. Crank the engine over using the electric starter.
4. The meter reading must be within specification.

EFI Sensors/ Components (700 EFI)

CRANKSHAFT POSITION (CKP) SENSOR

To test the CKP sensor, see Stator Coil/Crankshaft Position (CKP) Sensor (700 EFI) in this section.

AIR PRESSURE SENSOR (APS)



1. Disconnect the APS connector from the pressure sensor located on the right front-side of the air filter housing.
2. Select DC Voltage on the tester and turn the ignition switch to the ON position.
3. Connect the black tester lead to the black/green wire and the red tester lead to the brown wire. The meter should read 4.5-5.5 DC volts. If the meter does not read as specified, check the ECU connector or wiring.

4. Connect the APS to the harness; then using MaxiClips (p/n 0744-041), connect the red tester lead to the brown/white wire and the black tester lead to the black/green wire. With the engine running at idle speed, the meter should read approximately 2.6 DC volts.

■ NOTE: If the meter does not read as specified, check the hose connecting the APS to the intake pipe or replace the sensor.

Electronic Speedometer Speed Sensor

■ NOTE: Prior to testing the speed sensor, inspect the three-wire connector on the sensor harness (400/500 manual models) or on the speed sensor (500 auto/650 H1/700 EFI models) for contamination, broken pins, and/or corrosion.



1. Set the meter selector to the DC Voltage position.
2. With appropriate needle adapters on the meter leads, connect the red tester lead to the voltage lead (V); then connect the black tester lead to the ground lead (G).
3. Turn the ignition switch to the ON position.

4. The meter must show 6 DC volts (500 auto/650 H1/700 EFI) or 12 DC volts (400/500 manual).
5. Leave the black tester lead connected; then connect the red tester lead to the signal lead (S) pin.
6. Slowly move the ATV forward or backward; the meter must show 0 and 6 DC volts alternately (500 auto/650 H1/700 EFI) or 0 and 12 DC volts alternately (400/500 manual).

■ NOTE: If the sensor tests are within specifications, the speedometer must be replaced. See Section 9.


To replace a speed sensor, use the following procedure.

1. Disconnect the three-wire connector from the speed sensor harness or from the speed sensor; then remove the Allen-head cap screw securing the sensor to the sensor housing.
2. Remove the sensor from the sensor housing accounting for an O-ring.



5

3. Install the new speed sensor into the housing with new O-ring lightly coated with multi-purpose grease; then secure the sensor with the Allen-head cap screw (threads coated with blue Loctite #242). Tighten securely.



CD071

Ignition Switch

On the 400/500, the connector is the black three-wire one beneath the steering post cover. On the 650 H1/700 EFI, the connector is a four-wire one. To access the connector, the cover must be removed.

VOLTAGE

■ **NOTE:** Perform this test on the lower side of the connector.

1. Set the meter selector to the DC Voltage position.
2. Connect the red meter lead to the red wire; then connect the black meter lead to ground.
3. Meter must show battery voltage.

■ **NOTE:** If the meter shows no battery voltage, troubleshoot the battery or the main wiring harness.

RESISTANCE

⚠ CAUTION

Always disconnect the battery when performing resistance tests to avoid damaging the multimeter.

■ **NOTE:** Perform this test on the upper side of the connector.

1. Turn the ignition switch to the ON position.
2. Set the meter selector to the OHMS position.
3. Connect the red tester lead to the red wire; then connect the black tester lead to the orange wire (400/500) or to the red/black wire (650 H1/700 EFI).
4. The meter must show less than 1 ohm.
5. Turn the ignition switch to the LIGHTS position.
6. Connect the red tester lead to the red wire; then connect the black tester lead to the orange wire (400/500) or to the red/black wire (650 H1/700 EFI).
7. The meter must show less than 1 ohm.
8. Connect the red tester lead to the red wire; then connect the black tester lead to the gray wire.

9. The meter must show less than 1 ohm.

10. With the switch in the OFF position, connect the red tester lead to the red wire and the black tester lead to each of the remaining wires. The meter must show an open circuit on all wires.

11. On the 650 H1/700 EFI, connect the red tester lead to the red wire and the black tester lead to the brown wire. With the switch in the ON position, the meter must show 980-1020 ohms.

■ **NOTE:** If the meter shows more than 1 ohm of resistance, troubleshoot or replace the switch/component, the connector, or the switch wiring harness.

Handlebar Control Switches

The connector is the yellow one next to the steering post. To access the connector, the steering post cover and the right-side fender splash shield must be removed (see Section 8).

■ **NOTE:** These tests should be made on the top side of the connector.

⚠ CAUTION

Always disconnect the battery when performing resistance tests to avoid damaging the multimeter.

RESISTANCE (HI Beam)

1. Set the meter selector to the OHMS position.
2. Connect the red tester lead to the yellow wire; then connect the black tester lead to the gray wire.
3. With the dimmer switch in the HI position, the meter must show less than 1 ohm.

■ **NOTE:** If the meter shows more than 1 ohm of resistance, troubleshoot or replace the switch/component, the connector, or the switch wiring harness.

RESISTANCE (LO Beam)

1. Connect the red tester lead to the white wire; then connect the black tester lead to the gray wire.
2. With the dimmer switch in the LO position, the meter must show an open circuit.

■ **NOTE:** If the meter reads resistance, troubleshoot or replace the switch/component, the connector, or the switch wiring harness.

DIODE (Starter Button)

■ **NOTE:** If voltage is not as specified, check the condition of the battery in the meter prior to replacing the switch. A low battery will result in a low voltage reading during a diode test.

1. Set the meter selector to the Diode position.
2. Connect the red tester lead to the orange/white wire; then connect the black tester lead to the yellow/green wire.
3. With the starter button depressed, the meter must show 0.5-0.7 DC volts.
4. With the starter button released, the meter must show 0 DC volts.
5. Connect the red tester lead to the yellow/green wire; then connect the black tester lead to the orange/white wire.
6. With the starter button depressed, the meter must show 0 DC volts.

■ **NOTE:** If the meter does not show as specified, replace the switch/component, connector, or switch harness.

RESISTANCE (Emergency Stop)

1. Set the meter selector to the OHMS position.
2. Connect the red tester lead to the orange wire; then connect the black tester lead to the orange/white wire.
3. With the switch in the OFF position, the meter must show an open circuit.
4. With the switch in the RUN position, the meter must show less than 1 ohm.

■ **NOTE:** If the meter shows more than 1 ohm of resistance, troubleshoot or replace the switch/component, the connector, or the switch wiring harness.

RESISTANCE (Reverse Override)

The connector is the four-prong white one next to the steering post. To access the connector, the front rack and front fenders must be removed (see Section 8).

1. Set the meter selector to the OHMS position.

2. Connect the red tester lead to one red/yellow wire; then connect the black tester wire to the other red/yellow wire. The meter must show less than 1 ohm.

3. Depress and hold the reverse override button. The meter must show an open circuit.
4. Connect the red tester lead to the blue wire; then connect the black meter lead to the black wire. The meter must show an open circuit.
5. Depress and hold the reverse override button. The meter must show less than 1 ohm.

■ **NOTE:** If the meter does not show as specified, replace the switch/component, connector, or switch harness.

Front Drive Selector Switch

The connector is the two-wire black snap-lock one in front of the steering post. To access the connector, the cover must be removed.

■ **NOTE:** Resistance tests should be made with the connector disconnected and on the selector-side of the connector.

5

RESISTANCE

⚠ CAUTION

Always disconnect the battery when performing resistance tests to avoid damaging the multimeter.

1. Set the meter selector to the OHMS position.
2. Connect the red tester lead to the red wire; then connect the black tester lead to the white wire.
3. With the selector switch in the 2WD position, the meter must show a closed circuit.
4. With the selector switch in the 4WD position, the meter must show an open circuit.

■ **NOTE:** If the meter does not show as specified, replace the front drive selector switch.

VOLTAGE

■ **NOTE:** The battery must be connected when performing voltage tests.

1. Set the meter selector to the DC Voltage position.

2. Connect the black tester lead to the negative battery terminal.
3. Connect the red tester lead to the red wire on the harness side of the connector.
4. Turn the ignition switch to the RUN position.
5. The meter must show 12 DC volts.

■ **NOTE:** If the meter shows other than specified, check the harness, connector, 30 amp fuse, and battery connections.

Front Drive Selector Actuator

■ **NOTE:** With the engine stopped and the ignition switch in the ON position, a momentary "whirring" sound must be noticeable each time the selector switch is moved to 2WD and 4WD. Test the switch, 30 amp fuse, and wiring connections prior to testing the actuator.

■ **NOTE:** The differential must be in the unlocked position for this procedure.

VOLTAGE

1. Select the 2WD position on the front drive selector switch; then disconnect the connector on the actuator wiring harness.
2. With the ignition switch in the OFF position, connect the black tester lead to the black wire in the supply harness; then connect the red tester lead to the orange wire in the supply harness.
3. Turn the ignition switch to the ON position. The meter must show 12 DC volts.
4. Connect the red tester lead to the white/red wire in the supply harness. The meter must show 12 DC volts.
5. Select the 4WD position on the front drive selector switch; then connect the red tester lead to the white/red wire in the supply harness. The meter must show 0 DC volts.

■ **NOTE:** The 4WD icon on the LCD should illuminate.

6. Connect the red tester lead to the orange wire in the supply harness. The meter must show 12 DC volts.


■ **NOTE:** If the voltage readings are as specified and the actuator does not function correctly, replace the actuator (see Section 6).

Differential Lock Switch

■ **NOTE:** The following procedure does not include the 400 TRV model.

VOLTAGE

1. Select DC Voltage on the multimeter; then connect the red tester lead to the switch terminal (leaving the wire connected) and the black tester lead to ground.



2. Turn the ignition switch to the ON position. The meter must show 12 DC volts.

■ **NOTE:** If no voltage is indicated, check the wiring harness, fuse, or battery connections.

3. Select the lock position on the differential. The meter should drop to 0 volts, and the front drive selector actuator switch should operate to engage 4-wheel drive.

■ **NOTE:** It may be necessary to rock the ATV slightly to engage the differential lock fully.

■ **NOTE:** The 4WD and the LOCK icons on the LCD should illuminate.



CD576



CF094C

4. If the differential lock engages (front wheels locked) and the voltage does not drop to 0, the switch is faulty and must be cleaned or replaced.

Magneto Coils (400/500/650 H1)

VOLTAGE (Stator Coil - Regulated Output)

1. Set the meter selector to the DC Voltage position.
2. Connect the red tester lead to the positive battery post; then connect the black tester lead to the negative battery post.
3. With the engine running at a constant 5000 RPM (with the headlights on), the meter must show 14-15.5 DC volts.

⚠ CAUTION

Do not run the engine at high RPM for more than 10 seconds.

■ NOTE: If voltage is lower than specified, test stator coil - no load.

VOLTAGE (Stator Coil - No Load)

The connector is the black three-pin one on the right side of the engine just above the starter motor.

■ NOTE: Test the connector that comes from the engine.

1. Set the meter selector to the AC Voltage position.
2. Test between the three black wires for a total of three tests.
3. With the engine running at the specified RPM, all wire tests must show 60 AC volts.

⚠ CAUTION

Do not run the engine at high RPM for more than 10 seconds.

■ NOTE: If both stator coil tests failed, check all connections, etc., and test again. If no voltage is present, replace the stator assembly.

RESISTANCE (Charging Coil)

⚠ CAUTION

Always disconnect the battery when performing resistance tests to avoid damaging the multimeter.

1. Set the meter selector to OHMS position.
2. Test between the three black wires for a total of three tests.
3. The meter reading must be within specification.

RESISTANCE (Trigger Coil)

⚠ CAUTION

Always disconnect the battery when performing resistance tests to avoid damaging the multimeter.

1. Disconnect the gray four-pin connector on the right side of the engine just above the starter motor.
2. Set the meter selector to the OHMS position.
3. Connect the red tester lead to the green wire; then connect the black tester lead to the blue wire. The meter reading must be within specification.

RESISTANCE (Source Coil)

1. Set the meter selector to the OHMS position.
2. Connect the red tester lead to the yellow wire; then connect the black tester lead to the white wire.
3. The meter reading must be within specification.

■ NOTE: If the meter shows other than specified in any resistance test, replace the stator assembly.

PEAK VOLTAGE (400)

■ NOTE: All of the peak voltage tests should be made using the Fluke Model 73 Multimeter (p/n 0644-191) with Peak Voltage Reading Adapter (p/n 0644-307). If any other type of tester is used, readings may vary due to internal circuitry.

■ NOTE: The battery must be at full charge for these tests.

Magneto Coil (Trigger)

1. Set the meter selector to the DC Voltage position.
2. Connect the red tester lead to the green wire; then connect the black tester lead to the blue wire.
3. Crank the engine over using the electric starter.
4. The meter reading must be within specification.

Magneto Coil (Source)

1. Set the meter selector to the DC Voltage position.
2. Connect the red tester lead to the yellow wire; then connect the black tester lead to the white wire.
3. Crank the engine over using the electric starter.
4. The meter reading must be within specification.

PEAK VOLTAGE (500/650 H1)

■ NOTE: All of the peak voltage tests should be made using the Fluke Model 73 Multimeter (p/n 0644-191) with Peak Voltage Reading Adapter (p/n 0644-307). If any other type of tester is used, readings may vary due to internal circuitry.

■ NOTE: The battery must be at full charge for these tests.

Magneto Coil (Trigger)

1. Set the meter selector to the DC Voltage position.
2. Connect the red tester lead to the green wire; then connect the black tester lead to the blue wire.
3. Crank the engine over using the electric starter.
4. The meter reading must be within specification.

Magneto Coil (Source)

1. Set the meter selector to the DC Voltage position.
2. Connect the red tester lead to the yellow wire; then connect the black tester lead to the white wire.
3. Crank the engine over using the electric starter.
4. The meter reading must be within specification.

Stator Coil/Crankshaft Position (CKP) Sensor (700 EFI)

VOLTAGE (Regulator/Rectifier - Output)

1. Set the meter selector to the DC Voltage position.
2. Connect the red tester lead to the positive battery post; then connect the black tester lead to the negative battery post.
3. With the engine running at a constant 5000 RPM (with the headlights on), the meter must show 14-15.5 DC volts.

⚠ CAUTION

Do not run the engine at high RPM for more than 10 seconds.


■ NOTE: If voltage is lower than specified, test stator coil - no load.

VOLTAGE (Stator Coil - No Load)

The connector is the black three-pin one on the left side above the shift lever.

■ NOTE: Test the connector that comes from the engine.

1. Set the meter selector to the AC Voltage position.
2. Test between the three yellow wires for a total of three tests.



3. With the engine running at a constant 5000 RPM, all wire tests must be within specifications.

⚠ CAUTION

Do not run the engine at high RPM for more than 10 seconds.


■ NOTE: If both stator coil tests failed, check all connections, etc., and test again. If no voltage is present, replace the stator assembly.

RESISTANCE (Charging Coil)

⚠ CAUTION

Always disconnect the battery when performing resistance tests to avoid damaging the multimeter.

1. Set the meter selector to OHMS position.
2. Test between the three yellow wires for a total of three tests.



FI083B

3. The meter reading must be within specification.

RESISTANCE (Crankshaft Position Sensor)

⚠ CAUTION

Always disconnect the battery when performing resistance tests to avoid damaging the multimeter.

1. Set the meter selector to the OHMS position.
2. Connect the red tester lead to the blue wire; then connect the black tester lead to the white wire. The meter reading must be within specification.

PEAK VOLTAGE

■ NOTE: All of the peak voltage tests should be made using the Fluke Model 73 Multimeter (p/n 0644-191) with Peak Voltage Reading Adapter (p/n 0644-307). If any other type of tester is used, readings may vary due to internal circuitry.

■ NOTE: The battery must be at full charge for these tests.

Crankshaft Position Sensor

1. Set the meter selector to the DC Voltage position.
2. Connect the red tester lead to the blue wire; then connect the black tester lead to the white wire.
3. Crank the engine over using the electric starter.
4. The meter reading must be within specification.

5

Starter Motor

REMOVING/DISASSEMBLING

1. Disconnect the battery.

⚠ CAUTION

Always disconnect the negative battery cable from the battery first; then disconnect the positive cable.

2. Remove the nut securing the positive cable to the starter; then remove the cable from the starter.
3. Remove the two cap screws securing the starter to the crankcase; then remove the starter. Account for the wiring forms and an O-ring.

4. For assembly purposes, scribe a line across the outside of the starter assembly.



AR652D

5. Remove the two long starter cap screws securing the starter components.


6. Remove the front cover from the starter housing and armature shaft. Account for a seal protector and three washers.



BC003


7. Remove the rear cover.

8. Slide the armature free of the starter housing.



BC006

9. Bend the two positive brushes outward; then remove the brush holder.




BC007



BC010

10. Remove the nut from the positive post. Account for the lock washer, flat washer, a fiber washer, and an O-ring.



BC008

11. Remove the positive brush assembly from the starter housing.



BC009

CLEANING AND INSPECTING

■ **NOTE:** Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Thoroughly clean all components except the armature and brushes in parts-cleaning solvent; then dry with compressed air.

⚠ CAUTION


Do not wash the armature and brushes in any kind of solvent. Use only compressed air and a clean dry, lint-free cloth.

2. Inspect all threaded areas for damage or stripped threads.
3. Inspect the brush holder assembly and brushes for damage or wear. Using a caliper, measure the length of the brushes. If brush measurement is less than 10.1 mm (0.40 in.), replace with new brushes and brush springs as a set.
4. Inspect the brush leads for cracks, wear, or fraying. If any of these conditions exist, replace with new brushes and brush springs as a set.
5. Inspect the rear cover bushing for wear.
6. Inspect the front cover bearing for wear.
7. Inspect the brass commutator end of the armature for any discolored spots or damage. If the commutator is lightly discolored or damaged, the armature must be replaced. This is a molded commutator and turning it down in a lathe should not be attempted.

⚠ CAUTION

Do not use emery cloth to clean the commutator as emery particles will become imbedded in the brass commutator resulting in a short circuit. Use only #200 grit sandpaper.

8. Inspect the commutator end of the armature for buildup in the grooves. Carefully remove any buildup by undercutting using a thinly ground hacksaw blade. Do not undercut any deeper than the original groove which can be seen by looking at the end of the commutator.
9. Using a caliper, measure the undercut. Maximum undercut groove must be 0.2 mm (0.008 in.).




ATV-1054

⚠ CAUTION

Buildup in the grooves must be removed to prevent any chance of an electrical arc between individual sections of the commutator.

10. Inspect the commutator for shorting using a multimeter and the following procedure.
 - A. Set the selector to the OHMS position.
 - B. Touch the black lead to the armature shaft.
 - C. Using the red tester lead, probe the commutator end of the armature. The meter indicator should not change. If the indicator shows resistance, the armature is shorted and must be replaced.
11. Inspect the armature for shorting using a "growler" and the following procedure.
 - A. Place the armature in the "growler."
 - B. While holding a metal strip on the armature, rotate the armature an entire revolution. If the metal strip vibrates at any point on the armature, the armature is shorted and must be replaced.

5



0725-653

12. Inspect the ground brushes to make sure they are properly grounded. Use a multimeter and the following procedure.
 - A. Set the selector to the OHMS position.

- B. Touch the black tester lead to a ground brush.
- C. Touch the red tester lead to the brush holder assembly.

■ NOTE: If no resistance is indicated, check the ground connection for tightness and for cleanliness. If there is still no meter indication, replace the brush assembly.


ASSEMBLING/INSTALLING

1. Install the positive post on the positive brush assembly; then install on the starter housing.



BC009

2. On the positive post, install an O-ring washer, a fiber washer, a flat washer, and a lock washer. Secure with the nut.




BC008

3. Align the tab on the brush holder with the notch in the starter housing; then install.




BC010

4. Install the armature into the starter housing; then while holding the brushes out, slide the commutator into the brush holder.




BC006

5. Apply a small amount of grease to the rear cover bushing; then install the cover on the starter housing making sure the reference marks align.




BC013

6. In order, install the thick metal washer, thin metal washer, and the fiber washer on the armature shaft; then install the housing O-ring on the starter housing.




BC014

7. Apply a small amount of grease to the front cover bearing and seal; then install the seal protector.




BC015



BC004

8. Place the front cover onto the starter housing making sure it seats properly.
9. Apply red Loctite #271 to the threads of the two long cap screws and install. Tighten to 0.8-1.2 kg-m (6-9 ft-lb).



AR653D

10. Apply a small amount of grease to the O-ring seal on the starter; then install the starter into the crankcase. Secure with two cap screws and wiring forms.

11. Secure the positive cable to the starter with the nut.
12. Connect the battery.

TESTING VOLTAGE

Perform this test on the starter motor positive terminal. To access the terminal, slide the boot away.

5

■ **NOTE: The ignition switch must be in the ON position, the emergency stop switch in the RUN position, the reverse lever (on manual transmission models) in the FORWARD position, and the shift lever (on automatic transmission models) in the NEUTRAL position.**


1. Set the meter selector to the DC Voltage position.
2. Connect the red tester lead to the starter terminal; then connect the black tester lead to ground.
3. With the starter button depressed, the meter must show battery voltage and the starter motor should operate.



AR607D

■ NOTE: If the meter showed battery voltage but the starter did not operate or operated slowly, inspect battery voltage (at the battery), starter motor condition, and/or ground connections.


■ NOTE: If the meter showed no battery voltage, inspect the main fuse, ground connections, starter motor lead, battery voltage (at the battery), starter relay, or the neutral start relay.



KX059A

Starter Relay

1. Remove the seat; then using the multimeter set to the DC Voltage position, check the relay as follows.
2. Connect the red tester lead to the positive battery terminal; then connect the black tester lead to the starter cable connection on the starter relay. The meter must show battery voltage.



KX206A

■ NOTE: Make sure that the ignition switch is in the ON position, transmission in neutral, brake lock released, and the emergency stop switch in the RUN position.

3. Depress the starter button while observing the multimeter. The multimeter should drop to 0 volts and a "click" should be heard from the relay.

■ NOTE: If a "click" is heard and any voltage is indicated by the multimeter, replace the starter relay. If no "click" is heard and the multimeter continues to indicate battery voltage, proceed to step 4.

4. Disconnect the two-wire plug from the starter relay; then connect the red tester lead to the green wire and the black tester lead to the black wire.

5. Depress the starter button and observe the multimeter.

■ NOTE: If battery voltage is indicated, replace the starter relay. If no voltage is indicated, proceed to Neutral Start Relay check.

CDI Unit (400/TBX/500/650 H1)

The CDI is located beneath the seat near the battery.

■ NOTE: The CDI unit is not a serviceable component. If the unit is defective, it must be replaced.

The CDI is rarely the cause for electrical problems; however, if the CDI is suspected, substitute another CDI unit to verify the suspected one is defective.

■ NOTE: Prior to replacing the CDI unit to assure the CDI unit is defective, it is advisable to perform a CDI peak voltage test (see Ignition Coils in this section) and/or perform a continuity test of the wiring harness from the CDI connector to the CDI unit.

Electronic Control Unit (ECU) (700 EFI)

The electronic control unit (ECU) is located beneath the seat near the battery.

■ NOTE: The ECU is not a serviceable component. If the unit is defective, it must be replaced.

The ECU is rarely the cause for electrical problems; however, if the ECU is suspected, substitute another ECU to verify the suspected one is defective.

Error codes can be cleared by following the procedures located in the ECU Error Codes (700 EFI) sub-section in this section.

Regulator/Rectifier

The regulator/rectifier is located under the rear rack and rear fenders.

TESTING

1. Start engine and warm up to normal operating temperatures; then connect a multimeter to the battery as follows.
2. Select the DC Voltage position; then connect the red tester lead to the positive battery post and the black tester lead to the negative battery post.
3. Start the engine and slowly increase RPM. The voltage should increase with the engine RPM to a maximum of 15.5 DC volts.

■ NOTE: If voltage rises above 15.5 DC volts, the regulator is faulty or a battery connection is loose or corroded. Clean and tighten battery connections or replace the regulator/rectifier. If voltage does not rise, check Voltage (Charging Coil - No Load) in this section. If charging coil voltage is normal, replace the regulator/rectifier.

Neutral Start/Front Drive Actuator/Start-in-Gear/ Differential Lock/2WD Relays

The relays are identical plug-in type located on the power distribution module. Relay function can be checked by switching relay positions. The relays are interchangeable.

■ NOTE: The module and wiring harness are not a serviceable component and must be replaced as an assembly.

Headlights

The connectors are the four 2-prong ones secured to the front bumper supports (two on each side) with cable ties.

BULB VERIFICATION (Low and High Beam)

■ NOTE: Perform this test on each headlight bulb. Also, a 12-volt external power supply w/jumpers will be needed.

1. Disconnect the wiring harness from the bulb to be tested.
2. Connect the power supply (positive) to one bulb contact; then connect the power supply (negative) to the remaining bulb contact.
3. The bulb should illuminate.
4. If the bulb fails to illuminate, it must be replaced.

VOLTAGE

■ NOTE: Perform this test in turn on the main harness side of all four connectors. Also, the ignition switch must be in the LIGHTS position.

■ NOTE: The LO beam is the outside bulb, and the HI beam is the inside bulb.

1. Set the meter selector to the DC Voltage position.
2. Connect the red tester lead to one wire; then connect the black tester lead to the other wire.
3. With the dimmer switch in the LO position, test the two outside connectors (LO beam). The meter must show battery voltage.
4. With the dimmer switch in the HI position, test the two inside connectors (HI beam). The meter must show battery voltage.

■ NOTE: If battery voltage is not shown in any test, inspect the fuses, battery, main wiring harness, connectors, or the left handlebar switch.

Taillight - Brakelight

The connector is the 3-prong one located under the rear fender assembly.

BULB VERIFICATION

■ NOTE: Perform this test on the taillight-brake-light side of the connector. Also, a 12-volt external power supply (jumper) will be needed.

1. Connect the power supply (positive) to the middle terminal; then connect the power supply (negative) to the bottom terminal.
2. The taillight should illuminate.
3. With the negative power supply still connected, connect the positive supply wire to the top terminal.
4. The brakelight should illuminate.

■ NOTE: If either the taillight or brakelight fails to illuminate, inspect the bulb, the connectors, or the component wiring harness.

VOLTAGE (Taillight)

■ NOTE: Perform this test on the main harness side of the connector. Also, the ignition switch should be in the LIGHTS position.

1. Set the meter selector to the DC Voltage position.
2. Connect the red tester lead to the white wire; then connect the black tester lead to the black wire.
3. With the ignition key in the LIGHTS position, the meter must show battery voltage.

■ NOTE: If the meter shows no voltage, inspect fuses, wiring harness, connectors, and switches.

VOLTAGE (Brakelight)

■ NOTE: Perform this test on the main harness side of the connector. Also, the ignition switch should be in the ON position and the brake (either foot pedal or hand lever) must be applied.

■ NOTE: Make sure the brake lever (hand) and brake pedal (auxiliary) are properly adjusted for this procedure.

1. Set the meter selector to the DC Voltage position.
2. Connect the red tester lead to the red/blue wire; then connect the black tester lead to the black wire.
3. With either brake applied, the meter must show battery voltage.

■ NOTE: If the meter shows no voltage, inspect bulb, fuses, wiring harness, connectors, and switches.

Ignition Timing

The ignition timing cannot be adjusted; however, verifying ignition timing can aid in troubleshooting other components. To verify engine timing, see Section 2.

ECU Error Codes (700 EFI)

If a sensor fails or an out-of-tolerance signal is sensed by the ECU, an error code will be generated by the ECU. This will result in the analog needle swinging full scale (LE model) or the LCD gauge going blank (standard model). The EFI icon will flash.


To read the error code, use the following procedure.

1. Make sure the ignition switch is in the OFF position; then remove the seat.

CAUTION

Always make sure the ignition switch is in the OFF position before disconnecting the ECU.

2. Locate the diagnostic plug in front of the ECU; then remove the black rubber cap.
3. Connect the Diagnostic Harness (p/n 0486-219) to the diagnostic plug.



ATV-112

4. Turn the ignition switch to the ON position and read the error code on the LCD. Refer to the following ECU Error Code List to identify the specific problem area.

ECU Error Code List

- EC00 = No Fault Detected
- EC12 = CKP (Crankshaft Position) Sensor
- EC13 = APS (Air Pressure Sensor)
- EC14 = TPS (Throttle Position Sensor)
- EC15 = Water Temperature Sensor
- EC20 = Differential Lock Relay
- EC21 = Air Temperature Sensor
- EC23 = Tilt Sensor
- EC24 = Ignition Coil #1
- EC32 = Fuel Injector #1
- EC40 = ISC Valve
- EC41 = Fuel Pump Relay
- EC99 = Start Not Possible

■ NOTE: EC99 indicates that the engine will not start and that the spark plug and fuel pump are disabled. EC99 will be displayed following EC23 (Tilt Sensor), EC24 (Ignition Coil), etc.

To clear an error code after repairs or adjustments are made, install the Diagnostic Harness (p/n 0486-219) by connecting it to the diagnostic plug; then turn the ignition switch to the ON position. After three seconds, turn the ignition switch to the OFF position and disconnect the diagnostic harness. When the ignition switch is turned on, the error code should not be displayed.

Tilt Sensor (700 EFI)

⚠ WARNING


Incorrect installation of the tilt sensor could cause sudden loss of engine power which could result in loss of vehicle control resulting in injury or death.

⚠ CAUTION

Do not drop the tilt sensor as shock can damage the internal mechanism.


SUPPLY VOLTAGE

1. Disconnect the three-wire connector from the sensor; then select DC Voltage on the multimeter and connect the red tester lead to the orange wire (C) and the black tester lead to the black wire (A).



CD706A

2. Turn the ignition switch to the ON position. The multimeter should read battery voltage. If battery voltage is not indicated, check the 30-amp fuse, wiring harness, or the ignition switch.
3. Remove the red tester lead and connect to the blue/brown wire (B). The multimeter should read 0 DC volts. If the specified voltage is not indicated, check wire connections at the CDI or substitute another CDI to verify the test.




CD706B

5


OUTPUT VOLTAGE

■ NOTE: Needle adapters will be required on the multimeter leads as the following tests are made with the sensor connected.

1. Connect the three-wire plug to the sensor; then remove the right-side mounting screw securing the sensor to the rear frame.




CD707A



CD705A

2. Install the needle adapters to the multimeter leads; then select DC Voltage on the multimeter.
3. Connect the red tester lead to the blue/brown wire (B) and the black tester lead to the black/yellow wire (A); then turn the ignition switch ON and observe the meter. The meter should read 0.8-3.0 DC volts.



CD705B

4. Tilt the sensor 60° or more to the left and right observing the meter. The meter should read 4.0-8.0 DC volts after approximately one second in the tilted position. If the meter readings are not as specified, the tilt sensor is defective.



CD709

■ NOTE: When replacing the sensor after testing, make sure the arrow marking is directed up.

Throttle Position Sensor (TPS) (700 EFI)

INSPECTING


1. Remove the left-side engine cover; then disconnect the three-wire TPS connector plug.



FI450A

■ NOTE: Prior to testing the TPS, inspect the three-wire plug connector on the main harness and the three-pin plug on the TPS for contamination, broken pins, and/or corrosion.

2. Make sure the ignition switch is in the OFF position; then select the DC Voltage position on the meter.
3. Connect the black tester lead to spade terminal C and the red tester lead to spade terminal A. Turn the ignition switch to the ON position. The meter should read 4.5-5.5 DC volts.



FI456A



FI455A

4. Remove the red tester lead from spade terminal A and connect it to spade terminal B. The meter should read 4.5-5.5 DC volts.

■ **NOTE:** If the meter does not read as specified, check for poor connections at the ECU or open/broken wires in the wiring harness.

⚠ CAUTION

Always make sure the ignition switch is in the OFF position before disconnecting the ECU.

5. Turn the ignition switch to the OFF position; then disconnect the battery (negative cable first).

⚠ CAUTION

Always disconnect the battery when performing resistance tests to avoid damaging the multimeter.

6. Select the OHMS position on the meter; then perform the following resistance tests on the TPS.

- A. Pin (B) to ground - infinity (open circuit).
- B. Pin (A) to pin (B) - approximately 1.22k ohms (throttle closed).
- C. Pin (A) to pin (B) - approximately 4.36k ohms (throttle full-open).
- D. Pin (A) to pin (C) - approximately 4.05k ohms.

5



FI451A

9. Select the DC Voltage position on the meter and turn the ignition switch to the ON position. The meter should read approximately 1.12 DC volts with the throttle closed and approximately 4.32 DC volts with the throttle in the full-open position.

■ **NOTE:** If the meter readings are as specified, check the main harness connector at the ECU main harness wiring. If the meter readings are not as specified, replace the TPS and adjust to specifications (see INSTALLING/ADJUSTING in this sub-section).

⚠ CAUTION

Always make sure the ignition switch is in the OFF position before disconnecting the ECU.

10. Clear all ECU error codes after servicing is complete (see ECU Error Codes (700 EFI) in this section).

REMOVING


1. Remove the left-side engine cover; then disconnect the three-wire TPS connector plug.






2. Remove the two screws securing the TPS to the throttle body and remove the TPS.

INSTALLING/ADJUSTING

1. Place the TPS into position on the throttle body and secure with the two screws. Do not tighten at this time.
2. Connect the main harness to the TPS.
3. Locate the diagnostic connector under the seat; then install the test plug from Test Plug/Error Code List Kit (p/n 0444-216) onto the connector.



4. Turn the ignition switch to the ON position and note the position of the TPS indicator icon (A, B, or C); then adjust the TPS until the TPS icon appears in the center position (B).



5. Tighten the mounting screws securely; then verify the TPS icon appears in the center position.
6. Remove the test plug; then install the left-side engine cover.

SECTION 6 - DRIVE SYSTEM

6

TABLE OF CONTENTS

Drive System	6-2
General Information.....	6-2
Front Drive Actuator	6-3
Front Differential	6-4
Drive Axles	6-18
Rear Gear Case	6-22
Hub.....	6-24
Hydraulic Brake Caliper.....	6-24

Drive System

■ **NOTE:** Some photographs and illustrations used in this section are used for clarity purposes only and are not designed to depict actual conditions.

■ **NOTE:** Critical torque specifications are located in Section 10.

General Information

All gear cases are tagged beneath a cover bolt. This tag is marked with a production date code, sequence code, and a ratio code.

- A. A "6" or "3.6" on the lower-right corner indicates a 3.6:1 gear set ratio (10:36 teeth).
- B. A "1" or "3.1" on the lower-right corner indicates a 3.1:1 gear set ratio (11:34 teeth).
- C. A "4.0" on the lower-right corner indicates a 4.0:1 gear set ratio (9:36 teeth).

The die-cast aluminum housings have been assembled with thread-rolling screws (trilobular). When assembling with these screws, start the screws carefully into the housing; then use the following torque values.

Size	New Housing	Reassembled Housing
M6 (Torx T-30 Recess)	1.1-1.3 kg-m (8-9.5 ft-lb)	0.9-1.2 kg-m (6.5-9 ft-lb)
M8 (Torx T-40 Recess)	3.5-4.3 kg-m (25-31 ft-lb)	2.9-3.5 kg-m (21-25 ft-lb)
M10 (Torx T-50 Recess)	5.1-6.3 kg-m (37-45.5 ft-lb)	4.3-5.3 kg-m (31-38 ft-lb)

SPECIFICATIONS

Specific specifications regarding the gear cases (capacities, lubricant type, etc.) can be found in Section 1 of this manual.

Ring Gear Backlash	0.28-0.38 mm (0.011-0.015 in.)
Ring Gear End Play	0.1-0.2 mm (0.004-0.008 in.)

SPECIAL TOOLS

A number of special tools must be available to the technician when servicing the gear case.

Description	p/n
CV Boot Clamp Tool	0444-120
Pinion Gear/Shaft Removal Tool	0444-127
Slide Hammer Kit	0444-225
Internal Hex Socket (48 mm)	0444-104

■ **NOTE:** Special tools are available from the Arctic Cat Service Parts Department.

TROUBLESHOOTING

If a noise is heard from the gear case area, it can be difficult to locate and/or diagnose. If the noise is related to wheel speed, but not to engine RPM, the problem is probably in the final drive or engine/transmission bevel gear set. When a problem is localized, a number of inspections must be made to pinpoint that problem. The most obvious of the inspections include CV boots, wheel and hub nut tightness, wheel bearing damage, gear case lubricant contamination, low lubricant level, seal leakage, CV joints, or selector arm.

■ **NOTE:** Small metallic particles will collect on the magnetic drain plug as a normal part of break-in and will also give a metallic cast to drained lubricant. Contamination would include large particles or water which gives a "milky" look to the lubricant.

■ **NOTE:** Lubricant on a new pinion housing assembly could be grease. If the front of the gear case is leaking at the rear drive boot, wipe excess lubricant from the bottom of the pinion housing; then operate the ATV for a period of time. Inspect the pinion housing area for any signs of leakage. If lubricant is again on the bottom of the pinion housing, the seal must be replaced.

Additional troubleshooting could include the following.

- Binding/abrupt motion: CV boot torn (grease loss, foreign object damage, broken cage); gear lubricant loss or not filled (bearing seizure, broken gear teeth, seal leakage, bladder or hose leakage, missing filler/drain plug).
- Noise from drive system: wheel or gear case bearing damage, improper gear backlash, improper assembly, low or no gear case lubricant.
- Lockup: gear case lubricant loss or not filled, water contamination causing bearing seizure.

Front Drive Actuator

■ **NOTE:** The actuator is not a serviceable component. If it is defective, it must be replaced.

■ **NOTE:** The actuator will operate only when the ignition switch is in the ON position.

The front drive actuator is located on the left side of the front drive input housing. With the engine stopped and the ignition switch in the ON position, a momentary “whirring” sound can be heard each time the front drive selector switch is shifted. If no sound is heard, see Section 5. If the actuator runs constantly or makes squealing or grinding sounds, the actuator must be replaced.


REMOVING

1. Remove the left-front inner fender panel; then disconnect the connector on the actuator harness.
2. Using a T-30 torx wrench, remove the mounting cap screw from the driveshaft side of the actuator.




AG926

3. Remove the mounting cap screw from below the actuator on the suspension side.



AG927

4. Loosen but do not remove the mounting cap screw at the front of the actuator; then slide the actuator to the rear enough to clear the slotted mounting tab and the selector shaft.



AG928


INSTALLING

1. Lubricate the O-ring on the actuator; then ensure that all mounting surfaces are clean and free of debris.
2. Align the actuator with the selector shaft and slide it forward onto the shaft taking care to engage the cap screw in the slot of the front mounting tab.



AG925

3. While holding the actuator firmly forward, tighten the front cap screw to hold the actuator in place; then install but do not tighten the two remaining cap screws.



AG928

4. Loosen the front cap screw; then tighten the cap screw on the driveshaft side.



AG926

■ NOTE: It is important to tighten this cap screw while the others are loose to ensure proper seating of the actuator.

5. Tighten the remaining cap screws; then connect the electrical plug to the main harness.
6. Turn the ignition switch to the ON position and check the operation by shifting the selector switch several times.
7. Secure the wiring harness to the frame with a nylon cable tie; then install the inner fender panel.

Front Differential

■ NOTE: To remove the rear gear case, see Rear Gear Case in this section.


REMOVING DIFFERENTIAL

1. Secure the ATV on a support stand to elevate the wheels.

WARNING


Make sure the ATV is solidly supported on the support stand to avoid injury.

2. Remove the drain plug and drain the gear lubricant into a drain pan; then reinstall the plug.



ATV0082A

3. Remove the front wheels.
4. Pump up the hand brake; then engage the brake lever lock.
5. Remove the cotter pin securing the hex nut; then remove the hex nut and washer.



KX041

6. Release the brake lever lock.

■ NOTE: It is not necessary to remove the brake hoses from the calipers for this procedure.

7. Remove the two brake calipers. Account for the four cap screws and four 0.76 mm (0.030 in.) spacer washers.



AF894D

8. Remove the tie rod cotter pins and discard the pins.



AF895D

9. Remove the tie rod lock nuts.



AF896D

10. Remove the upper ball joint cap screws taking care not to strip the threads on the ball joint shaft; then using a rubber mallet, tap the end of the axle and free it from the knuckle assembly.



AF628D

11. Pull the steering knuckle away from the axle taking care not to damage the seals with the axle end.



KX151

12. Support the axle to not allow it to drop or hang.

6

CAUTION


The axle must be supported. If the axle is allowed to drop or hang, damage to the inner CV joint may occur.

13. Remove the lower shock bolts. Account for the lock nuts; then move the shocks aside and secure them with a strap.



AF897D

14. Remove the upper A-arm lock nuts and cap screws; then remove the A-arms.



AF610D


15. Using a slide hammer, remove the front axles.



AF899D


16. Remove the inner fender panels.

17. Using a T-30 torx wrench, remove the three screws securing the front drive actuator to the gear case; then remove the actuator.



AG925

18. Remove the lower differential mounting cap screw. Account for a lock nut and washers.



CD026

19. Remove the upper differential mounting cap screws.



CD016

20. Free the differential assembly from the frame mountings; then shift the differential assembly forward enough to disengage the front drive-shaft from the output yoke.



KX161

21. Place the differential on its right side; then remove it from the frame.



KX159

Disassembling Input Shaft


■ NOTE: This procedure can be performed on a rear gear case; however, some components may vary from model to model. The technician should use discretion and sound judgment.

1. Using a T-40 torx wrench, remove the cap screws securing the pinion housing.



CD102

2. Using a rubber mallet, remove the housing. Account for a gasket. Remove the fork, collar, and spring. Note the location of all the components for assembling purposes.



CD103



CD106

3. Using a side-cutter (or suitable substitute), remove the boot clamps; then remove the boots and splined drive from the input shaft.



CD114

4. Remove the input shaft from the pinion housing.



CD107

5. Using a seal removal tool, remove the input shaft seal. Account for a spacer.

6

Assembling Input Shaft




AF982

6. Remove the snap ring securing the input shaft bearing; then place the pinion housing in a press and remove the bearing.




AF983



AF984



KX219



AF993



AF994

2. Install the input shaft seal making sure it is flush with the edge of the housing.
3. Lubricate the input shaft splines with High-Performance Grease (p/n 0436-905).

■ NOTE: Any time drive splines are separated, clean all splines with parts-cleaning solvent and dry with compressed air; then lubricate with recommended grease.



KX221



KX222

4. On the 400/500/650 H1, install the input shaft into the housing; then install the front boot and secure with Boot Clamp (p/n 0423-393) and the rear boot with Boot Clamp (p/n 0423-411).




CD112



CD099

5. Place the pinion housing with new gasket onto the gear case housing; then secure with the existing cap screws. Tighten to specifications.

■ NOTE: If a new gear case housing is being installed, tighten the cap screws to 3.5-4.3 kg-m (25-31 ft-lb).



CD103

Disassembling Pinion Gear

■ NOTE: This procedure can be performed on a rear gear case.

1. Using a T-40 torx wrench, remove the cap screws securing the pinion housing. Account for the coupler, fork, and spring.



6

KX209

2. Using a T-40 torx wrench, remove the cap screws securing the gear case cover. Account for and make note of the ID tag location for assembling purposes.



KX173

3. Using a plastic mallet, tap lightly to remove the differential cover. Account for an O-ring.



KX174

■ **NOTE: If the cover is difficult to remove, pry on the cover in more than one recessed location.**

4. Remove the splined coupler, shifter fork, pin, and spring of the differential lock assembly and set aside. Note position of parts for assembling purposes.



KX175

5. Make match marks on the left bearing housing and differential housing; then remove the plate and account for a shim. Mark the shim as left-side.



KX176



KX177



KX178

6. Place the differential with the open side down; then lift the housing off the spider assembly. Account for shim(s) and mark as right-side.




KX179




KX181

7. Using the 48 mm Internal Hex Socket (p/n 0444-104), remove the lock collar securing the pinion gear assembly.

■ NOTE: On a front differential, the lock collar has right-hand threads. On a rear gear case, the lock collar has left-hand threads.




CC875




CC876

8. Using the Pinion Gear/Shaft Removal Tool (p/n 0444-127) and a hammer, remove the pinion gear from the gear case housing.



CC878

9. Secure the pinion gear in a bearing puller; then remove the pinion bearing using a press. Account for a collar and a bearing.



CC879


■ NOTE: If gears are being replaced, use the existing shims. The numbers are scribed onto the gears: the ring gear has the number on the opposite side of the gears, and the pinion gear has the number on the end of the pinion gear shaft by the splines. If no number is present, it should be considered as being in the 0 category.

■ NOTE: If the gear case housing is being replaced, proceed to the following Shimming Procedure/Shim Selection sub-section.

Shimming Procedure/Shim Selection


1. Press bearings into bores by outer ring to hard contact with seat.
2. Install the lock collar and tighten to specifications; then on final assembling, stake the lock collar edge approximately 1.5 mm (0.060 in.) into the lower oil channel.

6



CC891

3. Note the following shim selections (shims are nominally 1.5 mm/0.060 in. thick):



738-268B

A. Cover Side - add value A on the gear case housing to value B (all models except 400 TRV) or value C (400 TRV) on the gear case cover; then add 1.5 mm (0.060 in.). This will give you the proper shim thickness.

■ NOTE: When shimming a rear gear case, add value A to value B on all models.


B. Gear Case Side - install a 1.3-1.4 mm (0.050-0.055 in.) shim and tighten the bolts to 3.5-4.3 kg-m (25-31 ft-lb). Verify backlash to be within a range of 0.28-0.38 mm (0.011-0.015 in.) and end-play to be within a range of 0.10-0.20 mm (0.004-0.008 in.). If not within specification range, reselect shim until backlash specification range can be verified.

4. Prior to final assembling, apply molybdenum disulfide grease to all oil seal lips.


5. Prior to final assembling, prelubricate journal on pinion assembly with SAE 80W-90 hypoid gear lubricant prior to pressing assembly into gear case housing.

Assembling Pinion Gear

1. Install the bearing onto the pinion shaft. Install the pinion shaft collar.




CC882



CC883


2. Place the pinion assembly in a bearing puller; then install the bearing using a press.



CC884


3. Install the pinion gear assembly into the housing. Using the 48 mm Internal Hex Socket (p/n 0444-104), secure the pinion gear assembly with the existing lock collar. Tighten to specifications.

■ NOTE: On a front differential, the lock collar has right-hand threads. On a rear gear case, the lock collar has left-hand threads.




CC890

4. Place a punch on the edge of the lock collar in the oil gallery area; then using a hammer, stake the lock collar to ensure that the collar will remain securely tightened.




CC891

5. Install the shift fork shaft w/spring into the gear housing making sure the shaft O-ring is positioned to the inside.



CC892


6. Install the shift fork assembly making sure the fork leg is facing upward. Apply a small amount of oil to the gasket; then install the gasket.



CC893

7. Place the input shaft assembly onto the gear housing; then secure with the existing cap screws. Tighten to specifications.

■ NOTE: If a new gear housing is being installed, tighten the cap screws to 3.5-4.3 kg-m (25-31 ft-lb).



CD103




CD110


8. Install the proper shim onto the ring gear spider assembly making sure the chamfer side of the shim is facing toward the ring gear. Install the ring gear in the housing; then install the outside shim with the chamfer side of the shim toward the ring gear.

■ NOTE: The spider and ring gear assembly must be replaced as a complete unit.

6



CC896



CC897



KX174



KX178

9. Install the left bearing housing aligning the match mark to the mark on the differential housing.



KX177

10. Install the differential lock assembly into the bearing housing; then place the O-ring on the gear case housing.



KX175

11. Making sure the O-ring is properly positioned on the gear case housing, install the housing with existing hardware. Account for the ID tag. Tighten the cap screws to specifications.

■ **NOTE:** Grease can be applied to the O-ring for ease of assembling.


■ **NOTE:** If a new gear case housing is being installed, tighten the cap screws to 3.5-4.3 kg-m (25-31 ft-lb).

Removing Needle Bearing

■ **NOTE:** Removing the needle bearing is rarely necessary. Avoid removing the needle bearing unless the bearing is clearly damaged.


■ **NOTE:** This procedure can be performed on a rear gear case.

1. Place a 6.35 mm (1/4 in.) drill bit on the inside surface of the needle bearing (against the bottom side); then drill through the pinion shaft needle bearing housing.



CC885

2. Using a propane torch, heat the area surrounding the needle bearing to soften the Loctite.



CC886


3. Using a flat-nosed punch, drive the bearing out of the housing.



CC887

Installing Needle Bearing

1. Apply red Loctite #271 to the outside of a new bearing; then place the new bearing into the housing.



CC888


2. Using a suitable driver, install the needle bearing into the gear case housing making sure the bearing is seated.

■ NOTE: Do not push the bearing too far into the housing.



CC889


3. Install the pinion shaft and secure with the existing 48 mm lock collar. Tighten to specifications.



CC890

4. Place a punch on the edge of the lock collar in the oil gallery area; then using a hammer, stake the lock collar to ensure that the collar will remain securely tightened.

6



CC891

5. Install the pinion housing.

Removing/Installing Axle Seal

■ NOTE: This procedure can be performed on a rear gear case.

1. Remove the seal using a seal removal tool.




CC899

2. Using a press, remove the bearing.



CC900


3. Using a press, install the new bearing into the housing.



CC901

■ NOTE: Prior to installing the seal, apply grease to the seal outside diameter.

4. Install the seal into the housing pressing evenly on the outside edge until the seal is seated.



CD018

5. Repeat steps 1-4 for the opposite side.

INSTALLING DIFFERENTIAL

1. Align the splined input yoke with the front output splines; then place the differential into position on the frame and install the cap screws, washers, and flex-lock nuts. Tighten to specifications. Make sure the rubber boot is properly seated on the input yoke.




CD857



CD859

2. Pour 275 ml (9.3 fl oz) of SAE 80W-90 hypoid lubricant into the differential and install the filler plug. Tighten to specifications.

3. Install the front drive actuator with the three torx-head cap screws; then connect the wire connector to the main wiring harness.



AG925

4. Install the inner fender panels.
5. Install the front axles (see Drive Axles in this section).
6. Secure the upper A-arms with cap screws and lock nuts. Tighten to specifications.



AF610D

7. Secure the lower shock eyelets with cap screws and lock nuts. Tighten to specifications.



AF897D

8. Secure the tie rods with the lock nuts. Tighten to specifications; then install and spread the cotter pins.




AF896D



AF895D

9. Making sure that each caliper has the 0.76 mm (0.030 in.) spacer washers between the caliper and the knuckle, install the brake calipers. Secure with the cap screws tightened to specifications.



AF894D

10. Install the wheels and tighten to specifications.
11. Remove the ATV from the support stand.

6

Drive Axles


REMOVING REAR DRIVE AXLE

1. Secure the ATV on a support stand to elevate the wheels.

⚠ WARNING

Make sure the ATV is solidly supported on the support stand to avoid injury.

2. Pump up the hand brake; then engage the brake lever lock.
3. Remove the wheel.
4. Remove the cotter pin securing the hex nut; then remove the hex nut. Release the brake lever lock.



5. Remove the two brake calipers (right side only).

■ NOTE: Do not allow the brake calipers to hang from their cable/hose.

⚠ CAUTION

The calipers should be supported. If the calipers are allowed to hang from the cable/hose, damage may occur.

6. Slide the hub out of the knuckle and set aside.
7. Remove the cap screw and lock nut securing the knuckle to the upper A-arm. Discard the lock nut.

■ NOTE: Never reuse a lock nut. Once a lock nut has been removed, it must be replaced with a new lock nut.

8. While holding the drive axle stationary, pull the top of the knuckle out and down until it is free of the drive axle.
9. Place a drain pan under the ATV to contain any oil leakage; then using a slide hammer, remove the drive axle.



REMOVING FRONT DRIVE AXLE

■ NOTE: For removing a front drive axle, see Front Differential in this section.

CLEANING AND INSPECTING

■ NOTE: Always clean and inspect the drive axle components to determine if any service or replacement is necessary.

1. Using a clean towel, wipe away any oil or grease from the axle components.




2. Inspect boots for any tears, cracks, or deterioration.

■ NOTE: If a boot is damaged in any way, it must be replaced with a boot kit.

3. Inspect the gear case seals for nicks or damage.

DISASSEMBLING AXLES

1. Using a side-cutters (or suitable substitute), remove the large clamp from the boot.



CD020

2. Wipe away excess grease to access the retaining ring. Using an awl or circlip pliers, remove the circlip.



CD021

3. Using a snap ring pliers, remove the circlip securing the bearing ring to the shaft. Note the direction of the bearing for assembling purposes.



CD023

4. Note the difference inside each bearing ring end for assembling purposes; then remove the bearing ring.

■ NOTE: The recess of the bearing must face toward the housing.



CD022

5. Inspect the splines of the shaft, the bearing ring, and the housing for damage.

■ NOTE: If any damage is apparent to the splines, the bearing ring, and/or the housing, the drive axle must be replaced as an assembly.

6. Using a side-cutters (or suitable substitute), remove the small clamp from the shaft.



CD752


■ NOTE: At this point if the outside boot is damaged, continue with step 7.

7. Using a side-cutters (or suitable substitute), remove both outside boot clamps from the shaft. Note the position of the different-sized clamps for assembling purposes.



CD751

8. Apply 40 grams (1/3 of contents) of grease from the Grease Pack (p/n 0441-173) into the knuckles and the new outside boot.



ATV-1052

■ **NOTE:** Grease Pack (p/n 0441-173) contains 120 grams of grease. The inside joint (double-offset) requires approximately 70-90 grams of grease and the outside (bell-type) requires approximately 35-55 grams. When replacing boots, use 2/3 of the pack for inside boots and 1/3 of the pack for outside boots.

CAUTION

Do no over-fill the joint as boot damage may occur resulting in joint failure.

9. Slide the new outside boot onto the shaft with the new clamps positioned as shown. Note the different-sized clamps from removal.

■ **NOTE:** The boot is positioned correctly when the small end of the boot seats down into the recessed groove.



CD754

10. Using a CV Boot Clamp Tool (p/n 0444-120), secure both outside boot clamps.

CAUTION

It is important that the clamps are positioned correctly or they may loosen when in motion.



CD024

ASSEMBLING AXLES


1. Install the inner boot with the small clamp making sure the ends of the clamp are positioned correctly.

■ **NOTE:** The boot is positioned correctly when the small end of the boot seats down into the recessed groove.



CD754

2. Using the boot clamp pliers, secure the small clamp of the inner boot.



ATV-1048

3. Apply 80 grams (2/3 of contents) of grease from the pack into the bearing housing.
4. Install the bearing onto the shaft making sure the recess of the bearing is facing the housing.




CD022

⚠ CAUTION

The bearing ring must go onto the shaft with the side without splines facing toward the small clamp of the inner boot or severe damage will result.

5. Secure the bearing ring with the circlip making sure the sharp side of the circlip faces away from the boot.



CD023

6. Making sure the marks made during disassembling align, slide the housing over the bearing ring; then completely seat the bearing ring into the housing and install the circlip.

■ NOTE: Pull the bearing ring out of the housing until it contacts the circlip; then slide the ring in half way. This will purge air from the housing and ensure the bearing is packed properly.



CD021

7. Slide the boot over the housing; then using the boot clamp pliers, secure the boot with the clamp.




CD024

8. Inspect the axle components for correct positioning of the four clamps. Also, inspect the boots for being correctly positioned on the shaft.

INSTALLING REAR DRIVE AXLE

1. Slide the drive axle into place in the gear case.
- **NOTE: To assure proper seating of the axle, give it a light pull; the axle should remain “clipped” in place.**
2. Swing the knuckle up and onto the drive axle; then place the knuckle into place in the upper A-arm. Secure the knuckle to the A-arm with a cap screw and a new lock nut. Tighten to specifications.
3. Place the hub into position on the axle followed by a hex nut. Tighten the hex nut finger-tight at this time.
4. If the brake calipers were removed, position them on the knuckle and secure with existing cap screws. Tighten the auxiliary brake caliper cap screws to specifications. Tighten the hydraulic brake caliper cap screws to specifications.
5. Pump up the hand brake lever; then engage the brake lever lock.
6. Tighten the hub hex nut (from step 3) to specifications; then install and spread a new cotter pin making sure each side of the pin is flush to the hub nut.

6




CD027

7. Install the wheel. Tighten to specifications.
8. Remove the ATV from the support stand and release the brake lever lock.

INSTALLING FRONT DRIVE AXLE


1. Position the drive axle in the gear case and steering knuckle; then insert the upper A-arm ball joint into the steering knuckle. Secure with a cap screw tightened to specifications.
2. Place the brake hose into position on the upper A-arm; then secure the lower shock eyelet to the A-arm with a cap screw and a new lock nut. Tighten to specifications.
3. Secure the tie rod to the steering knuckle with a new lock nut. Tighten securely; then install and spread a new cotter pin.
4. Slide the hub w/brake disc into position in the steering knuckle followed by a washer and hex nut. Tighten finger-tight at this time.
5. Install the brake caliper on the steering knuckle. Tighten to specifications; then pump up the hand brake lever and engage the brake lever lock.
6. Tighten the hub hex nut (from step 4) to specifications; then install and spread a new cotter pin making sure each side of the pin is flush to the hub nut.



CD027

7. Install the wheel and tighten to specifications.

8. Remove the ATV from the support stand and release the brake lever lock.
9. Check the front differential oil level and add oil as necessary.




CF113A

Rear Gear Case


REMOVING

1. Remove the left-side rear A-arms (see Rear A-Arms in Section 7).
2. Remove both of the rear drive axles (see Drive Axles in this section).
3. Remove the four cap screws securing the engine output shaft to the rear gear case input flange.




CD028

4. Remove the two cap screws and lock nuts securing the rear gear case to the frame; then remove the gear case through the left side.



AF960A



KX041

☞ AT THIS POINT

For servicing the input shaft, pinion gear, needle bearing, and axle seal, see Front Differential in this section.

INSTALLING

1. Slide the gear case into position through the left side of the frame; then secure it to the frame with cap screws and lock nuts. Tighten to specifications.

■ NOTE: If a new gear case is being installed, tighten the cap screws to 5.1-6.3 kg-m (37-45.5 ft-lb).

2. Secure the engine output shaft to the rear gear case input flange with three cap screws (coated with red Loctite #271) and lock nuts. Tighten to specifications.
3. Install the rear drive axles (see Drive Axles in this section).
4. Install the left-side rear A-arms (see Rear A-Arms in Section 7).

Hub

REMOVING

1. Secure the ATV on a support stand to elevate the wheel; then remove the wheel.

⚠ WARNING


Make sure the ATV is solidly supported on the support stand to avoid injury.

2. Remove the cotter pin from the nut.

■ NOTE: During assembly, new cotter pins should be installed.

3. Remove the flange nut securing the hub.

4. Remove the brake caliper.



PR243A

5. Remove the hub assembly.

6. Remove the four cap screws securing the brake disc.

6


CLEANING AND INSPECTING

■ NOTE: Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Clean all hub components.
2. Inspect all threads for stripping or damage.
3. Inspect the brake disc for cracks or warping.
4. Inspect the hub for pits, cracks, loose studs, or spline wear.


INSTALLING

1. Secure the brake disc to the hub with the four cap screws coated with blue Loctite #243. Tighten to specifications.
2. Apply grease to the splines in the hub.



PR291


3. Install the hub assembly onto the shaft.



CD009


4. Secure the hub assembly with the nut. Tighten only until snug.

5. Secure the brake caliper to the knuckle with the two cap screws. Tighten the auxiliary caliper to specifications. Tighten the hydraulic caliper to specifications.



PR243A

6. Tighten the hub nut (from step 4) to specifications; then install and spread a new cotter pin making sure each side of the pin is flush to the hub nut.



CD008

7. Install the wheel and tighten to specifications.



CD006

8. Remove the ATV from the support stand.

Hydraulic Brake Caliper

■ NOTE: The brake caliper is a non-serviceable component; it must be replaced as an assembly (see Section 2).

SECTION 7 - SUSPENSION

7

TABLE OF CONTENTS

Suspension	7-2
Shock Absorbers	7-2
Front A-Arms	7-3
Rear A-Arms	7-5
Wheels and Tires	7-7

Suspension

■ NOTE: Critical torque specifications are located in Section 10.

Shock Absorbers

REMOVING

1. Secure the ATV on a support stand to elevate the wheels and to release load on the suspension.

⚠ WARNING

Make sure the ATV is solidly supported on the support stand to avoid injury.

2. Remove the two cap screws and nuts securing each front shock absorber to the frame and the upper A-arm. Account for bushings and sleeves from each.



AF605D

⚠ CAUTION

Additional support stands are necessary to support the rear axle when the shock absorbers are removed or damage may occur.

3. Remove the two cap screws and nut securing each rear shock absorber to the frame and lower A-arm. Account for bushings and sleeves from each.



AF626D

4. Compress the shock absorber spring, remove the retainer, and remove the spring.



AF730D

CLEANING AND INSPECTING

■ NOTE: Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Clean all shock absorber components in parts-cleaning solvent.
2. Inspect each shock rod for nicks, pits, rust, bends, and oily residue.
3. Inspect all springs, spring retainers, shock rods, sleeves, bushings, shock bodies, and eyelets for cracks, leaks, and bends.

INSTALLING

1. Place the shock absorber spring over the shock absorber, compress the spring, and install the retainer.

2. Place bushings and sleeves (where appropriate) into shock eyelet; then install shock with two cap screws and nuts. Tighten all nuts to specifications.

⚠ CAUTION

Do not tighten the nuts beyond the 4.8 kg-m (35 ft-lb) specification or the shock eyelet or mount WILL be damaged.

■ **NOTE:** The rear shock absorber-to-lower A-arm torque factor is 2.8 kg-m (20 ft-lb).

3. Remove the ATV from the support stand.

Front A-Arms

REMOVING

1. Secure the ATV on a support stand to elevate the front wheels; then remove the wheels.

⚠ WARNING

Make sure the ATV is solidly supported on the support stand to avoid injury.

2. Remove the cotter pin from the nut. Discard the cotter pin.



CD008

3. Remove the nut securing the hub.

4. Remove the brake caliper. Account for two cap screws and two 0.76 mm (0.030 in.) spacer washers.



CD007

5. Remove the hub assembly.

6. Remove the cotter pin and slotted nut securing the tie rod end to the knuckle; then remove the tie rod end from the knuckle.



AF618D

7. Remove the cap screws securing the ball joints to the knuckle.

⚠ CAUTION

Support the knuckle when removing the cap screws or damage to the threads will occur.




AF628D

8. Tap the ball joints out of the knuckle; then remove the knuckle.

9. Remove the lower shock absorber eyelet from the upper A-arm.

10. Remove the cap screws securing the A-arms to the frame.



AF610D

11. Remove the circlip from the ball joint; then remove the ball joint from the A-arm.



AF610D

CLEANING AND INSPECTING

■ NOTE: Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Clean all A-arm components in parts-cleaning solvent.
2. Clean the ball joint mounting hole of all residual Loctite, grease, oil, or dirt for installing purposes.
3. Inspect the A-arm for bends, cracks, and worn bushings.
4. Inspect the ball joint mounting holes for cracks or damage.
5. Inspect the frame mounts for signs of damage, wear, or weldment damage.


INSTALLING

1. Apply green Loctite #609 to the entire outside diameter of the ball joint; then install the ball joint into the A-arm and secure with the circlip.



AF616D

2. Install the A-arm assemblies into the frame mounts and secure with the cap screws. Only finger-tighten at this time.



AF610D

3. Route the brake hose through the upper A-arm shock absorber mount; then secure the hose to the A-arm with a cable tie and grommet.



DE054A

4. Secure the lower eyelet of the shock absorber to the upper A-arm. Tighten nut to specifications.
5. Secure the A-arm assemblies to the frame mounts (from step 2). Tighten the cap screws to specifications.

⚠ CAUTION

Do not tighten the nut beyond the 4.8 kg-m (35 ft-lb) specification or the shock eyelet or mount WILL be damaged.

6. Install the knuckle assembly onto the ball joints and secure with cap screws. Tighten to specifications.



AF628D

7. Install the tie rod end and secure with the nut. Tighten to specifications; then install a new cotter pin and spread the pin to secure the nut.

■ NOTE: During assembly, new cotter pins should be installed.



AF618D


8. Apply grease to the hub and drive axle splines; then install the hub assembly onto the drive axle.



CD009

9. Secure the hub assembly with the nut. Tighten only until snug.

10. Secure the brake caliper to the knuckle with the two cap screws making sure the two 0.76 mm (0.030 in.) spacer washers are positioned between the caliper and the knuckle. Tighten to specifications.



CD007

11. Secure the hub nut (from step 9) to the shaft/axle. Tighten to specifications.
12. Install a new cotter pin and spread the pin to secure the nut.



CD008

13. Install the wheel and tighten to specifications.
14. Remove the ATV from the support stand.

7

Rear A-Arms

REMOVING

1. Secure the ATV on a support stand to elevate the wheels.

WARNING

Make sure the ATV is solidly supported on the support stand to avoid injury.

2. Pump up the hand brake; then engage the brake lever lock.

3. Remove the wheel.
4. Remove the cotter pin securing the hex nut; then remove the hex nut. Release the brake lever lock.
5. Remove the caliper (right side only).

■ NOTE: Do not allow the brake calipers to hang from their cable/hose.

6. Remove the cap screws and lock nut securing the shock absorber to the frame and lower A-arm; then remove the shock absorber.
7. Remove the cap screws securing the boot guard to the lower A-arm.



AF934

8. Slide the hub out of the knuckle and set aside.
9. Remove the cap screws and lock nuts securing the knuckle to the A-arms. Discard the lock nuts.

■ NOTE: Never reuse a lock nut. Once a lock nut has been removed, it must be replaced with a new lock nut.

10. Remove the cap screws and lock nuts securing the A-arms to the frame; then remove the A-arms.

■ NOTE: If removing the upper right A-arm, it will be necessary to disconnect the brake hose from the A-arm.

CLEANING AND INSPECTING

■ NOTE: Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Clean all A-arm components in parts-cleaning solvent.
2. Inspect the A-arm for bends, cracks, and worn bushings.

3. Inspect the frame mounts for signs of damage, wear, or weldment damage.

INSTALLING

1. Install the A-arm assemblies into the frame mounts and secure with the cap screws and new lock nuts. Only finger-tighten at this time.
2. Slide the knuckle onto the drive axle and into position on the A-arms; then secure the knuckle to the A-arms with cap screws and new lock nuts. Tighten to specifications.
3. Tighten the hardware securing the A-arms to the frame mounts (from step 1) to specifications.
4. Apply grease on the drive axle splines; then install the hub assembly onto the drive axle.



CD009

5. Secure the hub assembly with the nut. Tighten only until snug.
6. Secure the brake caliper to the knuckle with the two cap screws (right side only). Tighten the caliper to specifications.

■ NOTE: Ensure that the brake hose is properly routed and secured to the upper A-arm.



DE054A

7. Compress the hand brake lever and engage the brake lever lock; then secure the hub nut (from step 5) to the drive axle. Tighten to specifications.

8. Install a new cotter pin and spread the pin to secure the nut.




CD008

9. Secure the shock absorber to the frame with a cap screw and new lock nut. Tighten to specifications.
10. Secure the shock absorber to the lower A-arm with a cap screw and new lock nut. Tighten to specifications.
11. Secure the boot guard to the lower A-arm with the two cap screws. Tighten securely.
12. Install the wheel and tighten to specifications.
13. Remove the ATV from the support stand.

Wheels and Tires

KEY

1. Machine Screw
2. Brake Disc
3. Wheel Hub - Front
4. Hub Stud
5. Cotter Pin
6. Hex Nut
7. Wheel
8. Mounting Nut
9. Tire - Front
10. Valve Stem
11. Valve Stem Cap
12. Wheel Hub - Rear
13. Wheel
14. Tire - Rear



0739-534

TIRE SIZE

⚠ WARNING

Use only Arctic Cat approved tires when replacing tires. Failure to do so could result in unstable ATV operation.

The ATV is equipped with low-pressure tubeless tires of the size and type listed in the General Specifications (see Section 1). Do not under any circumstances substitute tires of a different type or size.

⚠ WARNING

Do not mix tire tread patterns. Use the same pattern type on front and rear. Failure to heed warning could cause poor handling qualities of the ATV and could cause excessive drive train damage not covered by warranty.

TIRE INFLATION PRESSURE

Front and rear tire inflation pressure should be 0.35 kg/cm² (5.0 psi).

REMOVING

1. Secure the ATV on a support stand to elevate the wheels.

⚠ WARNING

Make sure the ATV is solidly supported on the support stand to avoid injury.

2. Remove the wheels.

■ NOTE: Keep left-side and right-side wheels separated for installing them on their proper sides.

7

CLEANING AND INSPECTING

■ NOTE: Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Clean the wheels and hubs with parts-cleaning solvent.
2. Clean the tires with soap and water.
3. Inspect each wheel for cracks, dents, or bends.
4. Inspect each tire for cuts, wear, missing lugs, and leaks.

INSTALLING

1. Install each wheel on its hub.



CD006

■ **NOTE:** Make sure each wheel is installed on its proper hub as noted in removing (the “rotation arrow” (if applicable) must indicate forward direction of rotation).



AF612D

2. Tighten to specifications.

CHECKING/INFLATING

1. Using an air pressure gauge, measure the air pressure in each tire. Adjust the air pressure as necessary to meet the recommended inflation pressure.



CD005

2. Inspect the tires for damage, wear, or punctures.

⚠ WARNING

Do not operate the ATV if tire damage exists.

■ **NOTE:** If repair is needed, follow the instructions found on the tire repair kit or remove the wheel and have it repaired professionally.

■ **NOTE:** Be sure all tires are the specified size and have identical tread pattern.

3. Check the front wheel toe-in and toe-out and adjust as necessary (see Section 8).

4. Test drive the ATV on a dry, level surface and note any pulling to the left or right during acceleration, deceleration, and braking.

■ **NOTE:** If pulling is noted, measure the circumference of the front and rear tires on the pulling side. Compare the measurements with the tires on the opposite side. If pulling is noted during braking only, check and adjust the brakes as necessary and recheck operation (see Section 2).

5. Increase the air pressure in the tires with the smallest circumference measurement until all tires are equal in circumference.

6. Repeat steps 4-5 as necessary to ensure proper handling.

SECTION 8 - STEERING/FRAME

TABLE OF CONTENTS

8


Steering/Frame.....	8-2
Steering Post/Tie Rods	8-2
Handlebar Grip	8-5
Steering Knuckles	8-6
Measuring/Adjusting Toe-In.....	8-8
Front Rack	8-9
Front Bumper Assembly.....	8-10
Front/Rear Body Panel.....	8-10
Front Body Panel/Side Panels (TBX/TRV/500/650 H1/700 EFI)	8-13
Footrests	8-17
Belly Panel	8-18
Exhaust System	8-18
Rear Body Panel/Rack	8-19
Side Storage Box (TBX Models)	8-20
Cargo Box (TBX Models)	8-21
Adjusting Headlight	8-22
Taillight Assembly.....	8-22
Seat.....	8-22

Steering/Frame

■ NOTE: Critical torque specifications are located in Section 10.


Steering Post/ Tie Rods

■ NOTE: Some components may vary from model to model. The technician should use discretion and sound judgment.



REMOVING

1. Remove the ignition switch retaining ring; then remove the reinstallable rivets securing the instrument pod to the mounting bracket and remove the pod.



CD759

2. Remove the reinstallable rivets securing the radiator access cover and remove the cover.



CD666

3. Remove four reinstallable rivets securing the steering post cover and remove the cover.



CD667

4. Unlatch the storage compartment lid; then slide the storage compartment cover assembly forward and lift off.



CD669

5. Remove the storage compartment.



CD671

6. Remove the four cap screws securing the handlebar caps and speedometer bracket to the steering post; then move the handlebar and speedometer out of the way. Account for four handlebar caps.



CD762

7. Remove two cap screws securing the upper steering post bearing to the frame. Account for two bearings and two housings.




CD760

8. Using a suitable lift stand, raise the ATV enough to remove the front wheels; then remove the left-side and right-side splash panels.




CD685

9. Remove the cotter pins and slotted nuts from the inner and outer tie rod ends; then remove the tie rods from the steering post arm and the left-side and right-side steering knuckles.




AF778D

8



KX039

10. Remove two cap screws securing the lower steering post bearing flange to the frame; then remove the steering post.



AL600D

CLEANING AND INSPECTING

■ **NOTE:** Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Wash the tie rod ends in parts-cleaning solvent. Dry with compressed air. Inspect the pivot area for wear. Apply a low-temperature grease to the ends.

⚠ WARNING

Always wear safety glasses when using compressed air.


2. Inspect the tie rods for damaged threads or wear.
3. Inspect the tie rods for cracks or unusual bends.
4. Inspect all welded areas for cracks or deterioration.
5. Inspect the steering post and steering-post brackets for cracks, bends, or wear.
6. Inspect the bearing halves, bearing caps, and bearing housings for cracks or wear.

7. Inspect the handlebar tube for cracks, wear, or unusual bends.

8. Inspect the handlebar grips for damage or wear.

INSTALLING

1. Place the steering post into position; then secure the lower bearing flange to the frame with two cap screws. Tighten to specifications.



AL600D


2. Place the upper steering post bearings into the housings; then position on the steering post and secure the housings to the frame with two cap screws. Tighten to specifications.



CD760

3. Install the tie rods and secure with the slotted nuts. Tighten to specifications; then install new cotter pins.

■ **NOTE:** If the slots do not align with the holes in the tie rod ends, tighten the nuts just enough to allow installation of the cotter pins.



AF778D



CD677

4. Install the splash panels; then install the front wheels and tighten to specifications using a crisscross pattern.
5. Lower the ATV and place the handlebar and caps into position on the steering post; then position the speedometer on top of the caps and secure with the four cap screws. Tighten to specifications.
6. Install the storage compartment box; then attach the storage compartment cover assembly by engaging the lugs into the slots and sliding rearward. Lock the storage compartment lid to hold the assembly in place.



CD671



CD676

8. Install the steering post access cover and secure with four reinstallable rivets; then install and secure the radiator access cover.

Handlebar Grip

REMOVING

1. Remove the plug from the head of the rivet.
2. Using a 1/8-in. drill bit, drill out the rivet.
3. Using compressed air between the grip and the handlebar, twist the grip back and forth until it slides free of the handlebar.

8

INSPECTING

■ **NOTE:** Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Inspect the grip for wear, cuts, or cracks.
2. Inspect the grip for deterioration.




CD670

7. Place the instrument pod into position over the speedometer; then secure with two reinstallable rivets and the ignition switch locking ring.


INSTALLING

■ **NOTE:** Before installing a grip, use contact spray or alcohol to clean the inside of the grip and the handlebar of glue residue, oil, or any other contaminant.

1. Apply a liberal amount of Handlebar Grip Adhesive to the inside of the grip.
2. Align the rivet hole in the grip with the rivet hole in the handlebar; then align the notch (inside the grip) with the slot in the handlebar and slide the grip onto the handlebar until it is fully seated.
3. Wipe off any excess glue; then secure the grip with a new rivet.
4. Install the plug on the head of the rivet.



PR287A



PR288

Steering Knuckles

REMOVING AND DISASSEMBLING

1. Secure the ATV on a support stand to elevate the wheel; then remove the wheel.

⚠ WARNING

Make sure the ATV is solidly supported on the support stand to avoid injury.

2. Remove the wheel cap from the hub; then remove the cotter pin from the nut.
3. Remove the nut securing the hub.
4. Remove the brake caliper.
5. Remove the hub assembly.
6. Remove the cotter pin from the tie rod end and remove the tie rod end from the knuckle.
7. Remove the two cap screws securing the ball joints in the knuckle.
8. Tap the ball joint end out of the knuckle; then remove the knuckle.
9. Remove the snap ring from the knuckle; then remove the bearing.

⚠ CAUTION

Use extreme care when removing the bearing. If the bearing is allowed to fall, it will be damaged and will have to be replaced.


CLEANING AND INSPECTING

■ **NOTE:** Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.


1. Clean all knuckle components.
2. Inspect the bearing for pits, gouges, rusting, or premature wear.
3. Inspect the knuckle for cracks, breaks, or porosity.
4. Inspect threads for stripping or damage.

ASSEMBLING AND INSTALLING


1. Install the bearing; then install the snap ring making sure it seats into the knuckle.




2. Install the knuckle to the upper and lower ball joints and secure with the two cap screws. Tighten to specifications.



3. Install the tie rod end and secure with the nut. Tighten to specifications; then install a new cotter pin and spread the pin.



4. Apply a small amount of grease to the hub splines.



5. Install the hub assembly onto the splines of the shaft.
6. Secure the hub assembly with the nut. Tighten only until snug.



7. Secure the brake caliper to the knuckle with the two cap screws. Tighten to specifications.




8

8. Pump the hand brake lever; then engage the brake lever lock.
9. Secure the hub nut (from step 6) to the shaft. Tighten to specifications.
10. Install a new cotter pin and spread the pin to secure the nut.
11. Install the wheel; then using a crisscross pattern, tighten to specifications.



CD006

12. Remove the ATV from the support stand.



CD012A

5. Adjust the handlebar direction until the two measurements are equal; then secure the handlebar to the rear rack using tie-down straps.

■ **NOTE: Care must be taken not to allow the handlebar to turn while securing it.**



CD014

6. Measure the distance from the inside of each front rim to the lower frame tube.



AF785D




CD005

3. Place the ATV in a level position taking care not to push down or lift up on the front end; then turn the handlebar to the straight ahead position.

■ **NOTE: When measuring and adjusting, there should be a normal operating load on the ATV (without an operator but with Arctic Cat approved accessories).**


4. Measure the distance from the outside edge of each handlebar grip to the seat catch brackets.




AF786D

■ **NOTE:** The distances from the inside rims to the frame tubes should be equal. If the measurements are equal, proceed to step 8; if the measurements are not equal, proceed to step 7.

7. To make the measurements equal, loosen the appropriate tie rod jam nuts and adjust accordingly; then proceed to step 8.



AF617D



AF778D

■ **NOTE:** The front wheels do not have to be removed to adjust the tie rod. Also, care should be taken not to disturb the handlebar position.


8. Using a permanent marker of some type, mark the center of each front tire (at a height parallel to the belly panel).



AF789D

9. Measure the distance between the marks (at a height parallel to the belly panel) at the front side; then record the measurement.
10. Push the ATV forward until the marks are parallel to the belly panel on the back side; then measure the distance between the marks.
11. The difference in the measurements must show 3.2-6.4 mm (1/8-1/4 in.) toe-in (the front measurement 3.2-6.4 mm (1/8-1/4 in.) less than the rear measurement).
12. If the difference in the measurements is not within specifications, adjust both tie rods equally until within specifications.

■ **NOTE:** Prior to locking the jam nuts, make sure the ball joints are at the center of their normal range of motion and at the correct angle.



733-559A

8

Front Rack

REMOVING

1. Remove the two cap screws and lock nuts securing the front fender panel.
2. Remove the cap screws and lock nuts securing the rack to the frame.

3. Remove the front rack from the ATV.

CLEANING AND INSPECTING

■ NOTE: Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Clean all rack components with parts-cleaning solvent.
2. Inspect all welds for cracking or bending.
3. Inspect threaded areas of all mounting bosses for stripping.
4. Inspect for missing decals and/or reflectors.

INSTALLING

1. Place the rack into position on the frame and front fender panel. Install the cap screws and lock nuts and finger-tighten only.
2. Install the two cap screws and lock nuts securing the rack to the fenders. Tighten all hardware securely.

Front Bumper Assembly

REMOVING

1. Remove the two flange bolts and lock nuts securing the upper bumper supports to the bumper.
2. Remove the through-bolt and lock nut securing the bumper to the frame; then remove the bumper.

CLEANING AND INSPECTING

■ NOTE: Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Clean all bumper components with parts-cleaning solvent.
2. Inspect all welds for cracking or bending.

INSTALLING

1. Place the front bumper assembly into position and install the through-bolt. Start the lock nut and finger-tighten only.
2. Install the two flange bolts and lock nuts on the upper supports. Tighten all hardware securely.

Front/Rear Body Panel


REMOVING

1. Remove the seat; then remove the battery cover/tool tray.
2. Remove the negative battery cable from the battery; then remove the positive cable. Remove the vent hose; then remove the battery.


CAUTION

Battery acid is harmful if it contacts eyes, skin, or clothing. Care must be taken whenever handling a battery.

3. Remove four reinstallable rivets securing the storage compartment to the body; then remove the storage compartment and the steering post cover.




CF145A



CF143A

4. Remove the left-side and right-side fender splash panels; then remove one press-in fastener and one reinstallable rivet from the left side and right side of the air-intake splash shroud. Do not remove the shroud.
5. Disconnect the four headlight connectors and the taillight/brakelight connector from the sockets.




CF135A

6. Remove the shift knob; then remove the nut and axle pivot bolt securing the lever to the shift lever axle. Remove the shift lever. Account for the two O-rings on the axle bolt and one spring.



CD779




CF201A



CF160A

8. Remove the two cap screws and lock nuts securing the left foot peg and remove the foot peg.



CD780A


7. Remove the front and rear racks; then remove the two body bolts adjacent to the air filter housing and two push nuts located behind the grille.



CD782

8

9. Remove eight cap screws and lock nuts and one reinstallable rivet securing the right-side footwell to the fenders.
10. Lift and support the rear of the body to allow access to the torx-head cap screws securing the front and rear body sections together; then remove six self-locking nuts (three from each side). Remove the rear body panel; then remove the front one.



CF213A

■ **NOTE:** To aid in removing the body without separating the front and rear panels, it is advisable to have an assistant help with lifting and guiding the body clear of the handlebar.

CLEANING AND INSPECTING

■ **NOTE:** Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.


1. Clean all fender components with part-cleaning solvent and soap and water.
2. Inspect fenders for cracks and/or loose rivets.
3. Inspect for any missing decals.

INSTALLING

1. Place the body assembly into position on the ATV.


■ **NOTE:** If the front and rear body panels have been separated, proceed to step 2; if the panels have not been separated, proceed to step 3.

2. Install the torx-head cap screws and lock nuts securing the front and rear body panels together. Tighten securely.



CF213A

3. Making sure the body mounting grommets are in place, position the front and rear racks; then install the eight flanged cap screws and lock nuts. Do not tighten at this time.



CD679A




CD690A



4. Install four rack-to-body machine screws and lock nuts on the front and rear racks, two push nuts behind the grille, and two body bolts adjacent the air filter housing; then tighten all fasteners (from step 3 and 4) securely.



CF160A



5. Install eight cap screws and lock nuts securing the right-side footwell to the front and rear fenders; then place the left-side foot peg into position and secure with two cap screws and lock nuts. Tighten securely.
6. Place the storage compartment into position; then install the steering post cover. Secure with the reinstallable rivets.



7. Place the shift lever into position making sure the spring is installed; then secure with the axle pivot bolt and lock nut.
8. Install the shift knob and the left-side and right-side splash panels; then reconnect the headlights. Tighten all fasteners securely.
9. Place the battery into position in the battery box; then connect the vent hose.

10. Connect the positive battery cable; then connect the negative battery cable. Tighten the battery terminal cap screws securely.

11. Install the battery cover/tool tray; then install the seat. Make sure the seat locks securely.

Front Body Panel/ Side Panels

(TBX/TRV/500/650 H1/700 EFI)

REMOVING

1. Remove the reinstallable rivets securing the radiator access cover and remove the cover; then remove four reinstallable rivets securing the steering post cover and remove the cover.



8

2. Unlock the storage compartment lid; then slide the storage compartment cover assembly forward and lift off the storage compartment.




CD669

3. Remove the storage compartment box; then remove the seat.




CD671

4. Remove the ignition switch lock collar and two reinstallable rivets securing the instrument pod; then remove the instrument pod.




CF207A

5. Remove four machine screws and lock nuts securing the front rack to the frame; then remove the front rack. Account for four grommets and four bushings.



CD679A




CD680

6. Remove three reinstallable rivets securing the right side panel; then remove two torx-head cap screws securing the rear of the front panel to the frame.



CD683A



CD684A

7. Remove the torx-head cap screws and nylon ties securing the left-side and right-side splash panels; then remove the panels.



CD685



CD779

8. Remove one shoulder screw and four plastic rivets on each side to separate the front panel lower fenders from the left-side and right-side footwells.




CD691



CD682

9. Remove the shift knob retaining pin and remove the shift knob; then remove the shift lever pivot axle nut and remove the axle and shift lever. Account for a spring and two O-rings.



CD780A

10. Disconnect four headlight connectors and secure the wires out of the way; then disconnect the wires to the front accessory plug.



CD681

8

11. Rotate the handlebar to the full-left position; then lift and slide the panel to the rear and lift the rear up to clear the handlebar.



CD765A

■ **NOTE:** It may be necessary to rotate the body panel to the right to align the opening with the handlebar.

CLEANING AND INSPECTING

■ **NOTE:** Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Clean all fender components with part-cleaning solvent and soap and water.
2. Inspect fenders for cracks and/or loose rivets.
3. Inspect for any missing decals.

INSTALLING

1. Rotate the handlebar to the full-left position; then place the front body panel over the handlebar and rotate and lower into position.




CD765

2. Connect the headlight connectors to the appropriate headlights and the front accessory plug wires to the accessory plug.



CD681

3. Make sure the four rubber grommets and bushings are in place; then place the front rack into position and secure with four machine screws and flange nuts. Tighten securely.




CD679A

4. Install one machine screw and flange nut and four plastic rivets on each side to secure the front fenders to the footwells. Tighten the flange nuts securely.

■ **NOTE:** If the footwells have been removed, see Footrests in this section.

5. Install four cap screws securing the front body panel to the frame and rear panel.




CD684A

6. Install the shift lever spring, shift lever, and pivot axle; then tighten the axle nut securely.



CD779

7. Install the left-side and right-side splash panels and tighten the cap screws securely. Install new nylon ties in the appropriate locations.
8. Install the instrument pod and ignition switch; then secure with two reinstallable rivets and the ignition switch lock collar.




CF207A

9. Set the storage compartment box into position; then install the storage compartment cover making sure the mounting lugs engage the slots. Slide rearward to secure and lock by engaging the lid lock.



CD671



CD670A

10. Install the steering post cover and secure with the reinstallable rivets; then install and secure the radiator access panel.
11. Install the left and right side panels and secure with reinstallable rivets.



CD683A

Footrests

8


REMOVING

1. Remove the machine screws and flange nuts securing the front and rear fenders to the footwells.



CD691A

2. Remove the cap screws securing the foot pegs to the footrests; then remove the foot pegs and footwells.



3. Remove the cap screws and flange nuts securing the footrests to the frame; then remove the footrests.

CLEANING AND INSPECTING

■ NOTE: Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Clean the footrest in parts-cleaning solvent.
2. Inspect the footrest weldments for cracks or unusual bends.
3. Inspect all tubing for cracks or unusual bends.

INSTALLING

1. Secure the footrests to the frame with four cap screws and two flange nuts; then tighten securely.
2. Place the footwells onto the footrests; then put the foot pegs in position and secure with two cap screws.



3. Install the machine screws and flange nuts securing the front and rear fenders to the footwells.

Belly Panel


REMOVING/INSTALLING

1. Remove the machine screws and shoulder washers securing the belly panel to the underside of the frame; then remove the belly panel.
2. Place the belly panel into position on the underside of the frame; then install the machine screws and shoulder washers. Tighten securely.

Exhaust System

REMOVING MUFFLER

1. Remove the two exhaust springs at the muffler/exhaust pipe juncture.



2. Slide the muffler rearward to clear the mounting lugs and remove the muffler.

INSPECTING MUFFLER


■ NOTE: Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Inspect muffler externally for cracks, holes, and dents.
2. Inspect the muffler internally by shaking the muffler back and forth and listening for rattles or loose debris inside the muffler.

■ NOTE: For additional details on cleaning the muffler/spark arrester, see Section 2.

INSTALLING MUFFLER

1. Place the muffler into position engaging the mounting lugs into the grommets; then slide the muffler forward.
2. Install the two exhaust springs.



CD687A

Rear Body Panel/Rack

REMOVING

1. Remove four machine screws and flanged nuts securing the rear rack; then remove the rear rack. Account for four bushings.



CD690A

2. Remove one shoulder screw and lock nut and three plastic rivets (on each side) securing the rear body panel to the footwells.



CD691A

3. Remove two machine screws securing the battery cover and remove the cover.



CD688

4. Disconnect the battery (negative cable first); then remove the battery.
5. Disconnect the taillight/brakelight; then remove the gas tank cap and lift off the rear body panel. Install the gas tank cap.

■ **NOTE:** If the front body panel has not been removed, the left-side and right-side panels and the two machine screws must be removed (see Front Body Panel/Side Panels in this section).

CLEANING AND INSPECTING

■ **NOTE:** Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

8

1. Clean all rear body panel components with parts-cleaning solvent and soap and water.
2. Inspect side panels and rear body panel for cracks and loose rivets.
3. Inspect threaded areas of all mounting bosses for stripping.
4. Inspect for missing decals.

INSTALLING


1. Remove the gas tank cap and set the rear body panel in position; then install the cap and connect the taillight/brakelight connector.
2. Place the rear rack in position with four bushings and secure with four machine screws and flanged nuts. Tighten securely.



3. Install one shoulder screw and three plastic rivets (on each side) to secure the front of the rear body panel to the footwells.



4. Place the battery into the battery box; then connect the battery (positive cable first) and secure with the battery cover.



5. Secure the front and rear panels with two machine screws; then install the left and right side panels.


■ **NOTE:** If the front body panel has not been installed, see **Front Body Panel/Side Panels** in this section.

6. Place the seat into position making sure it locks securely.

Side Storage Box (TBX Models)

REMOVING

1. Rotate the cargo box latch handle (located on the left and right sides between the cargo box and the rear tire) and fully raise the cargo box.
2. Pull the seat lock lever forward (located below the right side of the seat), raise the front end of the seat, and slide it forward and off the ATV.
3. Remove the two cap screws (located inside the side storage box) securing the box to the footrest.
4. Remove the screw securing the box to the side panel.
5. Remove cap screws (A and B) securing the box to the frame.




CLEANING AND INSPECTING

■ **NOTE:** Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Clean all side storage box components with soap and water.
2. Inspect the box for cracks, tears, and loose mounting hardware.
3. Inspect the box hatch O-ring seals for cuts or tears.

INSTALLING

1. Place the side storage box into position on the frame; then secure with the two cap screws (A and B). Tighten cap screws to specifications.



2. Secure the box to the side panel with the existing screw.
3. Secure the box to the footrest with existing hardware. Tighten securely.
4. Install the seat.
5. Lower the cargo box and press down firmly on the front of the box. The cargo box will automatically lock into position.

Cargo Box (TBX Models)

REMOVING

1. Rotate the cargo box latch handle (located on the left and right sides between the cargo box and the rear tire) and fully raise the cargo box.



2. Remove the nut from the lower end of the box lift support.

3. Remove the two cap screws and lock nuts securing the cargo box to the frame; then remove the cargo box and discard the lock nuts.



■ **NOTE:** Never reuse a lock nut. Once a lock nut has been removed, it must be replaced with a new lock nut.

CLEANING AND INSPECTING

■ **NOTE:** Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Clean all cargo box components with soap and water.
2. Inspect the cargo box for cracks, tears, and loose mounting hardware.
3. Inspect the welds of the cargo box frame for cracking or bending.
4. Inspect the cargo box gate latches for smooth operation.

INSTALLING

1. Place the cargo box into position on the frame. Secure with cap screws and new lock nuts. Tighten to specifications.

8



CD122

2. While an assistant holds the cargo box in the raised position, secure the lower end of the box lift support to the frame with the cap screw and nut.
3. Lower the cargo box and press down firmly on the front of the box. It will automatically lock into position.

Adjusting Headlight

The headlights can be adjusted vertically and horizontally. The geometric center of the HIGH beam light zone is to be used for vertical and horizontal aiming.

To check/adjust headlight beam, see Section 2.

⚠ WARNING

Do not operate the ATV unless the headlight beam is adjusted properly. An incorrectly adjusted beam will not provide the operator the optimum amount of light.

Taillight Assembly

REMOVING

1. Unplug the three-prong connector and free the taillight wiring harness from the frame.
2. Remove the torx-head cap screws securing the taillight assembly to the frame. Account for any washers.
3. Remove the taillight assembly.

INSPECTING

■ NOTE: Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Inspect wiring harness, three-prong connector, lens, base, cap screws, and socket for damage.
2. Inspect all wires for corrodung, pinching, and cracking.
3. Inspect the bulb for wattage, voltage, and proper operation.

INSTALLING

1. Place the assembly into position on the frame and secure with torx-head cap screws and any washers.
2. Tighten the cap screws securely.
3. Route the wiring harness over the rear frame; then connect the three-prong connector.

Seat

■ NOTE: Some components may vary from model to model. The technician should use discretion and sound judgment.

REMOVING/INSTALLING

1. To remove the seat, lift up on the latch release (located at the rear of the seat). Raise the rear of the seat and slide it rearward.
2. To lock the seat into position, slide the front of the seat into the seat retainers and push down firmly on the rear of seat. The seat should automatically lock into position.


REMOVING/INSTALLING (TRV)

1. To remove the rear seat, pull the two latch handles to the rear and rotate them to the vertical position.



CF226

2. Lift the rear of the seat up; then pull slightly to the rear and lift the seat off the mountings.




CF227A

3. To lock the seat into position, engage the two front mounting lugs into the mounting rack; then holding down firmly on the front of the seat, push the seat forward until the rear tabs engage the rear mounting latches.



CF226A

■ **NOTE:** The rear seat must be removed prior to removing the front seat.



CF229A

4. Lock the seat into position by pulling the two latch handles to the rear and rotating them to the horizontal position.
5. To remove the front seat, pull the seat lock lever up (located at the rear of the seat). Raise the rear end of the seat and slide it rearward.
6. To lock the seat into position, slide the front of the seat into the seat retainers and push down firmly on rear of seat. The seat should automatically lock into position.

SECTION 9 - CONTROLS/INDICATORS

TABLE OF CONTENTS

Hand Brake Lever/Master Cylinder Assembly	9-2
Throttle Control	9-3
Gearshift Pedal (Manual Transmission).....	9-5
Drive Selector.....	9-5
Front Differential Lock	9-5
Shift Lever	9-5
Speedometer/Tachometer/LCD.....	9-6

Hand Brake Lever/ Master Cylinder Assembly

■ NOTE: The master cylinder is a non-serviceable component; it must be replaced as an assembly.

REMOVING


1. Slide a piece of flexible tubing over one of the wheel bleeder valves and direct the other end into a container. Remove the reservoir cover; then open the bleeder valve. Allow the brake fluid to drain completely.

■ NOTE: Compressing the brake lever several times will quicken the draining process.



AF637D

2. Place an absorbent towel around the connection to absorb brake fluid. Remove the banjo-fitting from the master cylinder. Account for two crush washers and a banjo-fitting bolt.




DE059A

CAUTION

Brake fluid is highly corrosive. Do not spill brake fluid on any surface of the ATV.


3. Remove the circlip and pivot pin securing the brake lever to the master cylinder housing; then remove the brake lever and set aside.

4. Dislodge the brakelight switch from the master cylinder housing by gently pressing it toward the pivot pin hole in the housing; then lay it aside leaving the switch and wiring harness connected.



BC205

5. Remove the clamp screws securing the brake housing to the handlebar; then remove the assembly from the handlebar.



DE058A

INSPECTING


■ NOTE: Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

1. Inspect the pin securing the brake lever for wear.
2. Inspect the brake lever for elongation of the pivot hole.
3. Inspect the reservoir for cracks and leakage.
4. Inspect the banjo-fitting for cracks and deterioration and the condition of the fittings (threaded and compression).
5. Inspect the brakelight switch for corrosion, cracks, missing or broken mounting tabs, or broken and frayed wiring.


■ NOTE: If the brakelight switch is determined to be not serviceable, see Section 5.

INSTALLING


1. Position the brake housing on the handlebar. Secure with clamp screws; then tighten securely.



2. Using two new crush washers, connect the banjo-fitting to the master cylinder; then secure with the banjo-fitting bolt.



3. Gently press the brakelight switch into the housing (left to right) until the mounting tabs snap into the four locating holes; then install the brake lever, pivot pin, and circlip.




4. Bleed the brake system (see Section 2).


Throttle Control

REMOVING


1. Remove the two machine screws securing the throttle control to the handlebar.
2. Slide the grommet out of the lower half of the throttle control; then remove the cable from the actuator arm.



3. Remove the cap screw, lock washer, and washer securing the actuator arm to the throttle control lever.




4. Remove the actuator arm and account for a bushing. Note the position of the return spring for installing purposes.



AF678D


INSTALLING

1. Place the return spring into the throttle control; then place the bushing and actuator arm into position. Secure with the cap screw, lock washer, and washer.



AF679D

2. Using a pair of needle-nose pliers, place the spring into position on the actuator arm.




AF680D

3. Place the two halves of the throttle control onto the handlebars and secure with the two machine screws.


ADJUSTING

1. Slide the boot back to reveal the jam nut; then loosen the jam nut.




AF682D

2. Rotate the adjuster sleeve until 0.5-1.0 mm (0.02-0.04 in.) is attained.



AL611D


3. Secure the adjustment by tightening the jam nut; then slide the boot over the jam nut.



0732-412

Gearshift Pedal (Manual Transmission)


The gearshift pedal is attached to a ratchet mechanism in the transmission. Each time a gear is selected, the gearshift pedal will return to its normal position ready to select the next gear. To return to neutral, press down repeatedly (once for each gear) on the front of the pedal. Shift into gears by pressing down on the back of the pedal once for each gear. The ratchet mechanism makes it impossible to upshift or downshift more than one gear at a time.



Drive Selector

The automatic drive selector allows the operator to operate in either 2-wheel drive (rear wheels) or 4-wheel drive (all wheels). For normal riding on flat, dry, hard surfaces, 2-wheel drive should be sufficient. In situations of aggressive trail conditions, 4-wheel drive would be the desired choice.

To either engage or disengage the front wheels, move the switch to the 4WD position or to the 2WD position.



CAUTION

Do not attempt to either engage or disengage the front differential while the ATV is moving.

Front Differential Lock

Certain ATV models are equipped with a front differential lock. The front differential lock allows the operator to mechanically lock the differential to apply equal power to both front wheels. To engage the front differential lock, rotate the handle fully clockwise to LOCK; to disengage the front differential lock, rotate the handle fully counterclockwise to UNLOCK.



To adjust the differential lock cable, see Section 2.

Shift Lever

REMOVING


1. Remove the E-clip securing the shift rod to the engine shift arm.
2. Remove two cap screws, two self-tapping screws, and three nylon ties securing the left-side splash panel and remove the panel.
3. Remove the axle and nut securing the shift lever to the upper shift arm; then remove the shift lever. Account for a spring and two O-rings.
4. Using two open-end wrenches, remove the lock nut securing the shift rod to the upper shift arm. Remove the shift rod and discard the lock nut.

■ **NOTE: Never reuse a lock nut. Once a lock nut has been removed, it must be replaced with a new lock nut.**

9

INSTALLING

1. Place the shift rod into position on the engine shift arm and secure with the existing E-clip.
2. Using a new lock nut (B), secure the shift rod to the upper shift arm; then using two open-end wrenches, tighten securely.



3. Place the spring into position between the upper shift arm and shift lever; then making sure the O-rings are in place on the axle, secure the shift lever to the arm with the existing axle and nut.
4. Check shift lever adjustment (see Section 2); then tighten jam nut (A) securely.
5. Install the left-side splash panel.

Speedometer/ Tachometer/LCD

REPLACING

To replace the speedometer, use the following procedure.

1. Remove the two reinstallable rivets securing the instrument pod; then remove the ignition switch retaining ring.
2. Remove the two nuts securing the mounting studs; then remove the speedometer and disconnect the multi-pin connector.
3. Mount the speedometer and secure with the two nuts; then connect the multi-pin connector.
4. Install the instrument pod and secure with the reinstallable rivets.
5. Secure the ignition switch with the retaining ring.

SECTION 10 - AIDS FOR MAINTENANCE

TABLE OF CONTENTS

10

Torque Specifications (400/500 - Manual Transmission)	10-2
Torque Specifications (400/500 - Automatic Transmission/650 H1)	10-3
Torque Specifications (700 EFI)	10-5
Tightening Torque (General Bolts)	10-7
Torque Conversions	10-7

Torque Specifications

(400/500 - Manual Transmission)

DRIVE TRAIN COMPONENTS			
Part	Part Bolted To	Torque	
		kg-m	ft-lb
Engine (Lower Rear/Front)	Frame	5.5	40.0
Front Differential*	Frame/Differential Bracket	6.2	45.0
Pinion Housing	Differential Housing	2.9-3.5	21.0-25.0
Differential Housing Cover***	Differential Housing	2.9-3.5	21.0-25.0
Drive Bevel Gear Nut***	Shaft	10.0	72.0
Differential Gear Case***	Hub	2.3-3.0	16.5-22.0
Lock Collar	Differential Housing	17.3	125.0
Hub Nut	Shaft/Axle (max)	27.6	200.0
Oil Drain Plug	Front Differential/Rear Drive	0.5	3.5
Oil Fill Plug	Front Differential/Rear Drive	2.2	16.0
Oil Drain Plug	Engine	2.2	16.0
Inspection Plug	Front Differential/Rear Drive	0.5	3.5
Wheel	Hub	5.5	40.0
Oil Fitting (400)	Engine	0.8	6.0
EXHAUST COMPONENTS			
Exhaust Pipe	Engine	2.8	20.0
ELECTRICAL COMPONENTS			
Coil*	Frame	1.7	12.0
Ground Wire	Engine	1.1	8.0
STEERING COMPONENTS			
Handlebar Block	Steering Post	2.8	20.0
Steering Post Bearing Housing	Frame	2.8	20.0
Steering Post Bearing Flange	Frame	2.8	20.0
Lower Steering Bearing Washer Cap Screw***	Steering Post	5.5	40.0
Tie Rod End	Knuckle/Steering Post	4.2	30.0

BRAKE COMPONENTS			
Part	Part Bolted To	Torque	
		kg-m	ft-lb
Brake Disc*	Hub	2.1	15.0
Brake Hose	Caliper	2.8	20.0
Brake Hose	Master Cylinder	2.8	20.0
Brake Hose	Auxiliary Brake Cylinder	2.8	20.0
Master Cylinder (Rear)	Frame	3.5	25.0
Master Cylinder Cover	Master Cylinder	0.1	1.0
Auxiliary Brake Pedal	Lever Axle	3.5	25.0
Hydraulic Caliper	Knuckle/Axle Retainer Assembly	2.8	20.0
Auxiliary Caliper	Knuckle/Axle Retainer Assembly	2.8	20.0
CHASSIS COMPONENTS			
Footrest	Frame (8 mm)	2.8	20.0
Footrest	Frame (10 mm)	5.5	40.0
Shift Lever*	Shift Axle	1.1	8.0
SUSPENSION COMPONENTS (Front)			
A-Arm	Frame	4.8	35.0
Ball Joint Cap Screw	Knuckle	4.8	35.0
Shock Absorber	Frame	4.8	35.0
Shock Absorber	Upper A-Arm	4.8	35.0
Knuckle	A-Arm	4.8	35.0
SUSPENSION COMPONENTS (Rear)			
Axle Retainer Assembly	Axle Housing	5.5	40.0
Shock Absorber (Upper)	Frame	4.8	35.0
Shock Absorber (Lower)	Lower A-Arm	2.8	20.0
A-Arm	Frame	4.8	35.0
Swing Arm	Axle Housing/Case	4.8	35.0
Knuckle	A-Arm	4.8	35.0

ENGINE/TRANSMISSION			
Part	Part Bolted To	Torque	
		kg-m	ft-lb
Clutch Shoe	Crankshaft	13.0	94.0
Clutch Sleeve Hub	Countershaft	10.0	72.0
Crankcase Half (6 mm)	Crankcase Half	0.9-1.3	6.5-9.5
Crankcase Half (8 mm)	Crankcase Half	2-2.4	14.5-17.0
Cylinder Head (Cap Screw)	Cylinder	3.8	27.5
Cylinder Head (6 mm Nut)	Cylinder	1.1	8.0
Cylinder Head (8 mm Nut)	Cylinder	2.5	18.0
Cylinder Head Cover	Cylinder Head	1.0	7.0
Left-Side Cover	Crankcase Half	0.9-1.3	6.5-9.5
Mechanical Water Pump Impeller	Pump Shaft	1.05	7.5
Oil Pump Drive Gear	Crank Balancer Shaft	8.0	58.0
Oil Pump*	Crankcase	1.0	7.0
Output Shaft Gear	Output Shaft	10.0	72.0
Rear Output Shaft	Output Joint	2.8	20.0
Recoil Starter	Left-Side Cover	0.8	6.0
Reverse Cam Stopper Housing	Crankcase	2.3	16.5
Right-Side Cover	Crankcase	0.9-1.3	6.5-9.5
Rotor/Flywheel Nut	Crankshaft	16.0	116.0
Shift Stop Housing	Crankcase	2.3	16.5
Cam Sprocket**	Camshaft	1.5	11.0
Starter Cup	Crankshaft	3.5	25.0
Spark Plug	Engine	1.7	12.0

* w/Blue Loctite #243

** w/Red Loctite #271

*** w/Green Loctite #609

Torque Specifications

(400/500 - Automatic Transmission/650 H1)

DRIVE TRAIN COMPONENTS			
Part	Part Bolted To	Torque	
		kg-m	ft-lb
Engine Mounting Through-Bolt (400/500)	Frame	5.5	40.0
Engine (650 H1)	Engine Cradle	5.5	40.0
Engine Cradle (650 H1/TRV)**	Rubber Mount	3.5	25.0
Rubber Mount (650 H1/TRV)	Frame Bracket	4.8	35.0
Front Differential*	Frame/Differential Bracket	6.2	45.0
Rear Output Joint Assembly	Engine	2.8	20.0
Input Housing	Differential Housing	2.9-3.5	21.0-25.0
Differential Housing Cover***	Differential Housing	2.9-3.5	21.0-25.0
Drive Bevel Gear Nut***	Shaft	10.0	72.0
Differential Gear Case***	Hub	2.3-3	16.5-22
Lock Collar	Differential Housing	17.3	125.0
Hub Nut	Shaft/Axle (max)	27.6	200.0
Oil Drain Plug	Front Differential/Rear Drive	0.5	3.5
Oil Fill Plug	Front Differential/Rear Drive	2.2	16.0
Oil Drain Plug	Engine	2.2	16.0
Inspection Plug	Rear Drive	0.5	3.5
Wheel	Hub	5.5	40.0

EXHAUST COMPONENTS			
Exhaust Pipe (400/500)	Engine	2.8	20.0
Exhaust Pipe (650 H1)	Engine	2.8	20.0

ELECTRICAL COMPONENTS			
Coil*	Frame	1.7	12.0
Ground Wire	Engine	1.1	8.0

STEERING COMPONENTS			
Part	Part Bolted To	Torque	
		kg-m	ft-lb
Handlebar Block	Steering Post	2.8	20.0
Steering Post Bearing Housing	Frame	2.8	20.0
Steering Post Bearing Flange	Frame	2.8	20.0
Lower Steering Bearing Washer Cap Screw***	Steering Post	5.5	40.0
Tie Rod End	Knuckle/Steering Post	4.2	30.0
BRAKE COMPONENTS			
Brake Disc*	Hub	2.1	15.0
Brake Hose	Caliper	2.8	20.0
Brake Hose	Master Cylinder	2.8	20.0
Brake Hose	Auxiliary Brake Caliper	2.8	20.0
Master Cylinder Cover	Master Cylinder	0.1	1.0
Auxiliary Brake Pedal	Lever Axle	3.5	25.0
Hydraulic Caliper	Knuckle	2.8	20.0
Auxiliary Caliper	Knuckle	2.8	20.0
CHASSIS COMPONENTS			
Footrest	Frame (8 mm)	2.8	20.0
Footrest	Frame (10 mm)	5.5	40.0
Shift Lever*	Shift Axle	1.1	8.0
SUSPENSION COMPONENTS (Front)			
A-Arm	Frame	4.8	35.0
Ball Joint Cap Screw	Knuckle	4.8	35.0
Shock Absorber	Frame	4.8	35.0
Shock Absorber	Upper A-Arm	4.8	35.0
Knuckle	A-Arm	4.8	35.0
SUSPENSION COMPONENTS (Rear)			
A-Arm	Frame	4.8	35.0
Shock Absorber (Upper)	Frame	4.8	35.0
Shock Absorber (Lower)	Lower A-Arm	2.8	20.0
Knuckle	A-Arm	4.8	35.0
SUSPENSION COMPONENTS (Rear) TBX Model			
Shock Absorber	Frame	4.8	35.0
Shock Absorber	A-Arm	2.8	20.0
Tilt Box Frame	ATV Frame	3.3	24.0
Cargo Box (Plastic)	Tilt Box Frame	1.7	12.0
Side Box	Frame	2.8	20.0
Side Box	Footwell	1.1	8.0
Rear CV Joint**	Engine	2.8	20.0

ENGINE/TRANSMISSION (400/500 - Automatic Transmission)			
Part	Part Bolted To	Torque	
		kg-m	ft-lb
Clutch Shoe	Crankshaft	13.0	94.0
Clutch Cover/Housing Assembly	Crankcase	1.1	8.0
Crankcase Half (6 mm)	Crankcase Half	0.9-1.3	6.5-9.5
Crankcase Half (8 mm)	Crankcase Half	2-2.4	14.5-17
Cylinder Head (Cap Screw)	Crankcase	3.8	27.5
Cylinder Head (6 mm)	Cylinder	1.1	8.0
Cylinder Head (8 mm)	Cylinder	2.5	18.0
Cylinder Head Cover	Cylinder Head	1.0	7.0
Driven Pulley Nut**	Fixed Face	10.4-11.8	75.0-85.0
Fixed Driven	Clutch Shaft	10.4-11.8	75.0-85.0
Ground Wire	Engine	1.1	8.0
Magneto Cover	Crankcase	1.1	8.0
Mechanical Water Pump Impeller	Pump Shaft	1.05	7.5
Movable Drive Face**	Driveshaft	10.4-11.8	75.0-85.0
Oil Pump Drive Gear	Crank Balancer Shaft	5.0	36.0
Output Shaft Gear	Output Shaft	10.0	72.0
Recoil Starter	Left-Side Cover	0.8	6.0
Rotor/Flywheel Nut	Crankshaft	16.0	116.0
Cam Sprocket**	Camshaft	1.5	11.0
Starter Cup	Crankshaft	3.5	25.0
V-Belt Cover	Crankcase	1.1	8.0
Spark Plug	Engine	1.7	12.0

* w/Blue Loctite #243

** w/Red Loctite #271

*** w/Green Loctite #609

**ENGINE/TRANSMISSION
(650 H1)**

Part	Part Bolted To	Torque	
		kg-m	ft-lb
Clutch Shoe	Crankshaft	31.8	230.0
Clutch Cover/Housing Assembly	Crankcase	1.1	8.0
Crankcase Half (6 mm)	Crankcase Half	0.9-1.3	6.5-9.5
Crankcase Half (8 mm)	Crankcase Half	2.8	20.0
Cylinder Head (Cap Screw)	Crankcase	5.5	40.0
Cylinder Head (6 mm)	Cylinder	1.1	8.0
Cylinder Head (8 mm)	Cylinder	2.5	18.0
Cylinder Head Cover	Cylinder Head	1.1-1.2	8.0-9.0
Driven Pulley Nut	Fixed Face	13.5	97.5
Fixed Driven**	Clutch Shaft	13.5	97.5
Ground Wire	Engine	1.1	8.0
Magneto Cover	Crankcase	1.1	8.0
Mechanical Water Pump Impeller	Pump Shaft	1.05	7.5
Movable Drive Face**	Driveshaft	10.4-11.8	75-85
Oil Pump Drive Gear	Crank Balancer Shaft	8.5	61.5
Output Shaft Gear	Output Shaft	8.5	61.5
Outer Magneto Cover	Left-Side Cover	0.8	6.0
Recoil Starter (Certain 650 H1 Models)	Left-Side Cover	0.8	6.0
Rotor/Flywheel Nut	Crankshaft	14.5	105.0
Cam Sprocket**	Camshaft	1.35	9.8
Starter Cup/Spacer	Crankshaft	3.8	27.5
V-Belt Cover	Crankcase	1.1	8.0
Spark Plug	Engine	1.7	12.0

* w/Blue Loctite #243

** w/Red Loctite #271

*** w/Green Loctite #609

**Torque Specifications
(700 EFI)**

DRIVE TRAIN COMPONENTS			
Part	Part Bolted To	Torque	
		kg-m	ft-lb
Engine Mounting Through-Bolt	Frame	5.5	40.0
Engine Mount (Rear)	Frame	5.5	40.0
Front Differential****	Frame/Differential Bracket	6.2	45.0
Rear Drive Gear Case	Frame	6.2	45.0
Pinion Housing	Differential Housing	2.9-3.5	21.0-25.0
Differential Housing Cover***	Differential Housing	2.9-3.5	21.0-25.0
Drive Bevel Gear Nut***	Shaft	11.0-13.0	79.5-94.0
Lock Collar	Differential Housing	17.3	125.0
Hub Nut	Shaft/Axle (max)	27.6	200.0
Oil Drain Plug	Front Differential/Rear Drive	0.5	3.5
Oil Fill Plug	Front Differential/Rear Drive	2.2	16.0
Oil Drain Plug	Engine	2.2	16.0
Inspection Plug	Front Differential	0.5	3.5
Wheel	Hub	5.5	40.0
EXHAUST COMPONENTS			
Muffler	Frame	2.8	20.0
Exhaust Pipe	Cylinder Head	1.9	14.0
ELECTRICAL COMPONENTS			
Coil****	Frame	1.7	12.0
Ground Wire	Engine	1.1	8.0
STEERING COMPONENTS			
Handlebar Block	Steering Post	2.8	20.0
Steering Post Bearing Housing	Frame	2.8	20.0
Steering Post Bearing Flange	Frame	2.8	20.0
Lower Steering Bearing Washer Cap Screw***	Steering Post	5.5	40.0
Tie Rod End	Knuckle/Steering Post	4.2	30.0

BRAKE COMPONENTS			
Part	Part Bolted To	Torque	
		kg-m	ft-lb
Brake Disc****	Hub	2.1	15.0
Brake Hose	Caliper	2.8	20.0
Brake Hose	Master Cylinder	2.8	20.0
Brake Hose	Auxiliary Brake Cylinder	2.8	20.0
Master Cylinder Cover	Master Cylinder	0.1	1.0
Auxiliary Brake Pedal	Lever Axle	3.5	25.0
Hydraulic Caliper	Suspension Knuckle	2.8	20.0
CHASSIS COMPONENTS			
Footrest	Frame (8 mm)	2.8	20.0
Footrest	Frame (10 mm)	5.5	40.0
Shift Lever****	Shift Axle	1.1	8.0
SUSPENSION COMPONENTS (Front)			
A-Arm	Frame	4.8	35.0
Ball Joint Cap Screw	Knuckle	4.8	35.0
Shock Absorber	Frame	4.8	35.0
Shock Absorber	Upper A-Arm	4.8	35.0
Knuckle	A-Arm	4.8	35.0
SUSPENSION COMPONENTS (Rear)			
A-Arm	Frame	5.5	40.0
Shock Absorber (Upper)	Frame	4.8	35.0
Shock Absorber (Lower)	Lower A-Arm	2.8	20.0
Knuckle	A-Arm	4.8	35.0

ENGINE/TRANSMISSION			
Clutch Shoe	Crankshaft	15.0	108.0
Clutch Cover/Housing Assembly	Crankcase	0.9	6.5
Crankcase Half (6 mm)	Crankcase Half	1.0	7.0
Crankcase Half (8mm)	Crankcase Half	2.6	19.0
Cylinder Head (Cap Screw)	Crankcase (Step 1) (Step 2)	2.5 3.7	18.0 27.0
Cylinder Head (6 mm)	Cylinder	1.0	7.0
Cylinder Head Cover	Cylinder (Step 1) Head (Step 2)	1.0 1.4	7.0 10.0
Driven Pulley Nut	Fixed Face	10.9	79.0
Fixed Driven**	Clutch Shaft	10.9	79.0
Ground Wire	Engine	1.1	8.0
Magneto Cover	Crankcase	1.1	8.0
Movable Drive Face**	Driveshaft	10.9	79.0
Oil Pump Drive Gear	Crank Balancer Shaft	15.0	108.0
Output Shaft Gear	Output Shaft	10.0	72.0
Recoil Starter	Left-Side Cover	0.8	6.0
Rotor/Flywheel Nut	Crankshaft	16.0	116.0
Cam Idler Shaft	Cylinder Head	4.1	29.5
Starter Cup	Crankshaft	3.8	27.5
V-Belt Cover	Crankcase	0.9	6.5
Spark Plug	Engine	1.1	8.0

* w/Blue Loctite #242


** w/Red Loctite #271

*** w/Green Loctite #609

****w/Blue Loctite #243

Tightening Torque (General Bolts)

Type of Bolt	Thread Diameter A (mm)	Tightening Torque	
		kg-m	ft-lb
(Conventional or 4 Marked Bolt)	5	0.2-0.4	1.5-3.0
	6	0.4-0.7	3.0-5.0
	8	1.0-1.6	7.0-11.5
	10	2.2-3.5	16.0-25.5
(7 Marked Bolt)	5	0.3-0.6	2.0-4.5
	6	0.8-1.2	6.0-8.5
	8	1.8-2.8	13.0-20.0
	10	4.0-6.0	29.0-43.5



Torque Conversions

ft-lb	kg-m								
1	0.1	21	2.9	41	5.7	61	8.4	81	11.2
2	0.3	22	3.0	42	5.8	62	8.6	82	11.3
3	0.4	23	3.2	43	5.8	63	8.7	83	11.5
4	0.6	24	3.3	44	6.1	64	8.9	84	11.6
5	0.7	25	3.5	45	6.2	65	9.0	85	11.8
6	0.8	26	3.6	46	6.4	66	9.1	86	11.9
7	1.0	27	3.7	47	6.5	67	9.3	87	12.0
8	1.1	28	3.9	48	6.6	68	9.4	88	12.2
9	1.2	29	4.0	49	6.8	69	9.5	89	12.3
10	1.4	30	4.2	50	6.9	70	9.7	90	12.5
11	1.5	31	4.3	51	7.1	71	9.8	91	12.6
12	1.7	32	4.4	52	7.2	72	10.0	92	12.8
13	1.8	33	4.6	53	7.3	73	10.1	93	12.9
14	1.9	34	4.7	54	7.5	74	10.2	94	13.0
15	2.1	35	4.8	55	7.6	75	10.4	95	13.1
16	2.2	36	5.0	56	7.7	76	10.5	96	13.3
17	2.4	37	5.1	57	7.9	77	10.7	97	13.4
18	2.5	38	5.3	58	8.0	78	10.8	98	13.6
19	2.6	39	5.4	59	8.2	79	10.9	99	13.7
20	2.8	40	5.5	60	8.3	80	11.1	100	13.8

SECTION 11 - TROUBLESHOOTING

TABLE OF CONTENTS

Engine	11-2
Drive	11-5
Fuel System (400/500/650 H1)	11-6
Fuel System (700 EFI)	11-6
Electrical.....	11-7
Steering/Suspension	11-9
Brakes	11-10

Engine

■ NOTE: A Condition/Remedy marked with an asterisk (*) is for manual transmission models only.

Problem: Engine will not start or is hard to start (Compression too low)

Condition	Remedy
1. Valve clearance out of adjustment	1. Adjust clearance
2. Valve guides worn - seated poorly	2. Repair - replace guides
3. Valves mistimed	3. Adjust valve timing
4. Piston rings worn excessively	4. Replace rings
5. Cylinder bore worn	5. Replace - rebore cylinder
6. Spark plug seating poorly	6. Tighten plug
7. Starter motor cranks too slowly - does not turn	7. See Electrical in this section

Problem: Engine will not start or is hard to start (No spark)

Condition	Remedy
1. Spark plug fouled	1. Clean - replace plug
2. Spark plug wet	2. Clean - dry plug
3. Magneto defective	3. Replace magneto
4. CDI unit/ECU defective	4. Replace CDI unit/ECU
5. Ignition coil defective	5. Replace ignition coil
6. High-tension lead open - shorted	6. Replace high tension lead

Problem: Engine will not start or is hard to start (No fuel reaching the carburetor/fuel injector)

Condition	Remedy
1. Gas tank vent hose obstructed	1. Clean vent hose
2. Carburetor float valve defective	2. Replace valve
3. Fuel hose obstructed	3. Clean - replace hose
4. Fuel screens obstructed	4. Clean - replace inlet screen - valve screen
5. Fuel pump defective	5. Replace fuel pump

Problem: Engine stalls easily

Condition	Remedy
1. Spark plug fouled	1. Clean plug
2. Magneto defective	2. Replace magneto
3. CDI unit/ECU defective	3. Replace CDI unit/ECU
4. Carburetor jets/fuel injector obstructed	4. Clean jets/replace fuel injector
5. Valve clearance out of adjustment	5. Adjust clearance

Problem: Engine noisy (Excessive valve chatter)

Condition	Remedy
1. Valve clearance too large	1. Adjust clearance
2. Valve spring(s) weak - broken	2. Replace spring(s)
3. Rocker arm - rocker arm shaft worn	3. Replace arm - shaft
4. Camshaft worn	4. Replace camshaft
5. Valve tappets worn	5. Replace tappets

Problem: Engine noisy (Noise seems to come from piston)

Condition	Remedy
1. Piston - cylinder worn	1. Replace - service piston - cylinder
2. Combustion chamber carbon buildup	2. Clean chamber
3. Piston pin - piston pin bore worn	3. Replace - service pin - bore
4. Piston rings - ring groove(s) worn	4. Replace rings - piston

Problem: Engine noisy (Noise seems to come from timing chain)

Condition	Remedy
1. Chain stretched	1. Replace chain
2. Sprockets worn	2. Replace sprockets
3. Tension adjuster malfunctioning	3. Repair - replace adjuster

Problem: Engine noisy (Noise seems to come from clutch)

Condition *	Remedy *
1. Crankshaft splines - bearings worn 2. Countershaft - hub splines worn 3. Clutch plate teeth worn 4. Driven - drive clutch plates distorted - broken 5. Clutch dampers weak	1. Replace crankshaft - bearings 2. Replace countershaft - hub 3. Replace clutch plate(s) 4. Replace clutch plate(s) 5. Replace dampers

Problem: Engine noisy (Noise seems to come from crankshaft)

Condition	Remedy
1. Bearing worn - burned 2. Lower rod-end bearing worn - burned 3. Connecting rod side clearance too large	1. Replace bearing 2. Replace bearing 3. Replace thrust washer(s)

Problem: Engine noisy (Noise seems to come from transmission)

Condition	Remedy
1. Gears worn - rubbing 2. Splines worn 3. Primary gears worn - rubbing 4. Bearings worn 5. Bushing worn	1. Replace gears 2. Replace shaft(s) 3. Replace gears 4. Replace bearings 5. Replace bushing

Problem: Engine noisy (Noise seems to come from secondary-transmission/left-side cover)

Condition *	Remedy *
1. Gears - shaft(s) worn 2. Bearing(s)/bushing(s) damaged	1. Replace gears - shafts 2. Replace bearing(s)/bushing(s)

Problem: Engine noisy (Noise seems to come from secondary bevel gear and final driven shaft)

Condition	Remedy
1. Drive - driven bevel gears damaged - worn 2. Backlash excessive 3. Tooth contact improper 4. Bearing damaged 5. Gears worn - rubbing 6. Splines worn 7. Final driven shaft thrust clearance too large	1. Replace gears 2. Adjust backlash 3. Adjust contact 4. Replace bearing 5. Replace gears 6. Replace shaft(s) 7. Replace thrust washer(s)

Problem: Clutch slipping

Condition *	Remedy *
1. Release roller out of adjustment - loss of free-play 2. Clutch springs weak 3. Clutch shoes worn 4. Pressure disc worn - distorted 5. Clutch plates (driven - drive) distorted	1. Adjust clutch bolts 1 & 2 2. Replace springs 3. Replace shoes 4. Replace disc 5. Replace plates

Problem: Clutch dragging

Condition *	Remedy *
1. Clutch release roller out of adjustment - too much free-play 2. Clutch springs weak 3. Pressure disc - clutch plates distorted 4. Clutch release mechanism worn - damaged	1. Adjust clutch bolts 1 & 2 2. Replace springs 3. Replace disc - plates 4. Adjust - replace mechanism

Problem: Transmission will not shift

Condition *	Remedy *
1. Gearshift cam broken 2. Gearshift forks distorted 3. Gearshift shaft worn 4. Clutch release mechanism worn - damaged 5. Gearshift linkage adjusted improperly	1. Replace cam 2. Replace forks 3. Replace shaft 4. Adjust - replace mechanism 5. Adjust linkage

Problem: Transmission will not shift back	
Condition *	Remedy *
<ol style="list-style-type: none"> 1. Reverse shift cam broken 2. Shift shafts rubbing - sticking 3. Gearshift forks distorted - worn 4. Gearshift lever return spring broken - damaged 	<ol style="list-style-type: none"> 1. Replace cam 2. Replace shafts 3. Replace forks 4. Replace spring
Problem: Transmission jumps out of gear	
Condition *	Remedy *
<ol style="list-style-type: none"> 1. Shifting gears (driveshaft - countershaft) worn 2. Gearshift forks distorted - worn 3. Cam stopper spring (gearshift cam) weak 4. Gearshift lever stopper pin worn 	<ol style="list-style-type: none"> 1. Replace gears 2. Replace forks 3. Replace spring 4. Replace pin
Problem: Secondary-transmission will not shift or shift back	
Condition *	Remedy *
<ol style="list-style-type: none"> 1. Sliding dog broken - worn 2. Gearshift fork broken - worn 3. Shift lever out of adjustment 4. Gearshift cam worn 5. Cam stopper spring weak 6. Gearshift fork shaft worn 	<ol style="list-style-type: none"> 1. Replace dog 2. Replace fork 3. Adjust lever 4. Replace cam 5. Replace spring 6. Replace shaft
Problem: Engine idles poorly	
Condition	Remedy
<ol style="list-style-type: none"> 1. Valve clearance out of adjustment 2. Valve seating poor 3. Valve guides defective 4. Rocker arms - arm shaft worn 5. Magneto defective 6. CDI unit/ECU defective 7. Spark plug fouled - gap too wide 8. Ignition coil defective 9. Float out of adjustment 10. Jets obstructed 11. Pilot screw setting improper 12. Fuel injector obstructed 	<ol style="list-style-type: none"> 1. Adjust clearance 2. Replace - service seats - valves 3. Replace guides 4. Replace arms - shafts 5. Replace magneto 6. Replace CDI unit/ECU 7. Adjust gap - replace plug 8. Replace ignition coil 9. Adjust float height 10. Clean jets 11. Adjust pilot screw 12. Replace fuel injector
Problem: Engine runs poorly at high speed	
Condition	Remedy
<ol style="list-style-type: none"> 1. High RPM "cut out" against RPM limiter 2. Valve springs weak 3. Valve timing out of adjustment 4. Cams - rocker arms - tappets worn 5. Spark plug gap too narrow 6. Ignition coil defective 7. Float level too low 8. Air cleaner element obstructed 9. Fuel hose obstructed 10. Fuel pump defective 	<ol style="list-style-type: none"> 1. Shift into higher gear - decrease speed 2. Replace springs 3. Adjust timing 4. Replace cams - arms - tappets 5. Adjust gap 6. Replace ignition oil 7. Adjust float height 8. Clean element 9. Clean or replace hose 10. Replace fuel pump
Problem: Exhaust smoke dirty or heavy	
Condition	Remedy
<ol style="list-style-type: none"> 1. Oil (in the engine) overfilled - contaminated 2. Piston rings - cylinder worn 3. Valve guides worn 4. Cylinder wall scored - scuffed 5. Valve stems worn 6. Stem seals defective 	<ol style="list-style-type: none"> 1. Drain excess oil - replace oil 2. Replace - service rings - cylinder 3. Replace guides 4. Replace - service cylinder 5. Replace valves 6. Replace seals



Problem: Engine lacks power	
Condition	Remedy
<ol style="list-style-type: none"> 1. Valve clearance incorrect 2. Valve springs weak 3. Valve timing incorrect 4. Piston ring(s) - cylinder worn 5. Valve seating poor 6. Spark plug fouled 7. Rocker arms - shafts worn 8. Spark plug gap incorrect 9. Carburetor jets/fuel injector obstructed 10. Float level out of adjustment 11. Air cleaner element obstructed 12. Oil (in the engine) overfilled - contaminated 13. Intake manifold leaking air 14. Cam chain worn 	<ol style="list-style-type: none"> 1. Adjust clearance 2. Replace springs 3. Re-time valve gear 4. Replace - service rings - cylinder 5. Repair seats 6. Clean - replace plug 7. Replace arms - shafts 8. Adjust gap - replace plug 9. Clean jets - replace injector 10. Adjust float height 11. Clean element 12. Drain excess oil - change oil 13. Tighten - replace manifold 14. Replace cam chain

Problem: Engine overheats	
Condition	Remedy
<ol style="list-style-type: none"> 1. Carbon deposit (piston crown) excessive 2. Oil low 3. Octane low - gasoline poor 4. Oil pump defective 5. Oil circuit obstructed 6. Gasoline level (in float chamber) too low 7. Intake manifold leaking air 8. Coolant level low 9. Fan malfunctioning 10. Fan switch malfunctioning 11. Thermostat stuck - closed 12. Radiator hoses - cap damaged - obstructed 	<ol style="list-style-type: none"> 1. Clean piston 2. Add oil 3. Drain - replace gasoline 4. Replace pump 5. Clean circuit 6. Adjust float height 7. Tighten - replace manifold 8. Fill - examine system for leaks 9. Check fan fuse - replace fan 10. Replace fan switch 11. Replace thermostat 12. Clear obstruction - replace hoses

Drive

Problem: Power not transmitted from engine to wheels	
Condition	Remedy
1. Rear axle shaft serration worn - broken	1. Replace shaft

Problem: Power not transmitted from engine to either front wheel	
Condition	Remedy
<ol style="list-style-type: none"> 1. Secondary drive - driven gear teeth broken 2. Propeller shaft serration worn - broken 3. Coupling damaged 4. Coupling joint serration worn - damaged 5. Front drive - driven bevel gears broken - damaged 6. Front differential gears/pinions broken - damaged 7. Sliding dog/shaft/fork worn - damaged 8. Front drive axle worn - damaged 9. Front drive axle serration worn - damaged 	<ol style="list-style-type: none"> 1. Replace gear(s) 2. Replace shaft 3. Replace coupling 4. Replace joint 5. Replace gear(s) 6. Replace gears - pinions 7. Replace gear(s) 8. Replace axle 9. Replace axle

Fuel System

(400/500/650 H1)

Problem: Starting impaired	
Condition	Remedy
1. Starter jet obstructed 2. Starter jet passage obstructed 3. Carburetor leaking air 4. Gas contaminated	1. Clean jet 2. Clean passage 3. Replace gasket 4. Drain gas tank and fill with clean gas
Problem: Idling or low speed impaired	
Condition	Remedy
1. Slow jet obstructed - loose 2. Slow jet outlet obstructed 3. Low speed fuel screw setting incorrect 4. Float height incorrect 5. TPS out of adjustment	1. Clean - tighten jet 2. Clean outlet 3. Adjust screw 4. Adjust float height 5. Adjust TPS
Problem: Medium or high speed impaired	
Condition	Remedy
1. High RPM "cut out" against RPM limiter 2. Main jet obstructed 3. Needle jet obstructed 4. Vacuum piston not operating properly 5. Filter obstructed 6. Float height incorrect	1. Shift into higher gear - decrease RPM speed 2. Clean main jet 3. Clean needle jet 4. Check piston operation 5. Clean filter 6. Adjust float height
Problem: Overflow and fuel level fluctuations	
Condition	Remedy
1. Float valve worn - damaged 2. Float valve spring broken 3. Float not working properly 4. Float valve dirty 5. Float height too high - too low	1. Replace valve 2. Replace spring 3. Adjust float height - replace float 4. Clean valve 5. Adjust float height

Fuel System

(700 EFI)

Problem: Starting impaired	
Condition	Remedy
1. Gas contaminated	1. Drain gas tank and fill with clean gas
Problem: Idling or low speed impaired	
Condition	Remedy
1. TPS out of adjustment	1. Adjust TPS
Problem: Medium or high speed impaired	
Condition	Remedy
1. High RPM "cut out" against RPM limiter	1. Decrease RPM speed

Electrical

Problem: Spark absent or weak	
Condition	Remedy
1. Ignition coil defective 2. Spark plug defective 3. Magneto defective 4. CDI unit/ECU defective 5. Pick-up coil defective	1. Replace ignition coil 2. Replace plug 3. Replace magneto 4. Replace CDI unit/ECU 5. Replace pick-up coil
Problem: Spark plug fouled with carbon	
Condition	Remedy
1. Mixture too rich 2. Idling RPM too high 3. Gasoline incorrect 4. Air cleaner element dirty 5. Spark plug incorrect (too cold) 6. Valve seals cracked - missing 7. Oil rings worn - broken	1. Adjust carburetor 2. Adjust carburetor 3. Change to correct gasoline 4. Clean element 5. Replace plug 6. Replace seals 7. Replace rings
Problem: Spark plug electrodes overheat or burn	
Condition	Remedy
1. Spark plug incorrect (too hot) 2. Engine overheats 3. Spark plug loose 4. Mixture too lean	1. Replace plug 2. Service cooling system 3. Tighten plug 4. Adjust carburetor
Problem: Magneto does not charge	
Condition	Remedy
1. Lead wires/connections shorted - loose - open 2. Magneto coils shorted - grounded - open 3. Regulator/rectifier defective	1. Repair - replace - tighten lead wires 2. Replace magneto coils 3. Replace regulator/rectifier
Problem: Magneto charges, but charging rate is below the specification	
Condition	Remedy
1. Lead wires shorted - open - loose (at terminals) 2. Stator coils (magneto) grounded - open 3. Regulator/rectifier defective 4. Electrolyte low 5. Cell plates (battery) defective	1. Repair - tighten lead wires 2. Replace stator coils 3. Replace regulator/rectifier 4. Add distilled water 5. Replace battery
Problem: Magneto overcharges	
Condition	Remedy
1. Internal battery short circuited 2. Regulator/rectifier resistor damaged - defective 3. Regulator/rectifier poorly grounded	1. Replace battery 2. Replace resistor 3. Clean - tighten ground connection
Problem: Charging unstable	
Condition	Remedy
1. Lead wire intermittently shorting 2. Magneto internally shorted 3. Regulator/rectifier defective	1. Replace lead wire 2. Replace magneto 3. Replace regulator/rectifier

Problem: Starter button not effective

Condition	Remedy
1. Battery charge low 2. Switch contacts defective 3. Starter motor brushes not seating 4. Starter relay defective 5. Emergency stop - ignition switch off 6. Wiring connections loose - disconnected	1. Charge - replace battery 2. Replace switch 3. Repair - replace brushes 4. Replace relay 5. Turn on switches 6. Connect - tighten - repair connections

Problem: Battery "sulfation" (Acidic white powdery substance or spots on surfaces of cell plates)

Condition	Remedy
1. Charging rate too low - too high 2. Battery electrolyte insufficient 3. Specific gravity too low 4. Battery run-down - damaged 5. Electrolyte contaminated	1. Replace battery 2. Keep electrolyte to prescribed level 3. Charge battery - add distilled water 4. Replace battery 5. Replace battery

Problem: Battery discharges too rapidly

Condition	Remedy
1. Electrolyte contaminated 2. Specific gravity too low 3. Charging system not charging 4. Cell plates overcharged - damaged 5. Battery short-circuited 6. Specific gravity too low	1. Replace battery 2. Charge battery - add distilled water 3. Check magneto - regulator/rectifier - circuit connections 4. Replace battery - correct charging system 5. Replace battery 6. Charge battery

Problem: Battery polarity reversed

Condition	Remedy
1. Battery incorrectly connected	1. Reverse connections - replace battery - repair damage

Steering/Suspension

Problem: Handling too heavy or stiff	
Condition	Remedy
1. Front wheel alignment incorrect 2. Lubrication inadequate 3. Tire inflation pressure low 4. Tie rod ends seizing 5. Linkage connections seizing	1. Adjust alignment 2. Lubricate appropriate components 3. Adjust pressure 4. Replace tie rod ends 5. Repair - replace connections
Problem: Steering oscillation	
Condition	Remedy
1. Tires inflated unequally 2. Wheel(s) wobbly 3. Wheel hub cap screw(s) loose - missing 4. Wheel hub bearing worn - damaged 5. Tie rod ends worn - loose 6. Tires defective - incorrect 7. A-arm bushings damaged 8. Bolts - nuts (frame) loose	1. Adjust pressure 2. Replace wheel(s) 3. Tighten - replace cap screws 4. Replace bearing 5. Replace - tighten tie rod ends 6. Replace tires 7. Replace bushings 8. Tighten bolts - nuts
Problem: Steering pulling to one side	
Condition	Remedy
1. Tires inflated unequally 2. Front wheel alignment incorrect 3. Wheel hub bearings worn - broken 4. Frame distorted 5. Shock absorber defective	1. Adjust pressure 2. Adjust alignment 3. Replace bearings 4. Repair - replace frame 5. Replace shock absorber
Problem: Tire wear rapid or uneven	
Condition	Remedy
1. Wheel hub bearings worn - loose 2. Front wheel alignment incorrect 3. Tire inflation pressure incorrect	1. Replace bearings 2. Adjust alignment 3. Adjust pressure
Problem: Steering noise	
Condition	Remedy
1. Caps screws - nuts loose 2. Wheel hub bearings broken - damaged 3. Lubrication inadequate	1. Tighten cap screws - nuts 2. Replace bearings 3. Lubricate appropriate components
Problem: Suspension too soft	
Condition	Remedy
1. Spring(s) weak 2. Shock absorber damaged 3. Shock absorber preload too low	1. Replace spring(s) 2. Replace shock absorber 3. Adjust shock absorber preload
Problem: Suspension too stiff	
Condition	Remedy
1. A-arm-related bushings worn 2. Shock absorber preload too high	1. Replace bushing 2. Adjust shock absorber preload
Problem: Suspension noisy	
Condition	Remedy
1. Cap screws (suspension system) loose 2. A-arm-related bushings worn	1. Tighten cap screws 2. Replace bushings

Problem: Rear wheel oscillation

Condition	Remedy
1. Rear wheel hub bearings worn - loose	1. Replace bearings
2. Tires defective - incorrect	2. Replace tires
3. Wheel rim distorted	3. Replace rim
4. Wheel hub cap screws loose	4. Tighten cap screws
5. Axle shaft nut loose (Manual Transmission)	5. Tighten nut (Manual Transmission)
6. Auxiliary brake adjusted incorrectly	6. Adjust brake
7. Rear suspension arm-related bushing worn	7. Replace bushing
8. Rear shock absorber damaged	8. Replace shock absorber
9. Rear suspension arm nut loose	9. Tighten nut

Brakes

Problem: Braking poor

Condition	Remedy
1. Pad worn	1. Replace pads
2. Pedal free-play excessive	2. Replace pads
3. Brake fluid leaking	3. Repair - replace hydraulic system component(s)
4. Hydraulic system spongy	4. Bleed hydraulic system - correct or repair leaks
5. Master cylinder/brake cylinder seal worn	5. Replace master cylinder

Problem: Brake lever travel excessive

Condition	Remedy
1. Hydraulic system entrapped air	1. Bleed hydraulic system
2. Brake fluid low	2. Add fluid to proper level
3. Brake fluid incorrect	3. Drain system - replace with correct fluid
4. Piston seal - cup worn	4. Replace master cylinder

Problem: Brake fluid leaking

Condition	Remedy
1. Connection joints loose	1. Tighten joint
2. Hose cracked	2. Replace hose
3. Piston seal worn	3. Replace brake caliper