


SERVICE MANUAL



PROWLER® XT™



www.arcticcat.com

FOREWORD

This Arctic Cat Service Manual contains service, maintenance, and troubleshooting information for certain 2015 Arctic Cat ROV (Recreational Off-Highway Vehicle) models (see cover). The complete manual is designed to aid service personnel in service-oriented applications.

This manual is divided into sections. Each section covers a specific vehicle component or system and, in addition to the standard service procedures, includes disassembling, inspecting, and assembling instructions. When using this manual as a guide, the technician should use discretion as to how much disassembly is needed to correct any given condition.

This service manual is designed primarily for use by an Arctic Cat CatMaster Basic Level technician. The procedures found in this manual are of varying difficulty, and certain service procedures in this manual require one or more special tools to be completed. The technician should use sound judgement when determining which procedures can be completed based on their skill level and access to appropriate special tools.

All Arctic Cat publications and decals display the words Warning, Caution, Note, and At This Point to emphasize important information. The symbol  **WARNING** identifies personal safety-related information. Be sure to follow the directive because it deals with the possibility of serious personal injury or even death. A **CAUTION** identifies unsafe practices which may result in vehicle-related damage. Follow the directive because it deals with the possibility of damaging part or parts of the vehicle. The symbol  **NOTE:** identifies supplementary information worthy of particular attention. The symbol  **AT THIS POINT** directs the technician to certain and specific procedures to promote efficiency and to improve clarity.

At the time of publication, all information, photographs, and illustrations were technically correct. Some photographs used in this manual are used for clarity purposes only and are not designed to depict actual conditions. Because Arctic Cat Inc. constantly refines and improves its products, no retroactive obligation is incurred.

All materials and specifications are subject to change without notice.

Keep this manual accessible in the shop area for reference.

**Product Service and
Warranty Department
Arctic Cat Inc.**

TABLE OF CONTENTS

General Information.....	2	Radiator	141
General Specifications	2	Thermostat (550/700)	142
Torque Specifications	3	Thermostat (1000)	142
Torque Conversions (ft-lb/N-m)	4	Fan.....	143
Gasoline - Oil - Lubricant	4	Water Pump (550/700)	143
Genuine Parts	5	Water Pump (1000)	144
Preparation For Storage.....	5	Troubleshooting	145
Preparation After Storage	6		
Periodic Maintenance	7		
Periodic Maintenance Chart.....	7	Electrical System	146
Lubrication Points.....	8	Battery	146
Air Filter.....	8	Switches	147
Valve/Tappet Clearance	8	Accessory Receptacle/Connector	147
Testing Engine Compression	9	Brakelight Switch	147
Spark Plug(s)	10	Engine Coolant Temperature (ECT) Sensor.....	148
Muffler/Spark Arrester.....	10	Fan Motor	148
Engine/Transmission Oil - Filter	11	Power Distribution Module (PDM).....	148
Front Differential - Rear Drive Lubricant	12	Ignition Coil	149
Driveshaft/Coupling.....	12	EFI Sensors/Components	150
Nuts/Bolts/Cap Screws	12	Speed Sensor.....	150
Headlight/Taillight - Brakelight.....	12	RPM Limiter.....	151
Shift Lever/Shift Cable	13	Electronic Power Steering (EPS).....	152
Hydraulic Brake System.....	14	Ignition Switch	153
Burnishing Brake Pads.....	15	Headlight Switch.....	154
Checking/Replacing V-Belt.....	16	Drive Select Switch.....	154
Steering/Frame/Controls	18	Reverse Override Switch	154
Steering Wheel	18	Front Drive Actuator.....	155
Steering System.....	18	Stator Coil.....	155
Steering Knuckles	22	Starter Motor	156
Front Wheel Alignment.....	24	Starter Relay.....	156
Hood	25	Electronic Control Module (ECM)	157
Fenders	25	Fuel Pump/Fuel Level Sensor	157
Floor	26	Regulator/Rectifier	158
Belly Panel	27	Headlights.....	159
Accelerator Pedal.....	27	Taillight - Brakelight.....	159
Shift Lever	28	Ignition Timing	159
LCD Gauge	28	Tilt Sensor	160
Exhaust System.....	28	Throttle Position Sensor (TPS)	161
Cargo Box	29	EFI Diagnostic System	161
Taillight Assembly.....	29	Troubleshooting	165
Seats	29		
Troubleshooting.....	30	Drive System	167
Engine/Transmission	31	Front Drive Actuator.....	167
Troubleshooting.....	32	Front Differential	168
Prowler 550/700 (Table of Contents).....	34	Drive Axles	180
Prowler 1000 (Table of Contents).....	78	Rear Gear Case	183
Fuel/Lubrication/Cooling.....	135	Hub	186
Throttle Body (550/700)	135	Hydraulic Brake Caliper	188
Throttle Body (1000)	136	Universal Joints (1000)	192
Gas Tank	137	Troubleshooting Drive System	195
Gas/Vent Hoses	139	Troubleshooting Brake System	195
Oil Filter/Oil Pump.....	139		
Oil Cooler (1000).....	140		
Liquid Cooling System	141	Suspension.....	196
		Shock Absorbers	196
		Front A-Arms	197
		Rear A-Arms	199
		Wheels and Tires.....	200
		Troubleshooting	201

General Information

■NOTE: Some photographs and illustrations used in this section are used for clarity purposes only and are not designed to depict actual conditions.

■NOTE: Whenever a part is worn excessively, cracked, or damaged in any way, replacement is necessary.

General Specifications

CHASSIS	
Dry Weight (approx)	558 kg (1230 lb) - 550 567 kg (1251 lb) - 700 596 kg (1315 lb) - 1000
ROPS Tested Curb Weight	645 kg (1428 lb)
Length (overall)	301.5 cm (118.7 in.)
Height (overall)	201 cm (79 in.)
Width (overall)	156.2 cm (61.5 in.)
Tire Size (550/700)	26 x 9R-14 (front) 26 x 11R-14 (rear)
Tire Size (1000)	27 x 9R-14 (front) 27 x 11R-14 (rear)
Tire Inflation Pressure	0.84-1.41 kg/cm ² (12-20 psi)
MISCELLANY	
Spark Plug Type	NGK CPR8E
Spark Plug Gap	0.5-0.6 mm (0.019-0.024 in.)
Gas Tank Capacity	31 L (8.2 U.S. gal.)
Coolant Capacity	2.9 L (3.0 U.S. qt) - 550/700 3.3 L (3.5 U.S. qt) - 1000
Front Differential Capacity	275 ml (9.3 fl oz)*
Rear Drive Capacity	250 ml (8.5 fl oz)*
Engine Oil Capacity (550/700)	2.5 L (2.6 U.S. qt) - Overhaul 1.9 L (2.0 U.S. qt) - Change
Engine Oil Capacity (1000)	3.3 L (3.5 U.S. qt) - Overhaul 2.8 L (3.0 U.S. qt) - Change
Gasoline (recommended)	87 Octane Regular Unleaded
Engine Oil (recommended)	Arctic Cat ACX All Weather Synthetic
Front Differential/Rear Drive Lubricant	SAE Approved 80W-90 Hypoid
Belt Width	35.0 mm (1.38 in.)
Brake Fluid	DOT 4
Taillight/Brakelight	12V/8W/27W
Headlight	12V/60W/55W
ELECTRICAL SYSTEM	
Spark Plug Cap	5000 ohms
Ignition Coil Resistance (primary)	Less than 1 ohm - 550/700
(secondary)	4.8 ohms - 1000 12k-19k ohms
Ignition Coil Primary Voltage	Battery Voltage
Stator Coil (crankshaft position sensor) Resistance (AC generator)	104-156 ohms Less than 1 ohm
Crankshaft Position Sensor AC Voltage	2.0 or more
AC Generator Output (no load)	60 AC volts @ 5000 RPM - 550/700 75 AC volts @ 5000 RPM - 1000
Ignition Timing	10° BTDC @ 1500 RPM

* Visible at plug threads.

VALVES AND GUIDES	
Valve Face Diameter	31.6 mm - intake 27.9 mm - exhaust
Valve/Tappet Clearance (cold engine) (max)	0.1016 mm - intake 0.1524 mm - exhaust
Valve Guide/Stem Clearance (max)	0.013 mm
Valve Guide Inside Diameter	5.000-5.012 mm
Valve Head Thickness (min)	2.3 mm
Valve Seat Angle	45° +15°/+30°
Valve Spring Free Length (min)	38.7 mm
Valve Spring Tension @ 31.5 mm	16.0 kg (36 lb)
CAMSHAFT AND CYLINDER HEAD	
Cam Lobe Height (min) (Ex/In)	33.60 mm - 550/700 33.40 mm - 1000 33.53 mm - 1000
Cam Lobe Height (max) (Ex)	33.40 mm - 1000
Cam Lobe Height (max) (In)	33.53 mm - 1000
Camshaft Journal Oil Clearance (max)	0.04 mm
Camshaft Journal Holder Inside Diameter (right & center) (left)	21.98-22.04 mm 17.48-17.53 mm
Camshaft Journal Outside Diameter (right & center) (left)	21.96-21.98 mm - 550/700 21.94-21.98 - 1000 17.48-17.53 mm - 550/700 17.44-17.48 - 1000
Camshaft Runout (max)	0.05 mm
Cylinder Head/Cover Distortion (max)	0.05 mm
CYLINDER, PISTON, AND RINGS	
Piston Skirt/Cylinder Clearance	0.025-0.075 mm
Cylinder Bore	91.995-92.005 mm - 550 101.992-102.008 mm - 700 91.992-92.008 mm - 1000
Piston Diameter 15 mm from Skirt End	92.940-92.975 mm - 550/1000 101.940-101.985 mm - 700
Piston Ring Free End Gap (min) (1st/2nd)	12.5 mm
Bore x Stroke	92 x 82 mm - 550 102 x 85 mm - 700 92 x 71.6 mm - 1000
Cylinder Trueness (max)	0.02 mm
Piston Ring End Gap - Installed	0.38 mm
Piston Ring to Groove Clearance (max)	0.35 mm
Piston Ring Groove Width (1st/2nd) (oil)	1.202-1.204 mm 2.01-2.03 mm - 550/700 2.501-2.503 mm - 1000
Piston Ring Thickness (1st/2nd)	1.970-1.990 mm - 550/700 1.170-1.195 mm - 1000
Piston Pin Bore (max)	23.012 mm - 550/700 20.012 mm - 1000
Piston Pin Outside Diameter (min)	22.99 mm - 550/700 19.995 mm - 1000
CRANKSHAFT	
Connecting Rod (small end inside diameter) (max)	23.021 mm - 550/700 20.021 mm - 1000
Connecting Rod (big end side-to-side)	0.6 mm - 550/700 0.95 mm - 1000
Connecting Rod (small end deflection) (max)	0.3 mm
Crankshaft (web-to-web)	71 mm - 550/700 98 mm - 1000
Crankshaft Runout (max)	0.03 mm
Oil Pump Gerotor Clearance (1000) (max)	0.15 mm

Specifications subject to change without notice.

Torque Specifications

■NOTE: Torque specifications have the following tolerances:

Torque (ft-lb)	Tolerance
0-15	±20%
16-39	±15%
40+	±10%

MISCELLANEOUS COMPONENTS			
Part	Part Bolted To	Torque ft-lb N-m	
Exhaust Pipe	Cylinder Head	20	27
O2 Sensor	Exhaust Pipe	20	27
Spark Arrester	Muffler	50 in.-lb	5
Voltage Regulator	Storage Box	8	11
Coolant Bottle	Storage Box	48 in.-lb	5
Radiator	Frame	8	11
Ground Wire	Engine	8	11
Coil	Mount	6 in.-lb	1
BRAKE COMPONENTS			
Brake Disc*	Hub	15	20
Brake Hose	Caliper	20	27
Brake Hose	Master Cylinder	20	27
Master Cylinder	Frame	25	34
Caliper Holder***	Knuckle	20	27
Brake Caliper***	Gear Case Housing	20	27
Brake Caliper	Rear Drive Housing	20	27
SUSPENSION COMPONENTS (Front)			
Upper A-Arm	Frame	40	54
Knuckle	Ball Joint	35	48
Shock Absorber	Frame/Upper A-Arm	35	48
Lower A-Arm	Frame	35	48
SUSPENSION COMPONENTS (Rear)			
Sway Bar Bracket (1000)	Frame	35	48
Sway Bar Bracket (550/700)	Frame	35	48
A-Arm	Frame	35	48
Shock Absorber (Lower) (1000)	Lower A-Arm	35	48
Shock Absorber (Lower) (550/700)	Lower A-Arm	20	27
Shock Absorber (Upper)	Frame	35	48
Knuckle	A-Arm	35	48
STEERING COMPONENTS			
Steering Wheel*	Upper Steering Shaft	25	34
Steering Wheel Shaft**	Intermediate Shaft	36	49
Rack and Pinion Assembly	Frame	35	48
Tie Rod* (550)	Rack	52	70
Tie Rod* (700/1000)	Rack	37	50
Tie Rod End*	Knuckle	30	41
Jam Nut	Tie Rod End	8	11
EPS Assembly (700/1000)	Frame	35	48
EPS Assembly (700/1000)	Rack Coupler	11	15
EPS Mounting Bracket	Frame	20	27
Intermediate Shaft Coupler	Intermediate Shaft	31	42
Intermediate Shaft** (550)	Steering Pinion Shaft	36	49
Intermediate Shaft (700/1000)	EPS Input Shaft	25	34
Steering Shaft Housing (700/1000)	Frame	20	27
Tilt Assembly	Steering Support	20	27

* w/Red Loctite #271

** w/Green Loctite #609

*** w/“Patch-Lock”

CHASSIS/ROPS ASSEMBLY			
Part	Part Bolted To	Torque ft-lb N-m	
Seat Base	Frame	6	8
Seat Belt Loop	ROPS	35	48
Seat Belt Buckle	Frame	60	81
Front ROPS Tube	Steering Support	35	48
Top ROPS Support	Front/Rear ROPS Tubes	35	48
Rear ROPS Tube	Lower ROPS Support	35	48
Cargo Box Hinge	Cargo Box Frame	20	27
Cargo Box	Cargo Box Frame	20	27
Latch Pivot Bushing	Cargo Box Frame	15	20
Latch Striker	Cargo Box Liner	60 in.-lb	7
DRIVE TRAIN COMPONENTS			
Rear Gear Case	Frame	38	48
Drive Coupler (Front) (550/700)	Drive Flange	20	27
Front Input Drive Flange (1000)	Front U-Joint	40	54
Driveline	Rear Drive Input Flange	20	27
Front Differential	Frame/Differential Bracket	38	52
Rear Output Flange	Rear U-Joint Flange	20	27
Input Shaft Assembly	Gear Case Housing	23	31
Pinion Housing	Differential Housing	23	31
Thrust Button	Gear Case Cover	9	12
Differential Housing Cover**	Differential Housing	23	31
Drive Bevel Gear Nut**	Shaft	87	118
Hub	Axle (min)	200	272
Oil Drain Plug	Front Differential - Rear Drive	45 in.-lb	5
Oil Fill Plug	Front Differential - Rear Drive	16	22
Wheel (Aluminum w/chrome nuts)	Hub	80	108
Wheel (Aluminum w/black nuts)	Hub	60	81
Wheel (Steel)	Hub	40	54
ENGINE/TRANSMISSION			
Clutch Shoe*	Crankshaft	221	300
Clutch Cover/Housing Assembly	Crankcase	9.5	13
Cylinder Head Nut (6 mm)	Cylinder	10	14
Cylinder Head Nut (8 mm)	Cylinder	18	25
Valve Cover	Cylinder Head	8.5	11.5
Driven Pulley Bolt (550)	Driveshaft	60	81
Driven Pulley Nut* (700/1000)	Driveshaft	162	220
Movable Drive Face Nut*	Driveshaft	162	220
Magneto Cover	Crankcase	9.5	13
Tappet Cover	Valve Cover	8.5	11.5
Crankshaft Spacer	Crankshaft	28	38
Oil Pump Cover*	Crankcase	8.5	11.5
Outer Magneto Cover	Magneto Cover	8.5	11.5
Cam Sprocket	Camshaft	10	14
Speed Sensor Housing	Crankcase	8.5	11.5
Clutch Cover	Crankcase	10	14
Oil Drain Plug	Engine	16	27
Shift Lever	Shift Axle Bracket	20	27
Intake Boot Clamp	Intake Boot	30 in.-lb	3.4
Intake Manifold	Engine	8	11
Oil Pump Drive Gear*	Crank Balancer Shaft	63	85
Starter Motor	Crankcase	10	14
Output Yoke Nut*	Output Shaft	200	270
Starter One-Way Clutch*	Flywheel	26	35

ENGINE/TRANSMISSION - 550/700			
Part	Part Bolted To	Torque	
		ft-lb	N-m
CVT Cover	Clutch Cover	48 in.-lb	5
Crankcase Half (6 mm)	Crankcase Half	10	14
Crankcase Half (8 mm)	Crankcase Half	21	28
Cylinder Head (Cap Screw)	Crankcase	37	50
Output Shaft Flange Nut*	Output Shaft	200	270
Magneto Rotor Nut*	Crankshaft	107	145
Secondary Shaft Bearing Housing	Crankcase Half	25	34
Stator Coil	Magneto Cover	13	18
Engine	Engine Cradle	42	57
Rubber Mount	Frame	25	34
Engine Cradle	Rubber Mount	25	34
ENGINE/TRANSMISSION - 1000			
Lower Crankcase Cover (6 mm)	Crankcase	10	14
Lower Crankcase Cover (8 mm)	Crankcase	21	28
Cylinder Head (Cap Screw)*	Crankcase	(step 1) 20 (step 2) 30 (final) 37	27 41 50
Rotor/Flywheel Nut*	Crankshaft	107	145
Clutch Cover	Crankcase	10	14
Secondary Drive Gear Nut*	Secondary Drive Output Shaft	200	270
Oil Filler Cover	Crankcase	9.5	13
Shift Cable Bracket	Crankcase	9.5	13
Oil Strainer Cap Screw	Crankcase	50 in.-lb	6
Stator Coil	Magneto Cover (New)	13	18
Stator Coil	Magneto Cover (Existing)	11	15
CVT Cover	Clutch Cover	9.5	13
Engine	Frame	33	45

* w/Red Loctite #271 ** w/Green Loctite #609

Torque Conversions (ft-lb/N-m)

ft-lb	N-m	ft-lb	N-m	ft-lb	N-m	ft-lb	N-m
1	1.4	26	35.4	51	69.4	76	103.4
2	2.7	27	36.7	52	70.7	77	104.7
3	4.1	28	38.1	53	72.1	78	106.1
4	5.4	29	39.4	54	73.4	79	107.4
5	6.8	30	40.8	55	74.8	80	108.8
6	8.2	31	42.2	56	76.2	81	110.2
7	9.5	32	43.5	57	77.5	82	111.5
8	10.9	33	44.9	58	78.9	83	112.9
9	12.2	34	46.2	59	80.2	84	114.2
10	13.6	35	47.6	60	81.6	85	115.6
11	15	36	49	61	83	86	117
12	16.3	37	50.3	62	84.3	87	118.3
13	17.7	38	51.7	63	85.7	88	119.7
14	19	39	53	64	87	89	121
15	20.4	40	54.4	65	88.4	90	122.4
16	21.8	41	55.8	66	89.8	91	123.8
17	23.1	42	57.1	67	91.1	92	125.1
18	24.5	43	58.5	68	92.5	93	126.5
19	25.8	44	59.8	69	93.8	94	127.8
20	27.2	45	61.2	70	95.2	95	129.2
21	28.6	46	62.6	71	96.6	96	130.6
22	29.9	47	63.9	72	97.9	97	131.9
23	31.3	48	65.3	73	99.3	98	133.3
24	32.6	49	66.6	74	100.6	99	134.6
25	34	50	68	75	102	100	136

Gasoline - Oil - Lubricant

RECOMMENDED GASOLINE

The recommended gasoline to use is 87 minimum octane regular unleaded. In many areas, oxygenates are added to the gasoline. Oxygenated gasolines containing up to 10% ethanol or 5% methane.

When using ethanol blended gasoline, it is not necessary to add a gasoline antifreeze since ethanol will prevent the accumulation of moisture in the fuel system.

CAUTION


Do not use white gas. Only Arctic Cat approved gasoline additives should be used.

RECOMMENDED ENGINE/TRANSMISSION OIL

CAUTION

Any oil used in place of the recommended oil could cause serious engine damage. Do not use oils which contain graphite or molybdenum additives. These oils can adversely affect clutch operation. Also, not recommended are racing, vegetable, non-detergent, and castor-based oils.

The recommended oil to use is Arctic Cat ACX All Weather synthetic engine oil, which has been specifically formulated for use in this Arctic Cat engine. Although Arctic Cat ACX All Weather synthetic engine oil is the only oil recommended for use in this engine, use of any API certified SM 0W-40 oil is acceptable.



RECOMMENDED FRONT DIFFERENTIAL/REAR DRIVE LUBRICANT

The recommended lubricant is Arctic Cat Gear Lube or an equivalent gear lube which is SAE approved 80W-90 hypoid. This lubricant meets all of the lubrication requirements of the Arctic Cat vehicle front differential and rear drive.

CAUTION

Any lubricant used in place of the recommended lubricant could cause serious front differential/rear drive damage.

FILLING GAS TANK

⚠ WARNING

Always fill the gas tank in a well-ventilated area. Never add fuel to the gas tank near any open flames or with the engine running. DO NOT SMOKE while filling the gas tank.

Since gasoline expands as its temperature rises, the gas tank must be filled to its specified capacity only. Expansion room must be maintained in the tank particularly if the tank is filled with cold gasoline and then moved to a warm area.

⚠ WARNING

Do not overflow gasoline when filling the gas tank. A fire hazard could materialize. Always allow the engine to cool before filling the gas tank.

Tighten the gas tank cap securely after filling the tank.

⚠ WARNING

Do not over-fill the gas tank.

Genuine Parts

When replacement of parts is necessary, use only genuine Arctic Cat parts. They are precision-made to ensure high quality and correct fit. Refer to the appropriate Illustrated Parts Manual for the correct part number, quantity, and description.

Preparation For Storage

CAUTION

Prior to storing the vehicle, it must be properly serviced to prevent rusting and component deterioration.

1. Clean the seat cushion (cover and base) with a damp cloth and allow it to dry.
2. Clean the vehicle thoroughly by washing dirt, oil, grass, and other foreign matter from the entire vehicle. Allow it to dry thoroughly. DO NOT get water into any part of the engine or air intake.
3. Either drain the gas tank or add Fuel Stabilizer to the gas in the gas tank.

CAUTION

If the interior of the air filter housing is dirty, clean the area before starting the engine.

4. Plug the exhaust hole in the exhaust system with a clean cloth.
5. Apply light oil to the plungers of the shock absorbers.
6. Tighten all nuts, bolts, cap screws, and screws. Make sure rivets holding components together are tight. Replace all loose rivets. Care must be taken that all calibrated nuts, cap screws, and bolts are tightened to specifications.
7. Fill the cooling system to the bottom of the stand pipe in the radiator neck with properly mixed coolant.

8. Disconnect the battery cables; then remove the battery, clean the battery posts and cables, and store in a clean, dry area.
9. Store the vehicle indoors in a level position.

CAUTION

Avoid storing outside in direct sunlight and avoid using a plastic cover as moisture will collect on the vehicle causing rusting.

Preparation After Storage

Taking the vehicle out of storage and correctly preparing it will assure many miles and hours of trouble-free riding.

1. Clean the vehicle thoroughly.
2. Clean the engine. Remove the cloth from the exhaust system.
3. Check all control wires and cables for signs of wear or fraying. Replace if necessary.
4. Change the engine/transmission oil and filter.

5. Check the coolant level and add properly mixed coolant as necessary.
6. Charge the battery; then install. Connect the battery cables.

CAUTION

The ignition switch must be in the OFF position prior to installing the battery or damage may occur to the ignition system.

CAUTION

Connect the positive battery cable first; then the negative.

7. Check the entire brake systems (fluid level, pads, etc.), all controls, headlights, taillight, brakelight, and headlight aim; adjust or replace as necessary.
8. Tighten all nuts, bolts, cap screws, and screws making sure all calibrated nuts, cap screws, and bolts are tightened to specifications.
9. Check tire pressure. Inflate to recommended pressure as necessary.
10. Make sure the steering moves freely and does not bind.
11. Check the spark plug(s). Clean or replace as necessary.

Periodic Maintenance

This section has been organized into sub-sections which show common maintenance procedures for the Arctic Cat ROV.

SPECIAL TOOLS

A number of special tools must be available to the technician when performing service procedures in this section. Refer to the current Special Tools Catalog for the appropriate tool description.

Description	p/n
Compression Tester Kit	0444-213
Oil Filter Wrench	0644-389
Timing Light	0644-296
Valve Clearance Adjuster	0444-255

■NOTE: Special tools are available from the Arctic Cat Service Department.

Periodic Maintenance Chart

A = Adjust I = Inspect C = Clean L = Lubricate R = Replace T = Tighten

Item	Initial Service After Break-In (First Month or 100 Miles)	Every Day	Every Month or Every 100 Miles	Every 3 Months or Every 300 Miles	Every 6 Months or Every 500 Miles	Every Year or Every 1500 Miles	As Needed
Battery	I		I				C
Fuses				I			R
Air Filter	I			I*			R
Valve/Tappet Clearance	I				I		A
Engine Compression						I	
Spark Plug(s)	I			I	I		R (4000 Mi or 18 Mo)
Muffler/Spark Arrestor					C		R
Gas Hoses	I	I					R (2 Yrs)
Throttle Cable Ends/Accelerator Pedal Pivot	I	I			C-L		A-R
Engine-Transmission Oil Level			I				A
Engine-Transmission Oil/Filter	R			R*/R**/R***			R
Front Differential - Rear Drive Lubricant	I		I				R (4 Yrs)
Tires/Air Pressure	I	I					R
Steering Components	I	I		I			R
V-Belt	I					I	R
Suspension (Ball joint boots, drive axle boots front and rear, tie rods, differential and rear drive bellows)	I	I					R
Nuts/Bolts/Cap Screws	T		T				A
Ignition Timing						I	
Headlight/Taillight-Brakelight	I	I					R
Switches	I	I					R
Shift Lever					I		A-L
Gauges/Indicators	I	I					R
Frame/Welds	I		I		I		
Electrical Connections					I		C
Complete Brake System	I	I					
Brake Pads	I			I*			R
Brake Fluid	I			I			R (2 Yrs)
Brake Hoses	I			I			R (4 Yrs)
Coolant/Cooling System	I		I				R (2 Yrs)
Wheel Lug Nuts	T			T			

* Service/Inspect more frequently when operating in adverse conditions.


** When using an API certified SM 0W-40 oil.

*** When using Arctic Cat ACX All Weather synthetic oil, oil change and strainer inspection interval can be increased to every 1,000 miles or every year.

Lubrication Points

It is advisable to lubricate certain components periodically to ensure free movement. Apply light oil to the components using the following list as reference.

- A. Accelerator Pedal Pivot/Cable Ends
- B. Brake Pedal Pivot
- C. Shift Cable



PR882A

Air Filter

■NOTE: To access the air filter, the seats and the center console must be removed.

1. Remove dirt and debris from around the filter housing.
2. Unsnap the four spring-clip fasteners and remove the air filter cover.
3. Fill a wash pan larger than the element with a non-flammable cleaning solvent; then dip the element in the solvent and wash it.

■NOTE: Foam Air Filter Cleaner and Foam Air Filter Oil are available from Arctic Cat.

4. Squeeze the element by pressing it between the palms of both hands to remove excess solvent. Do no twist or ring the element or it will develop cracks.
5. Dry the element.
6. Put the element in a plastic bag; then pour in air filter oil and work the oil into the element.
7. Squeeze the element to remove excess oil.

CAUTION

A torn air filter can cause damage to the engine. Dirt and dust may get inside the engine if the element is torn. Carefully examine the element for tears before and after cleaning it. Replace the element with a new one if it is torn.

8. Clean any dirt or debris from inside the filter housing.
9. Inspect the drain beneath the main housing for debris and for proper sealing.

Valve/Tappet Clearance

To check and adjust valve/tappet clearance, use the following procedure.

■NOTE: The engine must be cold for this procedure.

■NOTE: The seats, center console, spark plug(s), and air filter housing must be removed for this procedure.

1. Remove the spark plug(s) and timing inspection plug(s); then remove the tappet covers (see the Engine/Transmission section - Servicing Top-Side Components).

■NOTE: On the 1000, remove the crankshaft end cap and install the special cap screw (left-hand threads) to rotate the engine.

2. Rotate the crankshaft to the TDC position on the compression stroke (front cylinder on the 1000).



GZ063

■NOTE: At this point, the rocker arms and adjuster screws must not have pressure on them.

Feeler Gauge Procedure


A. Using a feeler gauge, check each valve/tappet clearance. If clearance is not within specifications, loosen the jam nut and rotate the tappet adjuster screw until the clearance is within specifications. Tighten each jam nut securely after completing the adjustment.

CAUTION

The feeler gauge must be positioned at the same angle as the valve and valve adjuster for an accurate measurement of clearance. Failure to measure the valve clearance accurately could cause valve component damage.

VALVE/TAPPET CLEARANCE

Intake	0.1016 mm (0.004 in.)
Exhaust	0.1524 mm (0.006 in.)



CC007DC

B. On the 1000, rotate the engine 270° to the TDC position of the rear cylinder; then repeat step A. The stamped "R" must be visible.



GZ059

Valve Adjuster Procedure

A. Place the Valve Clearance Adjuster onto the jam nut securing the tappet adjuster screw; then rotate the valve adjuster dial clockwise until the end is seated in the tappet adjuster screw.

B. While holding the valve adjuster dial in place, use the valve adjuster handle and loosen the jam nut; then rotate the tappet adjuster screw clockwise until friction is felt.

C. Align the valve adjuster handle with one of the marks on the valve adjuster dial.

D. While holding the valve adjuster handle in place, rotate the valve adjuster dial counterclockwise until proper valve/tappet clearance is attained.

■NOTE: Refer to the appropriate specifications in Feeler Gauge Procedure sub-section for the proper valve/tappet clearance.

■NOTE: Rotating the valve adjuster dial counterclockwise will open the valve/tappet clearance by 0.05 mm (0.002 in.) per mark.

E. While holding the adjuster dial at the proper clearance setting, tighten the jam nut securely with the valve adjuster handle.

F. On the 1000, rotate the engine 270° to the TDC position of the rear cylinder; then repeat steps A-E for the rear cylinder.

3. Install the spark plug(s) and timing inspection plug; then on the 1000 remove the cap screw and install the crankcase end cap.
4. Place the two tappet covers into position making sure the proper cap screws are with the proper cover. Tighten the cap screws securely.

Testing Engine Compression

To test engine compression, use the following procedure.

■NOTE: The engine should be warm (operating temperature) and the battery fully charged for an accurate compression test. On the 550/700, throttle must be in the wide-open throttle (WOT) position. In the event the engine cannot be run, cold values are included.

■NOTE: The seats and center console must be removed for this procedure.

1. Remove the high tension lead from the spark plug(s).
2. Using compressed air, blow any debris from around the spark plug(s).

⚠ WARNING

Always wear safety glasses when using compressed air.

3. Remove the spark plug(s); set aside. Disconnect the primary ignition coil connector(s).
4. Attach the Compression Tester Kit.
5. While holding the throttle in the full-open position, crank the engine over with the electric starter until the gauge stops climbing (five to 10 compression strokes).

Model	PSI Hot (WOT)	PSI Cold (WOT)
550	120-140	80-120
700	125-145	100-140
1000 (Front)	125-145	80-120
1000 (Rear)	165-185	150-190

6. If compression is abnormally low, verify the following items.


- A. Starter cranks engine over.
- B. Gauge is functioning properly.
- C. Throttle in the full-open position.
- D. Valve/tappet clearance correct.
- E. Engine warmed up.
- F. Intake not restricted.

■NOTE: To service top-side components, see the Engine/Transmission section.

- 7. Pour approximately 30 ml (1 fl oz) of oil into the spark plug hole(s), reattach the gauge, and retest compression.
- 8. If compression increases to normal, service the piston rings (see the appropriate Engine/Transmission - Top side Components).

Spark Plug(s)

A light brown insulator indicates that the plug is correct. A white or dark insulator indicates that the engine may need to be serviced. To maintain a hot, strong spark, keep the plug free of carbon.




ATV-0051

CAUTION

Before removing a spark plug, be sure to clean the area around the spark plug. Dirt could enter engine when removing or installing the spark plug.

Adjust the gap to 0.5-0.6 mm (0.019-0.024 in.).



ATV0052E

When installing a spark plug, be sure to tighten it securely. A new spark plug should be tightened 1/2 turn once the washer contacts the cylinder head. A used spark plug should be tightened 1/8-1/4 turn once the washer contacts the cylinder head.

Muffler/Spark Arrestor

Clean the spark arrester using the following procedure.

WARNING

Wait until the muffler cools to avoid burns.

1. Remove the cap screws securing the spark arrester assembly to the muffler; then loosen and remove the spark arrester. Account for a gasket.



PR879

2. Using a suitable brush, clean the carbon deposits from the screen taking care not to damage the screen.

■NOTE: If the screen or gasket is damaged in any way, it must be replaced.



3. Install the spark arrester assembly and gasket and secure with the cap screws. Tighten the cap screws to 50 in.-lb.

Engine/Transmission Oil - Filter


■NOTE: To change oil and filter, the seats and center console must be removed.

■NOTE: The engine should always be warm when the oil is changed so the oil will drain easily and completely.

1. Park the vehicle on level ground.
2. Remove the oil level stick/filler plug.



3. Remove the drain plug from the bottom of the engine and drain the oil into a drain pan.



4. Using the Oil Filter Wrench and a ratchet handle (or a socket or box-end wrench), remove the old oil filter.

■NOTE: Clean up any excess oil after removing the filter.

5. Apply oil to a new filter O-ring and check to make sure it is positioned correctly; then install the new oil filter. Tighten securely.
6. Install the engine drain plug and tighten to 16 ft-lb. Pour the specified amount of the recommended oil in the filler hole. Install the oil level stick/filler plug.

CAUTION

Any oil used in place of the recommended oil could cause serious engine damage. Do not use oils which contain graphite or molybdenum additives. These oils can adversely affect clutch operation. Also, not recommended are racing, vegetable, non-detergent, and castor-based oils.

7. Start the engine (while the vehicle is outside on level ground) and allow it to idle for a few minutes.
8. Turn the engine off and wait approximately one minute.
9. Unscrew the oil level stick and wipe it with a clean cloth.
10. Install the oil level stick and thread into the engine case.

■NOTE: The oil level stick should be threaded into the case for checking the oil level.


11. Remove the oil level stick; the oil level must be within the operating range.

550/700



GZ461A

1000



XR075A

CAUTION


Do not over-fill the engine with oil. Always make sure that the oil level is not above the upper mark.

12. Inspect the area around the drain plug and oil filter for leaks.

Front Differential - Rear Drive Lubricant

To check lubricant, use the following procedure.

1. Remove the fill plug; the lubricant level should be one inch below the plug threads.



PR530A


2. If low, add SAE approved 80W-90 hypoid gear lube as necessary.

To change the lubricant, use the following procedure.

1. Place the vehicle on level ground.
2. Remove each fill plug.
3. Drain the lubricant into a drain pan by removing in turn the drain plug from each.



HDX255



PR530B

4. After all the lubricant has been drained, install the drain plugs and tighten to 45 in.-lb.
5. Pour the appropriate amount of recommended lubricant into the fill hole.
6. Install the fill plug.

■NOTE: If the lubricant is contaminated with water, inspect the drain plug, fill plug, and/or bladder.

Driveshaft/Coupling

The following drive system components should be inspected periodically to ensure proper operation.

- A. Spline lateral movement (slop).
- B. Coupling cracked, damaged, or worn.
- C. Universal joints worn or missing bearings.

Nuts/Bolts/Cap Screws

Tighten all nuts, bolts, and cap screws. Make sure rivets holding components together are tight. Replace all loose rivets. Care must be taken that all calibrated nuts, bolts, and cap screws are tightened to specifications.

Headlight/Taillight - Brakelight

HEADLIGHT

The wattage rating of each bulb is shown in the chart. When replacing a burned bulb, always use the same wattage rating.

Headlight	12V/60W/55W
Taillight/Brakelight	12V/8W/27W

CAUTION

Use only specified bulbs indicated in the chart as replacement bulbs.

■**NOTE:** The bulb portion of the headlight is fragile. **HANDLE WITH CARE.** When replacing the headlight bulb, do not touch the glass portion of the bulb. If the glass is touched, it must be cleaned with a dry cloth before installing. Skin oil residue on the bulb will shorten the life of the bulb.

To replace the headlight bulb, use the following procedure.

1. Remove the wiring harness connector from the back of the headlight.
2. Grasp the bulb housing, turn it counterclockwise, and remove the bulb.
3. Install the new bulb into the housing and rotate it completely clockwise.
4. Install the wiring harness connector.

CAUTION

When replacing the headlight bulb, be careful not to touch the glass portion of the bulb. Grasp the new bulb with a clean cloth.

TAILLIGHT - BRAKELIGHT


To replace the taillight - brakelight bulb, use the following procedure.

1. Remove the mounting screws securing the taillight/brakelight assembly to the rear canopy tube.
2. Rotate the socket counterclockwise and remove it from the housing.
3. To remove the bulb from the socket, pull it straight out of the socket.
4. To install the bulb, push it straight into the socket.
5. Insert the socket into the housing and rotate it clockwise.
6. Position the taillight/brakelight assembly on the rear canopy tube; then tighten the mounting screws securely.

CHECKING/ADJUSTING HEADLIGHT AIM

The headlights can be adjusted vertically and horizontally. The geometric center of the HIGH beam light zone is to be used for vertical and horizontal aiming.


1. Position the vehicle on a level floor so the headlights are approximately 6.1 m (20 ft) from an aiming surface (wall or similar aiming surface).



0748-733

■**NOTE:** There should be an average operating load on the vehicle when adjusting the headlight aim.

2. Measure the distance from the floor to the mid-point of each headlight.
3. Using the measurements obtained in step 2, make horizontal marks on the aiming surface.
4. Make vertical marks which intersect the horizontal marks on the aiming surface directly in front of the headlights.
5. Switch on the lights. Make sure the HIGH beam is on. DO NOT USE LOW BEAM.
6. Observe each headlight beam aim. Proper aim is when the most intense beam is centered on the vertical mark 5 cm (2 in.) below the horizontal mark on the aiming surface.
7. Loosen the headlight adjustment screw; then adjust the headlight up or down as required. Tighten the headlight adjustment screw.



PR875A

Shift Lever/Shift Cable

CHECKING

Turn the ignition switch on; then shift the transmission into park. The letter P should illuminate on the LCD gauge and the park icon (P) should illuminate. The vehicle should not be able to move.



PR920

Move the shift lever all the way back. The letter L should illuminate on the LCD gauge.




PR921

If either park or low range cannot be reached, the shift cable must be adjusted.

ADJUSTING

■NOTE: Shift cable adjustment should not be necessary unless replacing the shift cable or shift lever.

1. Remove the seats; then remove the battery cover and center console.
2. Loosen adjuster nut (A) and jam nut (B) and adjust the cable as necessary to obtain park in the full aft position of the shift lever and low range full forward. Tighten the jam nut securely.



PR916A

Hydraulic Brake System

CHECKING/BLEEDING


The hydraulic brake system has been filled and bled at the factory. To check and/or bleed a hydraulic brake system, use the following procedure.

1. With the master cylinder in a level position, check the fluid level in the reservoir. If the level in the reservoir is not above the MIN, add DOT 4 brake fluid.



PR095

2. Depress the brake pedal several times to check for a firm brake. If the brake is not firm, the system must be bled.
3. To bleed the brake system, use the following procedure.
 - A. Remove the cover and fill the reservoir with DOT 4 Brake Fluid.
 - B. Install and secure the cover; then slowly depress the brake pedal several times.
 - C. Remove the protective cap, install one end of a clear hose onto the RIGHT REAR bleeder screw, and direct the other end into a container; then while holding slight pressure on the brake pedal, open the bleeder screw and watch for air bubbles. Close the bleeder screw before releasing the brake pedal. Repeat this procedure until no air bubbles are present.



PR377C

■NOTE: During the bleeding procedure, watch the reservoir very closely to make sure there is always a sufficient amount of brake fluid. When the level falls below MIN, refill the reservoir before the bleeding procedure is continued. Failure to maintain a sufficient amount of fluid in the reservoir will result in air in the system.

- D. At this point, perform steps B and C on the LEFT REAR bleeder screw; then move to the FRONT RIGHT and FRONT LEFT bleeder screws and follow the same procedure.
- E. Repeat steps B and C until the brake pedal is firm.
- 4. Carefully check the entire hydraulic brake system that all hose connections are tight, the bleed screws are tight, the protective caps are installed, and no leakage is present.

CAUTION

This hydraulic brake system is designed to use DOT 4 brake fluid only. If brake fluid must be added, care must be taken as brake fluid is very corrosive to painted surfaces.


INSPECTING HOSES

Carefully inspect the hydraulic brake hoses for cracks or other damage. If found, the brake hoses must be replaced.

CHECKING/REPLACING PADS

The clearance between the brake pads and brake discs is adjusted automatically as the brake pads wear. The only maintenance that is required is replacement of the brake pads when they show excessive wear. Check the thickness of each of the brake pads as follows.

1. Remove a front wheel.
2. Measure the thickness of each brake pad.



PR376A

3. If thickness of either brake pad is less than 1.0 mm (0.039 in.), the brake pads must be replaced.


■NOTE: The brake pads should be replaced as a set.

4. To replace the brake pads, use the following procedure.
 - A. Remove the wheel.
 - B. Remove the cap screws securing the caliper holder to the knuckle; then remove the pads from the caliper.



PR377A

- C. Install the new brake pads.
- D. Secure the caliper holder to the knuckle with new "patch-lock" cap screws. Tighten to 20 ft-lb.



PR377B

- E. Install the wheels and using a crisscross pattern, tighten the wheel nuts in 20 ft-lb increments to a final torque of 40 ft-lb (steel wheel), 60 ft-lb (aluminum wheel w/black nuts), or 80 ft-lb (aluminum wheel w/chrome nuts).
5. Burnish the brake pads (see Burnishing Brake Pads in this section).

BRAKE DISC

Using a micrometer, measure the thickness of the brake disc in the contact surface. If thickness is 0.125-in. or less, the disc must be replaced. To replace the brake disc, see the Drive System section – Hub.

Burnishing Brake Pads

Brake pads must be burnished to achieve full braking effectiveness. Braking distance will be extended until brake pads are properly burnished. To properly burnish the brake pads, use the following procedure.

⚠ WARNING

Failure to properly burnish the brake pads could lead to premature brake pad wear or brake loss. Brake loss can result in severe injury.


1. Choose an area large enough to safely accelerate the vehicle to 30 mph and to brake to a stop.

- Accelerate to 30 mph; then depress the brake pedal to decelerate to 0-5 mph.
- Repeat procedure 20 times until brake pads are burnedished.


Checking/Replacing V-Belt

REMOVING

- Remove the seats and center console; then remove the left-side seat-base (550/700) or right-side seat base (1000).
- Remove the floor; then on the 550/700, loosen the gas tank and slide it forward.
- Remove the cap screws securing the CVT cover noting the location of the different-lengthed cap screws for installing purposes; then using a rubber mallet, gently tap on the cover tabs to loosen the cover. Remove the cover.
- Remove the nut securing the movable drive face; then remove the face. Account for the flat washer and spacer.




CF364A



CD966A

■NOTE: Keep the drive face plate in contact with the drive face when removing or installing the drive face to prevent the rollers from falling out.



CD963

- On the 1000, install one of the CVT cover cap screws into the driven pulley fixed face; then turn the cap screw clockwise to spread the pulley faces. Remove the V-belt.



PR476A

- On the 550/700, install the cap screw from the tool kit into the driven pulley fixed face; then turn the cap screw clockwise to spread the pulley faces. Remove the V-belt.



GZ076

INSTALLING


- Place the V-belt into position on the driven pulley and over the front shaft.

■NOTE: The arrows on the V-belt should point in the direction of engine rotation.

2. Pinch the V-belt together near its center and slide the spacer and movable drive face onto the driveshaft. Secure the drive face with a washer and nut (coated with red Loctite #271). Using Spanner Wrench, tighten the nut to 165 ft-lb.

CAUTION

Make sure the movable drive face plate is fully engaged onto the spines of the clutch shaft before tightening the nut or false torque readings may occur. This will cause the assembly to loosen damaging the shaft and clutch face plate.



GZ485A

■NOTE: At this point, remove the cap screw from the driven pulley face.

3. With the vehicle in neutral, rotate the V-belt and driven pulley/clutch counterclockwise until the V-belt is flush with the top of the driven pulley.
4. Place the V-belt cover gasket into position; then install the cover and secure with the cap screws making sure the different-lengthed cap screws are in their proper location. Tighten the cap screws to 8 ft-lb.
5. Secure the seat-base with the four cap screws. Tighten securely.
6. Slide the gas tank into position (550/700) and secure with the cap screws; then install the floor.
7. Install the seats and center console making sure the seats lock securely in place.

Steering/Frame/Controls

The following steering components should be inspected periodically to ensure safe and proper operation.

- A. Steering wheel secure.
- B. Steering has equal and complete full-left and full-right capability.
- C. Steering assembly mounting bolts tight.
- D. Ball joints not worn, cracked, or damaged.
- E. Tie rods not bent or cracked.
- F. Knuckles not worn, cracked, or damaged.
- G. Cotter pins not damaged or missing.
- H. Steering wheel tilt locks securely (if equipped).

The frame and welds should be checked periodically for damage, bends, cracks, deterioration, broken components, and missing components.

SPECIAL TOOL

A special tool must be available to the technician when performing service procedures in this section. Refer to the current Special Tools Catalog for the appropriate tool description.

Description	p/n
Hub Retaining Wrench	0444-270

■NOTE: Special tools are available from the Arctic Cat Service Department.

Steering Wheel

REMOVING

1. Remove the steering wheel cover; then match mark the steering shaft and steering wheel.

■NOTE: Any time steering components are disassembled, all connecting components should be marked for proper alignment during assembling.

2. Remove the hairpin clip from the steering shaft; then remove the nut securing the steering wheel and remove the steering wheel. Account for the flat thrust washer and two wave washers.



PR226

INSPECTING

1. Inspect the steering wheel for cracks, missing padding, or broken spokes.
2. Inspect the splines for wear.
3. Check that the steering wheel is not bent.

INSTALLING

1. Place the flat thrust washer and then the two wave washers onto the steering shaft.
2. Install the steering wheel aligning the two match marks; then apply a drop of red Loctite #271 to the threads of the nut and secure the steering wheel. Tighten to 25 ft-lb.

■NOTE: If a new steering wheel is being installed, mark the wheel as close as possible to the old wheel mark; then check for proper positioning with the front wheels straight forward.

3. Install the hairpin clip on the steering shaft.

■NOTE: If the hole in the steering shaft does not align with the slots in the castle nut, tighten the nut slightly until the next slot aligns with the hole.



PR899

4. Check for freedom of movement of the steering system; then install the steering wheel cover.


ASSEMBLY

■NOTE: Thoroughly troubleshoot the EPS system (if equipped) prior to replacing the EPS assembly (see the Electrical System section) as there are several possible external causes for system failure.

Steering System

REMOVING STEERING SHAFT/EPS


1. Remove the hood, front access panel, and front fenders; then disconnect the regulator/rectifier and remove the screws securing the coolant bottle to the front storage box.
2. Remove the front storage box; then remove the steering wheel.
3. Disconnect the tilt steering mechanism from the steering shaft; then remove the shift lever knob.
4. Disconnect the wiring harness connectors from the back of the dash; then remove the dash.
5. Remove the two cap screws securing the steering shaft housing to the frame.



PR897A

■NOTE: Steps 6 and 7 are for non-EPS models. For EPS models, complete steps 8-11.

6. Make matching alignment marks on the pinion shaft and steering shaft joint.



PR333A

7. Remove the cap screw and lock nut securing the lower steering shaft joint to the pinion shaft; then slide the joint free of the pinion. Discard the lock nut.




PR302

8. Make matching alignment marks; then disconnect the cap screw and lock nut securing the steering shaft to the EPS assembly. Discard the lock nut.



PR917

9. Disconnect the two EPS connectors.
10. Remove the cap screws securing the EPS assembly to the frame; then remove the cap screw securing the rack coupler to the EPS output shaft.




PR761A

■NOTE: No repairs are authorized on the EPS assembly and it must be replaced as a complete assembly.

11. Remove the EPS from the top side.

INSTALLING STEERING SHAFT/EPS ASSEMBLY

1. Install the EPS into position.
2. Align the slot in the rack coupler to the notch in the frame (front wheels centered).




PR766A

3. On the non-EPS models, insert the steering rack coupler into the pinion shaft using the matching alignment marks. Secure with the cap screw and a new lock nut. Tighten to 25 ft-lb.

■NOTE: Steps 4-6 are for the EPS models only.

4. Rotate the EPS shaft to align the index (flattened) spline with the slot in the rack coupler and install the EPS assembly into the coupler; then seat the EPS firmly onto the frame.




PR776A

5. Install the cap screws securing the EPS assembly to the frame and tighten to 35 ft-lb. Install the cap screw and new lock nut in the EPS to rack coupler and tighten to 11 ft-lb.
6. Connect the two electrical connectors; then align the slot in the steering shaft coupler to the index (flattened) spline on the EPS input shaft and install. Install but do not tighten the cap screw.



PR759B

7. Install the steering shaft housing. Secure to the frame with two cap screws and nuts. Tighten to 20 ft-lb.



PR897

8. Tighten the cap screw (from step 6) to 25 ft-lb.
9. Install the front storage box.
10. Connect the regulator/rectifier and install the coolant bottle to the front storage box. Tighten the regulator/rectifier to 8 ft-lb and the coolant bottle to 48 in.-lb.
11. Install the dash and connect the electrical connectors. Secure with screws and tighten securely. Do not over-tighten.
12. Connect the tilt steering mechanism and tighten securely. Install the shift knob.
13. Install the front access panel, front fenders, and hood.
14. Install the steering (see Steering Wheel in this section).

REMOVING RACK AND PINION

■NOTE: If equipped, the EPS assembly must be removed prior to removing the steering rack assembly.

1. Remove the right front wheel.
2. Remove the cotter pins and nuts securing the tie rod ends to the knuckles; then remove the tie rod ends from the knuckles.



PR301

3. Remove the EPS mounting bracket; then remove the cap screws securing the steering rack assembly to the rack bracket and remove from the left side.

INSPECTING RACK AND PINION

1. Inspect the tie rod ends for damaged threads, torn boots, or excessive wear.
2. Inspect the tie rods for bends or deformation.
3. Inspect the rack and pinion-to-tie rod boots for tears or deterioration.




PR785

4. Check boot clamps for security.
5. Check that the steering assembly operates smoothly with no binding from full-left to full-right position.
6. Inspect for grease seepage from the steering assembly.

■NOTE: The rack and pinion is not repairable and must be replaced as an assembly; however, the tie rods and boots are replaceable.

INSTALLING RACK AND PINION

1. From the left side, install the steering rack assembly to the frame and secure with two cap screws. Tighten to 35 ft-lb.
2. Install the EPS mounting bracket and secure with four cap screws. Do not tighten the cap screws at this time.



PR773A

3. Place the tie rod ends into the knuckles and secure with the castle nuts (coated with red Loctite #271). Tighten to 30 ft-lb; then install new cotter pins.

■NOTE: If the slots in the castle nut are not aligned with the hole in the tie rod end, tighten until the cotter pin can be installed.

4. Install the EPS assembly; then tighten the cap screws (from step 2) to 20 ft-lb.

5. Install the wheels and using a crisscross pattern, tighten the wheel nuts in 20 ft-lb increments to a final torque of 40 ft-lb (steel wheel), 60 ft-lb (aluminium wheel w/black nuts), or 80 ft-lb (aluminum wheel w/chrome nuts).

REMOVING TIE RODS

1. Remove the rack and pinion assembly.
2. Support the steering rack assembly in a suitable holding fixture or bench vise; then cut the securing band and slide the boot toward the outer tie rod end.
3. Using a punch or chisel, bend the lock washer away from the flats on the tie rod joint.



PR780

4. Using an appropriate crow-foot and backing wrench, remove the tie rod assembly.

■NOTE: Tie rods come as a complete assembly. No further disassembly is required.

5. Remove and discard the lock washer.

INSTALLING TIE RODS

1. Remove the tie rod end and lock nut from the tie rod; then install the tie rod boot onto the tie rod.
2. Install the tie rod lock nut and tie rod end.
3. Coat the tie rod joint threads with red Loctite #271; then with a new lock washer, thread the tie rod into the rack.




PR784

4. While holding the rack shaft with a wrench, tighten the tie rod joint to 37 ft-lb using an appropriate crow-foot.



PR781

■NOTE: Always attach the crow-foot to the torque wrench with the open end 90° to the torque wrench handle to ensure accurate torque application.



PR528A

5. Install the boot onto the rack and secure with the nylon tie.

6. Center the rack in the steering rack assembly and align the white paint line on the pinion with the mark on the rack housing.



PR785A

Steering Knuckles

REMOVING AND DISASSEMBLING

1. Secure the vehicle on a support stand to elevate the wheel; then remove the wheel.

WARNING

Make sure the vehicle is solidly supported on the support stand to avoid injury.

2. Remove the cotter pin from the axle.


3. Remove the nut securing the hub.

4. Remove the brake caliper.

5. Remove the hub assembly.

6. Remove the cotter pin from the tie rod end and remove the tie rod end from the knuckle.

7. Remove the two cap screws securing the ball joints in the knuckle.



PR193

8. Tap the ball joint end out of the knuckle; then remove the knuckle.

9. Remove the snap ring securing the bearing in the knuckle; then press the bearing out of the knuckle.



PR289


CLEANING AND INSPECTING

1. Clean all knuckle components.

2. Inspect the bearing for pits, scoring, rusting, or premature wear.
3. Inspect the knuckle for cracks, breaks, or galling of the bearing surface.

ASSEMBLING AND INSTALLING

1. Using a suitable press and driver, press the bearing into the knuckle until firmly seated; then install the snap ring.



PR292A



PR289

2. Install the knuckle to the upper and lower ball joints and secure with the two cap screws. Tighten to 35 ft-lb.



PR202



PR203

3. Install the tie rod end and secure with the nut (coated with red Loctite #271). Tighten to 30 ft-lb; then install a new cotter pin and spread the pin.


■NOTE: During assembling, new cotter pins should be installed.

4. Apply a small amount of grease to the hub splines.




PR290A

5. Install the hub assembly onto the splines of the shaft.




CD009

6. Using Hub Retaining Wrench, secure the hub assembly with the nut. Tighten to 200 ft-lb.




7. Install a new cotter pin and secure by spreading as shown.



■NOTE: If the hole in the axle shaft does not align with the slots in the castle nut, tighten the nut until the hole and slots align.

8. Secure the brake caliper to the knuckle with the two new "patch-lock" cap screws. Tighten to 20 ft-lb.




9. Install the wheels and using a crisscross pattern, tighten the wheel nuts in 20 ft-lb increments to a final torque of 40 ft-lb (steel wheel), 60 ft-lb (aluminium wheel w/black nuts), or 80 ft-lb (aluminum wheel w/chrome nuts).

10. Remove the vehicle from the support stand.

Front Wheel Alignment


■NOTE: All measurements and adjustments must be made with the vehicle unloaded.

Mark the center-line of the front tires at the front and rear of the tire; then using a tape measure, measure and record the distance between the marks at the front and rear. The front measurement should be 3-6 mm (1/8-1/4 in.) greater than the rear measurement (toe-out).



To adjust the wheel alignment, use the following procedure:

1. Position the steering wheel as shown; then using an open-end wrench to hold the tie rod ends (A), loosen the right-side and left-side jam nuts (B).



CAUTION

Always use a wrench to hold the tie rod ends when loosening or tightening the jam nuts or damage to the boots could occur.

2. Turn the left-side and right-side tie rods (C) in equal increments to achieve the proper toe-out; then tighten the jam nuts to 8 ft-lb.

Hood

REMOVING

1. Open the hood; then remove the four cap screws securing the hood hinges to the frame.



PR902A

2. Remove the hood assembly.

CLEANING AND INSPECTING

1. Clean all hood components with soap and water.
2. Inspect the hood for cracks and/or loose fasteners.
3. Inspect for any missing decals.


INSTALLING

Place the hood into position on the vehicle; then secure with the cap screws. Tighten securely.

Fenders


REMOVING - FRONT

1. Remove the four cap screws securing each outer fender to the corresponding inner fender; then remove the fenders.
2. Remove the push pins securing the front access panel. Tilt the access panel back to access the inner fender fasteners.



PR890A

3. Remove the remaining cap screws securing the inner fender from the inside of the headlight assembly, storage tray, and frame.




PR944A

INSTALLING - FRONT

1. Install the inner fenders and secure using the existing cap screws.
2. Install the access panel and secure with the push pins.
3. Secure the outer fenders to the vehicle using the existing cap screws.


REMOVING - REAR

1. Tilt the cargo box up.
2. Remove the screws securing the rear fender bracket to the cargo box.



PR948A

3. Remove the remaining cap screws to remove the fender from the fender bracket.



PR949A

INSTALLING - REAR

1. Install the fender to the bracket and secure with the screws. Tighten securely.
2. Secure the rear fender bracket to the cargo box. Tighten securely.
3. Lower the cargo box.

Floor

REMOVING

1. Remove the seats and center console; then remove the left-side and right-side seat-bases.
2. Remove the cap screws securing the left side panel to the frame.




PR934

3. Remove the gas tank cap; then remove the cap screws securing the right side panel to the frame.



PR935

4. Remove the four cap screws securing the left foot restraint to the frame; then carefully move the panel outward to reveal the steel foot panel cap screws.



PR932A

5. Remove the screws securing the side panel to the foot panel; then remove the cap screws securing the foot panel to the frame.




PR933

6. Repeat steps 4-5 for the right side.
7. On the 700/1000, remove the center console.
8. Remove the remaining cap screws and self-tapping screws securing the floorboard to the frame.
9. While pulling forward on the upper portion of the floorboard, lift the rear panel above the seat lock studs; then insert a small wood block to hold in position.



PR163



PR164

10. From the opposite side of the vehicle, repeat step 9; then lift the rear of the floorboard up and lift the floorboard out of the vehicle.



PR945

CLEANING AND INSPECTING

1. Clean the floor with soap and water.
2. Inspect the floor for cracks or holes.

INSTALLING

1. Position the floorboard into the vehicle and secure with the cap screws and self-tapping screws; then on the 700/1000, install the center console.
2. Install the steel foot panels with the cap screws.
3. Install the foot panels to the side panels.
4. Install the gas tank cap, side panels, center console, seat-bases, and seats ensuring the seats lock securely.

Belly Panel

REMOVING

1. Remove the screws securing the belly panel to the underside of the frame.
2. Remove the belly panel.

INSTALLING

1. Place the belly panel into position on the underside of the frame.
2. Install the screws. Tighten securely.


Accelerator Pedal

REMOVING

Dislodge the throttle cable holding grommet from the actuator arm; then remove two torx-head screws and nuts securing the accelerator pedal assembly to the splash panel and remove the accelerator pedal.



PR709



UTV354


INSTALLING

Align the mounting holes with the holes in the splash panel and secure with the two torx-head screws and nuts; then snap the throttle cable holding grommet into the actuator arm.

Shift Lever

REMOVING

1. Remove the plastic push-pin from the shift lever knob; then remove the knob.
2. Remove the cap screw and lock nut securing the shift lever to the shift cable. Discard the lock nut.
3. Remove the cap screw and lock nut securing the shift lever to bottom pivot location (underneath the dashboard). Slide the shift lever down and out. Discard the lock nut.



INSTALLING

1. Slide the shift lever up through the opening; then secure to the pivot using the existing cap screw and new lock nut.
2. Secure the shift lever to the shift cable using the existing cap screw and a new lock nut.
3. With the knob in position, install the plastic push-pin.
4. Check for proper shifter operation (see Periodic Maintenance - Shift Lever/Shift Cable).

LCD Gauge


REMOVING/INSTALLING

To remove the gauge, pull out on one side of it; then disconnect the multi-pin connector and remove the gauge.



To install the gauge, connect the multi-pin connector and press the gauge into the dash.

■NOTE: Ensure the rubber mounting ring is oriented correctly on the tab and seats fully through the dash.



WT601A

Exhaust System

REMOVING MUFFLER

1. Remove the two exhaust springs at the muffler/exhaust pipe juncture.



2. Slide the muffler assembly clear of the holder pins.

INSPECTING MUFFLER

1. Inspect muffler externally for cracks, holes, and dents.

2. Inspect the muffler internally by shaking the muffler back and forth and listening for rattles or loose debris inside the muffler.

■NOTE: For additional details on cleaning the muffler/spark arrester, see the Periodic Maintenance section.


INSTALLING MUFFLER

1. Place the muffler onto the holder pins and slide into position.
2. Secure the muffler to the exhaust pipe with the two exhaust springs.


Cargo Box

REMOVING

1. Raise the cargo box; then remove the screw and nut securing the lower lift support to the frame. The cargo box will tilt fully rearward.



2. Loosen but do not remove the four shoulder cap screws securing the pivot housings to the cargo box.



3. Lower the cargo box; then remove the four cap screws (from step 2).
4. With the help of an assistant or an adequate lift, remove the cargo box from the vehicle. Account for four pivot housings.

CLEANING AND INSPECTING

1. Clean all cargo box components with soap and water.

2. Inspect the cargo box for cracks, tears, and loose hardware.
3. Inspect the welds of the cargo box frame for cracking or bending.
4. Inspect the cargo box gate latches for smooth operation.

INSTALLING

1. With the help of an assistant or an adequate lift, set the cargo box into position on the frame; then position the two upper pivot housings between the cargo box and frame. Lightly grease the pivot housings.
2. Align the holes in the upper pivot housings with the holes in the cargo box; then install the lower pivot housings and secure with the four shoulder cap screws. Tighten to 20 ft-lb.
3. Raise the cargo box; then connect the lift support to the frame, install the screw and nut, and tighten the nut securely.
4. Lower the cargo box and lock into position.

Taillight Assembly

REMOVING

1. Remove two torx-head screws and lock nuts securing the taillight assembly to the rear ROPS bracket; then rotate the taillight assembly left or right to allow the connector to clear the access opening.
2. Disconnect the three-prong connector from the bulb socket and remove the taillight assembly.

INSPECTING

1. Inspect wiring harness, three-prong connector, lens, base, cap screws, and socket for damage.
2. Inspect all wires for corrodng, pinching, and cracking.
3. Inspect the bulb for wattage, voltage, and proper operation.

INSTALLING

1. Connect the three-prong connector to the bulb socket; then place the taillight assembly into position on the rear ROPS bracket.
2. Install the two torx-head screws and new lock nuts and tighten securely.

Seats

REMOVING/INSTALLING

1. To remove a seat, pull the seat lock lever up. Raise the front of the seat and slide it forward.
2. To install a seat, slide the rear of the seat into the seat retainers and push down firmly on the front of seat. The seat should automatically lock into position.

Troubleshooting

Problem: Handling too heavy or stiff	
Condition	Remedy
1. Front wheel alignment incorrect 2. Lubrication inadequate 3. Tire inflation pressure incorrect 4. Tie rod ends seizing 5. Linkage connections seizing	1. Adjust alignment 2. Lubricate appropriate components 3. Adjust pressure 4. Replace tie rod ends 5. Repair - replace connections
Problem: Steering oscillation	
Condition	Remedy
1. Tires inflated unequally 2. Wheel(s) wobbly 3. Wheel hub cap screw(s) loose - missing 4. Wheel hub bearing worn - damaged 5. Tie rod ends worn - loose 6. Tires defective - incorrect 7. A-arm bushings damaged 8. Bolts - nuts (frame) loose	1. Adjust pressure 2. Replace wheel(s) 3. Tighten - replace cap screws 4. Replace bearing 5. Replace - tighten tie rod ends 6. Replace tires 7. Replace bushings 8. Tighten bolts - nuts
Problem: Steering pulling to one side	
Condition	Remedy
1. Tires inflated unequally 2. Front wheel alignment incorrect 3. Wheel hub bearings worn - broken 4. Frame distorted 5. Shock absorber defective	1. Adjust pressure 2. Adjust alignment 3. Replace bearings 4. Repair - replace frame 5. Replace shock absorber
Problem: Steering impaired	
Condition	Remedy
1. Tire pressure too high 2. Steering linkage connections worn 3. Cap screws (suspension system) loose	1. Adjust pressure 2. Replace connections 3. Tighten cap screws
Problem: Tire wear rapid or uneven	
Condition	Remedy
1. Wheel hub bearings worn - loose 2. Front wheel alignment incorrect	1. Replace bearings 2. Adjust alignment
Problem: Steering noise	
Condition	Remedy
1. Caps screws - nuts loose 2. Wheel hub bearings broken - damaged 3. Lubrication inadequate	1. Tighten cap screws - nuts 2. Replace bearings 3. Lubricate appropriate components
Problem: Rear wheel oscillation	
Condition	Remedy
1. Rear wheel hub bearings worn - loose 2. Tires defective - incorrect 3. Wheel rim distorted 4. Wheel hub cap screws loose 5. Rear suspension arm-related bushing worn 6. Rear shock absorber damaged 7. Rear suspension arm nut loose	1. Replace bearings 2. Replace tires 3. Replace rim 4. Tighten cap screws 5. Replace bushing 6. Replace shock absorber 7. Tighten nut

Engine/Transmission

This section has been organized into sub-sections which show a progression for the complete servicing of the Arctic Cat ROV engine/transmission.

To service the center crankcase halves, the engine/transmission must be removed from the frame. To service top-side, left-side, and right-side components, the engine/transmission does not have to be removed from the frame.

■NOTE: Arctic Cat recommends the use of new gaskets, lock nuts, O-rings, and seals and lubricating all internal components when servicing the engine/transmission.

■NOTE: A new ROV and an overhauled ROV engine require a "break-in" period. The first 10 hours (or 200 miles) are most critical to the life of this ROV. Proper operation during this break-in period will help assure maximum life and performance from the ROV. Instruct the customer to follow the proper break-in procedure as described in the Operators Manual.

SPECIAL TOOLS

A number of special tools must be available to the technician when performing service procedures in this section. Refer to the current Special Tools Catalog for the appropriate tool description.

Description	p/n
Seal Protector Tool	0444-252
Crankcase Separator/Crankshaft Remover	0444-152
Magneto Rotor Remover Set	0444-254
Piston Pin Puller	0644-328
Secondary Drive Gear Holder	0444-253
Spanner Wrench	0544-005
Surface Plate	0644-016
V Blocks	0644-535

■NOTE: Special tools are available from the Arctic Cat Service Department.

Troubleshooting

Problem: Engine will not start or is hard to start (Compression too low)

Condition	Remedy
<ol style="list-style-type: none"> 1. Valve clearance out of adjustment 2. Valve guides worn 3. Valves mistimed 4. Piston rings worn - broken 5. Cylinder bore worn 6. Starter motor cranks too slowly - does not turn 	<ol style="list-style-type: none"> 1. Adjust clearance 2. Repair - replace guides 3. Retime engine 4. Replace rings 5. Replace cylinder 6. See the Electrical System section

Problem: Engine will not start or is hard to start (No spark)

Condition	Remedy
<ol style="list-style-type: none"> 1. Spark plug(s) fouled 2. Spark plug(s) wet 3. Magneto defective 4. ECM defective 5. Ignition coil defective 6. High-tension lead open - shorted 	<ol style="list-style-type: none"> 1. Clean - replace plug(s) 2. Clean - dry plug(s) 3. Replace stator coil 4. Replace ECM 5. Replace ignition coil 6. Replace high tension lead

Problem: Engine will not start or is hard to start (No fuel reaching the fuel injector)

Condition	Remedy
<ol style="list-style-type: none"> 1. Gas tank vent hose obstructed 2. Fuel hose obstructed 3. Fuel screens obstructed 4. Fuel pump defective 	<ol style="list-style-type: none"> 1. Clean vent hose 2. Clean - replace hose 3. Clean - replace inlet screen - valve screen 4. Replace fuel pump

Problem: Engine stalls easily

Condition	Remedy
<ol style="list-style-type: none"> 1. Spark plug(s) fouled 2. Magneto defective 3. ECM defective 4. Fuel injector obstructed 5. Valve clearance out of adjustment 	<ol style="list-style-type: none"> 1. Clean - replace plug(s) 2. Replace stator coil 3. Replace ECM 4. Replace fuel injector 5. Adjust clearance

Problem: Engine noisy (Excessive valve chatter)

Condition	Remedy
<ol style="list-style-type: none"> 1. Valve clearance excessive 2. Valve spring(s) weak - broken 3. Rocker arm - rocker arm shaft worn 4. Camshaft worn 	<ol style="list-style-type: none"> 1. Adjust clearance 2. Replace spring(s) 3. Replace arm - shaft 4. Replace camshaft

Problem: Engine noisy (Noise seems to come from piston)

Condition	Remedy
<ol style="list-style-type: none"> 1. Piston - cylinder worn 2. Combustion chamber carbon buildup 3. Piston pin - piston pin bore worn 4. Piston rings - ring groove(s) worn 	<ol style="list-style-type: none"> 1. Replace - service piston - cylinder 2. Clean cylinder head and piston 3. Replace - service pin - bore 4. Replace rings - piston

Problem: Engine noisy (Noise seems to come from timing chain)

Condition	Remedy
<ol style="list-style-type: none"> 1. Chain stretched 2. Sprockets worn 3. Tension adjuster malfunctioning 	<ol style="list-style-type: none"> 1. Replace chain 2. Replace sprockets 3. Repair - replace adjuster

Problem: Engine noisy (Noise seems to come from crankshaft)

Condition	Remedy
<ol style="list-style-type: none"> 1. Main bearing worn - burned 2. Lower rod-end bearing worn - burned 3. Connecting rod side clearance too large 4. Centrifugal clutch loose 5. Rotor/flywheel loose 	<ol style="list-style-type: none"> 1. Replace bearing 2. Replace crankshaft assembly 3. Replace crankshaft assembly 4. Tighten - replace clutch 5. Tighten - replace flywheel - crankshaft

Problem: Engine noisy (Noise seems to come from transmission)

Condition	Remedy
<ol style="list-style-type: none"> 1. Gears worn - chipped 2. Splines worn 3. Primary gears worn - chipped 4. Bearings worn 5. Bushing worn 	<ol style="list-style-type: none"> 1. Replace gears 2. Replace shaft(s) 3. Replace gears 4. Replace bearings 5. Replace bushing

Problem: Engine noisy (Noise seems to come from secondary bevel gear and final driven shaft)	
Condition	Remedy
1. Drive - driven bevel gears damaged - worn 2. Backlash excessive 3. Tooth contact improper 4. Bearing damaged 5. Gears worn - chipped 6. Splines worn	1. Replace gears 2. Adjust backlash 3. Adjust contact 4. Replace bearing 5. Replace gears 6. Replace shaft(s)
Problem: Engine idles poorly	
Condition	Remedy
1. Valve clearance incorrect 2. Valve seating poor 3. Valve guides defective 4. Rocker arms - arm shaft worn 5. Magneto defective 6. ECM defective 7. Spark plug(s) fouled - gap too wide 8. Ignition coil defective 9. Fuel injector obstructed	1. Adjust clearance 2. Replace valves/cylinder head 3. Replace guides 4. Replace arms - shafts 5. Replace stator coil 6. Replace ECM 7. Adjust gap - replace plug(s) 8. Replace ignition coil 9. Replace fuel injector
Problem: Engine runs poorly at high speed	
Condition	Remedy
1. High RPM "cut out" against RPM limiter 2. Valve springs weak 3. Valve timing incorrect 4. Cams - rocker arms worn 5. Spark plug gap too narrow 6. Ignition coil defective 7. Air cleaner element obstructed 8. Fuel hose obstructed	1. Shift into higher gear - decrease speed 2. Replace springs 3. Retime engine 4. Replace cams - arms 5. Adjust gap 6. Replace ignition oil 7. Clean element 8. Clean - prime hose
Problem: Exhaust smoke dirty or heavy	
Condition	Remedy
1. Engine oil overfilled - contaminated 2. Piston rings - cylinder worn 3. Valve guides worn 4. Cylinder wall scored 5. Valve stems worn 6. Stem seals defective	1. Drain excess oil - change oil 2. Replace - service rings - cylinder 3. Replace guides 4. Replace cylinder 5. Replace valves 6. Replace seals
Problem: Engine lacks power	
Condition	Remedy
1. Valve clearance incorrect 2. Valve springs weak 3. Valve timing incorrect 4. Piston ring(s) - cylinder worn 5. Valve seating poor 6. Spark plug fouled 7. Rocker arms - shafts worn 8. Spark plug gap incorrect 9. Fuel injector obstructed 10. Air cleaner element obstructed 11. Engine oil overfilled - contaminated 12. Intake manifold leaking air 13. Cam chain worn	1. Adjust clearance 2. Replace springs 3. Time camshaft 4. Replace - service rings - cylinder 5. Repair seats 6. Clean - replace plug 7. Replace arms - shafts 8. Adjust gap - replace plug 9. Replace fuel injector 10. Clean element 11. Drain excess oil - change oil 12. Tighten - replace manifold 13. Replace cam chain - sprockets
Problem: Engine overheats	
Condition	Remedy
1. Carbon deposit (piston crown) excessive 2. Oil low 3. Octane low - gasoline poor 4. Oil pump defective 5. Oil filter obstructed 6. Intake manifold leaking air 7. Coolant level low 8. Fan malfunctioning 9. Fan relay malfunctioning 10. Thermostat stuck - closed 11. Radiator hoses - cap damaged - obstructed	1. Clean piston 2. Add oil 3. Drain - replace gasoline 4. Replace pump 5. Replace filter 6. Tighten - replace manifold 7. Fill - examine system for leaks 8. Check fan fuse - replace fan 9. Replace fan relay 10. Replace thermostat 11. Clear obstruction - replace hoses - cap

Prowler 550/700 (Table of Contents)

Removing Engine/ Transmission.....	34
Top-Side Components	37
Removing Top-Side Components	37
Servicing Top-Side Components.....	41
Installing Top-Side Components	47
Right-Side Components.....	51
Removing Right-Side Components.....	52
Servicing Right-Side Components	54
Installing Right-Side Components.....	55
Left-Side Components	58
Removing Left-Side Components	58
Servicing Left-Side Components	61
Installing Left-Side Components	62
Center Crankcase Components.....	65
Separating Crankcase Halves.....	65
Disassembling Crankcase Half	65
Servicing Center Crankcase Components.....	67
Assembling Crankcase Half.....	72
Joining Crankcase Halves.....	74
Installing Engine/Transmission.....	74

Removing Engine/ Transmission

Many service procedures can be performed without removing the engine/transmission from the frame. Closely observe the note introducing each sub-section for this important information.

AT THIS POINT

If the technician's objective is to service/replace left-side cover oil seals, front output joint oil seal, rear output joint oil seal, and/or the oil strainer (from beneath the engine/transmission), the engine/transmission does not have to be removed from the frame.

Support the vehicle on a suitable lift or jack stands allowing room to perform work from the underside.


■NOTE: Locate the jack stands to allow removing of the center belly panel.

WARNING

Make sure the vehicle is solidly supported on the support stands to avoid injury.

1. Remove the seats and center console; then remove the left-side and right-side seat-bases.
2. Remove the center belly panel; then drain the oil and coolant.

■NOTE: Use a small funnel between the frame and coolant drain plug to prevent coolant from draining on the frame and splashing.



PR122A




PR156A

3. Remove the negative cable from the battery; then remove the positive cable.
4. From the right-side, remove the spark plug cap; then disconnect the ECT sensor lead, speed sensor connector, fuel pump connector, and reverse override switch connector.




PR130B




PR155D


5. From the left-side, disconnect the starter wire and alternator connector; then remove the cap screw securing the main harness ground and the battery ground wires to the starter.



PR145A




PR925A




PR926A

6. Remove the cap screws securing the shift cable bracket to the engine case. Remove the cap screw from the shift arm and disconnect the gear position switch connector. Slide the gear position switch off the engine.




HDX251

7. Remove four machine screws securing the cross brace to the frame; then remove the cross brace.




PR596A



PR598A

8. Loosen the clamp (A) securing the air intake boot to the throttle body and the clamp (B) securing the air filter housing to the inlet housing boot; then remove the crankcase breather hose from the crankcase.




PR578A

9. Depressurize the gasline hose; then disconnect the gasline hose connector from the fuel rail.

WARNING

Gasoline may be under pressure. Place an absorbent towel under the connector to absorb any gasoline spray when disconnecting.


10. Disconnect the fuel injector connector and the ISC, MAP, and TPS sensors from the throttle body; then disconnect the IAT sensor from the air box.




11. Remove two self-tapping screws securing the air filter mounting bracket to the frame; then remove the air filter and mounting bracket as an assembly.





12. Remove the throttle arm cover from the throttle body; then disconnect and remove the throttle cable and the throttle body.




13. Remove the coolant hoses from the water pump and thermostat housings; then position the upper coolant line to the left-side of the engine compartment.



14. Remove the exhaust duct from the V-belt housing; then remove the inlet boot connecting the inlet duct to the V-belt housing.



15. Disconnect the O2 sensor; then remove the O2 sensor.




16. Remove the muffler; then remove the exhaust pipe.

17. From the underside of the vehicle, remove the cap screws securing the driveshafts to the drive couplers.
18. Remove two flange nuts from the underside of the rear engine mounts.




PR153A

19. Remove two flange nuts securing the engine mounting bracket to the front engine mounts.



PR147

20. Attach suitable lifting chains to the engine/transmission; then using an engine hoist, lift the assembly out of the engine compartment.



PR114

■NOTE: The front engine mounting bracket should slide free of the engine mounts first; then the rear engine mounting bracket and two rear engine mounts will lift free of the frame.



PR146

Top-Side Components

■NOTE: For efficiency, it is preferable to remove and disassemble only those components which need to be addressed and to service only those components. The technician should use discretion and sound judgment.

AT THIS POINT

To service any one specific component, only limited disassembly of components may be necessary. Note the AT THIS POINT information in each sub-section.

■NOTE: The engine/transmission does not have to be removed from the frame for this procedure.

Removing Top-Side Components

A. Valve Cover/Rocker Arms B. Cylinder Head/Camshaft

■NOTE: Remove the spark plug and timing inspection plug; then using a socket and ratchet, rotate the crankshaft to top-dead-center of the compression stroke.

1. Remove the two tappet covers.



CC001D


■**NOTE: Keep the mounting hardware with the covers for assembly purposes or thread them back into the head to keep them separated.**

2. Loosen the twelve cap screws securing the valve cover to the head.
3. Remove all cap screws except the two top-side cap screws next to the spark plug. These will keep the alignment pins in place. Note the two rubber washers on the remaining cap screws.




H1-013A

4. Remove the valve cover. Account for and note the orientation of the cylinder head plug. Note the location of the two alignment pins.



CD206



CD211A

5. Loosen the cap screw on the end of the tensioner; then remove the two cap screws securing the tensioner adjuster assembly and remove the assembly. Account for a gasket.



CC009D


6. Using an awl, rotate the C-ring in its groove until it is out of the cylinder head; then remove the C-ring.

■**NOTE: Care should be taken not to drop the C-ring down into the crankcase.**



CC012D

7. Bend the washer tabs down and remove the two cap screws securing the sprocket to the camshaft; then drop the sprocket off the camshaft.



CC013D

8. While holding the chain, slide the sprocket and cam shaft out of the cylinder head.

■**NOTE: Loop the chain over the cylinder and secure it to keep it from falling into the crankcase.**

■NOTE: On the 700, account for rubber O-rings.




FI620

9. Remove the cap screw securing the chain tensioner (account for a washer); then remove the tensioner.




FI617

10. Remove the five nuts securing the cylinder head to the cylinder.




CC017D



CC018D

11. Remove the four cylinder head bolts.



H1-016A

12. Remove the cylinder head from the cylinder, remove the gasket, and account for two alignment pins; then remove the cam chain guide.



CC020D

☞ AT THIS POINT

To service valves and cylinder head, see Servicing Top-Side Components sub-section.

☞ AT THIS POINT

To inspect cam chain guide, see Servicing Top-Side Components sub-section.




CC022D

C. Cylinder D. Piston

■NOTE: Steps 1-12 in the preceding sub-section must precede this procedure.


13. Loosen the clamp securing the coolant hose to the union; then detach the hose.

14. Remove the two nuts securing the cylinder to the crankcase.




CC023D

15. Lift the cylinder off the crankcase taking care not to allow the piston to drop against the crankcase. Account for the gasket and two alignment pins.



CC024D



CC025D



CC026D


☞ AT THIS POINT

To service cylinder, see Servicing Top-Side Components sub-section.

CAUTION

When removing the cylinder, be sure to support the piston to prevent damage to the crankcase and piston.


16. Using an awl, remove one piston-pin circlip.



CC032D

17. Using the Piston Pin Puller, remove the piston pin. Account for the opposite-side circlip. Remove the piston.

■**NOTE:** It is advisable to remove the opposite-side circlip prior to using the puller.



CC033D

■NOTE: Support the connecting rod with rubber bands to avoid damaging the rod or install the Connecting Rod Holder.

CAUTION

Do not allow the connecting rod to go down inside the crankcase. If the rod is down inside the crankcase and the crankshaft is rotated, severe damage will result.

■NOTE: If the existing rings will not be replaced with new rings, note the location of each ring for proper installation. When replacing with new rings, replace as a complete set only. If the piston rings must be removed, remove them in this sequence.

- A. Starting with the top ring, slide one end of the ring out of the ring-groove.
- B. Remove each ring by working it toward the dome of the piston while rotating it out of the groove.

AT THIS POINT

To service piston, see Servicing Top-Side Components sub-section.

AT THIS POINT

To service center crankcase components only, proceed to Removing Left-Side Components.

Servicing Top-Side Components

VALVE ASSEMBLY

When servicing valve assembly, inspect valve seats, valve stems, valve faces, and valve stem ends for pits, burn marks, or other signs of abnormal wear.

■NOTE: Whenever a valve is out of tolerance, it must be replaced.


Cleaning/Inspecting Valve Cover

■NOTE: If the valve cover cannot be trued, the cylinder head assembly must be replaced.

1. Wash the valve cover in parts-cleaning solvent.
2. Place the valve cover on the Surface Plate covered with #400 grit wet-or-dry sandpaper. Using light pressure, move the valve cover in a figure eight motion. Inspect the sealing surface for any indication of high spots. A high spot can be noted by a bright metallic finish. Correct any high spots before assembly by continuing to move the valve cover in a figure eight motion until a uniform bright metallic finish is attained.

CAUTION

Do not remove an excessive amount of the sealing surface or damage to the camshaft will result. Always check camshaft clearance when resurfacing the valve cover.



CC130D

CAUTION

Water or parts-cleaning solvent must be used in conjunction with the wet-or-dry sandpaper or damage to the sealing surface may result.

Removing Valves


■NOTE: Index all valves, springs, and cotters to their original position when removing. When installing, all valve components should be installed in their original position.

1. Using a valve spring compressor, compress the valve springs and remove the valve cotters. Account for an upper spring retainer.



CC132D

2. Remove the valve seal and the lower remaining spring seat. Discard the valve seal.



CC136D

■NOTE: The valve seals must be replaced.

3. Remove the valve springs; then invert the cylinder head and remove the valves.

Measuring Valve Guide (Bore)

1. Insert a snap gauge 1/2 way down into each valve guide bore; then remove the gauge and measure it with a micrometer.
2. Acceptable inside diameter range must be within specifications.
3. If a valve guide is out of tolerance, it must be replaced.

Servicing Valves/Valve Guides/Valve Seats


If valves, valve guides, or valve seats require servicing or replacement, Arctic Cat recommends that the components be taken to a qualified machine shop for servicing.

CAUTION

If valves are discolored or pitted or if the seating surface is worn, the valve must be replaced. Do not attempt to grind the valves or severe engine damage may occur.

Installing Valves


1. Apply grease to the inside surface of the valve seals; then place a lower spring seat and valve guide seal over each valve guide.



CC144D


2. Insert each valve into its original location.
3. Install the valve springs with the painted end of the spring facing away from the cylinder head.

■NOTE: If the paint is not visible, install the ends of the springs with the closest wound coils toward the head.



ATV-1011A

4. Place a spring retainer over the valve springs; then using the valve spring compressor, compress the valve springs and install the valve cotters.



CC132D

PISTON ASSEMBLY

■NOTE: Whenever a piston, rings, or pin are out of tolerance, they must be replaced.

Inspecting Piston

1. Inspect the piston for cracks in the piston pin, dome, and skirt areas.
2. Inspect the piston for seizure marks or scuffing. Repair with #400 grit wet-or-dry sandpaper and water or honing oil.
3. Inspect the perimeter of each piston for signs of excessive "blowby." Excessive "blowby" indicates worn piston rings or an out-of-round cylinder.

Removing Piston Rings

1. Starting with the top ring, slide one end of the ring out of the ring-groove.




CC400D

2. Remove each ring by working it toward the dome of the piston while rotating it out of the groove.

■NOTE: If the existing rings will not be replaced with new ones, note the location of each ring for proper installation. When installing new rings, install as a complete set only.

Measuring Piston-Ring End Gap (Installed)


1. Place each compression ring in the wear portion of the cylinder. Use the piston to position each ring squarely in the cylinder.
2. Using a feeler gauge, measure each piston-ring end gap. Acceptable ring end gap must not exceed specifications.



CC280D


Measuring Piston Pin (Outside Diameter) and Piston-Pin Bore

1. Measure the piston pin outside diameter at each end and in the center. If measurement is not within specifications, the piston pin must be replaced.



ATV-1070


2. Insert an inside dial indicator into the piston-pin bore. The diameter must not exceed specifications. Take two measurements to ensure accuracy.



ATV-1069

Measuring Piston Skirt/Cylinder Clearance

1. Measure the cylinder front to back in six places.




CC127D

2. Measure the corresponding piston diameter at the recommended point above the piston skirt at a right angle to the piston-pin bore. Subtract this measurement from the measurement in step 1. The difference (clearance) must not exceed specifications.

Installing Piston Rings


1. Install ring expander (4) in the bottom groove of the piston; then install the thin oil rings (3) over the expander making sure the expander ends do not overlap. Stagger the end gaps of the upper and lower thin oil rings according to the illustration.




ATV-1085B

■**NOTE:** Note the direction of the exhaust side of the piston (5) for correct ring end gap orientation.

2. The ring with the orientation mark (MTOP or TOP) should be installed in the second (middle) groove and the ring with the orientation mark (M or O) should be installed in the first (top) groove.



ATV-1024A



ATV-1024B



CYLINDER/CYLINDER HEAD ASSEMBLY

■**NOTE:** If the cylinder/cylinder head cannot be trued, they must be replaced as an assembly.

Cleaning/Inspecting Cylinder Head


CAUTION

The cylinder head studs must be removed for this procedure.

1. Using a non-metallic carbon removal tool, remove any carbon buildup from the combustion chamber being careful not to nick, scrape, or damage the combustion chamber or the sealing surface.
2. Inspect the spark plug hole for any damaged threads. Repair damaged threads using a "heli-coil" insert.
3. Place the cylinder head on the Surface Plate covered with #400 grit wet-or-dry sandpaper. Using light pressure, move the cylinder head in a figure eight motion. Inspect the sealing surface for any indication of high spots. A high spot can be noted by a bright metallic finish. Correct any high spots before assembly by continuing to move the cylinder head in a figure eight motion until a uniform bright metallic finish is attained.

CAUTION


Water or parts-cleaning solvent must be used in conjunction with the wet-or-dry sandpaper or damage to the sealing surface may result.



CC128D

Measuring Cylinder Head Distortion

1. Remove any carbon buildup in the combustion chamber.
2. Lay a straightedge across the cylinder head; then using a feeler gauge, check the distortion factor between the head and the straightedge.
3. Maximum distortion must not exceed specifications.



CC141D

Cleaning/Inspecting Cylinder

1. Wash the cylinder in parts-cleaning solvent.
2. Inspect the cylinder for pitting, scoring, scuffing, warpage, and corrosion. If marks are found, repair the surface using a cylinder hone (see Inspecting Cylinder in this sub-section).
3. Place the cylinder on the surface plate covered with #400 grit wet-or-dry sandpaper. Using light pressure, move the cylinder in a figure eight motion. Inspect the sealing surface for any indication of high spots. A high spot can be noted by a bright metallic finish. Correct any high spots before assembly by continuing to move the cylinder in a figure eight motion until a uniform bright metallic finish is attained.

CAUTION

Water or parts-cleaning solvent must be used in conjunction with the wet-or-dry sandpaper or damage to the sealing surface may result.




CC129D

Inspecting Cam Chain Guide

1. Inspect cam chain guide for cuts, tears, breaks, or chips.
2. If the chain guide is damaged, it must be replaced.

Inspecting Cylinder


1. Using a slide gauge and a dial indicator or a snap gauge, measure the cylinder bore diameter in three locations from top to bottom and again from top to bottom at 90° from the first measurements for a total of six measurements. The trueness (out-of-roundness) is the difference between the highest and lowest reading. Maximum trueness (out-of-roundness) must not exceed specifications.



CC127D

2. Wash the cylinder in parts-cleaning solvent.
3. Inspect the cylinder for pitting, scoring, scuffing, and corrosion. If marks are found, repair the surface using a #320 grit ball hone.

■**NOTE:** To produce the proper 60° cross-hatch pattern, use a low RPM drill (600 RPM) at the rate of 30 strokes per minute. If honing oil is not available, use a lightweight petroleum-based oil. Thoroughly clean cylinder after honing using soap and hot water. Dry with compressed air; then immediately apply oil to the cylinder bore. If the bore is severely damaged or gouged, replace the cylinder.




CC390D

4. If any measurement exceeds the limit, replace the cylinder and piston.

Measuring Camshaft Runout

■**NOTE:** If the camshaft is out of tolerance, it must be replaced.

1. Place the camshaft on a set of V blocks; then position the dial indicator contact point against the shaft and zero the indicator.




CC283D

2. Rotate the camshaft and note runout; maximum runout must not exceed specifications.

Measuring Camshaft Lobe Height

1. Using a calipers, measure each cam lobe height.



ATV1013A


2. The lobe heights must be greater than minimum specifications.

Inspecting Camshaft Bearing Journal

1. Inspect the bearing journal for scoring, seizure marks, or pitting.
2. If excessive scoring, seizure marks, or pitting is found, the cylinder head assembly must be replaced.

Measuring Camshaft to Cylinder Head Clearance

1. Remove the adjuster screws and jam nuts.




CC005D

2. Place a strip of plasti-gauge in each of the camshaft lands in the cylinder head.
3. Place the valve cover on the cylinder head and secure with the valve cover cap screws. Tighten securely.


■NOTE: Do not rotate the camshaft when measuring clearance.

4. Remove the cap screws securing the valve cover to the cylinder; then remove the valve cover and cam-shaft.




CC003D

5. Match the width of the plasti-gauge with the chart found on the plasti-gauge packaging to determine camshaft to cylinder head and valve cover clearance.



CC145D

6. If clearance is excessive, measure the journals of the camshaft.




CC287D


■NOTE: If the journals are worn, replace the cam-shaft; then measure the clearance again. If it is still out of tolerance, replace the cylinder head.

Inspecting Camshaft Spring/Drive Pin

1. Inspect the spring and drive pin for damage.



CF061A



CF060A

2. If damaged, the camshaft must be replaced.


Installing Top-Side Components

A. Piston

B. Cylinder

1. Install the piston on the connecting rod making sure the circlip on each side is fully seated in the piston.

■NOTE: The piston should be installed so the arrow points toward the exhaust.



CC032D

2. Place the two alignment pins into position. Place the cylinder gasket into position; then place a piston holder (or suitable substitute) beneath the piston skirt and square the piston in respect to the crankcase.



CF083

3. Lubricate the inside wall of the cylinder; then using a ring compressor or the fingers, compress the rings and slide the cylinder over the piston. Route the cam chain up through the cylinder cam chain housing; then remove the piston holder and seat the cylinder firmly on the crankcase.

CAUTION


The cylinder should slide on easily. Do not force the cylinder or damage to the piston, rings, cylinder, or crankshaft assembly may occur.



CC024D

4. Loosely install the two nuts which secure the cylinder to the crankcase.

■NOTE: The two cylinder-to-crankcase nuts will be tightened in step 11.



CC023D

5. Install the coolant hose onto the crankcase union and tighten the clamp.

C. Cylinder Head


D. Valve Cover

■NOTE: Steps 1-5 in the preceding sub-section must precede this procedure.

6. Place the chain guide into the cylinder.


CAUTION

Care should be taken that the bottom of the chain guide is secured in the crankcase boss.




CF058A


7. Place a new head gasket into position on the cylinder. Place the alignment pins and four O-rings (700 only) into position; then place the head assembly into position on the cylinder.



CC020D




CF057A




CF289A

8. Install the four cylinder head cap screws and washers. Tighten only until snug.



CC272D


9. Loosely install the five cylinder head nuts.
10. Using a crisscross pattern, tighten the four cap screws (from step 8) initially to 20 ft-lb; then in 10 ft-lb increments, tighten to a final torque of 40 ft-lb.
11. Tighten the 8 mm nuts from step 9 to 21 ft-lb and the 6 mm nuts to 8.5 ft-lb; then tighten the two cylinder-to-crankcase nuts (from step 4) securely.
12. With the timing inspection plug removed and the chain held tight, rotate the crankshaft until the piston is at top-dead-center.
13. Install the rear cam chain tensioner guide into the cylinder head. Install the pivot cap screw and washer.



CD461

■NOTE: At this point, oil the camshaft journals, cam lobes, and the three seating surfaces on the cylinder.


14. With the alignment pin installed in the camshaft, loosely place the cam sprocket (with the recessed side facing the cam shaft lobes) onto the camshaft. At this point, do not "seat" the sprocket onto the shaft.



732-307B


15. With the cam lobes directed down (toward the piston), maneuver the camshaft/sprocket assembly through the chain and towards its seating position; then loop the chain over the sprocket.

■NOTE: Note the position of the alignment marks on the end of the camshaft. They must be parallel with the valve cover mating surface. If rotating the cam-shaft and sprocket is necessary for alignment, do not allow the crankshaft to rotate and be sure the cam lobes end up in the down position.



CD463

16. Seat the cam sprocket onto the camshaft making sure the alignment pin in the camshaft aligns with the smallest hole in the sprocket; then place the camshaft/sprocket assembly onto the cylinder ensuring the following.



CF013A


A. Piston still at top-dead-center.

- B. Camshaft lobes directed down (toward the piston).
- C. Camshaft alignment marks parallel to the valve cover mating surface.
- D. Recessed side of the sprocket directed toward the cam lobes.
- E. Camshaft alignment pin and sprocket alignment hole (smallest) are aligned.

CAUTION

If any of the above factors are not as stated, go back to step 12 and carefully proceed.

17. Place the tab-washer onto the sprocket making sure it covers the pin in the alignment hole.




ATV1027

CAUTION


Care must be taken that the tab-washer is installed correctly to cover the alignment hole on the sprocket. If the alignment pin falls out, severe engine damage will result.

18. Install the first cap screw (threads coated with red Loctite #271) securing the sprocket and tab-washer to the camshaft. Tighten only until snug.



CD464

19. Rotate the crankshaft until the second cap screw securing the sprocket to the camshaft can be installed; then install the cap screw (threads coated with red Loctite #271) and tighten to 10 ft-lb. Bend the tab to secure the cap screw.



CD465

20. Rotate the crankshaft until the first cap screw (from step 18) can be accessed; then tighten to 10 ft-lb. Bend the tab to secure the cap screw.



CD466

21. Place the C-ring into position in its groove in the cylinder head.




CC012D

22. Install the cylinder head plug in the cylinder head with the open end facing downward and toward the inside.

CAUTION

The open end of the plug must be positioned downward.



CD468


23. Remove the cap screw from the end of the chain tensioner; then using a flat-blade screwdriver, rotate the adjuster screw inside the tensioner clockwise until the screw bottoms.



CD501


■NOTE: The adjuster shaft will be drawn into the tensioner as the adjuster screw is rotated clockwise. The adjuster shaft tension will be released in step 25.

24. Place the chain tensioner adjuster assembly and gasket into position on the cylinder and secure with the two cap screws.




CD469

25. Using a flat-blade screwdriver, rotate the adjuster screw inside the tensioner counterclockwise until all tension is released; then install the cap screw into the end of the chain tensioner.




CD470



CD471

26. Loosen the four adjuster screw jam nuts; then loosen the four adjuster screws on the rocker arms in the valve cover.



CC005D

27. Apply a thin coat of Three Bond Sealant to the mating surfaces of the cylinder head and valve cover.




CC275D

28. Place the valve cover into position.

■NOTE: At this point, the rocker arms and adjuster screws must not have pressure on them.

29. Install the four top side cap screws with rubber washers; then install the remaining cap screws. Tighten only until snug.



CC003D

30. In a crisscross pattern starting from the center and working outward, tighten the cap screws (from step 29) to 8.5 ft-lb.

31. Adjust valve/tappet clearance (see Periodic Maintenance).

32. Place the two tappet covers into position making sure the proper cap screws are with the proper cover. Tighten to 8.5 ft lb.



CC001D

33. If removed, install the spark plug. Tighten securely.

Right-Side Components

■NOTE: For efficiency, it is preferable to remove and disassemble only those components which need to be addressed and to service only those components. The technician should use discretion and sound judgment.

AT THIS POINT

To service any one specific component, only limited disassembly of components may be necessary. Note the AT THIS POINT information in each sub-section.

■NOTE: The engine/transmission does not have to be removed from the frame for this procedure.

Removing Right-Side Components

A. Outer Magneto Cover


B. Water Pump

C. Cover

D. Rotor/Flywheel

1. Remove the four cap screws securing the outer magneto cover to the right-side cover; then remove the outer magneto cover.
2. Remove the flange nut securing the bushing to the crankshaft; then remove the bushing. Account for the O-ring inside the spacer.
3. Remove the cap screws securing the speed sensor housing to the crankcase and remove the housing assembly; then remove the snap ring securing the speed sensor trigger to the shaft and remove the trigger. Account for the gasket.

■NOTE: It may be necessary to use a small two-jaw puller to remove the trigger.





4. Loosen the clamps securing the coolant hose to the water pump; then remove the crossover tube from the cylinder head. Account for an O-ring.
5. Remove the two cap screws securing the water pump to the engine; then remove the water pump.


6. Remove the cap screws securing the right-side cover to the crankcase noting the location of the different-sized cap screws for installing purposes.
7. Using an appropriate side case puller, remove the side cover. Account for a gasket and two alignment pins.
8. Remove the nut securing the magneto rotor to the crankshaft; then install the magneto rotor puller adapter.

■NOTE: The puller has left-hand threads.


9. Using Magneto Rotor Remover Set and the appropriate crankshaft protector, remove the rotor/flywheel assembly from the crankshaft. Account for the key; then remove the starter clutch gear assembly and washer.



10. Remove the two starter gears from the crankcase noting the direction of the beveled side of the gears for installing purposes; then remove the two starter gear shafts.



CD136



CD952A



CD140

11. Remove the snap ring securing the water pump drive gear; then remove the gear noting the direction of the sides of the gear for installing purposes. Account for the drive gear alignment pin.




CD944

12. Remove the snap ring securing the water pump driven gear; then remove the gear noting the direction of the sides of the gear for installing purposes. Account for the driven gear alignment pin.



PR430A

13. Remove the shift shaft noting the timing marks for assembling purposes. Account for two washers.



PR434A

■**NOTE:** There is an oil passage beneath the driven gear/drive gear assembly. This passage should be plugged prior to removing the driven gear and drive gear. Failure to do so could result in the loss of an alignment pin into the crankcase.

14. Remove the gear shift cam plate and account for a washer; then remove the cam stopper and cam stopper spring. Account for two washers.

Servicing Right-Side Components

INSPECTING STARTER CLUTCH/GEAR

1. Place the starter clutch gear onto the rotor/flywheel and attempt to rotate the starter clutch gear clockwise. It should lock up to the rotor/flywheel. Rotate the gear counterclockwise and it should turn freely. If it moves or locks up both ways, the starter clutch must be replaced.
2. Inspect the starter clutch gear for chipped or missing teeth or discoloration/scoring of the clutch surface. Inspect the bearing for loose, worn, or discolored rollers. If bearing is damaged, it must be replaced.



FI569



FI570

2. Thoroughly clean the rotor/flywheel; then install the new clutch and secure with the cap screws after applying a drop of red Loctite #271 to the threads. Tighten to 26 ft-lb using a crisscross pattern. Make sure the one-way bearing is installed with the notches directed away from the rotor/flywheel.



FI576A



FI572



FI578

REPLACING STARTER CLUTCH ASSEMBLY

1. Remove the cap screws securing the starter clutch assembly to the flywheel; then remove from the flywheel.

REPLACING STARTER GEAR BEARING

1. Support the starter clutch gear in a press making sure to support the hub around the entire circumference; then using a suitable bearing driver, press the bearing from the gear.



FI583

2. Thoroughly clean the gear hub; then apply a drop of green Loctite #620 to the bearing outer race and press into the gear hub until even with the lower chamfer radius.




FI580

INSPECTING STATOR COIL/MAGNETO COVER ASSEMBLY

1. Inspect the stator coil for burned or discolored wiring, broken or missing hold-down clips, or loose cap screws.
2. Inspect the bearings in the magneto housing for discoloration, roughness when rotated, and secure fit in bearing bores.


REPLACING STATOR COIL/CRANKSHAFT POSITION SENSOR

1. Remove the three cap screws securing the stator coil, two cap screws securing the crankshaft position sensor, and one cap screw from the harness hold-down.
2. Lift the rubber grommet out of the housing; then remove the stator coil/crankshaft position sensor. Account for and note the position of the harness hold-down under the crankshaft position sensor.



FI590

3. Install the new stator coil assembly and secure with three new "patch-lock" cap screws. Tighten to 15 ft-lb.
4. Place the stator wire harness hold-down into position; then install the crankshaft position sensor and secure with two cap screws. Tighten securely.
5. Install the upper cable hold-down and secure with a cap screw. Tighten securely.




FI595A

Installing Right-Side Components

■**NOTE:** Plug the oil passage in the crankcase housing prior to installing the drive gear/driven gear assembly to prevent loss of an alignment pin.


1. Install the water pump driven gear alignment pin and the driven gear (with the beveled side of the gear facing outward as noted in removing); then secure with the snap ring.




CD950A



CD944




CD952A




CD949

■NOTE: The sharp side of the snap ring should be facing outward.


2. Install the water pump drive gear drive pin and the drive gear (with the flat side of the gear facing outward as noted in removing); then secure with the snap ring.



CD946A




CD139




PR447A


4. In order on the crankshaft, install a washer, ring gear, key, and the magneto rotor. Secure with the nut. Tighten to 107 ft-lb.



CD948A




PR434A



CD940B

5. Install the thrust washer and shift cam plate onto the shift cam shaft; then coat the cap screw threads with red Loctite #271 and tighten to 8 ft-lb.




PR433A




CD934

6. Install the shift cam stopper, spring, and two washers (thick washer closest to the nut); then coat the threads on the mounting stud with red Loctite #271 and install the nut. Tighten to 8 ft-lb.




CD954A




CD927A

8. Lubricate the magneto cover gasket with fresh engine oil; then place it into position on the two alignment pins. Make sure the outer shift shaft washer is in place.



PR431A

9. Install the magneto cover and secure with the cap screws. Tighten only until snug.
10. Place the bushing into position on the crankshaft making sure a new, lubricated O-ring is inside the bushing. Tighten the flange nut to 25 ft-lb.
11. Using a crisscross pattern, tighten the cap screws (from step 9) to 8 ft-lb.
12. Clean the countershaft and trigger splines thoroughly and install the inner snap ring onto the shaft; then apply green Loctite #620 to the trigger and counter-shaft splines and install the trigger. Secure with a flat washer and outer snap ring.



CD069

14. Place the water pump into position and secure with two cap screws. Tighten to 8 ft-lb.

■NOTE: Ensure the slotted water pump shaft is aligned with the groove in the counter balancer shaft.

15. Install the crossover tube on the water pump and cylinder head making sure the O-ring is properly positioned.
16. Place the outer magneto cover into position on the right-side cover; then tighten four cap screws to 6 ft-lb.


Left-Side Components

■NOTE: For efficiency, it is preferable to remove and disassemble only those components which need to be addressed and to service only those components. The technician should use discretion and sound judgment.

☞ AT THIS POINT

To service any one specific component, only limited disassembly of components may be necessary. Note the AT THIS POINT information in each sub-section.

■NOTE: The engine/transmission does not have to be removed from the frame for this procedure.



GZ254

13. Using a new gasket, install the speed sensor housing onto the crankcase and secure with two cap screws. Tighten to 8 ft-lb.

Removing Left-Side Components


- A. V-Belt Cover**
- B. Driven Pulley**
- C. Clutch Cover**
- D. Oil Pump**

1. Remove the cap screws securing the V-belt cover noting the location of the different-lengthed cap screws for installing purposes; then using a rubber mallet, gently tap on the cover tabs to loosen the cover. Account for two alignment pins.




CD079

2. Remove the nut and washer securing the movable drive face; then remove the face. Account for a spacer.



CD963



CD966A

3. Remove the V-belt.
4. Remove the bolt (550) or nut (700) securing the fixed driven assembly; then remove the assembly.



H1-019



PR388


5. Remove the fixed drive face.
6. Remove the cap screws securing the clutch cover. Note the location of the different-lengthed cap screws for installing purposes. Using a rubber mallet, carefully remove the cover. Account for two alignment pins.



CD973A

CAUTION


Care must be taken when removing the cover so the cover gasket is not damaged.



CD974A

■NOTE: For steps 7-13, refer to illustration CC829B.

■NOTE: To aid in installing, it is recommended that the assemblies are kept together and IN ORDER.



CC829C

7. Using a hydraulic press, remove the clutch housing assembly from the clutch cover. Account for the left fixed drive spacer and an O-ring inside the fixed drive spacer.




CF085




CC596

■NOTE: Account for and inspect the clutch housing seal.




CF088A

8. Remove the nut (left-hand threads) securing the clutch shoe assembly (C).




PR410A

9. Remove the cap screw securing the oil pump drive gear (B). Account for a cap screw, washer, pin, and spacer.



CC606



CD987




CD993

10. Using an impact wrench, remove the cap screws securing the final drive carrier bearing housing (D); then remove the housing and account for two alignment pins.




CD999

11. Remove the snap ring securing the oil pump driven gear (A); then remove the gear noting the direction of the sides of the gear for installing purposes. Account for a pin and a washer.



CD984



CD895A

12. Using an impact driver, remove the three torx-head screws securing the oil pump; then remove the pump.




CD988

Servicing Left-Side Components

INSPECTING CENTRIFUGAL CLUTCH SHOE

1. Inspect the clutch shoes for uneven wear, chips, cracks, or discoloration. If any shoe is damaged, replace the complete set.
2. Inspect the clutch shoes for wear or damage. If any shoe is worn to the bottom of the groove, replace the clutch assembly.



Inspecting clutch shoe groove


ATV1014

INSPECTING CLUTCH HOUSING

1. Inspect the clutch housing for burns, grooving, cracks, or uneven wear.
2. If the housing is damaged in any way, the housing must be replaced.

INSPECTING OIL PUMP

1. Inspect the pump for damage.
2. It is inadvisable to remove the screw securing the pump halves. If the oil pump is damaged, it must be replaced.



CC446D




CD988

3. Install the oil pump drive gear spacer onto the crank balancer shaft. Grease the pin and insert it into the shaft; then install the drive gear making sure the raised side of the gear is facing toward the inside. Secure the gear with the cap screw (threads coated with red Loctite #271) and the washer. Tighten the cap screw to 63 ft-lb.




CD992



CD991


1. Install the secondary shaft bearing housing making sure the two alignment pins are properly positioned. Tighten the new "patch-lock" cap screws to 28 ft-lb.




CD999

2. Install the oil pump onto the engine; then tighten the screws (coated with red Loctite #271) to 8 ft-lb.


4. Grease the driven gear pin and insert the oil pump into the case. Tighten the oil pump screws to 8 ft-lb. Install the washer and pin; then install the driven gear noting the direction on the sides of the gear from removing). Secure with a snap ring.



CD985A




CF088A



CD984

■NOTE: When installed correctly, the sides of the drive and driven gears will be flush with each other.

5. Install the clutch shoe assembly and secure with the flange nut (threads coated with red Loctite #271). Tighten to 221 ft-lb.




PR410A

6. Install the clutch cover alignment pins into the crankcase, apply oil to the cover gasket, and install the gasket onto the crankcase.
7. Lightly grease the clutch housing seal; then insert the left fixed-drive spacer.




CF088A

8. Apply grease to the outer edges of the clutch housing; then from inside the clutch cover, install the clutch housing into the cover using a rubber mallet.
9. Place the clutch cover/housing assembly into position on the crankcase; then secure with the cap screws making sure the different-lengthed cap screws are in their proper location. Tighten to 8 ft-lb.



H1-023

10. Place the driven pulley assembly into position and secure with the bolt (550) or nut (700). Tighten to 80 ft-lb (550) or 162 ft-lb (700).




CF262

11. Tighten the cap screw with washer to 60 ft-lb.




H1-019

12. Slide the fixed drive face onto the clutch shaft.
13. Spread the faces of the driven pulley by threading a cap screw into one of the bosses of the driven fixed face; then tighten the cap screw until the V-belt drops into the driven pulley 1/2 to 3/4 inch.




CF270A



H1-020A

14. Place the V-belt into position on the driven pulley and over the front shaft.



PR389

■NOTE: The arrows on the V-belt should point in the direction of rotation.

15. Pinch the V-belt together near its center and slide the spacer and movable drive face onto the driveshaft. Using an appropriate spanner wrench, secure the drive face with a nut and (threads coated with red Loctite #271). Tighten the nut to 165 ft-lb.

CAUTION

Make sure the splines extend beyond the drive face or a false torque reading and spline damage may occur.




FI428A

■NOTE: At this point, the cap screw can be removed from between the driven pulley faces.

16. With the vehicle in neutral, rotate the V-belt and clutches counterclockwise until the V-belt is flush with the top of the driven pulley.

17. Place the V-belt cover gasket into position; then install the cover and secure with the cap screws making sure the different-lengthed cap screws are in their proper location. Tighten the cap screws to 8 ft-lb.



CD083

Center Crankcase Components


■NOTE: This procedure cannot be done with the engine/transmission in the frame. Complete Removing procedures for Top-Side, Left-Side, and Right-Side must precede this procedure.

■NOTE: For efficiency, it is preferable to remove and disassemble only those components which need to be addressed and to service only those components. The technician should use discretion and sound judgment.

Separating Crankcase Halves

1. Remove the left-side cap screws securing the crankcase halves. Note the location of the different-lengthed cap screws.
2. Remove the right-side cap screws securing the crankcase halves. Note the location of the different-lengthed cap screws.
3. Using the Crankcase Separator/Crankshaft Remover and tapping lightly with a rubber mallet, separate the crankcase halves. Account for two alignment pins.

■NOTE: To keep the shaft/gear assemblies intact for identification, tap the shafts toward the right-side crankcase half when separating the halves.




PR786

Disassembling Crankcase Half


■NOTE: For steps 1-7, refer to illustration PR787A.

■NOTE: To aid in installing, it is recommended that the assemblies are kept together and IN ORDER.




PR787A

1. Remove the secondary driven shaft assembly (A) noting the location of the bearing locating pins. Account for the bearing C-ring.



PR787B

2. Remove the reverse idler gear assembly (F). Account for all washers, shaft, bushing, and the gear.




CC668

3. Remove the shift shaft (H); then remove the two forks taking note of the direction of the tabs on the forks for assembling purposes.
4. Remove the gear shift shaft (G) noting the location of the two holes on the end of the shaft. Account for a spacer and a washer.



DE677A


5. Remove the countershaft assembly (D). Account for a washer on each end of the countershaft.



CC674

■NOTE: Do not disassemble the countershaft assembly unless necessary. If necessary, see Servicing Center Crankcase Components sub-section.

6. Using a rubber mallet, tap on the crankcase to remove the driveshaft.



CC675

7. Note the timing marks on the crank balancer assembly (B) gear and crankshaft (C) gear for assembling purposes; then slide the crank balancer gear off the crank balancer. Account for the key in the keyway.



CD826

8. Remove the crank balancer.

■NOTE: There is a flat spot on the crank balancer bearing flange to allow clearance past the crankshaft.




CD832B

9. Remove the snap ring securing the water pump driven gear shaft.
10. Using a hydraulic press, remove the crankshaft assembly.


■NOTE: Use a protective end cap to prevent damage to the crankshaft threads.

11. Remove the cap screws securing the oil strainer cap; then remove the cap.
12. Remove the two cap screws securing the oil strainer; then remove the strainer.

■NOTE: Thoroughly clean any sealant from the oil strainer cap.




PR406



MT011A

- Using a suitable press, install the driven gear (C) on the shaft until the gear firmly seats on the shoulder of the shaft.



MT011B

- To remove the secondary drive/bevel gear, remove the secondary drive bearing housing; then remove the nut securing the drive/bevel gear shaft in the bearing and using a plastic mallet, drive the shaft out of the bearing. Account for shim/shims.

■NOTE: Shims should be measured and kept for a starting point in adjusting backlash.

Servicing Center Crankcase Components

SECONDARY OUTPUT DRIVE GEARS


Initial Set-Up

■NOTE: If the secondary output driven shaft is replaced or disassembled, the initial set-up must be performed to establish correct gear tooth contact. If only the secondary output drive shaft or secondary output driven gear is replaced, proceed to Correcting Backlash in this sub-section.

- Install a new bearing (A) onto the secondary driven shaft (B) making sure the bearing locating groove is directed away from the driven gear splines.




MT012



MT008A


4. Install a new seal (F), output yoke (G), and nut (H) and tighten to 74 ft-lb.



MT008B

■**NOTE:** Do not use a new lock nut at this time as this procedure may have to be repeated.

5. Place the assembled shaft into the left crankshaft case; then lightly coat the gear teeth with machinist's lay-out dye. Rotate the shafts through several rotations in both directions. Gear contact should extend from the root to the top of the gear teeth.



MT016A


6. To adjust tooth contact, use the following chart to correctly shim the driven shaft.

Tooth Contact	Shim Correction
Contact at Top	Increase Shim Thickness
Contact at Root	Decrease Shim Thickness

7. After correct tooth contact is established, proceed to Checking Backlash in this sub-section.

Checking Backlash

1. If removed, install the secondary drive/bevel gear shaft into the crankcase; then tighten the nut to 59 ft-lb.
2. Install the secondary drive bearing support; then install the secondary driven output shaft into the crankcase.
3. Mount the dial indicator so the tip is contacting a tooth on the secondary drive bevel gear.
4. While rocking the drive bevel gear back and forth, note the maximum backlash reading on the gauge.



MT005A

5. Acceptable backlash range is 0.127-0.381 mm (0.005-0.015 in.).

Correcting Backlash

■**NOTE:** If backlash measurement is within the acceptable range, no correction is necessary.

1. If backlash measurement is less than specified, remove an existing shim, measure it, and install a new thinner shim.
2. If backlash measurement is more than specified, remove an existing shim, measure it, and install a thicker shim.

■**NOTE:** Continue to remove, measure, and install until backlash measurement is within tolerance. Note the following chart.

Backlash Measurement	Shim Correction
Under 0.127 mm (0.005 in.)	Decrease Shim Thickness
At 0.127-0.381 mm (0.005-0.015 in.)	No Correction Required
Over 0.381 mm (0.015 in.)	Increase Shim Thickness


After backlash and tooth contact are within specifications, apply red Loctite #271 to the driveshaft threads and driven output shaft threads; then using new nuts, tighten the output shaft nut to 59 ft-lb and the output yoke nut to 74 ft-lb.

CRANKSHAFT ASSEMBLY

■**NOTE:** The crankshaft and connecting rod is a non-serviceable assembly. If any component is out of specification, the assembly must be replaced.

Measuring Connecting Rod (Small End Inside Diameter)

1. Insert a snap gauge into the upper connecting rod small end bore; then remove the gauge and measure it with micrometer.



CC290D

2. Maximum diameter must not exceed specifications.

Measuring Connecting Rod (Small End Deflection)

1. Place the crankshaft on a set of V blocks and mount a dial indicator and base on the surface plate. Position the indicator contact point against the center of the connecting rod small end journal.
2. Zero the indicator and push the small end of the connecting rod away from the dial indicator.
3. Maximum deflection must not exceed specifications.

Measuring Connecting Rod (Big End Side-to-Side)

1. Push the lower end of the connecting rod to one side of the crankshaft journal.
2. Using a feeler gauge, measure the gap between the connecting rod and crankshaft journal.




CC289D

3. Acceptable gap range must not exceed specifications.

Measuring Crankshaft (Runout)

1. Place the crankshaft on a set of V blocks.
2. Mount a dial indicator and base on the surface plate. Position the indicator contact at point 1 of the crankshaft.



H1-003

3. Zero the indicator and rotate the crankshaft slowly.

CAUTION


Care should be taken to support the connecting rod when rotating the crankshaft.

4. Maximum runout must not exceed specifications.

■NOTE: Proceed to check runout on the other end of the crankshaft by positioning the indicator contact at point 2 and following steps 3-4.

Measuring Crankshaft (Web-to-Web)


1. Using a calipers, measure the distance from the outside edge of one web to the outside edge of the other web.



H1-005

2. Acceptable width range must not exceed specifications.

COUNTERSHAFT




GZ281A

CAUTION


When disassembling the countershaft, care must be taken to note the direction each major component (dog, gear) faces. If a major component is installed facing the wrong direction, transmission damage may occur and/or the transmission will malfunction. In either case, complete disassembly and assembly will be required.

Disassembling

1. Remove the shift forks noting the positions for assembling; then remove the high driven gear outer washer, high driven gear, high driven gear bearing, high driven gear bushing, and high driven gear inner washer.



2. Remove the drive gear; then remove the snap ring securing the reverse driven gear dog and bushing to the countershaft.



3. Remove the reverse driven gear dog.




GZ313A

4. Remove the snap ring securing the reverse driven gear and washer; then remove the washer and gear.




5. Remove the reverse driven washer; then remove the low driven gear locking washer.





GZ318A


6. Remove the low driven gear. Account for a bearing, bushing, and thrust washer.




GZ316

Assembling

1. From the drive gear end, install a thrust washer, bushing, and bearing; then install the low driven gear and washer.



GZ317A




GZ318

2. Install the low driven gear locking washer; then install the inner reverse driven gear washer.




GZ319B



GZ320B

3. Install the reverse driven bushing and bearing; then install the reverse driven gear.




GZ286A




GZ287

4. Install the outer reverse driven washer; then secure the reverse driven gear assembly with a snap ring.



GZ288A



GZ288B

7. Install the two drive gear washers and the shift forks. The countershaft is now ready for installation.

■NOTE: When installing the countershaft assembly, account for the washer on each end of the shaft.




GZ314

5. Install the reverse driven gear dog onto the countershaft and secure with a snap ring.



GZ313A




GZ312

6. From the opposite end of the countershaft, install the high/low driven gear dog (A), thrust washer (B), bushing (C), bearing (D), high/low driven gear (E), and spacer washer (F).




MT014

2. Apply a liberal amount of engine oil to the crankshaft bearing. Using a propane torch, heat the bearing until the oil begins to smoke; then slide the crankshaft assembly into place.



CC688



CC689

■**NOTE:** If heating the bearing is not possible, the crankshaft can be installed using a crankshaft installing tool.


3. Install the crank balancer.



CD832B


■**NOTE:** It will be necessary to rotate the crank balancer until the counterweight is facing away from the crankshaft; then rotate the crankshaft clockwise into the journal area to allow the crank balancer to be fully seated.

4. Place the key into the crank balancer keyway; then install the crank balancer gear making sure the alignment dots on the crank balancer gear and the crankshaft gear align.




CD826A

5. Install the driveshaft.



CC675

6. Place a washer on each end of the countershaft assembly; then install the assembly.



CC674


7. Place a washer on the end of the gear shift shaft; then install the shaft assembly making sure the two holes on the end of the shaft are positioned vertically. Install the spacer on the shift shaft.



DE677A


8. Insert the two shift forks into the sliding dogs noting the direction of the tabs from disassembling; then install the shift fork shaft.

■**NOTE:** Make sure the shift fork tabs face upward and that they are properly seated into the shift cams.



CC669

9. Install the reverse idler gear assembly noting the positioning of the two washers, gear, bushing, and shaft.



CC668

10. Install the front and rear secondary driven shaft assemblies into the left side of the crankcase making sure the bearing locating pins are toward the top of the crankcase and the bearing C-ring is fully seated in the crankcase.



PR787B

11. Place the oil strainer into position; then secure with the two screws.
12. Place the oil strainer cap into position making sure silicone sealant is applied; then secure the cap with cap screws. Tighten to 10 ft-lb.

Joining Crankcase Halves

1. Apply High-Temp Sealant to the right-side mating surface smoothing out any build-up or bumps.

2. Lightly oil all bearings and grease all shafts in the left-side crankcase.
3. Using a plastic mallet, lightly tap the case halves together until cap screws can be installed.
4. From the left side, install the 8 mm cap screws; then tighten only until snug.

■**NOTE: Rotate the shafts back and forth to ensure no binding or sticking occurs.**

5. From the right side, install the remaining 8 mm cap screws (two inside the case); then tighten only until snug.

■**NOTE: Rotate the shafts back and forth to ensure no binding or sticking occurs.**

6. From the right side, install the case half 6 mm cap screws; then tighten only until snug.

■**NOTE: Rotate the shafts back and forth to ensure no binding or sticking occurs.**

7. From the left side, install the 6 mm cap screws; then tighten only until snug.

■**NOTE: Rotate the shafts back and forth to ensure no binding or sticking occurs.**

8. In a crisscross/case-to-case pattern, tighten the 8 mm cap screws (from steps 4-5) until the halves are correctly joined; then tighten to 20 ft-lb.

■**NOTE: Rotate the shafts back and forth to ensure no binding or sticking occurs.**

9. In a crisscross/case-to-case pattern, tighten the 6 mm cap screws (from steps 6-7) to 8 ft-lb.

■**NOTE: Rotate the shafts back and forth to ensure no binding or sticking occurs.**

AT THIS POINT

After completing center crankcase components, proceed to **Installing Left-Side Components**, to **Installing Right-Side Components**, and to **Installing Top-Side Components**.

Installing Engine/Transmission

■**NOTE: Arctic Cat recommends new gaskets and O-rings be installed whenever servicing the vehicle.**


1. Attach suitable lifting chains to the engine/transmission; then using an engine hoist, lower the assembly into the engine compartment.

WARNING

Keep hands and fingers clear when lowering the engine/transmission into place. The chains could shift causing severe injury.

CAUTION

Make sure that all wiring, hoses, and brake lines are routed away from engine mounts and engine brackets. Pinching or breaking of lines or shorting of wiring could occur.



PR114


■NOTE: The rear engine mounting bracket and rear engine mounts should be attached to the engine. The front engine mounting bracket should be attached to the engine, and the front engine mounts should be in the frame.

2. Align the rear engine mount studs with the holes in the frame and slowly lower into place. The front engine mounting bracket will then slip over the engine mount studs.




PR146

3. Install the flange nuts on the rear engine mount studs; then secure the front engine mounting bracket to the front engine mount studs with two flange nuts. Tighten the four flange nuts to 45 ft-lb.




PR153A




PR147

4. Install the cap screws securing the drive couplers to the drive flanges and tighten to 40 ft-lb.




PR120A


5. Set the exhaust pipe in place; then install the muffler and align the assembly to the engine. Install two cap screws securing the exhaust pipe to the cylinder head and tighten to 20 ft-lb.
6. Install the inlet boot on the V-belt housing; then install the exhaust duct connecting the outlet housing to the V-belt housing. Tighten all clamps securely.





HDX140A




7. Connect the lower coolant hose to the water pump housing; then connect the upper coolant hose to the thermostat housing. Tighten the hose clamps securely.
8. Install the starter wire on the starter and tighten the nut securely; then connect the magneto and crankshaft position sensor connector.




9. From the right-side, connect the speed sensor connector, fuel pump connector, and ECT sensor lead; then install the spark plug cap.




■NOTE: Make sure the main harness ground and battery ground wires are installed and secured in the proper location with the unpainted cap screw.



10. Install the throttle body and tighten the intake boot clamp to 30 in.-lb; then connect the gasline hose, vacuum line, and throttle cable. Install the throttle arm cover.



11. Install the gasline hose connector to the fuel rail.
12. Connect the fuel injector connector and the ISC, MAP, and TPS sensors to the throttle body; then connect the IAT sensor to the air box.
13. Place the air filter assembly into position and secure with the self-tapping screws; then connect the intake boot to the throttle body and the inlet housing boot to the air filter housing. Tighten the clamps securely.
14. Place the shifter assembly into position and secure with the four machine screws. Tighten securely.
15. On the 550, connect the shift cable to the shift arm; then secure with the E-clip.
16. On the 700, properly position the gear position switch on the engine (A to A and B to B); then secure the shift cable bracket to the engine case and tighten the engine case screws to 8 ft-lb. Connect the gear position switch connector.



17. Fill the engine/transmission with the appropriate lubricant.

18. Remove the coolant bleed screw from the upper coolant pipe near the thermostat; then pour the correct mixture of coolant into the radiator. When coolant with no air bubbles flows from the bleed hole, install the screw and tighten securely; then complete filling the system.



19. Connect the positive battery cable to the battery; then connect the negative cable.

■NOTE: Before operating vehicle, check and adjust shift lever/cable as required (see Periodic Maintenance).

20. Install the left- and right-side seat bases; then install the center console and seats. Make sure the seats lock securely.
21. Start the engine and warm up to operating temperature. Check for fluid leaks; then shut off engine and check oil and coolant levels (see Periodic Maintenance - Engine/Transmission Oil - Filter and Fuel/Lubrication/Cooling - Liquid Cooling System).

Prowler 1000 (Table of Contents)

Removing Engine/Transmission.....	78
Top-Side Components	84
Removing Top-Side Components	84
Servicing Top-Side Components.....	88
Installing Top-Side Components	93
Left-Side Components	100
Removing Left-Side Components	100
Servicing Left-Side Components	102
Installing Left-Side Components	104
Right-Side Components.....	106
Removing Right-Side Components.....	107
Servicing Right-Side Components.....	109
Installing Right-Side Components.....	113
Center Crankcase Components.....	116
Separating Crankcase Halves.....	116
Disassembling Crankcase Half	117
Servicing Center Crankcase Components.....	118
Assembling Crankcase Half.....	126
Joining Crankcase Halves.....	128
Installing Engine/Transmission.....	129

Removing Engine/Transmission

Many service procedures can be performed without removing the engine/transmission from the frame. Closely observe the note introducing each sub-section for this important information.

AT THIS POINT

If the technician's objective is to service/replace left-side cover oil seals, front output joint oil seal, rear output joint oil seal, and/or the oil strainer (from beneath the engine/transmission), the engine/transmission does not have to be removed from the frame.


Support the vehicle on a suitable lift or jack stands allowing room to perform work from the underside.

■NOTE: Locate the jack stands to allow removing of the center belly panel.

WARNING

Make sure the vehicle is solidly supported on the support stands to avoid injury.

1. Remove the floor.
2. Clamp off the lower radiator hose near the water pump; then place a suitable container and funnel under the water pump.



PR587A

3. Loosen the hose clamp and remove the hose from the water pump; then release the clamp from step 3 and drain the coolant.



PR588

4. Remove the upper hose from the front cylinder head allowing coolant to drain from the rear cylinder and thermostat housing.




PR590


5. Mark all routing clip locations with an appropriate marker; then remove the routing clips from their designated locations.



PR928A




PR931A




PR927A

6. Disconnect the negative battery cable; then from the right side, disconnect the engine coolant temperature (ECT) sensor (A), inlet air temperature (IAT) sensor (B), fuel pump/fuel gauge connector (C), rear ignition coil (D), and throttle position sensor (TPS) connector (E).




PR927B

7. Remove the rear spark plug cap; then from the left side, remove the fuel injector connectors (A), manifold absolute pressure (MAP) sensor (B), and idle speed control (ISC) valve (C).




PR596

8. Disconnect the front ignition coil and remove the front spark plug; then route the engine harness out of the engine compartment.



PR930A


9. From the left rear, disconnect the speed sensor connector, stator coil connector, crankshaft position (CKP) sensor, and gear position switch connector.
10. Remove four mounting cap screws securing the cross brace assembly to the frame; then remove the cap screw securing the upper coolant pipe support clamp to the cross brace.



PR596A




PR929




PR598A

11. Remove the machine screw securing the throttle arm cover; then loosen the mounting nuts and disconnect the throttle cable from the throttle body.



PR666A

12. Remove the E-clip from the transmission shift arm; then remove the shifter cable mounting bracket from the crankcase and move the shift support assembly and cable to right side of the vehicle.




PR663A

WARNING


Always make certain the battery is disconnected and the ignition key is removed before disconnecting fuel system components. Gasoline could be accidentally discharged by an activated fuel pump causing severe injury or death.

14. Remove four sheet metal screws securing the air filter mounting bracket to the frame; then loosen the intake boot clamp and remove the air filter assembly.




PR603A


15. Disconnect the engine/harness ground; then disconnect the starter cable from the starter.



PR604A



PR671A




PR605A

16. Disconnect the crankcase breather hoses from the rear cylinder and auxiliary drive cover and remove the separator tank and breather hoses.
17. Remove the upper radiator hose from the thermostat housing; then move the coolant pipe to the left side of the vehicle.



PR607A

18. Remove the sheet metal screws securing the constant variable transmission (CVT) cooling duct to the frame; then loosen the hose clamps and remove the duct from the front elbow and CVT boot.




PR670A

19. Remove the inlet boot from the CVT cover; then remove the outlet boot from the rear of the CVT cover.
20. Remove the oil cooler hoses from the fittings on the oil filter base and crankcase; then plug the hoses and cap the fittings.




PR617A




PR616A'


21. Remove the springs securing the muffler to the exhaust pipe and remove the muffler. Account for a grafoil seal.



PR668




PR661A



PR661B

22. Remove two cap screws securing the front exhaust pipe to the cylinder head; then remove two springs securing the front and rear exhaust pipes together. Remove the front exhaust pipe. Account for a grafoil seal and a grafoil gasket.



PR643A



Gasket

Seal

PR625A

■NOTE: The grafoil gasket may remain in the cylinder head.


23. Remove the cap screws securing the rear exhaust pipe to the cylinder head and remove the exhaust pipe. Account for a grafoil gasket.




PR641A

■NOTE: The grafoil gasket may remain in the cylinder head.


24. Mark the components on the front driveshaft; then remove the three cap screws securing the driveshaft to the front differential. Slide the spline boot forward and remove the driveshaft from the output yoke.



PR638A



PR629



PR639A

25. Remove four cap screws securing the rear driveshaft to the output flange. The rear driveshaft can remain on the vehicle.




PR647

26. Remove the lock nuts from the engine through-bolts; then attach a lifting chain to the engine/transmission.




PR630



PR631

27. Using a suitable engine hoist, remove the weight from the through-bolts; then remove the bolts. Account for a flat washer on each bolt and noting the front bolt is longer than the rear.

28. Lift the engine/transmission enough to clear the engine mounting tabs on the frame; then remove the assembly from the right side of the vehicle.



PR633

Top-Side Components

■NOTE: For efficiency, it is preferable to remove and disassemble only those components which need to be addressed and to service only those components. The technician should use discretion and sound judgment.

☞ AT THIS POINT

To service any one specific component, only limited disassembly of components may be necessary. Note the AT THIS POINT information in each sub-section.

■NOTE: The engine/transmission does not need to be removed for this procedure.

Removing Top-Side Components

A. Valve Cover/Rocker Arms B. Cylinder Head/Camshaft

1. Remove the timing inspection plug, spark plugs, and magneto housing cover; then install the 10 mm cap screw (left-hand threads) in the crankshaft and rotate the desired cylinder to top-dead-center of the compression stroke.



GZ027



GZ026

■NOTE: Timing marks on the rotor/flywheel are stamped with an "F" (front cylinder) and "R" (rear cylinder) adjacent to the mark.




GZ063



GZ059

2. Remove the tappet covers on the cylinder being serviced. The tappets should not have pressure on them.
3. Loosen the cap screws securing the valve cover to the head.




GZ126A


4. Remove all cap screws except the two top-side cap screws next to the spark plug. These will keep the alignment pins in place. Note the two rubber washers on the remaining cap screws.
5. Remove the valve cover. Account for and note the orientation of the cylinder head plug. Note the location of the two alignment pins.



GZ162



GZ155



GZ132A

6. Remove the cap screw on the end of the tensioner; then using a flat-blade screwdriver, turn the tensioner clockwise to remove the tension. Remove the two cap screws securing the tensioner adjuster assembly and remove the assembly. Account for a gasket.




GZ405

7. Using an awl, rotate the C-ring in its groove until it is out of the cylinder head; then remove the C-ring.


■NOTE: Care should be taken not to drop the C-ring into the crankcase.

8. Bend the washer tabs down and remove the two cap screws securing the sprocket to the camshaft; then drop the sprocket off the camshaft being careful not to drop the locating pin into the engine.




GZ154A

9. While holding the chain, slide the sprocket and cam-shaft out of the cylinder head.



CC266D


■NOTE: Loop the chain over the cylinder head and secure it to keep it from falling into the crankcase.



GZ408


10. Remove the five nuts securing the cylinder head to the cylinder; then remove the four cylinder head cap screws and washers.

■NOTE: Removing the starter will simplify removal of the front cylinder base nuts.




GZ209A

11. Remove the cylinder head from the cylinder, remove the gasket, and account for two alignment pins; then remove the cam chain guide.



GZ151



GZ161

12. If the remaining cylinder head is to be serviced, apply tension to the loose timing chain and rotate the second cylinder to top-dead-center of the compression stroke; then repeat steps 2-11 on the other cylinder head.

AT THIS POINT

To service valves and cylinder head, see **Servicing Top-Side Components** sub-section.

AT THIS POINT


To inspect cam chain guide, see **Servicing Top-Side Components** sub-section.

C. Cylinders

D. Pistons


■NOTE: Steps 1-12 in the preceding sub-section must precede this procedure.

13. Remove the cap screws securing the water hose union to the cylinder; then remove the union from the cylinder. Account for an O-ring.




GZ140A

14. Remove the two nuts securing the cylinder to the crankcase.




GZ141A



GZ160A

15. Lift the cylinder off the crankcase taking care not to allow the piston to drop against the crankcase. Account for the gasket and two alignment pins.



GZ142



GZ144

AT THIS POINT

To service cylinder, see Servicing Top-Side Components sub-section.

CAUTION

When removing the cylinder, be sure to support the piston to prevent damage to the crankcase and piston.

16. Using an awl, remove one piston-pin circlip.




GZ145

17. Using the Piston Pin Puller, remove the piston pin. Account for the opposite-side circlip. Remove the piston.

■**NOTE:** It is advisable to remove the opposite-side circlip prior to using the puller.

■**NOTE:** Support the connecting rod with rubber bands or a piece of hose to avoid damaging the rod or install a suitable connecting rod holder.



GZ146A

CAUTION

Do not allow the connecting rod to go down inside the crankcase. If the rod is down inside the crankcase and the crankshaft is rotated, severe damage will result.

AT THIS POINT

To service piston, see Servicing Top-Side Components sub-section.

AT THIS POINT

To service center crankcase components only, proceed to Removing Left-Side Components.

Servicing Top-Side Components

VALVE ASSEMBLY

When servicing valve assembly, inspect valve seats, valve stems, valve faces, and valve stem ends for pits, burn marks, or other signs of abnormal wear.

■NOTE: Whenever a valve is out of tolerance, it must be replaced.


Cleaning/Inspecting Valve Cover

■NOTE: If the valve cover cannot be trued, the cylinder head assembly must be replaced.

1. Wash the valve cover in parts-cleaning solvent.
2. Place the valve cover on the Surface Plate covered with #400 grit wet-or-dry sandpaper. Using light pressure, move the valve cover in a figure eight motion. Inspect the sealing surface for any indication of high spots. A high spot can be noted by a bright metallic finish. Correct any high spots before assembly by continuing to move the valve cover in a figure eight motion until a uniform bright metallic finish is attained.

CAUTION

Do not remove an excessive amount of the sealing surface or damage to the camshaft will result. Always check camshaft clearance when resurfacing the valve cover.



CC130D

CAUTION

Water or parts-cleaning solvent must be used in conjunction with the wet-or-dry sandpaper or damage to the sealing surface may result.

Removing Valves


■NOTE: Index all valves, springs, and cotters to their original position when removing. When installing, all valve components should be installed in their original position.

1. Using a valve spring compressor, compress the valve springs and remove the valve cotters. Account for an upper spring retainer.



CC132D

2. Remove the valve seal and the lower remaining spring seat. Discard the valve seal.



CC136D

■NOTE: The valve seals must be replaced.

3. Remove the valve springs; then invert the cylinder head and remove the valves.

Measuring Valve Guide (Bore)

1. Insert a suitable bore gauge 1/2 way into each valve guide bore and record the measurement.
2. Acceptable inside diameter range must be within specifications.
3. If a valve guide is out of tolerance, it must be replaced.

Servicing Valves/Valve Guides/Valve Seats


If valves, valve guides, or valve seats require servicing or replacement, Arctic Cat recommends the components be taken to a qualified machine shop for servicing.

CAUTION

If valves are discolored or pitted or if the seating surface is worn, the valve must be replaced. Do not attempt to grind the valves or severe engine damage may occur.

Installing Valves


1. Apply grease to the inside surface of the valve seals; then place a lower spring seat and valve guide seal over each valve guide.



CC144D

2. Insert each valve into its original location.
3. Install the valve springs with the painted end of the spring facing away from the cylinder head.

■NOTE: If the paint is not visible, install the ends of the springs with the closest wound coils toward the head.



4. Place a spring retainer over the valve springs; then using the valve spring compressor, compress the valve springs and install the valve cotters.

PISTON ASSEMBLY

■NOTE: Whenever a piston or pin is out of tolerance, it must be replaced.

Removing Piston Rings

1. Starting with the top ring, slide one end of the ring out of the ring-groove.
2. Remove each ring by working it toward the dome of the piston while rotating it out of the groove.




CC400D

Inspecting Piston

1. Inspect the piston for cracks in the piston pin, dome, and skirt areas.
2. Inspect the piston for seizure marks or scuffing.
3. Inspect the perimeter of each piston for signs of excessive "blowby." Excessive "blowby" indicates worn piston rings or an out-of-round cylinder.

Measuring Piston-Ring End Gap (Installed)


1. Place each compression ring in the wear portion of the cylinder. Use the piston to position each ring squarely in the cylinder.
2. Using a feeler gauge, measure each piston-ring end gap. Acceptable ring end gap must not exceed specifications.



CC280D


Measuring Piston Pin (Outside Diameter) and Piston-Pin Bore

1. Measure the piston pin outside diameter at each end and in the center. If measurement exceeds specifications, the piston pin must be replaced.



ATV-1070


2. Insert an inside dial indicator into the piston-pin bore. The diameter must not exceed specifications. Take two measurements to ensure accuracy.



ATV-1069

Measuring Piston Skirt/Cylinder Clearance

1. Measure the cylinder front to back in six places.




CC127D


2. Measure the corresponding piston diameter at a point 15 mm (0.6 in.) above the piston skirt at a right angle to the piston-pin bore. Subtract this measurement from the measurement in step 1. The difference (clearance) must not exceed specifications.

Installing Piston Rings

1. Install the expander spring making sure the ends are aligned on the wire; then install the oil ring with the ring gap 90° from the spring gap and the marking "E TOP" directed toward the top of the piston.



GZ168




GZ169A

2. Install the second compression ring with the marking "E TOP" directed toward the top of the piston.



GZ167

3. Install the first (unmarked) compression ring; then rotate the rings so the ring gaps are approximately 180° apart and oriented to the piston pin.



GZ187A

CAUTION

Incorrect installation of the piston rings will result in engine damage.

CYLINDER/CYLINDER HEAD ASSEMBLY

■**NOTE:** If the cylinder/cylinder head cannot be trued, they must be replaced as an assembly.

Cleaning/Inspecting Cylinder Head

CAUTION

The cylinder head studs must be removed for this procedure.

1. Using a non-metallic carbon removal tool, remove any carbon buildup from the combustion chamber being careful not to nick, scrape, or damage the combustion chamber or the sealing surface.
2. Inspect the spark plug hole for any damaged threads. Repair damaged threads using a "heli-coil" insert.
3. Place the cylinder head on the surface plate covered with #400 grit wet-or-dry sandpaper. Using light pressure, move the cylinder head in a figure eight motion. Inspect the sealing surface for any indication of high spots. A high spot can be noted by a bright metallic finish. Correct any high spots before assembly by continuing to move the cylinder head in a figure eight motion until a uniform bright metallic finish is attained.

CAUTION

Water or parts-cleaning solvent must be used in conjunction with the wet-or-dry sandpaper or damage to the sealing surface may result.

Measuring Cylinder Head Distortion

1. Remove any carbon buildup in the combustion chamber.
2. Lay a straightedge across the cylinder head; then using a feeler gauge, check the distortion between the head and the straightedge.
3. Maximum distortion must not exceed specifications.



CC141D


Cleaning/Inspecting Cylinder

1. Wash the cylinder in parts-cleaning solvent.
2. Inspect the cylinder for pitting, scoring, scuffing, warpage, and corrosion. If marks are found, repair the surface using a cylinder hone (see Inspecting Cylinder in this sub-section).

3. Place the cylinder on the surface plate covered with #400 grit wet-or-dry sandpaper. Using light pressure, move the cylinder in a figure eight motion. Inspect the sealing surface for any indication of high spots. A high spot can be noted by a bright metallic finish. Correct any high spots before assembly by continuing to move the cylinder in a figure eight motion until a uniform bright metallic finish is attained.


CAUTION

Water or parts-cleaning solvent must be used in conjunction with the wet-or-dry sandpaper or damage to the sealing surface may result.



CC129D


4. Using a slide gauge and a dial indicator or a snap gauge, measure the cylinder bore diameter in three locations from top to bottom and again from top to bottom at 90° from the first measurements for a total of six measurements. The trueness (out-of-roundness) is the difference between the highest and lowest reading. Maximum trueness (out-of-roundness) must not exceed specifications.



CC127D

5. Wash the cylinder in parts-cleaning solvent.
6. Inspect the cylinder for pitting, scoring, scuffing, and corrosion. If marks are found, repair the surface using a #320 grit ball hone.

■**NOTE: To produce the proper 60° cross-hatch pattern, use a low RPM drill (600 RPM) at the rate of 30 strokes per minute. If honing oil is not available, use a lightweight petroleum-based oil. Thoroughly clean cylinder after honing using soap and hot water. Dry with compressed air; then immediately apply oil to the cylinder bore. If the bore is severely damaged or gouged, replace the cylinder.**



7. If any measurement exceeds the limit, replace the cylinder and piston.


Inspecting Cam Chain Guide

1. Inspect cam chain guide for cuts, tears, breaks, or chips.
2. If the chain guide is damaged, it must be replaced.

Measuring Camshaft Runout

■NOTE: If the camshaft is out of tolerance, it must be replaced.


1. Place the camshaft on a set of V blocks; then position the dial indicator contact point against the shaft and zero the indicator.



2. Rotate the camshaft and note runout; maximum runout must not exceed specifications.

Measuring Camshaft Lobe Height

1. Using a calipers, measure each cam lobe height.




2. The lobe heights must be greater than minimum specifications.

Inspecting Camshaft Bearing Journal

1. Inspect the bearing journal for scoring, seizure marks, or pitting.
2. If excessive scoring, seizure marks, or pitting is found, the cylinder head assembly must be replaced.

Measuring Camshaft to Cylinder Head Clearance


1. Remove the adjuster screws and jam nuts.




2. Place a strip of plasti-gauge in each of the camshaft lands in the cylinder head.
3. Place the valve cover on the cylinder head and secure with the valve cover cap screws. Tighten securely.

■NOTE: Do not rotate the camshaft when measuring clearance.

4. Remove the cap screws securing the valve cover to the cylinder head; then remove the valve cover and camshaft.
5. Match the width of the plasti-gauge with the chart found on the plasti-gauge packaging to determine camshaft to cylinder head and valve cover clearance.



6. If clearance is excessive, measure the journals of the camshaft.




CC287D


■NOTE: If the journals are worn, replace the camshaft; then measure the clearance again. If it is still out of tolerance, replace the cylinder head.

Inspecting Camshaft Spring/Drive Pin (Front Camshaft Only)

1. Inspect the spring and drive pin for damage.



CF061A



CF060A


2. If damaged, the camshaft must be replaced.

Installing Top-Side Components

A. Pistons B. Cylinders


1. Install the piston on the connecting rod making sure the circlip on each side is fully seated in the piston.

■NOTE: The piston should be installed so the arrow points toward the exhaust of the respective cylinder.



GZ166

2. Place the two alignment pins into position. Place the cylinder gasket into position with a drop of silicone sealant at the front and rear crankcase junction; then place a piston holder (or suitable substitute) beneath the piston skirt and square the piston in respect to the crankcase.



GZ146B




GZ159

3. Lubricate the inside wall of the cylinder; then using a ring compressor, compress the rings and slide the cylinder over the piston. Route the cam chain up through the cylinder cam chain housing; then remove the piston holder and seat the cylinder firmly on the crankcase.

CAUTION


The cylinder should slide on easily. Do not force the cylinder or damage to the piston, rings, cylinder, or crankshaft assembly may occur.




GZ142

4. Loosely install the two nuts securing the cylinder to the crankcase.

■NOTE: The two cylinder-to-crankcase nuts will be tightened in step 10.



GZ141A



GZ160A

5. Install the coolant hose onto the crankcase union and tighten the clamp.

C. Cylinder Head

D. Valve Cover

■NOTE: Steps 1-5 in the preceding sub-section must precede this procedure.

6. Place the chain guide into the cylinder.


CAUTION

Care should be taken that the bottom of the chain guide is secured in the crankcase boss.




GZ161A

7. Place a new head gasket into position on the cylinder. Place the alignment pins into position; then place the head assembly into position on the cylinder while guiding the cam chain through the cylinder head.



GZ151

8. Apply a light coat of grease to the cylinder head cap screw threads and washers; then install the cap screws. Tighten only until snug.



GZ132B

9. Loosely install the five cylinder head nuts.
10. In a crisscross pattern, tighten the four cylinder head cap screws (from step 8) initially to 20 ft-lb; then increase to 30 ft-lb, and finally to 37 ft-lb. Tighten the 8 mm nut (from step 9) to 21 ft-lb; then using a crisscross pattern, tighten the 6 mm nuts (from step 9) to 8.5 ft-lb. Tighten the two cylinder-to-crankcase nuts (from step 4) to 8 ft-lb.


■NOTE: If both cylinders have been removed, repeat steps 1-10 for the remaining cylinder.

11. With the timing inspection plug removed and the front chain held tight, rotate the crankshaft until the front piston is at TDC indicated by timing mark F.




GZ063

12. With the alignment pin installed in the front camshaft, loosely place the cam sprocket (with the recessed side facing the cam shaft lobes) onto the camshaft. At this point, do not “seat” the sprocket onto the shaft.



732-307B




GZ130

■NOTE: At this point, oil the camshaft bearings, cam lobes, and the three seating journals on the cylinder.


13. With the cam lobes directed down (toward the piston), maneuver the camshaft/sprocket assembly through the chain and towards its seating position; then loop the chain over the sprocket.

■NOTE: Note the position of the alignment marks on the end of the camshaft. They must be parallel to the valve cover mating surface. If rotating the camshaft is necessary for alignment, rotate the sprocket inside the chain until the alignment pin can be engaged in the sprocket with the camshaft properly aligned to the head.



GZ519

14. Seat the cam sprocket onto the camshaft making sure the alignment pin in the camshaft aligns with the smallest hole in the sprocket; then place the cam-shaft/sprocket assembly onto the cylinder ensuring the following.




GZ190B

- Piston still at top-dead-center.
- Camshaft lobes directed down (toward the piston).
- Camshaft alignment marks parallel to the valve cover mating surface.
- Recessed side of the sprocket directed toward the cam lobes.
- Camshaft alignment pin and sprocket alignment hole (smallest) are aligned.

CAUTION

If any of the above factors are not as stated, go back to step 11 and carefully proceed.

15. Place the tab-washer onto the sprocket making sure it covers the pin in the alignment hole.



ATV1027

CAUTION

Care must be taken that the tab-washer is installed correctly to cover the alignment hole on the sprocket. If the alignment pin falls out, severe engine damage will result.

16. Install the first cap screw (threads coated with red Loctite #271) securing the sprocket and tab-washer to the camshaft. Tighten only until snug.




GZ195

17. Keeping tension on the opposite cam chain, rotate the crankshaft until the second cap screw securing the sprocket to the camshaft can be installed; then install the cap screw (threads coated with red Loctite #271) and tighten to 11 ft-lb. Bend the tab to secure the cap screw.

CAUTION

Failure to keep tension on any loose cam chain may cause severe engine damage.



GZ193

18. Rotate the crankshaft until the first cap screw (from step 16) can be tightened; then tighten to 11 ft-lb. Bend the tab to secure the cap screw.

AT THIS POINT


Return the engine to TDC on the front cylinder making sure the cam lobes are directed downward to ensure correct starting point for step 19.

19. Keeping tension on the rear cam chain, rotate the engine forward 270° until rear piston is at TDC indicated by timing mark R.




GZ59

20. With the alignment pin installed in the rear camshaft, loosely place the cam sprocket (with the recessed side facing the cam shaft lobes) onto the camshaft. At this point, do not "seat" the sprocket onto the shaft.



732-307B




GZ130


■NOTE: At this point, oil the camshaft bearings, cam lobes, and the three seating journals on the cylinder.

21. With the cam lobes directed down (toward the piston), maneuver the camshaft/sprocket assembly through the chain and towards its seating position; then loop the chain over the sprocket.

■NOTE: Note the position of the alignment marks on the end of the camshaft. They should be parallel with the plane of the cylinder head. If rotating the cam-shaft is necessary for alignment, rotate the sprocket inside the chain until the alignment pin can be engaged in the sprocket with the camshaft in the nearest possible position to parallel.




GZ519



GZ518

22. Seat the cam sprocket onto the camshaft making sure the alignment pin in the camshaft aligns with the smallest hole in the sprocket; then place the cam-shaft/sprocket assembly onto the cylinder ensuring the following.



GZ190B


A. Piston still at top-dead-center.
B. Camshaft lobes directed down (toward the piston).

C. Camshaft alignment marks parallel to the valve cover mating surface.
D. Recessed side of the sprocket directed toward the cam lobes.
E. Camshaft alignment pin and sprocket alignment hole (smallest) are aligned.

CAUTION

If any of the above factors are not as stated go back to step 19 and carefully proceed.

23. Place tab-washer onto the sprocket making sure it covers the pin in the alignment hole.




ATV-1027

CAUTION


Care must be taken that the tab-washer is installed correctly to cover the alignment hole on the sprocket. If the alignment pin falls out, severe engine damage will result.

24. Install the first cap screw (threads coated with red Loctite #271) securing the sprocket and tab-washer to the camshaft. Tighten only until snug.




GZ195

25. Rotate the crankshaft until the second cap screw securing the sprocket to the camshaft can be installed; then install the cap screw (threads coated with red Loctite #271) and tighten to 11 ft-lb. Bend the tab to secure the cap screw.



GZ193

26. Rotate the crankshaft until the first cap screw (from step 23) can be addressed; then tighten to 11 ft-lb. Bend the tab to secure the cap screw.



GZ194

27. Place the C-rings into position in their grooves in the cylinder heads.




CC012D

28. Install the cylinder head plugs in the cylinder heads with the open end facing downward and toward the inside.

CAUTION

The open end of the plug must be positioned downward.



GZ162A


29. Remove the cap screw from the end of the chain tensioner; then using a flat-blade screwdriver, rotate the adjuster screw inside the tensioner clockwise until the screw bottoms.



CD501


■NOTE: The adjuster shaft will be drawn into the tensioner as the adjuster screw is rotated clockwise. The adjuster shaft tension will be released in step 30.

30. Place the chain tensioner adjuster assembly and gasket into position on the cylinder and secure with the two cap screws.




CD469


31. Using a flat-blade screwdriver, rotate the adjuster screw inside the tensioner counterclockwise until the tensioner spring bears tension; then install the cap screw into the end of the chain tensioner.



GZ201




GZ206




CD471

32. Loosen the four adjuster screw jam nuts; then loosen the four adjuster screws on the rocker arms in the valve cover.




GZ199

33. Apply a thin coat of Three Bond Sealant to the mating surfaces of the cylinder heads.



GZ202

34. Lubricate the camshaft journals and lobes with engine oil; then place the valve cover into position.



CC003D

35. Install the top side cap screws with rubber washers; then install the remaining cap screws. Tighten only until snug.

36. In a crisscross pattern starting from the center and working outward, tighten the cap screws on both valve covers to 8.5 ft-lb.

37. Adjust valve/tappet clearance (see Periodic Maintenance/Tune-Up).

38. Place the tappet covers into position on the valve cover making sure the O-rings are properly installed. Tighten the cap screws to 9 ft-lb.



GZ208

39. If removed, install the spark plugs. Tighten securely.


Left-Side Components

■NOTE: For efficiency, it is preferable to remove and disassemble only those components which need to be addressed and to service only those components. The technician should use discretion and sound judgment.

☞ AT THIS POINT

To service any one specific component, only limited disassembly of components may be necessary. Note the AT THIS POINT information in each sub-section.

■NOTE: The engine/transmission does not have to be removed from the frame for this procedure.



GZ224A


■NOTE: The starter is not serviceable and must be replaced as a complete assembly.

3. Remove the rotor/flywheel nut; then install the appropriate crankshaft protector into the crankshaft.



H2-018


4. Install Magneto Rotor Remover Set and loosen the rotor/flywheel; then remove the crankshaft protector and rotor/flywheel from the crankshaft. Account for the flywheel key.



GZ212A

☞ AT THIS POINT

To replace stator coils/crankshaft position sensor, see Electrical System.



GZ216

2. Remove the starter motor, starter driven gear (A), starter countershaft bushing (B), and starter countershaft gear (C); then remove the starter gear shafts (D) noting the longer shaft is nearest the starter.



GZ217

5. With the flywheel key removed, remove the starter ring-gear and spacer washer.



GZ218




GZ249

6. Remove the hose clamps from the water pump; then remove the coolant hoses from the water pump outlets and coolant pipes.



GZ218

7. Remove the two cap screws securing the water pump to the crankcase.




GZ230A

8. Remove the water pump. Account for an O-ring.


■NOTE: The water pump is a non-serviceable component and must be replaced as a complete assembly.

9. Remove the cap screws securing the speed sensor housing to the crankcase; then remove the speed sensor housing. Account for a gasket.



GZ524

10. Remove the nut (A) from the shift cam stopper support (B); then remove the cam stopper spring (C). Account for a flat washer (D), cam stopper (F), and shim (E).



H2-019C

11. Remove the cap screw securing the shift cam plate to the shift cam shaft and remove the shift cam plate; then remove the shift shaft.



12. Remove the snap ring securing the speed sensor trigger to the shaft and remove the trigger using a suitable "two-jawed" puller. Account for a gasket.



13. Remove the cap screws securing the oil filler cover to the crankcase; then remove the cover. Account for an O-ring.



Servicing Left-Side Components

INSPECTING STARTER CLUTCH/GEAR

1. Place the starter clutch gear onto the rotor/flywheel and attempt to rotate the starter clutch gear clockwise. It should lock up to the rotor/flywheel. Rotate the gear counterclockwise and it should turn freely. If it moves or locks up both ways, the starter clutch must be replaced.

2. Inspect the starter clutch gear for chipped or missing teeth or discoloration/scoring of the clutch surface. Inspect the bearing for loose, worn, or discolored rollers. If bearing is damaged, it must be replaced.



3. Inspect the one-way bearing for chipped surfaces, missing rollers, or discoloration. If any of the above conditions exist, replace the starter clutch assembly.




REPLACING STARTER CLUTCH ASSEMBLY

1. Remove the cap screws securing the one-way clutch assembly to the flywheel; then remove from the flywheel.



2. Thoroughly clean the rotor/flywheel; then install the new starter one-way clutch and secure with the cap screws after applying a drop of red Loctite #271 to the threads. Tighten to 26 ft-lb using a crisscross pattern. Make sure the one-way bearing is installed with the notches directed away from the rotor/flywheel.



FI576A



FI580



FI578

REPLACING STARTER GEAR BEARING

1. Support the starter clutch gear in a press making sure to support the hub around the entire circumference; then using a suitable bearing driver, press the bearing from the gear.



FI583


2. Thoroughly clean the gear hub; then apply a drop of green Loctite #620 to the bearing outer race and press into the gear hub until even with the lower chamfer radius.

INSPECTING STATOR COIL/MAGNETO COVER ASSEMBLY

1. Inspect the stator coil for burned or discolored wiring, broken or missing hold-down clips, or loose cap screws.
2. Inspect the bearings in the magneto housing for discoloration, roughness when rotated, and secure fit in bearing bores.

REPLACING STATOR COIL/CRANKSHAFT POSITION SENSOR

1. Remove the three cap screws securing the stator coil, two cap screws securing the crankshaft position sensor, and two cap screws from the harness hold-down.
2. Lift the rubber grommet out of the housing; then remove the stator coil/crankshaft position sensor. Account for and note the position of the harness hold-down under the crankshaft position sensor.





H2-017A




H2-027

3. Install the new stator coil assembly and secure with three cap screws using a drop of red Loctite #271 on each. If installing the existing magneto cover, tighten the cap screws to 11 ft-lb. If installing a new magneto cover, tighten the cap screws to 13 ft-lb.
4. Place the stator wire harness hold-down into position; then install the crankshaft position sensor and secure with two cap screws. Tighten securely.
5. Install the upper cable hold-down and secure with the cap screws. Tighten securely.




H2-023



GZ254


4. If removed, install the shim (E) and cam stopper (F); then with the cam stopper support (B) in place, install the spring (C), washer (D), and nut (A). Tighten to 8 ft-lb.



FW-017B



3. Clean the countershaft and trigger splines thoroughly and install the inner snap ring onto the shaft; then apply green Loctite #620 to the trigger and countershaft splines and install the trigger. Secure with a flat washer and outer snap ring.



GZ256

5. Install the shift cam stopper spring onto the shift cam stopper and secure with a flat washer and nut. Tighten to 8 ft-lb.



6. Install the shift cam plate onto the shift cam shaft and secure with the cap screw. Tighten to 8 ft-lb.



7. Install the shift shaft into the crankcase making sure the washer is properly located; then align the timing reference marks and completely seat the shift shaft.



8. Apply grease to the lips of the shift shaft seal in the speed sensor housing; then using a new gasket, install the speed sensor housing and secure with the cap screws. Tighten in a crisscross pattern to 8 ft-lb.



9. With the O-ring properly positioned, install the water pump. Secure using the two existing cap screws.



■NOTE: The longer cap screw goes on the top of the water pump.


10. Install the coolant hoses and secure with the hose clamps.
11. Install the spacer washer on the crankshaft; then install the starter ring gear.





GZ226

12. Place the key into the keyway in the crankshaft; then wipe all oil from the crankshaft surface and rotor/flywheel bore and install the rotor/flywheel onto the crankshaft aligning the keyway with the key. Secure with the nut (coated with red Loctite #271) tightened to 105 ft-lb.




GZ225

CAUTION

Make sure the one-way starter clutch is properly engaged with the starter ring gear before installing and tightening the rotor/flywheel nut or damage to the clutch assembly could occur.

13. Install the starter driven and counter gear shafts (D) into the crankcase (longer shaft to the front); then install the starter countershaft gear (C), starter driven gear (A), and bushing (B) making sure the chamfered gear teeth on the countershaft gear are directed outward.




GZ224A

14. Install the starter motor with a new O-ring lightly lubricated with grease; then tighten the mounting cap screws to 8 ft-lb.



GZ251

15. Using Seal Protector Tool, install the outer magneto cover using a new gasket and secure with the cap screws. Using the pattern shown, tighten to 112 in.-lb.



GZ212B

Right-Side Components

■NOTE: For efficiency, it is preferable to remove and disassemble only those components which need to be addressed and to service only those components. The technician should use discretion and sound judgment.

☞ AT THIS POINT


To service any one specific component, only limited disassembly of components may be necessary. Note the AT THIS POINT information in each sub-section.

■NOTE: The engine/transmission does not have to be removed from the frame for this procedure.

Removing Right-Side Components


- A. CVT Cover**
- B. Driven Clutch**
- C. Clutch Cover**
- D. Centrifugal Clutch**

1. Remove the cap screws securing the CVT cover; then using a rubber mallet, gently tap on the cover tabs to loosen the cover. Account for a gasket and two alignment pins.




GZ244B

2. Remove the nut securing the movable drive face; then remove the face. Account for a spacer and a flat washer.



GZ074



CD966A


3. Remove the V-belt.

4. Remove the nut securing the fixed driven assembly; then remove the assembly.




PR388

5. Remove the fixed drive face.
6. Remove the cap screws securing the V-belt housing to the crankcase; then remove the V-belt housing. Account for two alignment pins.




GZ246A

7. Remove the cap screws securing the clutch cover; then using a rubber mallet, carefully remove the cover. Account for two alignment pins.




GZ246B

8. Using a suitable press, remove the clutch housing from clutch cover, account for fixed drive face spacer and O-ring.



GZ511



GZ507



CC596

■NOTE: Account for and inspect the clutch housing seal.



GZ500

9. Remove and retain the two machine cap screws, and bearing retainers.



GZ513

11. Carefully remove the existing clutch housing seal using caution not to damage the sealing surface of the cover.




GZ438A

■NOTE: Heating the nut will aid in removal.


12. Remove the nut (left-hand threads) securing the clutch shoe assembly.

13. Remove the water pump drive housings. Account for a gasket and two locator pins.



GZ437A

14. Remove the water pump drive shaft and gear assembly from the engine.



GZ439

Servicing Right-Side Components

INSPECTING CENTRIFUGAL CLUTCH SHOES

1. Inspect the clutch shoes for wear, chips, cracks, damage, or discoloration. If any shoe is damaged, replace the centrifugal clutch.

INSPECTING CLUTCH HOUSING

1. Inspect the clutch housing for burns, grooving, cracks, or uneven wear.
2. If the housing is damaged in any way, the housing must be replaced.


DRIVEN CLUTCH ASSEMBLY

Disassembling

1. Secure the clutch spring compressor base in a work vise attached to a stable work table or work bench.


⚠ WARNING

Use only a spring compressor tool base with a screw length of 14" or greater or serious injury could occur.




WC422A

2. Place the driven pulley assembly onto the base and mark the fixed sheave, moveable sheave, and cam; then note the location of the spring anchors in the movable sheave and cam and mark them for assembly purposes.



WC371A

3. With the centering bushing, compression yoke, and wing nut in place, tighten the wing nut sufficiently to relax pressure on the snap ring and remove the snap ring.



WC418A

4. Turn the wing nut counterclockwise to relax the spring. As the cam clears the key in the fixed driven shaft, there will be a slight clockwise rotation of the cam. This is normal due to spring preload.


⚠ WARNING

If at anytime the cam hangs up or the tool feels slack and the spring is not completely extended, stop and determine the cause. Failure to do so could result in the driven pulley assembly suddenly coming apart and severe injury or death could occur.

5. Completely relax the spring until all pressure is removed from the compression yoke; then remove the wing nut, compression yoke, snap ring, and centering bushing.
6. Remove the cam and spring; then remove the movable driven sheave. Account for a square key.
7. Remove the fixed driven sheave from the compression tool base.

INSPECTING

1. Inspect the sheave faces for cracks, grooving, or "checking".



WC381



WC383


2. Inspect the cam shoes on the movable driven sheave for chipping, excessive scoring, or general condition.



WC384A

■NOTE: Always replace the cam shoes as a complete set.

3. Inspect the cam ramp faces for galling, scoring, or excessive wear.



WC382

4. Inspect the key and keyways in the cam and fixed driven sheave for excessive wear.
5. Inspect the wear bushings in the movable driven sheave for wear or loose fit in the sheave. Replace as a set.



WC383A

6. Inspect the spring for kinks by rolling on a flat surface. The spring should roll freely with no eccentricities.
7. Inspect spring ends and spring anchors in cam and movable driven sheave for wear or enlarged spring anchor holes.


■NOTE: If any of the components fail the above inspection, the driven pulley must be replaced.

ASSEMBLING

WARNING

The clutch assemblies are under extreme spring pressure, and only experienced technicians using the proper tools should perform service on these components. Failure to follow proper procedures could result in serious injury or death. Always wear safety glasses and observe proper shop techniques. Keep bystanders clear of work area at all times.

1. Clamp the Clutch Spring Compressor in a suitable work vise; then set the fixed driven sheave on the base.



WC387

2. Install the movable driven sheave onto the fixed sheave shaft and align the match marks.



WC388

3. Install the spring over the hub of the movable driven sheave engaging the spring into the previously marked spring anchor hole.



WC391A

4. Place the cam over the spring and align the spring tip to the previously marked anchor hole.




WC753

5. Install the centering bushing into the fixed driven hub; then with the sharp side upward, place the snap ring onto the assembly and install the compression yoke and wing nut.




WC414

6. Turn the wing nut clockwise to compress the spring being very careful that the cam correctly engages the fixed driven hub; then continue to tighten until the cam ramps are just above the cam shoes.




WC398

7. Rotate the cam counterclockwise by hand enough to get the cam ramps on the correct side of the cam shoes; then continue to tighten the wing nut until the keyways align.



WC411A

8. Install the square key making sure it fits flush and clear of the snap ring groove; then install the snap ring making sure it is seated properly.



WC412



WC419

9. Turn the wing nut counterclockwise slowly allowing the cam to contact the snap ring; then loosen slightly and tap the cam with a plastic mallet to ensure the snap ring is securely seated.



WC408

10. Remove the wing nut, compression yoke, and centering bushing; then remove the driven pulley assembly from the Clutch Spring Compressor.

WATER PUMP DRIVE ASSEMBLY


Disassembling

1. Remove the two snap rings from the driveshaft; then remove the gear and drive pin noting the orientation of the gear for proper assembly.



GZ442


2. Remove the snap ring securing the bearing in the water pump drive cover; then remove the bearing using an appropriate blind bearing remover.



GZ441

Inspecting

1. Inspect the water pump drive housing (A) for scoring or discoloration.




GZ440A

2. Inspect the bearing (B) for smooth rotation and no discoloration or scoring.
3. Inspect the gear (C) for chipped or missing teeth, excessive hub wear, or excessive wear in the drive pin slot.
4. Inspect the drive pin (D) and driveshaft (E) for excessive wear or looseness.

Assembling

1. Install the bearing in the water pump drive cover and secure with the snap ring (flat side away from the bearing).



GZ441

2. Install the gear onto the driveshaft noting correct orientation (from step 1 of disassembling).



GZ442

3. Install the two snap rings on the driveshaft (flat side away from the gear).

Installing Right-Side Components

1. Install the clutch shoe assembly and secure with the flange nut (threads coated with red Loctite #271). Tighten to 221 ft-lb.



GZ241

2. Place a new clutch housing seal (with the spring side facing the clutch housing seal tool) into the clutch cover and secure with a rubber mallet or press.



GZ503

3. Using a suitable press, install the bearing into the clutch cover against the outer bearing face.



GZ501

■**NOTE:** It is critical to verify the seal on the bearing faces the clutch cover seal before pressing in the new bearing.

4. Secure the bearing in the clutch cover using existing bearing retainers and machine screws (threads coated with blue Loctite #242). Tighten to 8 ft-lb.




5. Press the clutch housing assembly into the clutch cover until it is seated against the bearing.





6. Install a new O-ring into a new fixed drive spacer, then apply a thin coat of grease to the inner O-ring and outside sealing surface of the drive spacer. Place it over the clutch housing assembly.




7. Place the clutch cover/clutch housing assembly into position on the crankcase; then secure with the cap screws. Tighten in a crisscross pattern to 8 ft-lb.




8. Making sure the alignment pins are correctly installed, place a bead of silicone sealant on the mating surfaces and install the V-belt cover. Secure with new "patch-lock" cap screws tightened to 8 ft-lb.



9. Place the driven clutch assembly into position and secure with the nut (coated with red Loctite #271). Tighten to 165 ft-lb.




10. Slide the fixed drive face onto the clutch shaft.
11. Spread the faces of the driven clutch by threading in a cap screw; then when the faces are separated, insert the belt and push down between the faces.



GZ065A

12. Place the V-belt into position on the driven clutch and over the front shaft.



GZ085

■NOTE: The arrows on the V-belt should point forward.


13. Pinch the V-belt together near its center and slide the spacer and movable drive face onto the shaft. Using an appropriate spanner wrench, secure the drive face with a flat washer and a nut (threads coated with red Loctite #271). Tighten the nut to 165 ft-lb.



GZ075

CAUTION


Make sure the splines extend beyond the drive face and washer or a false torque reading and spline damage may occur.



GZ485


■NOTE: At this point, the cap screw can be removed from between the driven clutch faces.

14. With the engine in neutral, rotate the V-belt and clutches counterclockwise until the V-belt is flush with the top of the driven clutch.
15. Place the CVT cover gasket into position; then install the cover and secure with the cap screws. Tighten the cap screws to 8 ft-lb.
16. Install the water pump drive shaft/gear assembly into the engine.



GZ439

17. Install the two locating pins and a new gasket on the engine; then install the water pump drive housing cover and tighten the cap screws to 8 ft-lb.




GZ437A


Center Crankcase Components

■NOTE: This procedure cannot be done with the engine/transmission in the frame. Complete Removing procedures for Top-Side, Left-Side, and Right-Side must precede this procedure.



■NOTE: For efficiency, it is preferable to remove and disassemble only those components which need to be addressed and to service only those components. The technician should use discretion and sound judgment.




3. Remove the secondary drive assembly; then remove the secondary driven shaft assembly and set aside. Account for one locating ring.



1. Remove the oil strainer cap; then remove the oil strainer.




2. Remove the cap screws securing the lower crankcase to the upper crankcase halves; then using a rubber hammer, free the lower crankcase and remove. Account for two alignment pins.




■NOTE: Do not disassemble these assemblies unless service is required. If disassembled, secondary gear sets will have to be reset for backlash and gear contact (see Servicing Center Crankcase Components sub-section).


4. Remove one cap screw from the right-side crankcase and eight cap screws from the left-side crankcase; then using a rubber mallet, separate the crankcase halves leaving all components in the right-side case. Account for a thrust washer on the crankshaft and flat washers on gear shift shaft, countershaft, and reverse idler. Note the location of two alignment pins.



GZ454A




GZ298



GZ272B

Disassembling Crankcase Half

■NOTE: For steps 1-8, refer to illustration GZ474A.




GZ474A

■NOTE: To aid in installing, it is recommended the assemblies are kept together and IN ORDER.

1. Support the right-side crankcase assembly on suitable support blocks; then carefully remove the crankshaft assembly (A) from the crankcase.

2. Remove the snap ring securing the water pump drive idler (B) to the idler shaft; then remove the drive idler.




GZ299A

3. Remove the snap ring securing the water pump idler shaft (C) in the crankcase; then remove the shaft and bearings.



GZ463A

4. Remove the snap ring securing the oil pump driven gear (D) to the oil pump driveshaft; then remove the gear. Account for a drive pin and washer.




5. Remove the shift fork shaft (E); then remove the gear shift shaft assembly (F). Account for a flat washer and a spacer.



DE677A




6. Remove two cap screws securing the oil pump in the crankcase and remove the oil pump.



GZ305

7. Remove the driveshaft (G); then remove the countershaft assembly (with shift forks) (H). Account for two flat washers on the countershaft.



GZ280B

8. Remove the reverse idler gear (I), shaft bushing, and two washers.



GZ279

■NOTE: Do not disassemble the countershaft assembly unless necessary. If necessary, see Servicing Center Crankcase Components sub-section.


Servicing Center Crankcase Components

SECONDARY OUTPUT DRIVE GEARS

Initial Set-Up


■NOTE: If the secondary output driven shaft is replaced or disassembled, the initial set-up must be performed to establish correct gear tooth contact. If only the secondary output driveshaft or secondary output driven gear are replaced, proceed to Correcting Backlash in this sub-section.

1. Install a new bearing (A) onto the secondary driven shaft (B) making sure the bearing locating groove is directed away from the driven gear splines.



MT011A

2. Using a suitable press, install the driven gear (C) on the shaft until the gear firmly seats on the shoulder of the shaft.




MT011B

3. If installing the existing shaft, start with the shims removed during disassembly or if installing a new shaft, start with approximately 1.0 mm shims at point (D); then install the output driveshaft bearing (E) making sure the locating pin is directed toward the center of the shaft.




MT012



FW-003A


4. Install a new seal (F), output yoke (G), washer, and nut (H) and tighten to 200 ft-lb.



MT008B

■NOTE: Do not use a new lock nut at this time as this procedure may have to be repeated.

5. Place the assembled shaft into the left crankshaft case; then lightly coat the gear teeth with machinist's lay-out dye. Rotate the shafts through several rotations in both directions. Gear contact should extend from the root to the top of the gear teeth.



MT016A


6. To adjust tooth contact, use the following chart to correctly shim the driven shaft.

Tooth Contact	Shim Correction
Contact at Top	Increase Shim Thickness
Contact at Root	Decrease Shim Thickness


7. After correct tooth contact is established, proceed to Checking Backlash in this sub-section.

Checking Backlash

1. Install the drive bevel gear assembly and driven bevel gear/output shaft assembly into the crankcase bottom cover.
2. Mount the dial indicator so the tip is contacting a tooth on the secondary drive bevel gear.



3. Firmly hold the bearing down and while rocking the drive bevel gear back and forth, note the maximum backlash reading on the gauge.



4. Acceptable backlash range is 0.127-0.381 mm (0.005-0.015 in.).

Correcting Backlash

■NOTE: If backlash measurement is within the acceptable range, no correction is necessary.

1. If backlash measurement is less than specified, remove an existing shim, measure it, and install a new thinner shim.



2. If backlash measurement is more than specified, remove an existing shim, measure it, and install a thicker shim.

■NOTE: Continue to remove, measure, and install until backlash measurement is within tolerance. Note the following chart.

Backlash Measurement	Shim Correction
Under 0.127 mm (0.005 in.)	Decrease Shim Thickness
At 0.127-0.381 mm (0.005-0.015 in.)	No Correction Required
Over 0.381 mm (0.015 in.)	Increase Shim Thickness

3. Once correct gear pattern and backlash are established, install a new lock nut (coated with red Loctite #271) on the output yoke and tighten to 200 ft-lb. Peen the lock nut to the shaft.



4. Using an appropriate holding fixture and wrench adapter, install the secondary drive gear nut (threads coated with red Loctite #271) and tighten to 200 ft-lb. The output drive assembly is now ready for installation.



FW-006A

OIL PUMP ASSEMBLY


Disassembling and Inspecting

1. Remove the oil pump cover; then remove the gerotor set, shaft, and pin (see Disassembling Crankcase Half in this sub-section).
2. Inspect the crankcase for scoring, discoloration, or cracks in the gerotor bore. If scored, crankcase assembly must be replaced.




GZ357

3. Inspect the gerotor set for scoring, discoloration, or cracks; then using a feeler gauge, check the inner to outer rotor clearance. If measurements exceed specifications, the gerotor set must be replaced.




GZ355

4. Inspect the oil pump cover for scoring, discoloration, or cracks. Replace if damaged.




GZ358

5. Inspect the oil pump driveshaft and drive pin for excessive wear or grooving. Replace as required.



GZ354A

6. Remove the oil seal from the oil pump cover.



GZ365

Assembling

1. Install a new oil seal into the oil pump cover; then coat the lips of the seal with grease and install the pump driveshaft from the seal side.



GZ359


2. Noting the reference dots on the gerotor set, separate the inner rotor from the outer rotor and with the reference dot directed toward the oil pump cover, place the rotor on the shaft; then install the drive pin and push the shaft into the rotor.

CRANKSHAFT ASSEMBLY

■NOTE: The crankshaft and connecting rod is a non-serviceable assembly. If any component is out of specification, the assembly must be replaced.

Measuring Connecting Rod (Small End Inside Diameter)

1. Insert a snap gauge into the upper connecting rod small end bore; then remove the gauge and measure it with micrometer.



CC290D

2. Maximum diameter must not exceed specifications.

Measuring Connecting Rod (Small End Deflection)


1. Place the crankshaft on a set of V blocks and mount a dial indicator and base on the surface plate. Position the indicator contact point against the center of the connecting rod small end journal.
2. Zero the indicator and push the small end of the connecting rod away from the dial indicator.
3. Maximum deflection must not exceed specifications.

Measuring Connecting Rod (Big End Side-to-Side)


1. Push the lower end of the connecting rod to one side of the crankshaft journal.
2. Using a feeler gauge, measure the gap between the connecting rod and crankshaft journal.
3. Acceptable gap range must be within specifications.

Measuring Crankshaft (Runout)

1. Place the crankshaft on a set of V blocks.
2. Mount a dial indicator and base on the surface plate. Position the indicator contact at point 1 of the crankshaft.



GZ356




GZ363

3. With the outer rotor reference dot directed toward the oil pump cover, install the rotor onto the inner rotor.




GZ360

4. Place a new O-ring seal on the outside of the oil pump cover. The oil pump assembly is now ready for assembly into the crankcase.



GZ362



H2-004A

3. Zero the indicator and rotate the crankshaft slowly.

CAUTION


Care should be taken to support the connecting rod when rotating the crankshaft.

4. Maximum runout must not exceed specifications.

■NOTE: Proceed to check runout on the other end of the crankshaft by positioning the indicator contact at point 2 and following steps 3-4.

Measuring Crankshaft (Web-to-Web)


1. Using a calipers, measure the distance from the outside edge of one web to the outside edge of the other web.



H2-005

2. Acceptable width range must be within specifications.

COUNTERSHAFT




GZ281A

CAUTION

When disassembling the countershaft, care must be taken to note the direction each major component (dog, gear) faces. If a major component is installed facing the wrong direction, transmission damage may occur and/or the transmission will malfunction. In either case, complete disassembly and assembly will be required.

Disassembling

1. Remove the shift forks noting the positions for assembling; then remove the high driven gear outer washer, high driven gear, high driven gear bearing, high driven gear bushing, and high driven gear inner washer.




GZ283A

2. Remove the drive gear; then remove the snap ring securing the reverse driven gear dog and bushing to the countershaft.



GZ296



GZ312

3. Remove the reverse driven gear dog.



GZ313A

4. Remove the snap ring securing the reverse driven gear and washer; then remove the washer and gear.



GZ314


5. Remove the reverse driven washer; then remove the low driven gear locking washer.



GZ320




GZ319



GZ318A


6. Remove the low driven gear. Account for a bearing, bushing, and thrust washer.




GZ316

Assembling

1. From the drive gear end, install a thrust washer, bushing, and bearing; then install the low driven gear and washer.



GZ317A




GZ318


2. Install the low driven gear locking washer; then install the inner reverse driven gear washer.



GZ319B




GZ288A



GZ320B

3. Install the reverse driven bushing and bearing; then install the reverse driven gear.



GZ286A



GZ287

4. Install the outer reverse driven washer; then secure the reverse driven gear assembly with a snap ring.




GZ314

5. Install the reverse driven gear dog onto the countershaft and secure with a snap ring.




GZ313A



GZ312

6. From the opposite end of the countershaft, install the high/low driven gear dog (A), thrust washer (B), bushing (C), bearing (D), high/low driven gear (E), and spacer washer (F).



GZ283B

7. Install the drive gear washer and the shift forks. The countershaft is now ready for installation.




GZ463A

4. Install the countershaft gear onto the countershaft and secure with a snap ring (flat-side away from the gear).


Assembling Crankcase Half

1. Install the oil pump gerotor assembly and oil pump cover into the crankcase and secure with two cap screws. Coat the threads with blue Loctite #243 and tighten securely to 8 ft-lb.




GZ305

2. Install a flat washer, drive pin, and drive gear onto the oil pump shaft; then secure with a snap ring (flat-side away from the gear).




GZ347

3. Install the countershaft into the crankcase and secure with the snap ring (flat side away from the bearing).



GZ299A


5. Using rubber bands to support the connecting rods, carefully install the crankshaft assembly into the crankcase.




GZ474

■NOTE: It will be necessary to rotate the crankshaft back and forth to engage the teeth of the oil pump and countershaft gears.

6. Install the driveshaft; then with a flat washer on each end of the reverse idler assembly, install into the crankcase.



GZ32




GZ33

7. Install the gear shift shaft into the crankcase making sure the flat washer is in place on the right case end and the spacer bearing assembly on the gear shift stop end.



DE677A




GZ35

8. Place the larger flat washer on the drive gear end of the countershaft and the smaller flat washer on the high driven gear end; then with shift forks and shift fork shaft, install the countershaft assembly into the crankcase.




GZ280B



GZ336

9. Engage the shift forks into the gear shift shaft and push the shift fork shaft into the crankcase.



GZ339

AT THIS POINT


Proper transmission shifting should be verified by turning the gear shift shaft to select High, Low, Neutral, and Reverse while rotating the input shaft and observing the countershaft rotation.

AT THIS POINT

The right-side crankcase is now ready for installation to the left-side crankcase. Proceed to Joining Crankcase Halves.


Joining Crankcase Halves

1. Using rubber bands, support the connecting rods to align with the cylinder bores.



GZ340


2. Coat both sides with engine oil; then install the spacer washer on the crankshaft with the radius directed toward the crankshaft.



GZ341


3. Install the two alignment pins; then apply a thin bead of Loctite #5900 or suitable substitute sealant to the crankcase mating surface.

■NOTE: Apply sealant sparingly in areas depicted by arrows.



GZ298B


4. Carefully join the crankcase halves by placing the left-side crankcase onto the assembled right side. Secure with the cap screws (eight left side and one right side).



GZ342

5. Tighten the 6 mm cap screws to 10 ft-lb and the 8 mm cap screws to 21 ft-lb using the pattern shown and turning the shafts frequently to ensure there is no binding.

■NOTE: Rotate the shafts back and forth to ensure no binding or sticking occurs.



GZ457A


■NOTE: Cap screw number eight (8) is installed from the right side.

■NOTE: If the secondary drive/driven assemblies have been disassembled, refer to Servicing Center Crankcase Components for proper gear tooth contact and backlash.


6. Install the locating ring in the crankcase assembly; then install the secondary driven shaft assembly and secondary drive assembly making sure the locating ring and bearing engage correctly.




GZ269A



7. Make sure the locating pins on the front and rear bearings are correctly seated in the crankcase.
8. Install two alignment pins into the upper crankcase assembly; then apply a thin bead of Loctite #5900 or suitable substitute sealant to the lower crankcase cover.



9. Carefully place the lower crankcase cover onto the joined crankcase halves; then secure with the cap screws. Tighten the 6 mm cap screws to 10 ft-lb and the 8 mm cap screws to 21 ft-lb.



10. Install the oil strainer; then apply a thin bead of silicone sealant to the oil strainer cap and secure with the cap screws. Tighten to 8 ft-lb.


AT THIS POINT


After completing center crankcase components, proceed to **Installing Right-Side Components**, to **Installing Left-Side Components**, and to **Installing Top-Side Components**.

Installing Engine/Transmission

■NOTE: Arctic Cat recommends new gaskets and O-rings be installed whenever servicing the vehicle.


1. Attach a suitable lifting chain to the engine; then using an engine hoist, lift the engine/transmission into the vehicle from the right side.






PR633

2. Carefully lower the engine/transmission into position between the engine mounting tabs being careful to keep all cables, wires, and hoses clear; then install the longer, front through-bolt with a flat washer.



PR634A

3. Install the rear through-bolts with flat washer; then secure both with new lock nuts and tighten to 40 ft-lb.



PR629



PR630

4. Secure the rear universal joint flange to the output drive flange and tighten the four cap screws to 20 ft-lb.




PR647

5. Lubricate the splines on the front driveshaft with multi-purpose grease; then align the match marks and install the driveshaft into the front output joint.




PR639

6. Align the match mark on the front drive flange to mark on the front universal joint flange and secure with three cap screws. Tighten to 20 ft-lb and slide the rubber boot back into position.



PR638A




PR640

7. Install a new grafoil gasket in the rear cylinder head; then place the rear exhaust pipe into position and loosely secure with two cap screws.




PR641A

8. With a new grafoil gasket in the front cylinder head and a new grafoil seal on the exhaust pipe, install the front exhaust pipe and loosely secure with two cap screws.




PR643A




PR642

9. Install the O2 sensor and tighten the sensor to 19 ft-lb. Connect the harness to the sensor.
10. Install the four springs (A) at the juncture of front and rear exhaust pipes. With a new grafoil seal (B) in place, install the muffler and secure with two springs; then tighten the cap screws from steps 7 and 8 to 20 ft-lb.




PR661C



PR668

11. Connect the oil cooler hoses to the engine and secure with the hose clamps. Tighten securely.




PR616A




PR617A

12. Install the inlet boot on the CVT cover; then install the CVT cooling duct and secure with the sheet metal screw. Tighten all fasteners and clamps securely.




PR615

14. Connect the starter cable to the starter; then connect the engine harness ground to the engine. Tighten the fasteners securely.




PR605A




PR671A

13. Install and secure the CVT cooling outlet boot to the CVT cover making sure to properly orient the outlet duct.




PR669

15. Install the air filter assembly and secure with four sheet metal screws; then secure the intake boot to the throttle body. Tighten the screws and clamp to 30 in.-lb.




PR604A

16. Connect the gasoline hoses to the fuel rails making sure the “quick-disconnect” couplers properly lock onto the fuel injector rails.




PR663

17. Install the cross brace assembly and secure with four cap screws; then secure the upper coolant pipe support clamp to the cross brace. Tighten the cap screws securely.




PR596A



PR598A

18. Connect the throttle cable to the throttle arm; then install the cable housing into the throttle body housing and tighten the nuts securely.
19. Adjust throttle cable free-play; then install the throttle cable cover.




PR666

20. Install the shift cable support bracket and secure with two cap screws; then tighten to 8 ft-lb and install the E-clip securing the shift cable to the shift arm.



PR929A

21. From the left side, connect the speed sensor connector, magneto connector, CKP sensor, and gear position switch.




PR930A

22. Route the engine harness through the cross brace bracket as marked during disassembly and secure with routing pins.




PR928A

23. Connect the front spark plug cap and front ignition coil; then install the front and rear injector connectors (A), MAP sensor (B), reverse override switch connector (D), and ISC valve (C).




PR931A

24. From the right side, connect the ECT sensor (A), IAT sensor (B), fuel pump/fuel gauge connector (C), rear ignition coil (D), and TPS connector (E).



PR927B

25. Check for correct routing of all wiring, hoses, and cables.



PR592A

26. Connect the negative battery cable and install the battery hold-down.

27. Pour the recommended amount of oil into the engine/transmission.

28. Remove the coolant bleed screw from the upper coolant pipe near the thermostat; then pour the correct mixture of coolant into the radiator. When coolant with no air bubbles flows from the bleed hole, install the screw and tighten securely.

29. Start the engine and check for oil or coolant leaks; then check all fluid levels and correct as necessary.

30. Wipe off any spilled coolant or lubricant; then install the floor, fenders, side panels, storage console, seat bases, center console, and seats.


Fuel/Lubrication/Cooling

⚠ WARNING

Whenever the gasoline hoses are removed (other than for pressure testing), the battery must be disconnected to prevent inadvertent activation of the electronic fuel pump.


⚠ WARNING

Whenever any maintenance or inspection is performed on the fuel system during which there may be fuel leakage, there should be no welding, smoking, open flames, etc., in the area.



PR486A

4. Disconnect the crankcase breather hose from the air filter housing; then remove the air filter assembly from the vehicle.




PR487A

5. Slowly disconnect the gasoline hose connector from the fuel rail.

⚠ WARNING

Gasoline may be under pressure. Place an absorbent towel under the connector to absorb any gasoline spray when disconnecting.



FI092A

6. Remove the screw securing the throttle actuator cover to the throttle body; then remove the cover.
7. Remove the throttle cable from the actuator arm.
8. Loosen the outer jam nut securing the throttle cable to the throttle body; then route the cable out of the way.
9. Remove the electrical connectors from the throttle body components.

Throttle Body (550/700)

REMOVING

1. Turn the ignition switch to the OFF position; then remove the ignition switch key.

⚠ WARNING

Do not turn the ignition switch to the ON position with the hoses removed. Gasoline will be pumped by the electric fuel pump causing a safety hazard.

2. Remove the left and right seats; then remove the center console and disconnect the battery.
3. Remove the connector from the IAT sensor (A); then loosen the inlet boot clamp (B) and remove the mounting screw (C).

10. Remove the throttle body assembly from the intake pipe.



FI104A

11. Use tape to cover and seal the intake opening.

CAUTION

Any objects or liquid entering the intake opening will fall into the engine causing severe damage if the engine is turned over or started.

INSTALLING

1. Install the throttle body into the intake pipe and secure with the clamp. Tighten securely.
2. Place a new O-ring in the intake pipe; then position the pipe onto the engine and secure with two cap screws.
3. Connect the throttle cable to the throttle body and adjust throttle cable free-play; then connect the gasline hose.
4. Connect the electrical connectors to the throttle body components.
5. Install the air filter assembly and secure with the existing hardware; then connect the IAT sensor and crankcase breather hose.
6. Install the center console and seats making sure the seats lock securely in place.

Throttle Body (1000)

REMOVING

1. Turn the ignition switch to the OFF position; then remove the ignition switch key.

WARNING

Do not turn the ignition switch to the ON position with the hoses removed. Gasoline will be pumped by the electric fuel pump causing a safety hazard.

2. Remove the left and right seats; then remove the center console and disconnect the battery.

3. Remove the air inlet boot; then disconnect the throttle position sensor (TPS) connector (A), manifold absolute pressure (MAP) sensor connector (B), and idle speed control (ISC) connector (C).



GZ094E

4. Remove the cap screws securing the throttle body to the manifold; then lift the throttle body off the manifold. Account for an O-ring.



GZ386

5. Remove the screw securing the throttle actuator cover to the throttle body; then remove the cover.
6. Remove the throttle cable from the actuator arm.
7. Loosen the outer jam nut securing the throttle cable to the throttle body. The throttle body can now be removed from the vehicle.
8. Use tape to cover and seal the intake opening.

CAUTION

Any objects or liquid entering the intake opening will fall into the engine causing severe damage if the engine is turned over or started.

INSTALLING

1. Connect the throttle cable to the throttle body and adjust throttle cable free-play; then install the throttle actuator cover and secure with the machine screw.
2. Remove the covering from the intake manifold opening; then using a new O-ring, install the throttle body onto the manifold and secure with the cap screws. Tighten securely.




GZ386

3. Connect the TPS connector (A), MAP sensor connector (B), and ISC connector (C) to the throttle body; then install the air inlet boot and tighten the clamps securely.




GZ094E

4. Install the center console and seats making sure the seats lock securely in place.



PR698A

3. Remove the outer cap screw securing the front tank hold-down; then swing the hold-down to the left.




PR167A



PR170

4. Remove the joining cap screw and nut from the rear gas tank hold-down strap; then remove the inside hold-down strap.



PR699A

Gas Tank

WARNING

Whenever any maintenance or inspection is made on the fuel system during which there may be fuel leakage, there should be no welding, smoking, open flames, etc., in the area.

REMOVING

1. Remove the floor.
2. Disconnect the vent hose (A), gasoline hose (B), and fuel pump/fuel level sensor connector (C); then cap the vent fitting and gas hose fitting.

5. Lift and slide the tank forward raising the front of the tank first; then turn the tank and lift out the right side.

CLEANING AND INSPECTING


1. Clean all gas tank components with parts-cleaning solvent.
2. Inspect all hoses for cracks or leaks.
3. Inspect gas tank cap and tank for leaks, holes, and damaged threads.
4. Inspect the fuel level sensor for proper operation (see Fuel Level Sensor in this section).

INSTALLING

1. Place the gas tank into position in the vehicle; then install the inside rear hold-down strap.



PR173




PR699A

2. Swing the front hold-down to the right into position and install the cap screw and nut. Do not tighten at this time.



PR171

3. Install the rear hold-down strap joining cap screw and nut. Do not tighten at this time.




PR699A

4. Place the right side panel into position; then if necessary, position the gas tank so the filler panel and filler neck are not binding or rubbing.




PR946

5. Secure the right side panel with six cap screws; then tighten the hardware securing the hold-down straps (from steps 2-3) securely.




PR166A



PR167A

6. Connect the vent hose (A) and gasline hose (B) to the proper fittings; then connect the fuel pump/fuel level sensor connector (C) to the main harness.



PR698A

7. Install the floor.

Gas/Vent Hoses

Replace the gas hose every two years. Damage from aging may not always be visible. Do not bend or obstruct the routing of the vent hoses. Make certain the vent hoses are securely connected and the opposite ends are always open.

Oil Filter/Oil Pump


■NOTE: Whenever internal engine components wear excessively or break and whenever oil is contaminated, the oil pump should be replaced.

TESTING OIL PUMP PRESSURE (550/700)

■NOTE: The engine must be warmed up to operating temperature (cooling fan cycling) for this test.

1. Remove the seats and center console; then remove the left-side seat-base.
2. Tilt the cargo box back.

3. Remove the upper plug from the base of the oil filter; then using an appropriate adapter, connect an oil pressure gauge to the engine.



CF264A

■NOTE: Some oil seepage may occur when installing the oil pressure gauge. Wipe up oil residue with a cloth.

4. Start the engine. Allow the engine to warm up to operating temperature (with cooling fan cycling).
5. Set the speedometer/tachometer to RPM. With the engine running at 3000 RPM, the pressure gauge must show 0.6-0.7 kg/cm² (8.5-10 psi), on the 550 or 1.2-1.5 kg/cm² (17-21 psi) on the 700.
6. Install the left-side seat-base; then install the center console and seats making sure the seats lock securely.

■NOTE: If the oil pressure is lower than specified, check for an oil leak, damaged oil seal, or defective oil pump.

■NOTE: If the oil pressure is higher than specified, check for too heavy engine oil weight (see General Information), clogged oil passage, clogged oil filter, or improper installation of the oil filter.

TESTING OIL PUMP PRESSURE (1000)

■NOTE: The engine must be warmed up to operating temperature (cooling fan cycling) for this test.

1. Remove both seats and center console; then remove the oil hose from the fitting nearest the oil filter base.



PR617C

2. Using a suitable "T" fitting, connect Oil Pressure Test Kit to the oil fitting and hose. Tighten all clamps securely.

■NOTE: Some oil seepage may occur when installing the oil pressure gauge. Wipe up oil residue with a cloth.

3. Start the engine. Allow the engine to warm up to operating temperature (with cooling fan cycling).
4. Set the speedometer/tachometer to RPM. With the engine running at 3000 RPM, the pressure gauge must show 1.05-1.2 kg/cm² (15-17 psi).
5. Remove the test kit from the vehicle and install the oil hose. Tighten the clamps securely.
6. Install the seats, seat base, and center console as required making sure the seats lock securely.

■NOTE: If the oil pressure is lower than specified, check for an oil leak, damaged oil seal, or defective oil pump.

■NOTE: If the oil pressure is higher than specified, check for too heavy engine oil weight (see the General Information section), clogged oil passage, clogged oil filter, or improper installation of the oil filter.

REMOVING/DISASSEMBLING

1. Remove the oil pump from the engine (see Left-Side Components (550/700) or Center Crankcase Components (1000) in the Engine/Transmission section).
2. Remove the Phillips-head screw on the back side of the pump and separate the pump housing and cover. Note the position of the inner and outer rotors and alignment pin for assembly.
3. Remove oil pump components.

CLEANING AND INSPECTING

1. Clean all oil-pump components.
2. Inspect the rotors for scoring and gouges.
3. Inspect the alignment pin, driveshaft, and driven sprocket for damage.
4. Inspect the pump housing and cover for cracks or damage.

ASSEMBLING/INSTALLING


1. Place the rotors into the pump housing making sure the alignment pin is in the groove of the rotor.
2. Place the cover onto the pump housing.
3. Secure the pump with the Phillips-head screw coated with red Loctite #271. Tighten to 8 ft-lb.
4. Install the oil pump into the engine (see Left-Side Components (550/700) or Center Crankcase Components (1000) in the Engine/Transmission section).

Oil Cooler (1000)

This model has an oil cooler in addition to the liquid cooling system. An oil cooler kit may be installed on any Arctic Cat ROV.


REMOVING

1. Loosen the clamps securing the oil hoses to the oil cooler; then place a shallow pan or absorbent towel under the connection and remove the hoses.



PR936

2. Remove the cap screws from the oil cooler mountings and remove the oil cooler.



PR937

CLEANING AND INSPECTING

1. Prior to washing, inspect the oil cooler for signs of leaks such as oily dirt build-up.
2. Wash the cooling fins using a garden hose and hot, soapy water and a soft brush.
3. Inspect all mounting brackets and the oil inlet and outlet for cracks or bends.

INSTALLING


1. Place the oil cooler into position and secure with the existing hardware. Tighten securely.
2. Connect the oil hoses and secure with the hose clamps. Tighten securely.

Liquid Cooling System

When filling the cooling system, use premixed Arctic Cat Antifreeze. While the cooling system is being filled, air pockets may develop; therefore, open the bleed screw on the upper coolant pipe or the thermostat housing to allow air to bleed from the cooling system. When clear coolant (no bubbles) is present, tighten the bleed screw securely; then fill the cooling system to the bottom of the stand pipe in the radiator neck. Run the engine for five minutes after the initial fill, shut the engine off, and then "top-off" the cooling system to the bottom of the stand pipe in the radiator neck.


CAUTION

After operating the vehicle for the initial 5-10 minutes, stop the engine, allow the engine to cool down, and check the coolant level. Add coolant as necessary.



PR183A

4. Remove the two shoulder bolts and nuts securing the radiator to the frame; then disconnect the upper and lower coolant hoses.



PR184A


5. Lift the radiator assembly from the vehicle. Account for two upper and two lower rubber mounting grommets.

CLEANING AND INSPECTING

1. Flush the radiator with water to remove any contaminants.
2. Inspect the radiator for leaks and damage.
3. Inspect all hoses for cracks and deterioration.
4. Inspect all fasteners and grommets for damage or wear.


INSTALLING

1. Place the radiator into position making sure the grommets are correctly installed; then secure to the mounts with the two shoulder bolts and nuts. Tighten securely.




PR890A

3. Drain the coolant into a suitable container; then disconnect the cooling fan wire connector from the main harness.



PR184A

2. Connect the upper and lower coolant hoses to the radiator and secure with the appropriate hose clamps; then connect the cooling fan wire connector to the main harness.



PR183A

3. Open the high-point bleed screw on the upper coolant pipe to allow trapped air to escape. Tighten securely after filling.
4. Pour the recommended coolant into the radiator and secure the radiator cap.
5. Install the oil cooler and secure with the four cap screws.
6. Install the front storage box, front fenders, and front access panel. Close the hood.
7. Start the engine and warm up to operating temperature; then verify the coolant level is at the bottom of the stand pipe in the radiator neck. Add coolant as necessary.
8. Install the front access panel and the weather strip.

Thermostat (550/700)

REMOVING

1. Drain approximately one quart of coolant from the cooling system.
2. Remove the two cap screws securing the thermostat housing to the cylinder head. Account for a thermostat with seal.

INSPECTING

1. Inspect the thermostat for corrosion, wear, or spring damage.
2. Using the following procedure, inspect the thermostat for proper operation.
 - A. Suspend the thermostat in a container filled with water.
 - B. Heat the water and monitor the temperature with a thermometer.
 - C. The thermostat should start to open at 65.0-80.0° C (149-176° F).
 - D. If the thermostat does not open, it must be replaced.
3. Inspect all coolant hoses, connections, and clamps for deterioration, cracks, and wear.


■NOTE: All coolant hoses and clamps should be replaced every four years or 4000 miles.

INSTALLING

1. Place the thermostat with seal into the thermostat housing; then secure the thermostat housing to the cylinder head with the two cap screws.

CAUTION

When installing the thermostat, make sure the bleed holes are straight up and down or air will remain trapped causing engine damage due to overheating.



PR281A

2. Fill the cooling system with the recommended amount of antifreeze. Check for leakage.

Thermostat (1000)

REMOVING

■NOTE: The thermostat is located in a housing in-line with the upper radiator hoses under the air filter housing.



GZ036A

1. Drain approximately one quart of coolant from the cooling system.
2. Remove the four machine screws securing the thermostat housing together. Remove the thermostat and account for an O-ring.

INSPECTING

1. Inspect the thermostat for corrosion or spring damage.
2. Using the following procedure, inspect the thermostat for proper operation.
 - A. Suspend the thermostat in a container filled with water.
 - B. Heat the water and monitor the temperature with a thermometer.
 - C. The thermostat should start to open at 71.0-86.0° C (160-187° F).
 - D. If the thermostat does not open, it must be replaced.
3. Inspect all coolant hoses, connections, and clamps for deterioration, cracks, and wear.

■NOTE: All coolant hoses and clamps should be replaced every four years or 4000 miles.

INSTALLING

1. Place the thermostat and O-ring into the thermostat housing; then secure the thermostat housing together with the four machine screws.
2. Fill the cooling system with the recommended amount of antifreeze. Check for leakage.

Fan

REMOVING

1. Remove the radiator.
2. Remove the fan assembly from the radiator.

INSTALLING

1. Position the fan assembly on the radiator; then secure with existing hardware.

■NOTE: The fan wiring must be in the upper-right position.


2. Install the radiator.

Water Pump (550/700)

■ NOTE: The water pump is not a serviceable component. If the pump is defective or if the mechanical seal is leaking (coolant dripping from the discharge hole), the water pump must be replaced.

REMOVING


1. Remove the radiator cap; then remove the water pump coolant drain plug and drain the coolant.



PR122A


■NOTE: Always use a large container and have sufficient floor drying material available when draining the coolant in case of coolant spillage.

2. Drain the oil from the engine/transmission.
3. Remove the seats and center console; then remove the right-side seat-base.
4. Loosen the coolant hose clamps and slide the clamps away from the hose ends.



PR132


5. Remove the two cap screws securing the water pump to the engine; then remove the water pump.



CC786A

INSTALLING

1. Secure the water pump to the engine with the two cap screws tightened securely.



CC786A

2. Connect the two coolant hoses to the water pump and secure with the clamps; then install the water pump coolant drain plug.



PR132

3. Fill the engine/transmission with the proper amount of recommended oil.
4. Fill the cooling system with the proper amount of recommended coolant.

■NOTE: While the cooling system is being filled, air pockets may develop; therefore, run the engine for five minutes after the initial fill, shut the engine off, and then fill the cooling system.

5. Check the entire cooling system for leakage.

CAUTION

After operating the vehicle for the initial 5-10 minutes, stop the engine, allow the engine to cool down, and check the coolant level. Add coolant as necessary.

6. Install the right-side seat-base; then install the center console and seats making sure the seats lock securely.

Water Pump (1000)

■NOTE: The water pump is a non-serviceable component. It must be replaced as an assembly.

REMOVING


1. Remove the coolant drain plug; then remove the radiator cap and drain the coolant into a suitable container.



GZ093A

■NOTE: Always use a large container and have sufficient floor drying material available when draining the coolant in case of coolant spillage.

2. Remove the coolant hoses from the water pump; then remove two cap screws securing the water pump to the crankcase.




GZ230A


3. Remove the water pump from the engine.

INSTALLING

1. Install a new O-ring onto the water pump and lightly coat with clean engine oil.



GZ252C



GZ252D

CAUTION

Do not force the water pump housing into the crankcase or severe engine damage may occur.

2. Install the water pump assembly onto the engine aligning the flat drive on the water pump to the slot in the driven gear shaft.

3. Secure the water pump with the two cap screws and tighten securely; then connect the coolant hoses and secure with hose clamps.
4. Tighten the coolant drain plug securely; then fill the cooling system with appropriate mixed coolant and install the radiator cap.
5. Start the engine and check for coolant leaks; then add coolant if necessary to proper level.

CAUTION

After operating the vehicle for the initial 5-10 minutes, stop the engine, allow the engine to cool down, and check the coolant level. Add coolant as necessary.

Troubleshooting

Problem: Starting impaired

Condition	Remedy
1. Gas contaminated 2. Air filter/housing contaminated	1. Drain gas tank and fill with clean gas 2. Clean or replace air filter/housing

Problem: Idling or low speed impaired

Condition	Remedy
1. Gas contaminated 2. TPS out of adjustment 3. Air filter/housing contaminated	1. Drain gas tank and fill with clean gas 2. Adjust TPS 3. Clean or replace air filter/housing

Problem: Medium or high speed impaired

Condition	Remedy
1. Gas contaminated 2. High RPM "cut out" against RPM limiter 3. Air filter/housing contaminated	1. Drain gas tank and fill with clean gas 2. Decrease RPM speed 3. Clean or replace air filter/housing

Electrical System

The electrical connections should be checked periodically for proper function.

TESTING ELECTRICAL COMPONENTS

All electrical tests should be made using the CATT II or the Fluke Model 77 Multimeter. The CATT II can return data for certain components which are identified at the beginning of their respective sub-section. If any other type of meter is used, readings may vary due to internal circuitry. When troubleshooting a specific component, always verify first that the fuse(s) are good, that the LED(s) are good, that the connections are clean and tight, that the battery is fully charged, and that all appropriate switches are activated.

■NOTE: For absolute accuracy, all tests should be made at room temperature of 68° F.

SPECIAL TOOLS

A number of special tools must be available to the technician when performing service procedures in this section. Refer to the current Special Tools Catalog for the appropriate tool description.

Description	p/n
Fluke Model 77 Multimeter	0644-559
Timing Light	0644-296
MaxiClips	0744-041
TPS Analyzer	0644-299

■NOTE: Special tools are available from the Arctic Cat Service Department.

Battery



Component data can be retrieved using the CATT II. Utilize the Sensor Data screen.

The battery is located in a compartment in front of the left-rear wheel under the driver seat.

■NOTE: To access the battery box, the driver's seat must be removed.

After being in service, batteries require regular cleaning and recharging in order to deliver peak performance and maximum service life. The following procedures are recommended for cleaning and maintaining lead-acid batteries. Always read and follow instructions provided with battery chargers and battery products.

■NOTE: Refer to all warnings and cautions provided with the battery or battery maintainer/charger.

Loss of battery charge may be caused by ambient temperature, ignition OFF current draw, corroded terminals, self discharge, frequent start/stops, and short engine run times. Frequent winch usage, snowplowing, extended low RPM operation, short trips, and high amperage accessory usage are also reasons for battery discharge.

Charging

■NOTE: Arctic Cat recommends the use of the CTEK Multi US 800 or the CTEK Multi US 3300 for battery maintenance charging.

1. Be sure the battery and terminals have been cleaned with a baking soda and water solution.
2. Be sure the charger and battery are in a well-ventilated area and ensure the battery charger cables will not contact any battery acid. Be sure the charger is unplugged from the 110-volt electrical outlet.
3. Connect the red terminal lead from the charger to the positive terminal of the battery; then connect the black terminal lead of the charger to the negative terminal of the battery.
4. Plug the charger into a 110-volt electrical outlet.
5. By pushing the Mode button (A) on the left side of the charger, select the Normal Charge Icon (E). The Normal Charge Indicator (C) should illuminate on the upper left portion of the charger.



3300A

6. The battery will charge to 95% of its capacity at which time the Maintenance Charge Indicator (D) will illuminate.

■NOTE: For optimal charge and performance, leave the charger connected to the battery for a minimum 1 hour after the Maintenance Charge Indicator (D) illuminates. If the battery becomes hot to the touch, stop charging. Resume after it has cooled.

7. Once the battery has reached full charge, unplug the charger from the 110-volt electrical outlet.


■NOTE: If, after charging, the battery does not perform to operator expectations, bring the battery to an authorized Arctic Cat dealer for further troubleshooting.

Switches

Each time the vehicle is used, switches should be checked for proper operation. Use the following list for reference.

- A. Ignition/start switch — engine will run; starter will engage.
- B. Drive select switch — differential will engage (4WD)/disengage (2WD).
- C. Headlight switch — high beam, low beam, and lights off can be selected.
- D. Brake switch — brakelight illuminates and starter can be engaged with vehicle in gear.

2. Connect the red tester lead to the orange wire; then connect the black tester lead to ground.



PR276A

3. The meter must show battery voltage.

■NOTE: If the meter shows no battery voltage, troubleshoot the battery, fuse, switch, or the main wiring harness.

■NOTE: If the meter shows battery voltage, the main wiring harness is good; proceed to test the switch/component, the connector, and the switch wiring harness for resistance.

Accessory Receptacle/Connector

■NOTE: This test procedure is for either the receptacles or the connectors.

VOLTAGE

1. Turn the ignition switch to the ON position; then set the meter selector to the DC Voltage position.
2. Connect the red tester lead to the red/white wire or the positive connector; then connect the black tester lead to ground.
3. The meter must show battery voltage.

■NOTE: If the meter shows no battery voltage, troubleshoot the battery, fuse, receptacle, connector, or the main wiring harness.

Brakelight Switch

CATT II
Cat Advanced Tech Tool

Component data can be retrieved using the CATT II. Utilize the Sensor Data screen.

The switch connector is the two-prong black connector below the master cylinder.

■NOTE: The ignition switch must be in the ON position.

VOLTAGE (Wiring Harness Connector)

1. Set the meter selector to the DC Voltage position.


RESISTANCE (Switch Connector)

CAUTION

Always disconnect the battery when performing resistance tests to avoid damaging the multimeter.

■NOTE: The brake pedal must be depressed for this test.

1. Set the meter selector to the OHMS position.
2. Connect the red tester lead to one black wire; then connect the black tester lead to the other black wire.



AR621D

3. When the lever is depressed, the meter must show less than 1 ohm.

■NOTE: If the meter shows more than 1 ohm of resistance, replace the switch.

Engine Coolant Temperature (ECT) Sensor

CATT II

Get Advanced Tech Tool Version 1

Component data can be retrieved using the CATT II. Utilize the Sensor Data screen.

1. Connect the meter leads (selector in OHMS position) to the sensor terminals.
2. Suspend the sensor and a thermometer in a container of cooking oil; then heat the oil.

■NOTE: Neither the sensor nor the thermometer should be allowed to touch the bottom of the container or inaccurate readings will occur. Use wire holders to suspend the sensor and thermometer.

⚠ WARNING

Wear insulated gloves and safety glasses. Heated oil can cause severe burns.

3. On the ECT sensor when the temperature reaches 40° C (105° F), the meter should read approximately 1136 ohms.
4. On the ECT sensor when the temperature reaches 100° C (212° F), the meter should read approximately 155 ohms.
5. If the readings are not as indicated, the sensor must be replaced.
6. Install the sensor and tighten securely.
7. Connect the leads.

Fan Motor

CATT II

Get Advanced Tech Tool Version 1

This component can be tested using the CATT II. Utilize the Test screen.

■NOTE: To determine if the fan motor is good, connect the red wire from the fan connector to the positive side of a 12 volt battery; then connect the black wire from the fan connector to the negative side. The fan should operate.



PR912A

⚠ WARNING

Care should be taken to keep clear of the fan blades.

■NOTE: Fan motor resistance checks are not recommended. Resistance values change with the motor commutator position.

Power Distribution Module (PDM)

FUSES

The fuses are located in a power distribution module under the dash panel on the left side. If there is any type of electrical system failure, always check the fuses first.

1. Remove a fuse from the power distribution module.


■NOTE: To remove the fuse, compress the locking tabs on either side of the fuse case and lift out.

2. Set the meter selector to the DC Voltage position.
3. Connect the black tester lead to ground.
4. Using the red tester lead, contact each end of the fuse holder connector terminals individually.
5. The meter must show battery voltage from one side of the connector terminal ends.

■NOTE: Battery voltage will be indicated from only one side of the fuse holder connector terminal; the other side will show no voltage.

■NOTE: When testing the HI fuse holder, the headlight OFF/HI/LO switch must be in the HI position; when testing the LIGHTS fuse holder, the headlight dimmer switch can be in either the HI or LO position.

■NOTE: If the meter shows no battery voltage, troubleshoot the battery, switches, power distribution module, or the main wiring harness.



3411-968

CAUTION

Always replace a blown fuse with a fuse of the same type and rating.

1. Set the meter selector to the OHMS position.
2. Connect the red tester lead to one spade end of the fuse; then connect the black tester lead to the other spade end.
3. The meter must show less than 1 ohm resistance. If the meter shows open, replace the fuse.

■NOTE: Make sure the fuses are returned to their proper position according to amperage. Refer to the amperage listed under each fuse on the power distribution module.

RELAYS

The 4-pin relays are identical plug-in type located on the power distribution module. Relay function can be checked by switching relay positions. The 4-pin relays are interchangeable.

■NOTE: The module and wiring harness are not a serviceable component and must be replaced as an assembly.

Ignition Coil

On the 550/700, the ignition coil is located beneath the passenger seat. On the 1000, the ignition coils are attached to the engine cross brace.

VOLTAGE

Primary Coil

1. Set the meter selector to the DC Voltage position; then disconnect the two wires from the coil.

■NOTE: The coil is located to the right of the engine and may be accessed from behind the right-side seat with the cargo box raised.

2. Connect the red tester lead to the orange wire and the black tester lead to the white/blue wire (550/700) or to ground (1000).
3. Turn the ignition switch to the ON position. The meter must show battery voltage.

RESISTANCE


CAUTION

Always disconnect the battery when performing resistance tests to avoid damaging the multimeter.

■NOTE: For these tests, the meter selector should be set to the OHMS position.

Primary Winding

1. Disconnect the primary connector and connect the red tester lead to the terminal (with the wire removed); then connect the black tester lead to the other terminal.




PR906

2. The meter reading must be within specification.

■NOTE: Secondary coil resistance checks are not recommended. An internal diode in the coil prevents accurate secondary resistance measurements.

Spark Plug Cap

1. Connect the red tester lead to one end of the cap; then connect the black tester lead to the other end of the cap.



AR603D

2. The meter reading must be within specification.

■NOTE: If the meter does not show as specified, replace the spark plug cap.

EFI Sensors/Components

CRANKSHAFT POSITION (CKP) SENSOR

1. Set the meter selector to the OHMS position.
2. Connect the red tester lead to the blue wire (550/700) or brown wire (1000); then connect the black tester lead to the green wire (550/700) or white wire (1000). The meter reading must be within specification.

■NOTE: The battery must be at full charge for these tests.

3. Set the meter selector to the AC Voltage position.
4. Connect the red tester lead to the brown/green wire (550/700) or brown wire (1000); then connect the black tester lead to the green/white wire (550/700) or white wire (1000).
5. Crank the engine over using the electric starter.
6. The meter reading must be within specification.

OXYGEN (O₂) SENSOR



Component data can be retrieved using the CATT II. Utilize the Sensor Data screen.

The oxygen sensor (O₂ Sensor) is located in the exhaust pipe.

■NOTE: When testing the resistance of the sensor's heater, the engine/exhaust pipe must be at room temperature (65-75° F) or inaccurate readings will occur.

1. Open the cargo box; then remove the driver's seat, air filter cover, and air filter.
2. Disconnect the sensor.



PR859

■NOTE: For this test, the meter must be in OHMS position.

3. On the sensor side of connector, connect the black (negative) test lead to one white wire pin; then connect the red (positive) test lead to the other white wire pin. Readings should be between 6.7 and 10.1 ohms.

■NOTE: If the meter does not read as specified, replace the sensor.

MANIFOLD ABSOLUTE PRESSURE/INLET AIR TEMPERATURE (MAP/IAT) SENSOR



Component data can be retrieved using the CATT II. Utilize the Sensor Data screen.

■NOTE: Preliminary checks may be performed on this component using the diagnostic mode on the LCD gauge (see EFI Diagnostic System in this section).

1. Disconnect the MAP/IAT connector from the sensor located on top of the throttle body.
2. Select DC Voltage on the tester and turn the ignition switch to the ON position.
3. Connect the black tester lead to the black/green wire and the red tester lead to the green/red wire. The meter should read 4.5-5.5 DC volts (IAT sensor). If the meter does not read as specified, check the ECM connector or wiring.
4. Connect the red tester lead to the orange/blue wire and the black tester lead to the black/green wire. The meter should read battery voltage.
5. Connect the MAP sensor to the harness; then using MaxiClips, connect the red tester lead to the brown/white wire and the black tester lead to the black/green wire. With the engine running at idle speed, the meter should read approximately 2.5 DC volts (MAP sensor).


■NOTE: If the meter does not read as specified, replace the sensor.

Speed Sensor

TESTING

■NOTE: Prior to testing the speed sensor, inspect the three-wire connector on the speed sensor for contamination, broken pins, and/or corrosion.

1. Set the meter selector to the DC Voltage position.
2. With appropriate needle adapters on the meter leads, connect the red tester lead to the voltage lead (V); then connect the black tester lead to the ground lead (G).




PR279A

3. Turn the ignition switch to the ON position.
4. The meter must show approximately 6 DC volts.
5. Leave the black tester lead connected; then connect the red tester lead to the signal lead pin (S).
6. Slowly move the vehicle forward or backward; the meter must show 0 and approximately 6 DC volts alternately.

■**NOTE: If the sensor tests are within specifications, the LCD gauge must be replaced.**


REPLACING (550/700)

1. Disconnect the three-wire connector from the speed sensor harness or from the speed sensor; then remove the Allen-head cap screw securing the sensor to the sensor housing.
2. Remove the sensor from the sensor housing accounting for an O-ring.



CD070

3. Install the new speed sensor into the housing with new O-ring lightly coated with multi-purpose grease; then secure the sensor with the Allen-head cap screw (threads coated with blue Loctite #242). Tighten securely.



CD071

RPM Limiter



Component data can be retrieved using the CATT II. Utilize the Sensor Data screen.

■**NOTE: This vehicle is equipped with an ECM that interrupts the ignition when maximum RPM is approached (see table). When the RPM limiter is activated, it could be misinterpreted as a high-speed misfire.**

550/700							
Gear	Park	Reverse	Neutral	High/Low	Fail-Safe Mode	Incorrect ECU/Gauge (P0630)	Warranty Registration
2WD	2250	4000	6000	7250	4000	6650	4500
4WD							
4WD Lock							
2WD Override							
4WD Override							
Differential-Lock Override							

1000							
Gear	Park	Reverse	Neutral	High/Low	Fail-Safe Mode	Incorrect ECU/Gauge (P0630)	Warranty Registration
2WD	2000	3500	6000	7500	3500	4500	4500
4WD							
4WD Lock							
2WD Override							
4WD Override							
Differential-Lock Override							

Electronic Power Steering (EPS)

CATT II

Get Advanced Tech Tool

Component data and system updates can be retrieved/Performed using the CATT II. Navigate the screens as required.

The EPS system is an electro-mechanical device that utilizes 12 volt DC power to drive a motor linked to the steering shaft to assist the driver when rotating the steering wheel. Driver steering inputs are detected by a torque-sensing transducer assembly within the EPS housing. These inputs are converted to electronic signals by the transducer and control circuitry to tell the motor which way to drive the steering shaft. When no steering input (pressure on the steering wheel) is detected, no torque signal is generated, and no steering assist is provided by the motor.

The EPS system is battery-system powered; therefore, the battery must be in good condition and fully charged. Power delivery and overload protection are provided by an EPS relay and 30-amp fuse, located under the seat in the Power Distribution Module (PDM).

If a system malfunction occurs, a diagnostic trouble code (DTC) will be displayed on the LCD gauge. The following is a list DTC's and possible conditions.

Code	Fault Description	Fault Condition	Possible Cause	EPS Fault Recovery Method
C1301	Over Current	EPS internal over-current condition has been detected	Internal EPS Condition	Correct EPS condition*
C1302	Excessive Current Error	EPS internal current measurement error has been detected	Internal EPS Condition	Correct EPS condition*
C1303	Torque Sensor Range Fault	EPS internal torque sensor range condition has been detected	Internal EPS Condition	Correct EPS condition*
C1304	Torque Sensor Linearity Fault	EPS internal torque sensor linearity condition has been detected	Internal EPS Condition	Correct EPS condition*
C1305	Rotor Position Encoder	EPS internal rotor position encoder condition has been detected	Internal EPS Condition	Correct EPS condition*
C1306	System Voltage Low	EPS battery power low-voltage condition has been detected	System voltage low (less than 11 VDC at the EPS). Wire harness issue, faulty voltage regulator, weak battery or loose battery terminals.	EPS will auto-recover when the battery supply returns to normal
C1307	System Voltage High	EPS battery power over-voltage condition has been detected	System voltage high (more than 16 VDC at the EPS). Wire harness issue, faulty voltage regulator or loose battery terminals.	EPS will auto-recover when the battery supply returns to normal
C1308	Temperature Above 110° C	EPS internal 110° C over-temp condition has been detected	Clean the EPS housing and cooling fins.	EPS will auto-recover when internal temperature drops below 105° C
C1309	Temperature Above 120° C	EPS internal 120° C over-temp condition has been detected	Clean the EPS housing and cooling fins.	EPS will auto-recover when internal temperature drops below 115° C
C1310	Vehicle Speed High	Vehicle speed signal received by the EPS exceeds the maximum speed specification	Intermittent main harness wires, defective speed-sensor, or intermittent speed sensor wires.	EPS will auto-recover when the vehicle speed signal drops below the maximum speed specification
C1311	Vehicle Speed Low	Vehicle speed signal received by the EPS is zero or missing	Broken main harness wires, defective speed-sensor, or broken speed sensor wires.	EPS will auto-recover when the vehicle speed signal returns to normal
C1312	Vehicle Speed Faulty	Vehicle speed CAN signal received by the EPS incorrect or missing	Broken main harness CAN wires, defective speed-sensor, or broken speed sensor wires.	EPS will auto-recover when the vehicle speed signal returns to normal
C1313	Engine RPM High	Engine RPM signal received by the EPS exceeds the maximum RPM specification	Intermittent main harness RPM wires, intermittent voltage regulator, intermittent ACG stator wires.	EPS will auto-recover when engine RPM signal drops below the maximum RPM specification
C1314	Engine RPM Low	Engine RPM signal received by the EPS suddenly dropped below 500 RPM	Handlebar switch in the "OFF" position, broken main harness RPM wires, defect voltage regulator, broken ACG stator wires.	EPS will auto-recover when engine RPM signal returns to normal
C1315	Engine RPM Faulty	Engine RPM CAN signal received by the EPS incorrect or missing	Broken main harness CAN wires or defective ECM.	EPS will auto-recover when engine RPM signal returns to normal
C1316	EEPROM Error	EPS internal memory error has been detected	Internal EPS condition	Correct EPS condition*
C1317	CAN Bus Error	The EPS has lost CAN communication with the EFI ECM	Broken CAN wires in the main harness. EFI ECM connector has been disconnected.	Correct EPS condition*
C1318	Internal CRC Error	EPS internal CRC calculation condition has been detected	EPS reflash has failed. Battery power was lost, or the keyswitch was turned off, during EPS reflash programming.	EPS must be reprogrammed
C1319	Boot Counter Exceeded	EPS internal application code condition has been detected	Intermittent power has prevented a successful application code launch.	Correct EPS power condition*

Code	Fault Description	Fault Condition	Possible Cause	EPS Fault Recovery Method
C1320	Incorrect Vehicle Speed-to-RPM Ratio	Vehicle speed signal received by the EPS exceeds 10 MPH, but the engine RPM signal less than 500 RPM	Intermittent or broken main harness RPM wires, intermittent voltage regulator, intermittent or broken ACG stator wires.	Correct EPS condition*
C1321	Vehicle Speed Erratic	Vehicle speed signal received by the EPS changing at an unrealistic rate	Intermittent main harness, intermittent speed sensor, dirty speed sensor or trigger wheel.	Correct EPS vehicle speed signal condition*
C1322	Engine RPM Lost	Engine RPM signal received by the EPS exceeds 500 RPM and then is zero or missing	Handlebar switch in the "OFF" position, broken main harness RPM wires, defect voltage regulator, broken ACG stator wires.	EPS will auto-recover when engine RPM signal returns to normal
C1323	"EPS OFF" Gauge Display	Battery power has been applied to the EPS for more than 5-minutes, but no engine RPM signal has been detected	The EPS has been automatically disabled, after 5-minutes of inactivity, to conserve battery power.	EPS will auto-recover when engine is started or the keyswitch is cycled On-Off-On
C1324	Loss of CAN communication with EPS unit	The gauge has lost CAN communication with the EPS	Broken CAN wires in the main harness or disconnected EPS. This is not an EPS-generated DTC; gauge DTC display only.	Gauge DTC display will clear when the EPS-to-gauge CAN communication is restored.
C1325	Dual Loss	EPS loss of both the vehicle speed and the engine RPM signals has been detected	Handlebar switch in the "OFF" position, the engine stalled (keyswitch "ON"), broken harness wires, loss of CAN data signal.	EPS will auto-recover when either the vehicle speed or engine RPM signal is restored.
C1326	Rotor Position Encoder	EPS internal rotor position encoder variance condition has been detected	Internal EPS Condition	Correct EPS condition*
C1327	Voltage Converter Error (Low)	EPS internal voltage converter low-voltage condition has been detected	Internal EPS Condition	Correct EPS condition*
C1328	Voltage Converter Error (High)	EPS internal voltage converter over-voltage condition has been detected	Internal EPS Condition	Correct EPS condition*
C1329	Internal Data Error	EPS internal preloaded data condition has been detected	Internal EPS Condition	EPS must be reprogrammed

* After correcting condition, cycle key switch On-Off-On

The following tests may aid in troubleshooting when the ignition switch is ON and no EPS assistance is present:

■NOTE: The EPS assembly is not serviceable and must not be disassembled or EPS warranty will be voided. Make sure to thoroughly troubleshoot the entire system before replacing the EPS assembly (see Steering/Frame/Controls).

■NOTE: Prior to troubleshooting below, make sure the ignition switch has not been left on with the engine not started. After five minutes, this will deactivate the EPS and display a code. Turn the ignition switch OFF and back to ON to reset and reactivate the EPS.

1. Check 30-amp EPS fuse.
2. Check EPS relay (may be switched with any other 4-pin relay on PDM - replace relay if EPS normal after switching).
3. Disconnect 2-pin connector on the EPS assembly and connect a volt meter set to DC voltage to the harness (black meter lead to BLK and red meter lead to ORG/BRN). With the ignition switch to the ON position, the meter must read more than 8.5 DC volts (if correct voltage is not present, check connections and wiring harness).

CAUTION

Do not attempt to check resistance of the EPS motor (2-pin input receptacle). There are internal capacitors holding a charge that can cause internal damage to an ohmmeter.

4. Check for updates using the CATT II tool.

■NOTE: If after completing the preceding tests and possible solutions with normal results a code or issue persists, the EPS assembly must be replaced (see Steering/Frame/Controls).

Ignition Switch

To access the ignition switch, dash switches, front accessory connectors, and front switched accessory connector, the dash must be unfastened and slid to the rear.

VOLTAGE

1. Set the meter selector to the DC Voltage position.
2. Connect the red meter lead to the red wire; then connect the black meter lead to ground.
3. Meter must show battery voltage.

■NOTE: If the meter shows no battery voltage, troubleshoot the main 30 amp fuse, the battery, or the main wiring harness.

4. Connect the red meter lead to the red/black wire; then with the black lead grounded, turn the ignition switch to the ON position. The meter must show battery voltage.
5. Connect the red meter lead to the yellow/green wire; then with the black lead grounded, turn the ignition switch to the START position. The starter should engage and the meter must show battery voltage.


■NOTE: When the starter is engaged, battery voltage will be approximately 10.5 DC volts.

Headlight Switch

VOLTAGE

1. Connect the red meter lead to the gray wire; then connect the black meter lead to the black wire.
2. Turn the ignition switch to the ON position. The meter must show battery voltage.
3. Connect the red meter lead to the yellow wire; then select the high beam position on the headlight switch. The meter must show battery voltage.
4. Connect the red meter lead to either of the two white wires; then select the low beam position on the headlight switch. The meter must show battery voltage.

■NOTE: The battery voltage will show lower in steps 3 and 4 due to electrical loading of the headlights.



PR566A

2WD	4WD	DIFFERENTIAL LOCK
A to D <1 ohm	A to D <1 ohm	A to D <1 ohm
C to E <1 ohm	C to E <1 ohm	C to E <1 ohm
A to B Open	A to B <1 ohm	A to B <1 ohm
A to C Open	A to C Open	A to C <1 ohm
A to E Open	A to B <1 ohm	A to C <1 ohm

VOLTAGE

■NOTE: Voltage tests must be made with the switch and the actuator connected. The meter can be connected at the actuator connector using a break-out harness or MaxiClips.

1. Connect the black tester lead to the black wire; then turn the ignition switch to the ON position.
2. Select the DC Volts position on the tester and observe the meter readings for each of the three switch positions.

WIRE COLOR	2WD	4WD	DIFFERENTIAL LOCK
Black to Red/Black	12.0 DC Volts	12.0 DC Volts	12.0 DC Volts
Black to White/Green	11.5 DC Volts	0 DC Volts	0 DC Volts
Black to White/Orange	11.5 DC Volts	11.5 DC Volts	0 DC Volts

■NOTE: If the meter does not show voltages according to the chart, make sure the front drive actuator is plugged in; then troubleshoot the switch, ignition fuses, battery connections, or wiring harness.

Drive Select Switch



Component data can be retrieved using the CATT II. Utilize the Sensor Data screen.

RESISTANCE

1. Remove the switch assembly from the dash; then disconnect the harness from the switch.
2. Using an ohmmeter, the following readings must be observed.

■NOTE: The switch can be removed from the dash using a thin, flat pry bar or suitable putty knife. It is not necessary to remove the dash to remove the switch.

Reverse Override Switch

VOLTAGE

■NOTE: To perform the following tests, the ignition switch must be in the ON position and the transmission shifted into reverse gear.

1. Connect the red meter lead to the white/green wire and the black meter lead to a suitable ground; then select 2WD on the drive select switch. The meter must show approximately 1.5 DC volts.
2. Depress the reverse override switch. The meter showing should not change from step 1.

3. Select 4WD on the drive select switch. The meter must show approximately 5 DC volts.
4. Depress the reverse override switch. The meter must show approximately 1.5 DC volts.
5. Connect the red meter lead to the red/green wire. The meter must show approximately 1.5 DC volts. Depress the reverse override switch. The meter must show approximately 1.5 DC volts.

Front Drive Actuator

■NOTE: With the engine stopped and the ignition switch in the ON position, a momentary “whirring” sound must be noticeable each time the drive select switch is moved to 2WD and 4WD. Test the switch, 30 amp fuse, and wiring connections prior to testing the actuator.

■NOTE: The differential must be in the unlocked position for this procedure.

VOLTAGE

1. Locate the 4-wire connector for the front drive selector actuator on the frame to the right of the differential; then connect the red meter lead to the orange wire using a MaxiClip.



PR293

2. Connect the black lead to the black wire using a Maxi-Clip; then select 2WD on the drive select switch.



PR295

■NOTE: The black tester lead can remain connected to the black wire for the remaining tests.

3. Turn the ignition switch to the ON position. The meter must show battery voltage.

■NOTE: If battery voltage is not shown, troubleshoot the 10 amp ignition (IGN) fuse on the power distribution module, the ignition switch, or the main wiring harness.

4. Connect the red meter lead to the white/red wire. The meter must show battery voltage.
5. Select 4WD on the drive select switch. The meter must show 0 DC volts.
6. Connect the red meter lead to the white/orange wire. The meter must show battery voltage.
7. Engage the differential lock. The meter must show 0 DC volts.

■NOTE: If the meter does not show 0 DC volts, rock the vehicle to help engage the differential lock; then troubleshoot the drive select switch.

Stator Coil

VOLTAGE (AC Generator - Regulated Output)

1. Set the meter selector to the DC Voltage position.
2. Connect the red tester lead to the positive battery post; then connect the black tester lead to the negative battery post.
3. With the engine running at a constant 5000 RPM (with the headlights on), the meter must show 14-15.5 DC volts.


CAUTION

Do not run the engine at high RPM for more than 10 seconds.

■NOTE: If voltage is lower than specified, test AC Generator - No Load.

VOLTAGE (AC Generator - No Load)

The connector is the black three-pin one on the left side of the engine. On the 550/700, the connector is located above the CVT exhaust tube. On the 1000, the connector is located near the shift linkage mount.



FI083B

■NOTE: Test the connector coming from the engine.

1. Set the meter selector to the AC Voltage position.
2. Test between the three yellow wires (550/700) or the three black wires (H2) for a total of three tests.
3. With the engine running at a constant 5000 RPM, all wire tests must be within specification.

CAUTION

Do not run the engine at high RPM for more than 10 seconds.

■NOTE: If the stator coil test failed, check all connections, etc., and test again. If no voltage is present, check the physical condition of the Rotor/Flywheel. If the physical condition is good, replace the stator assembly.

RESISTANCE (AC Generator)**CAUTION**

Always disconnect the battery when performing resistance tests to avoid damaging the multimeter.

1. Set the meter selector to OHMS position.
2. Test between the three black wires (550/700) or the three black wires (H2) for a total of three tests.
3. The meter reading must be within specification.

Starter Motor

■NOTE: The starter motor is not a serviceable component. If the motor is defective, it must be replaced.

REMOVING

1. Disconnect the battery.

CAUTION

Always disconnect the negative battery cable from the battery first; then disconnect the positive cable.

2. Remove the nut securing the positive cable to the starter motor; then remove the cable from the starter.

3. Remove the two cap screws securing the starter motor with ground wires to the crankcase; then remove the starter motor. Account for the wiring forms and an O-ring.

INSTALLING

1. Apply a small amount of grease to the O-ring seal on the starter motor; then install the starter into the crankcase. Secure with two machine screws and wiring forms.
2. Secure the positive cable to the starter motor with the nut.
3. Connect the battery.

TESTING VOLTAGE

Perform this test on the starter motor positive terminal. To access the terminal, slide the boot away.

■NOTE: The ignition switch must be in the ON position, and the shift lever in the NEUTRAL position.

1. Set the meter selector to the DC Voltage position.
2. Connect the red tester lead to the starter terminal; then connect the black tester lead to ground.
3. With the starter button depressed, the meter must show battery voltage and the starter motor should operate.



AR607D


■NOTE: If the meter showed battery voltage but the starter motor did not operate or operated slowly, inspect battery voltage (at the battery), starter motor condition, and/or ground connections.

■NOTE: If the meter showed no battery voltage, inspect the main fuse, ground connections, starter motor lead, battery voltage (at the battery), starter relay, or the neutral start relay.

Starter Relay

1. Remove the seats and center console; then using the multimeter set to the DC Voltage position, check the relay as follows.

2. Connect the red tester lead to the positive battery cable connection; then connect the black tester lead to the starter cable connection. The meter must show battery voltage.




■NOTE: Make sure the ignition switch is in the ON position and the transmission in neutral.

3. Depress the starter button while observing the multimeter. The multimeter should drop to 0 volts and a "click" should be heard from the relay.

■NOTE: If a "click" is heard and more than one volt is indicated by the multimeter, replace the starter relay. If no "click" is heard and the multimeter continues to indicate battery voltage, proceed to step 4.

4. Disconnect the two-wire plug from the starter relay; then connect the red tester lead to the green wire and the black tester lead to the black wire.



5. Depress the starter button and observe the multimeter.

■NOTE: If battery voltage is indicated, replace the starter relay. If no voltage is indicated, proceed to Neutral Start Relay check.

Electronic Control Module (ECM)

The ECM is located beneath the seat near the battery.

■NOTE: The ECM is not a serviceable component. If the unit is defective, it must be replaced.

The ECM is rarely the cause for electrical problems; however, if the ECM is suspected, substitute another ECM to verify the suspected one is defective.

This EFI system has a built-in feature that will only allow an ECM of the same part number to be used in these models. Do not attempt to substitute an ECM from a different model as the system will not allow it to start.

Error codes can be cleared by following the procedures located in the ECM Error Codes sub-section in this section.

Fuel Pump/Fuel Level Sensor

The fuel pump and fuel level sensor are not serviceable components. If either component fails, it must be replaced.

TESTING

⚠ WARNING

Whenever any maintenance or inspection is made on the fuel system during which there may be fuel leakage, there should be no welding, smoking, open flames, etc., in the area.


⚠ AT THIS POINT

Prior to removing the electric fuel pump, the following check should be performed to determine that removal is necessary.

1. Turn the ignition switch ON and listen for a momentary "whirring" sound of the pump building pressure. If the sound is heard (10 seconds), no electrical checks are necessary. Turn the ignition switch OFF.
2. Disconnect the gasoline hose from the fuel rail; then install a suitable pressure gauge.

⚠ WARNING

Gasoline may be under pressure. Place an absorbent towel under the connector to absorb any gasoline spray when disconnecting.



- Turn the ignition switch to the ON position. The fuel pressure should build until the pump shuts off. Pressure should read 3.0 kg-cm² (43 psi).
- If the pump is not running, disconnect the fuel pump/sensor connector by reaching under the rear rack from behind.
- Connect a multimeter to the power supply leads with the red tester lead to the red wire and the black tester lead to the black wire; then turn the ignition switch to the ON position. The meter should read battery voltage. If battery voltage is indicated and the fuel pump does not run, replace the pump assembly. If no battery voltage is indicated, check the ECM and the vehicle tilt sensor.

REMOVING

- Remove the key from the ignition switch.

WARNING

Always ensure that power cannot be inadvertently applied to the ignition/ECM when working on the fuel system. If the ignition switch is turned on, the electric fuel pump will start and gas could be rapidly pumped and spilled resulting in fire and severe injury.

- Remove the seats, center console, and right-side seat-base; then disconnect the negative battery cable.
- Disconnect the electrical plug from the main harness; then disconnect the gasoline hose from the fuel pump.
- Mark the fuel pump mounting and gas tank for installing purposes; then remove the screws securing the fuel pump to the gas tank and remove the fuel pump.

CAUTION

Take care not to damage the float or float arm or replacement of the entire assembly will be necessary.


- Using duct tape or other suitable means, cover the fuel pump opening.

INSPECTING

AT THIS POINT

If the pump has failed earlier test and must be replaced, proceed to INSTALLING.

- Inspect the fuel screen and blow clean with low pressure compressed air.
- Move the float lever and check for free movement. The float assembly should return to the lower position without force.
- Test the fuel level sensor by connecting a multimeter (A) to the fuel level sensor leads (B); then select OHMS. The multimeter should show 5 ohms at full fuel position (C) and 95 ohms at empty fuel position (D).



ATV2116

■NOTE: If readings are erratic, clean the resistor wiper and resistor with clean alcohol and retest. If still not correct, replace the fuel pump assembly.

INSTALLING

- Place the fuel pump assembly into the gas tank with a new gasket aligning the match marks; then secure with the four screws. Tighten securely.

■NOTE: It is important to install the fuel pump with the correct orientation to ensure adequate float lever clearance.

- Connect the gasoline hose to the fuel pump pipe and secure with the hose clamp; then connect the electrical plug to the main harness.
- Connect the negative battery cable; then turn the ignition switch to the ON position and verify that no gas leaks are present, the pump runs for 2-3 seconds, and the gas gauge reading is normal.
- Start the engine to verify proper engine operation; then shut off the engine and install the right-side seat-base, center console, and seats making sure the seats lock securely into place.

Regulator/Rectifier

The regulator/rectifier is located under the hood and in front of the storage tray. Try to verify all other charging system components before the regulator/rectifier is replaced.

TESTING

- Start engine and warm up to normal operating temperature; then connect a multimeter (set at the DC Voltage position) to the battery as follows.
- Connect the red tester lead to the positive battery post and the black tester lead to the negative battery post.
- Slowly increase RPM. The voltage should increase with the engine RPM to a maximum of 15.5 DC volts.

■**NOTE:** If voltage rises above 15.5 DC volts, the regulator is faulty or a battery connection is loose or corroded. Clean and tighten battery connections or replace the regulator/rectifier. If voltage does not rise, see **Stator Coil/Crankshaft Position (CKP) Sensor - Voltage** in this section. If charging coil voltage is normal, replace the regulator/rectifier.

Headlights

Each headlight has one HI/LO three-pin connector and one two-pin connector for the LED lights.

VOLTAGE

■**NOTE:** The HI/LO bulb-connector is located toward the inside of the headlight assembly. It uses a three-pin connector with the corresponding color codes: white, yellow/black, and black. The LED light and connector are located toward the outside of the headlight assembly and use the color codes white/red and black.

1. Set the meter selector to the DC Voltage position.
2. Set the light switch to the correct position for the affected light; then connect the black tester lead to the black wire using a MaxiClip.
3. Connect the red tester lead to the yellow/black wire (high beam) or white wire (low beam) using a MaxiClip. The meter must show battery voltage.

■**NOTE:** If battery voltage is not shown in any test, inspect the **LIGHTS** fuse on the power distribution module, headlight switch, ignition switch, switch connectors, or wiring harness.

4. To test LED voltage, disconnect the two-pin connector from the back of the headlight; then connect the black tester lead to the black wire using a MaxiClip. Connect the red tester lead to the white/red wire (LED). The meter must show battery voltage.

Taillight - Brakelight

VOLTAGE (Taillight)

■**NOTE:** Perform this test at the socket end of the tail-light - brakelight harness (pigtail). The ignition switch must be in the ON position and either high beam or low beam selected on the light switch.

1. Set the meter selector to the DC Voltage position.
2. Connect the black tester lead to the black wire; then connect the red tester lead to the white/red wire. The meter should show battery voltage.
3. With the ignition key in the LIGHTS position, the meter must show battery voltage.

■**NOTE:** If battery voltage is not shown and the headlights are illuminated, inspect the three-wire connector in the left-rear canopy tube at the juncture of the canopy tube and lower frame. If battery voltage is shown on the meter, replace the bulb.

VOLTAGE (Brakelight)

■**NOTE:** Perform this test at the socket end of the tail-light/brakelight harness (pigtail). The ignition switch must be in the ON position.

1. Set the meter selector to the DC Voltage position.
2. Connect the red tester lead to the red/blue wire; then connect the black tester lead to the black wire.
3. With the brake applied, the meter must show battery voltage.

■**NOTE:** If the meter shows no voltage, inspect the 10 amp ignition (IGN) fuse, brakelight switch, wiring harness, or connectors.

Ignition Timing

The ignition timing cannot be adjusted; however, verifying ignition timing can aid in troubleshooting other components. To verify ignition timing, use the following procedure.

■**NOTE:** To check ignition timing, the seats and center console must be removed.

1. Attach the Timing Light to the spark plug high tension lead; then remove the timing inspection plug from the left-side crankcase cover.
2. Start the engine and using the RPM function on the speedometer/tachometer, run at 1500 RPM; ignition timing should be 10° BTDC.
3. Install the timing inspection plug.

If ignition timing cannot be verified, the rotor may be damaged, the key may be sheared, the trigger coil bracket may be bent or damaged, or the ECM may be faulty.

Tilt Sensor

WARNING


Incorrect installation of the tilt sensor could cause sudden loss of engine power which could result in loss of vehicle control resulting in injury or death.

CAUTION

Do not drop the tilt sensor as shock can damage the internal mechanism.


SUPPLY VOLTAGE

1. Disconnect the three-wire connector from the sensor; then select DC Voltage on the multimeter and connect the red tester lead to the orange wire (C) and the black tester lead to the pink/black wire (A).



CD706A

2. Turn the ignition switch to the ON position. The multimeter should read battery voltage. If battery voltage is not indicated, check the 30-amp fuse, wiring harness, or the ignition switch.
3. Remove the red tester lead and connect to the blue/brown wire (B). The multimeter should read approximately 0.02 DC volts. If the specified voltage is not indicated, check wire connections at the ECM or substitute another ECM to verify the test.



CD706B

OUTPUT VOLTAGE


■NOTE: Needle adapters will be required on the multimeter leads as the following tests are made with the sensor connected.

1. Connect the three-wire plug to the sensor; then remove the right-side mounting screw securing the sensor to the rear frame.




CD707

2. Install the needle adapters to the multimeter leads; then select DC Voltage on the multimeter.
3. Connect the red tester lead to the blue/brown wire (B) and the black tester lead to the pink/black wire (A); then turn the ignition switch ON and observe the meter. The meter should read 0.3-1.5 DC volts.




CD705B

4. Tilt the sensor 60° or more to the left and right observing the meter. The meter should read 3.0-7.0 DC volts after approximately one second in the tilted position. If the meter readings are not as specified, the tilt sensor is defective.



CD709

■NOTE: When replacing the sensor after testing, make sure the arrow marking is directed up.



CD705A




FI672

Throttle Position Sensor (TPS)

■NOTE: Preliminary checks may be performed on this component using the diagnostic mode on the LCD gauge (see EFI Diagnostic System in this section).

TESTING

1. Remove the seats and center console; then disconnect the three-wire TPS connector plug.



PR533A

■NOTE: Prior to testing the TPS, inspect the three-wire plug connector on the main harness and the three-pin plug on the TPS for contamination, broken pins, and/or corrosion.

■NOTE: If the vehicle is in warranty, removing or adjusting the TPS will void warranty. If the TPS is tested out of specification, the throttle body must be replaced. If the vehicle is out of warranty, the TPS may be adjusted.

2. Connect the TPS Multi-Analyzer Harness connector #8 to the TPS; then connect the harness to the TPS Analyzer Tool.

3. Using a multimeter, connect the black tester lead to the white socket (VAR) on the analyzer and the red tester lead to the red socket (+5V); then select the DC Voltage position. With the vehicle off, the gauge should read 0.58-0.62 and at Wide-Open Throttle it should read up to approximately 3.7.



FI676A

EFI Diagnostic System

DIGITAL GAUGE

The digital gauge can be used as a diagnostic tool for many of the DTC's displayed. To place the gauge into the diagnostic mode, use the following procedure.

1. Turn the ignition switch ON.
2. Depress and hold both left and right buttons together for approximately three seconds until "DIAGNOSTIC" appears on the LCD.



WT541

3. Press the center button (SELECT) to enter diagnostic mode; cycle the display by pressing either the left or right button to step to the desired function.

■NOTE: The gauge can be utilized dynamically (engine running/vehicle moving) or statically (engine/vehicle stopped).

DIAGNOSTIC MODES

Battery (BATTERY)



WT540

Display: System DC voltage.

DTC: P0562, P0563, P2531, P2532

Usage: Verify system voltage under following conditions.

1. Battery voltage with engine and accessories off (>12.2 VDC for fully charged).
2. Battery voltage with engine idling (charging = 13.8 VDC or greater).
3. Battery voltage with electrical accessories operating, engine idling (13.5 VDC or greater).
4. Battery voltage starter cranking (10.5-11.5 VDC).

Coolant (COOLANT)



WT591

Display: Engine coolant temperature as measured by the ECT sensor.

DTC: P0116, P0117, P0118, P0119

Usage: Monitor coolant temperature to verify the following.

1. ECT sensor signal.
2. High Temperature indicator (on @ 230° F.)
3. Thermostat opening @ approximately 180° F, indicated by a momentary drop or pause in the rising temperature reading.
4. Fan ON @ 203° F, OFF @ 194° F:
 - A. fan motor
 - B. fan relay
 - C. fan fuse
 - D. wiring connections
5. High Temperature Rev Limiter 5000 RPM @ 230° F.

Inlet Air Temperature (INTAKE)



WT592

Display: Inlet air temperature in Fahrenheit or Celsius.

DTC: P0112, P0113, P0114

Usage: Verify correct output of IAT sensor.

■NOTE: After engine has been running, IAT readings will be higher than outside air temperature due to engine and engine compartment heat as well as intake manifold heating.

MAP (AIR PRESS)



WT602

Display: MAP in millibars and in./Hg.

DTC: P0107, P0108

Usage: Verify barometric pressure signal correct.

■NOTE: Local barometric pressure is given in in./Hg (inches of mercury) and millibars. The gauge should display approximately 965 millibars at 970 ft. above sea level. This number will not change when the engine is started. However, the value is being observed internally in the ECM.

Idle Step Control (ISC)



WT542

Display: ISC position

DTC: P0508, P0509

Usage: Verify correct ISC position.

TPS (TPS)



WT539

Display: TPS position (0% closed, 95-100% WOT).

DTC: P0121, P0122, P0123

Usage: Verify TPS signal and adjust throttle cable.

Fuel Sensor (FUEL)



WT545

Display: Fuel level signal from the fuel level sensor.

DTC: C1400, C1401, C1402

Usage: Check output of the fuel level sensor.*

1. Full fuel is indicated by a reading of 0-5 ohms.
2. Empty is indicated by a reading of 95-105 ohms.

* 110-500 ohms, suspect the fuel level sensor or wiring. 0-100 ohms but no gauge indication, suspect the gauge.

Tachometer (RPM)



WT544

Display: Engine RPM

DTC: P0336, P0337, P0339

Usage: Verify engine speed signal from the following.

1. CKP (crankshaft position) sensor to ECM
2. ECM (CAN) signal to gauge (tachometer)
3. ECM (CAN) signal to EPS

Speedometer (SPEED)



WT543

Display: Vehicle speed signal.

DTC: P0500

Usage: Verify speedometer sensor signal from the following.

1. Speed sensor to ECM.

2. ECM (CAN) signal to gauge (speedometer/odometer).

3. ECM (CAN) signal to EPS

DIAGNOSTIC TROUBLE CODES (DTC)

If an EFI or related chassis component fails or an out-of-tolerance signal is detected by the ECM, a diagnostic trouble code (DTC) will be generated in the ECM and displayed on the LCD. The DTC will be displayed alternately with a wrench icon or malfunction indicator light (MIL). The DTC will continue to flash, until the malfunction is corrected and the code cleared.

Code List

■**NOTE:** Each of the following numerical codes will have a one-letter prefix of C, P, or U. A “C” prefix denotes a chassis malfunction, a “P” prefix denotes a power train malfunction, and a “U” prefix denotes a loss of communication with the gauge.

■**NOTE:** Normal malfunction codes are cleared from the LCD when the component is replaced or the malfunction is corrected; however, intermittent codes must be cleared as noted in the code chart.

Code	Fault Description	Possible Cause	Fault Recovery
C0063	Tilt Sensor Circuit High	Sensor or interconnect harness shorted to battery power	Correct condition*
C0064	Tilt Sensor Circuit Low/SG/Open	Sensor or interconnect harness open or shorted to chassis ground	Correct condition*
C1263	Backup/Reverse-Light Circuit Open	Bulb has failed or is disconnected or interconnect harness is open	Correct condition*
C1264	Backup/Reverse-Light Circuit High	Bulb has failed or is disconnected or interconnect harness shorted to battery power	Correct condition*
C1265	Backup/Reverse-Light Circuit Low/SG	Bulb has failed or is disconnected or interconnect harness shorted to chassis ground	Correct condition*
P0030	O2 Heater Intermittent/Open	Heater or interconnect harness is intermittent or open	Correct condition*
P0031	O2 Heater Low/SG	Heater or interconnect harness shorted to chassis ground	Correct condition*
P0032	O2 Heater High/SP	Heater or interconnect harness shorted to battery power	Correct condition*
P0107	MAP Sensor Circuit Low/SG/Open	Sensor or interconnect harness shorted to chassis ground	Correct condition*
P0108	MAP Sensor Circuit High/SP	Sensor or interconnect harness shorted to battery power	Correct condition*
P0112	Intake Air Temp Sensor Circuit Low/SG	Sensor or interconnect harness shorted to chassis ground	Correct condition*
P0113	Intake Air Temp Sensor Circuit High/Open	Sensor or interconnect harness open or shorted to battery power	Correct condition*
P0114	Intake Air Temp Sensor Circuit Intermittent	Sensor or interconnect harness intermittent	Correct condition*
P0116	ECT Sensor Circuit Range/Performance	Sensor producing an out-of-range voltage	Correct condition*
P0117	ECT Sensor Circuit Low/SG	Sensor or interconnect harness shorted to chassis ground	Correct condition*
P0118	ECT Sensor Circuit High/Open/SP	Sensor or interconnect harness open or shorted to battery power	Correct condition*
P0119	ECT Sensor Circuit Intermittent	Sensor or interconnect harness intermittent	Correct condition*
P0121	TPS Range/Performance	Sensor producing an out-of-range voltage	Correct condition*
P0122	TPS Circuit Low/SG	Sensor or interconnect harness shorted to chassis ground	Correct condition*
P0123	TPS Circuit High	Sensor or interconnect harness open or shorted to battery power	Correct condition*
P0130	O2 Sensor Intermittent/Open	Sensor or interconnect harness intermittent or open	Correct condition*
P0131	O2 Sensor Low/SG or Air-Leak	Sensor or interconnect harness shorted to chassis ground or an air-leak exists	Correct condition*
P0132	O2 Sensor High/SP	Sensor or interconnect harness shorted to battery power	Correct condition*
P0171	O2 Feedback Below Minimum Correction	Low fuel rail pressure, dirty fuel filter, or dirty injectors	Correct condition*
P0172	O2 Feedback Exceeds Maximum Correction	Excessive fuel rail pressure, MAP or temp sensors out-of-spec	Correct condition*
P0219	Engine Over-Speed Condition	Engine speed (RPM) has exceeded the ECM over-speed set-point/limit	Reduce engine speed
P0231	Fuel Pump Relay Circuit Low/SG/Open	Relay removed or interconnect harness shorted to chassis ground	Correct condition*
P0232	Fuel Pump Relay Circuit High	Relay or interconnect harness shorted to battery power	Correct condition*
P0233	Fuel Pump Relay Circuit	Relay circuit erratic or intermittent	Correct condition*
P0261	Cylinder #1 Fuel injector Circuit Low/SG	Injector #1 or interconnect harness shorted to chassis ground	Correct condition**
P0262	Cylinder #1 Fuel injector Circuit High	Injector #1 or interconnect harness shorted to battery power	Correct condition**
P0263	Cylinder #1 Fuel injector Balance/Open	Injector #1 disconnected or interconnect harness is open	Correct condition**
P0264	Cylinder #2 Fuel injector Circuit Low/SG	Injector #2 or interconnect harness shorted to chassis ground	Correct condition**
P0265	Cylinder #2 Fuel injector Circuit High	Injector #2 or interconnect harness shorted to battery power	Correct condition**

Code	Fault Description	Possible Cause	Fault Recovery
P0266	Cylinder #2 Fuel Injector Balance/Open	Injector #2 disconnected or interconnect harness is open	Correct condition**
P0336	Crankshaft Angle Sensor Synchronization	Sensor or interconnect harness intermittent	Correct condition**
P0337	Crankshaft Angle Sensor Circuit/SG	Sensor or interconnect harness shorted to chassis ground	Correct condition**
P0339	Crankshaft Angle Sensor Intermittent/Erratic	Sensor or interconnect harness intermittent	Correct condition**
P0340	Camshaft Angle Sensor Synchronization	Sensor or interconnect harness intermittent	Correct condition**
P0341	Camshaft Angle Sensor Circuit/SG	Sensor or interconnect harness shorted to chassis ground	Correct condition**
P0342	Camshaft Angle Sensor Intermittent/Erratic	Sensor or interconnect harness intermittent	Correct condition**
P0480	Fan Relay Control Circuit	Relay erratic or intermittent	Correct condition*
P0484	Fan Relay Control Circuit High	Relay or interconnect harness shorted to battery power	Correct condition*
P0485	Fan Relay Control Circuit Low/SG/Open	Fan fuse has blown, fan relay removed, or interconnect harness shorted to chassis ground	Correct condition*
P0500	Vehicle Speed-Sensor	Sensor circuit signal intermittent or missing	Correct condition*, start and drive the vehicle*
P0508	Idle Air Control System Circuit Low/SG	IAC interconnect harness shorted to chassis ground	Correct condition*
P0509	Idle Air Control System Circuit High/Open	IAC disconnected or the interconnect harness shorted to battery power	Correct condition*
P0520	Engine Oil Sensor/Switch	Sensor or interconnect harness erratic or intermittent	Correct condition*
P0562	System Voltage Low	Battery charge condition low or the regulator/rectifier output low	Correct condition*
P0563	System Voltage High	Battery cable connections are loose or regulator/rectifier output high	Correct condition*
P0601	ECM CAN Communication Shutdown	Intermittent CAN connections or unstable CAN conditions have caused the ECM to temporarily shutdown CAN communication	Correct CAN communication issue*
P0615	Starter Relay Circuit	Start switch/button, starter relay, gearswitch or interconnect harness erratic or intermittent	Correct condition*
P0616	Starter Relay Circuit Low	Start switch/button, starter relay or interconnect harness intermittent or shorted to chassis ground	Correct condition*
P0617	Starter Relay Circuit High	Start switch/button, starter relay or interconnect harness intermittent or shorted to battery power	Correct condition*
P0630	VIN Not Programmed or Incompatible	Verify the LCD gauge and ECM part numbers are correct for the vehicle model number and VIN	Correct gauge and ECM VIN compatibility issue*
P0642	Sensor Power Circuit Low	One or more of the sensors defective or shorted to chassis ground	Correct condition*
P0643	Sensor Power Circuit High	One or more of the sensors defective or shorted to battery power	Correct condition*
P2300	Ignition Coil #1 Primary Circuit Low/SG/Open	Ignition coil #1 or interconnect harness open or shorted to chassis ground	Correct condition**
P2301	Ignition Coil #1 Primary Circuit High	Ignition coil #1 or interconnect harness shorted to battery power	Correct condition**
P2303	Ignition Coil #2 Primary Circuit Low/Open	Ignition coil #2 or interconnect harness open or shorted to chassis ground	Correct condition**
P2304	Ignition Coil #2 Primary Circuit High	Ignition coil #2 or interconnect harness shorted to battery power	Correct condition**
P2531	Ignition Switch Circuit Low	Battery charge condition low or the regulator/rectifier output low	Correct condition*
P2532	Ignition Switch Circuit High	Battery cable connections are loose or regulator/rectifier output high	Correct condition*
U0155	LCD Gauge to EFI ECM CAN Communication Lost	Gauge CAN circuit or interconnect harness intermittent or has failed	Correct condition*
U1000	Vehicle Not Registered or Invalid PIN Entered	An invalid registration PIN has been entered	Enter the correct registration PIN*
U1001	Vehicle Not Registered and Vehicle Limits Enabled	An invalid registration PIN has been entered	Enter the correct registration PIN*
FUEL OFF	Tilt Sensor Activation Code	Sensor activated	Restore the vehicle chassis to an upright position*

High: A high voltage condition has been detected

* After correcting the condition, cycle the key switch

Low: A low voltage condition has been detected

On-Off-On

Intermittent: An intermittent circuit condition has been detected

**After correcting the condition, cycle the key switch

Open: An open circuit condition has been detected

On-Off-On, start the engine, then cycle the key switch

Off-On.

Troubleshooting

Problem: Spark absent or weak

Condition	Remedy
1. Ignition coil defective 2. Spark plug(s) defective 3. CKP sensor defective 4. ECM defective	1. Replace ignition coil 2. Replace plug(s) 3. Replace CKP sensor 4. Replace ECM

Problem: Spark plug fouled with carbon	
Condition	Remedy
<ol style="list-style-type: none"> Gasoline incorrect Air cleaner element dirty Spark plug(s) incorrect (too cold) Valve seals cracked - missing Oil rings worn - broken 	<ol style="list-style-type: none"> Change to correct gasoline Clean element Replace plug(s) Replace seals Replace rings
Problem: Spark plug electrodes overheat or burn	
Condition	Remedy
<ol style="list-style-type: none"> Spark plug(s) incorrect (too hot) Engine overheats Spark plug(s) loose 	<ol style="list-style-type: none"> Replace plug(s) Service cooling system Tighten plug(s)
Problem: Battery does not charge	
Condition	Remedy
<ol style="list-style-type: none"> Lead wires/connections shorted - loose - open Stator coils shorted - grounded - open Regulator/rectifier shorted 	<ol style="list-style-type: none"> Repair - replace - tighten lead wires Replace stator coils Replace regulator/rectifier
Problem: Battery charges, but charging rate is below the specification	
Condition	Remedy
<ol style="list-style-type: none"> Lead wires shorted - open - loose (at terminals) Stator coils grounded - open Regulator/rectifier defective Electrolyte low Cell plates (battery) defective 	<ol style="list-style-type: none"> Repair - tighten lead wires Replace stator coils Replace regulator/rectifier Add distilled water Replace battery
Problem: Magneto overcharges	
Condition	Remedy
<ol style="list-style-type: none"> Internal battery short circuited Regulator/rectifier defective Regulator/rectifier poorly grounded 	<ol style="list-style-type: none"> Replace battery Replace regulator/rectifier Clean - tighten ground connection
Problem: Charging unstable	
Condition	Remedy
<ol style="list-style-type: none"> Lead wire intermittently shorting Magneto internally shorted Regulator/rectifier defective 	<ol style="list-style-type: none"> Replace lead wire Replace stator coil Replace regulator/rectifier
Problem: Starter does not engage	
Condition	Remedy
<ol style="list-style-type: none"> Battery charge low Switch contacts defective Starter motor brushes not seating Starter relay defective Emergency stop - ignition switch off Wiring connections loose - disconnected Start-in-gear/neutral relay defective 	<ol style="list-style-type: none"> Recharge - replace battery Replace switch Replace starter Replace relay Turn on switches Connect - tighten - repair connections Replace relay
Problem: Battery "sulfation" (Acidic white powdery substance or spots on surfaces of cell plates)	
Condition	Remedy
<ol style="list-style-type: none"> Charging rate too low - too high Battery electrolyte insufficient Specific gravity too low Battery discharged Electrolyte contaminated 	<ol style="list-style-type: none"> Replace battery Keep electrolyte to prescribed level Charge battery - add distilled water Charge battery Replace battery
Problem: Battery discharges too rapidly	
Condition	Remedy
<ol style="list-style-type: none"> Electrolyte contaminated Specific gravity low Charging system (charging operation) not set properly Cell plates overcharged - damaged Battery short-circuited Electrical load too high 	<ol style="list-style-type: none"> Replace battery Charge battery - add distilled water Check AC generator - regulator/rectifier - circuit connections Replace battery - correct charging system Replace battery Reduce load
Problem: Battery polarity reversed	
Condition	Remedy
<ol style="list-style-type: none"> Battery incorrectly connected 	<ol style="list-style-type: none"> Reverse connections - replace battery

Drive System

GENERAL INFORMATION

All gear cases are identified by a sticker. This tag is marked with a production date code, sequence code, and a ratio code.

The die-cast aluminum housings have been assembled with thread-rolling screws (trilobular). When assembling with these screws, start the screws carefully into the housing; then use the following torque values.

Size	New Housing	Reassembled Housing
M6 (Torx T-30 Recess)	9 ft-lb	8 ft-lb
M8 (Torx T-40 Recess)	28 ft-lb	23 ft-lb

■NOTE: Never reuse a lock nut. Once a lock nut has been removed, it must be replaced with a new lock nut.

SPECIAL TOOLS

A number of special tools must be available to the technician when performing service procedures in this section. Refer to the current Special Tools Catalog for the appropriate tool description.

Description	p/n
Backlash Measuring Tool (24-Spline Axle)	0544-010
Backlash Measuring Tool (27-Spline Axle)	0544-011
CV Boot Clamp Tool	0444-120
Internal Hex Socket	0444-104
Pinion Gear/Shaft Removal Tool	0444-127
Gear Case Seal Installer Tool	0444-224
U-Joint Separator Tool	0444-128

■NOTE: Special tools are available from the Arctic Cat Service Department.

Front Drive Actuator


■NOTE: The actuator is not a serviceable component. If it is defective, it must be replaced.

■NOTE: The actuator will operate only when the ignition switch is in the ON position.

On the 550/700, the front drive actuator is located on the right side of the front drive input housing. On the 1000, the front drive actuator is located on the left side of the front drive input housing. With the engine stopped and the ignition switch in the ON position, a momentary "whirring" sound can be heard each time the front drive select switch is shifted. If no sound is heard, see the Electrical System section. If the actuator runs constantly or makes squealing or grinding sounds, the actuator must be replaced.


REMOVING

1. Select LOCK on the drive select switch; then disconnect the connector on the actuator harness.
2. Using a T-30 torx wrench, remove the mounting cap screw from the driveshaft side of the actuator.




PR189A

3. Remove the mounting cap screw from above the actuator on the suspension side.



PR190A

4. Loosen but do not remove the mounting cap screw at the front of the actuator; then slide the actuator to the rear enough to clear the slotted mounting tab and the selector shaft. Remove from the right side.




AG928

INSTALLING

1. Lubricate the O-rings on the actuator; then ensure all mounting surfaces are clean and free of debris.
2. Align the actuator with the selector shaft and slide it forward onto the shaft taking care to engage the cap screw in the slot of the front mounting tab.

■**NOTE:** Make sure to properly align the differential lock actuator lever with the hole in the differential lock plunger.




GC002A

3. While holding the actuator firmly forward, tighten the front cap screw to hold the actuator in place; then install but do not tighten the two remaining cap screws.



GC001

4. Loosen the front cap screw; then tighten the cap screw on the driveshaft side.



AG926

■**NOTE:** It is important to tighten this cap screw while the others are loose to ensure proper seating of the actuator.

5. Tighten the remaining cap screws; then connect the electrical plug to the main harness.
6. Turn the ignition switch to the ON position and check the operation by shifting the drive select switch several times.

7. Secure the wiring harness to the frame with a nylon cable tie; then install the inner fender panel.

Front Differential

REMOVING


1. Remove the belly panel; then place the vehicle on jack stands adjusted high enough to allow working from the underside of the vehicle.

■**NOTE:** The jack stands should be placed under the main frame to avoid contact with front suspension components.

WARNING

Make sure the vehicle is solidly supported on the jack stands to avoid injury.

2. Remove the drain plug and drain the gear lubricant into a drain pan; then install the plug and tighten to 45 in.-lb.




PR022A

3. Remove the front wheels.
4. Turn the ignition switch to the ON position and select LOCK on the drive select switch.
5. Remove the cotter pin securing the axle nut; then remove the nut.


■**NOTE:** It is not necessary to remove the brake hoses from the calipers for this procedure.

6. Remove the two brake calipers. Account for the four cap screws; then remove the hubs.



PR264A

7. Disconnect the front drive actuator connector from the main harness.



PR191

8. Remove the lower and upper ball joint cap screws taking care not to strip the threads on the ball joint shaft; then using a rubber mallet, tap the end of the axle and free it from the knuckle assembly.



PR193

9. Pull the steering knuckle away from the axle.




PR222

10. Support the axle to not allow it to drop or hang.

CAUTION


The axle must be supported. If the axle is allowed to drop or hang, damage to the inner CV joint may occur.

11. Remove the lower shock cap screws. Account for the lock nuts; then move the shocks and upper A-arm up and secure them with a strap.



PR200

12. On the 1000, scribe match marks on the front input drive flange and the front drive yoke flange; then remove the cap screws securing the yoke and flange. Separate the flanges but do not remove the drive-shaft.



PR198A


13. Push the axle shaft toward the differential to release the "plunge" coupler; then remove the axle from the differential. Repeat for the opposite side.

■**NOTE: Keeping the axle level will aid in removal.**



PR729C

14. Remove the lower differential mounting cap screw. Account for a lock nut and four washers. Note the position of the washers for assembling.



PR205A

15. Remove the upper differential mounting cap screw. Account for a lock nut and two washers.



CD016

16. Free the differential assembly from the frame mountings; then lower the differential through the frame.

Disassembling Input Shaft

1. Using a T-40 torx wrench, remove the cap screws securing the pinion housing.




GC004A

2. Using a rubber mallet, remove the housing. Account for a gasket. Remove the fork, collar, and spring. Note the location of all the components for assembling purposes.



GC015




CD106

3. Remove the snap rings from the input shaft; then remove the input shaft from the pinion housing.



GC009A

4. Using a seal removal tool, remove the input shaft seal. Account for a spacer.



GC010

5. Remove the snap ring securing the input shaft bearing; then place the pinion housing in a press and remove the bearing.



GC012

Assembling Input Shaft

1. Place the pinion housing in a press and install the input shaft bearing. Secure the bearing with the existing snap ring making sure the sharp edge of the snap ring faces to the outside.



GC012



GC011

2. Install the input shaft seal making sure it is fully seated in the edge of the housing.



GC014

3. Lubricate the input shaft with High-Performance #2 Molybdenum Disulphide Grease packing the boot ribs and splines; then assemble allowing excess grease to freely escape. Slight pressure on the boot will be present during assembly. Secure with new clamps.

■**NOTE:** Any time drive splines are separated, clean all splines with parts-cleaning solvent and dry with compressed air; then lubricate with recommended grease.



KX219


4. Install the input shaft into the pinion housing; then secure in the bearing with a circlip.



GC009A

5. Place the pinion housing with new gasket onto the differential housing; then secure with existing cap screws. Tighten to 23 ft-lb.

■NOTE: If a new differential housing is being installed, tighten the cap screws to 28 ft-lb.



KX209



GZ004A

Disassembling Differential Assembly

■NOTE: This procedure can be performed on a rear gear case.

1. Using a T-40 torx wrench, remove the cap screws securing the pinion housing. Account for the coupler, fork, and spring (differential only).



GC015


2. Using a T-40 torx wrench, remove the cap screws securing the differential cover. Make note of the part number.
3. Using a plastic mallet, tap lightly to remove the differential cover. Account for an O-ring.



KX174


■NOTE: If the cover is difficult to remove, pry on the cover in more than one recessed location.

4. Remove the splined coupler, shifter fork, pin, and spring of the differential lock assembly and set aside. Note position of parts for assembling purposes.




KX175

5. Remove the left differential bearing flange assembly and account for a shim. Mark the shim as left-side.




6. Place the differential with the open side down; then lift the housing off the spider assembly. Account for shim(s) and mark as right-side.




Disassembling Pinion Gear


1. Remove the internal snap ring securing the pinion bearing in the housing.



2. Using the Pinion Gear/Shaft Removal Tool and a hammer, remove the pinion gear from the gear case housing.




3. Secure the pinion gear in a bearing puller; then remove the pinion bearing using a press. Account for a collar and a bearing.




4. Remove any reusable parts from the gear case housing; then discard the housing and lock collar.

Assembling Pinion Gear


1. Install the bearing onto the pinion shaft. Install the pinion shaft collar.



CC882




WC429



CC883

2. Place the pinion assembly in a bearing puller; then install the bearing using a press.



CC884

3. Coat a new needle bearing and the bearing pocket of a new gear case/differential housing with red Loctite #271; then using a suitable driver, install the bearing lightly seated against the bearing seats. Do not push the bearing too far into the pocket.

Shimming Procedure/Shim Selection

Case-Side Shims (Backlash)		
p/n	mm	in.
0402-405	1.3	0.051
0402-406	1.4	0.055
0402-407	1.5	0.059
0402-408	1.6	0.063
0402-409	1.7	0.067

Cover-Side Shims (Ring Gear End-Play)		
p/n	mm	in.
1402-074	1.3	0.051
1402-075	1.4	0.055
1402-076	1.5	0.059
1402-077	1.6	0.063
1402-078	1.7	0.067

It is very important to adjust bevel gears for the proper running tolerances. Gear life and gear noise are greatly affected by these tolerances; therefore, it is very important to properly adjust any gear set prior to final assembly.

The following procedure can be used on both front differential or rear drive gear case.

■NOTE: All bearings must be installed in the gear case and the pinion properly installed before proceeding.

Backlash

■NOTE: Always set backlash prior to any other shimming.

1. Install the existing shim or a 0.051-0.055-in. shim on the gear case side of the ring gear assembly.



GC031A

2. Install the ring gear with shim in the gear case; then while holding the pinion stationary, rock the ring gear forward and back to determine if any backlash exists. If no backlash exists, install a thicker shim and recheck.




GC033A

4. Install the existing shim or a 0.063 in. shim on the cover side of the ring gear; then place the assembled gear case cover onto the gear case and secure with three cap screws. Tighten evenly using a crisscross pattern.




GC036A

3. Install the bearing flange onto the gear case cover making sure the alignment/locating pin engages the locating hole in the cover; then make sure the bearing flange is completely seated in the cover.



GC036B


5. Place the appropriate Backlash Measuring Tool into the splines of the ring gear and install a dial indicator making sure it contacts the gauge at a 90° angle and on the index mark.



GC032A



GC040



GC039A

- Zero the dial indicator; then while holding the pinion stationary, rock the ring gear assembly forward and back and record the backlash. Backlash must be 0.011-0.015 in. If backlash is within specifications, proceed to Ring Gear End-Play. If backlash is not within specifications, increase shim thickness to increase backlash or decrease shim thickness to decrease backlash.

■NOTE: Higher backlash settings usually result in quieter gear operation.

- Zero the dial indicator; then push the ring gear toward the dial indicator and release. End-play should be 0.004-0.008 in.
- To increase end-play, decrease the shim thickness. To decrease end-play, increase the shim thickness.

■NOTE: Once proper backlash and end play are established, the gear case can be assembled (see Assembling Differential Assembly in this sub-section).



CC888

RING GEAR/THRUST BUTTON

Removing

Remove the thrust button from the gear case cover (left-hand threads). Account for a shim.

Inspecting

- Inspect the ring gear for excessive wear or discoloration.
- Inspect the thrust button for excessive wear or discoloration.
- Inspect the bearings for discoloration, roughness, or excessive wear.

Installing/Shimming

■NOTE: Ring gear end-play must be adjusted prior to selecting shim for the thrust button.

- Install the thrust button with shim into the gear case cover and tighten securely (left-hand threads).




GC037A

Ring Gear End-Play

After correcting backlash, ring gear end-play can be adjusted. To adjust end-play, use the following procedure.

- Secure the gear case in a holding fixture with the cover side up; then install a dial indicator contacting the ring gear axle flange.



GC035




Thrust Button



Shim

GC057A

2. Place the ring gear with selected shim into the cover and measure the ring gear to thrust button clearance with a thickness gauge. Clearance should be 0.002-0.004 in.



0.002-0.004 in.

GC058A

3. If clearance is as specified, remove the ring gear and thrust button; then place a drop of red Loctite #271 on the threads and tighten to 8 ft-lb (left-hand threads).
4. If clearance is not as specified, repeat steps 1 and 2 using thicker (clearance too great) or thinner (clearance too small) until correct specification is reached.

Assembling Differential Assembly

1. With the pinion gear and new bearings installed, place the selected (backlash) shim on the gear case side of the ring gear with the chamfered side toward the ring gear; then install into gear case/differential housing.




GC031A



GC020


2. Place the selected (end-play) shim, chamfered side toward the gear, onto the cover side of the ring gear.




GC036B

■**NOTE: The spider and ring gear assembly must be replaced as a complete unit.**

3. Assemble the fork and sliding collar into the cover assembly; then install the left bearing flange/bearing assembly and seat firmly into the cover.



CF266A



CF267A

4. Apply a liberal coat of grease to the O-ring; then install it on the assembled cover assembly making sure to seat the O-ring completely down around the circumference of the bearing flange.




CF275A

5. Making sure the O-ring is properly positioned on the differential housing cover assembly, install the cover with existing cap screws (coated with green Loctite #270). Account for the ID tag. Tighten the cap screws evenly to 23 ft-lb.

■NOTE: Grease can be applied to the O-ring for ease of assembling.


■NOTE: If a new housing is being installed, tighten the cap screws to 28 ft-lb.

6. Install the shift fork shaft w/spring into the housing making sure the shaft O-ring is positioned to the inside.



CC892


7. Install the shift fork assembly making sure the fork leg is facing upward. Apply a small amount of oil to the gasket; then install the gasket.



CC893

8. Place the input shaft assembly onto the gear case housing; then secure with the existing cap screws. Tighten to 23 ft-lb.

■NOTE: If a new housing is being installed, tighten the cap screws to 28 ft-lb.



CD103




CD110

Removing/Installing Axle Seal

■NOTE: This procedure can be performed on a rear gear case.


1. Remove the seal using a seal removal tool.




CC899

■NOTE: Prior to installing the seal, apply High-Performance #2 Molybdenum Disulphide grease to the seal outside diameter.

2. Using Gear Case Seal Installer Tool, evenly press the seal into the cover bore until properly seated.



CF278



PR198A


CAUTION

Make sure the tool is free of nicks or sharp edges or damage to the seal may occur.

3. Repeat steps 1-2 for the opposite side.

INSTALLING DIFFERENTIAL

1. Place the differential assembly into position in the frame; then install the top mounting cap screw, two washers, and lock nut. Do not tighten at this time.
2. Install the lower differential mounting cap screw, washers, and lock nut. Note the correct location for the washers.




PR205A

3. Tighten the nuts to 38 ft-lb.
4. Pour 275 ml (9.3 fl oz) of SAE 80W-90 hypoid lubricant into the differential and install the fill plug. Tighten to 16 ft-lb.
5. Align the scribed match marks on the front input drive flange and the front drive yoke flange; then secure with the cap screws tightened to 20 ft-lb.




PR729C

6. Push the axle shaft into the CV coupler to release the locking ring while pulling back on the CV coupler and slide the drive axle into place.




PR201




PR193

8. Secure the lower shock eyelets with cap screws and lock nuts. Tighten to 35 ft-lb.




AF897D

9. Install the brake calipers. Secure with new "patch-lock" cap screws tightened to 20 ft-lb.



PR264A

10. Connect the front drive actuator connector to the main harness; then secure the wires to the frame with nylon ties.
11. Apply a light coat of multi-purpose grease to the hub splines; then install the hubs and nuts. Tighten to 200 ft-lb; then install new cotter pins.



PR256

12. Install the wheels and using a crisscross pattern, tighten the wheel nuts in 20 ft-lb increments to a final torque of 40 ft-lb (steel wheel), 60 ft-lb (aluminium wheel w/black nuts), or 80 ft-lb (aluminum wheel w/chrome nuts).
13. Remove the vehicle from the support stand.
14. Install the belly panel.

Drive Axles


REMOVING REAR DRIVE AXLE

1. Secure the vehicle on a support stand to elevate the wheels; then remove the wheels.

⚠ WARNING

Make sure the vehicle is solidly supported on the support stand to avoid injury.

2. Turn the ignition switch to the ON position, select LOCK on the drive select switch. Turn the ignition switch to the OFF position.
3. Remove the cotter pins securing the axle nuts; then remove the nuts.




KX041

4. Remove the brake caliper. Account for the cap screws; then slide the hub out of the knuckle and set aside.



PR221

5. Remove the cap screw and lock nut securing the knuckle to the upper A-arm. Discard the lock nut.



PR220A

6. While holding the drive axle stationary, pull the top of the knuckle out and down until it is free of the drive axle.



PR218

7. Place a drain pan under the vehicle to contain any oil leakage; then pushing the axle shaft in, pull the axle assembly from the gear case.



PR729C

REMOVING FRONT DRIVE AXLE

■NOTE: For removing a front drive axle, see Front Differential in this section.

CLEANING AND INSPECTING AXLES

■NOTE: Always clean and inspect the drive axle components to determine if any service or replacement is necessary.

1. Using a clean towel, wipe away any oil or grease from the axle components.



CD019

2. Inspect boots for any tears, cracks, or deterioration.

■NOTE: If a boot is damaged in any way, it must be replaced with a boot kit.

DISASSEMBLING AXLES

■NOTE: Only the boots are serviceable on the axles; if any other component is worn or damaged, the axle must be replaced.

1. Using CV Boot Clamp Tool, remove and retain both clamps for assembly purposes.




CF337

2. Place the white-striped end of the CV joint into a vise.



CF335

3. To disengage the axle from the CV joint, sharply pull back on the axle; then slide the boot off of the axle.



CF334


■NOTE: Steps 1-3 can be used to replace the outboard boot.

ASSEMBLING AXLES

1. Install the inner boot with the small clamp making sure the ends of the clamp are positioned correctly.

■NOTE: The boot is positioned correctly when the small end of the boot seats down into the recessed groove.

2. Using the boot clamp tool, secure the small clamp of the inner boot.



ATV-1048

3. Apply 80 grams (2/3 of contents) of grease from the pack into the bearing housing.

■NOTE: Steps 1-3 can be used to replace the outboard boot.

■NOTE: In the outboard boot, use the final 40 grams (1/3 of contents) of grease from the pack in the bearing housing.

INSTALLING REAR DRIVE AXLE


1. Push the axle shaft into the CV coupler to release the lock ring while pulling back on the CV coupler and slide the drive axle into place in the gear case.



PR729C

■NOTE: To ensure proper axle seating, give it a light pull; the axle should remain “clipped” in place.

2. Swing the knuckle up and onto the drive axle; then place the knuckle into place in the upper A-arm. Secure the knuckle to the A-arm with a cap screw and a new lock nut. Tighten to 35 ft-lb.
3. Place the hub into position on the axle followed by a hex nut. Tighten the hex nut finger-tight at this time.
4. Tighten the hub hex nut (from step 3) to 200 ft-lb. If necessary, tighten the hub hex nut clockwise to align the hole for the cotter pin; then install and spread a new cotter pin making sure each side of the pin is flush to the hub nut.




CD027

5. Install the brake calipers. Secure with new “patch-lock” cap screws tightened to 20 ft-lb.
6. Install the wheels and using a crisscross pattern, tighten the wheel nuts in 20 ft-lb increments to a final torque of 40 ft-lb (steel wheel), 60 ft-lb (aluminium wheel w/black nuts), or 80 ft-lb (aluminum wheel w/chrome nuts).
7. Remove the vehicle from the support stand.


INSTALLING FRONT DRIVE AXLE

1. Push the axle shaft into the CV coupler to release the lock ring; then position the drive axle in the gear case and steering knuckle; then insert the ball joints into the steering knuckles. Secure with cap screws tightened to 35 ft-lb.
2. Secure the lower shock eyelet to the A-arm with a cap screw and a new lock nut. Tighten to 35 ft-lb.
3. Slide the hub w/brake disc into position in the steering knuckle followed by an axle nut. Finger-tighten at this time.
4. Install the brake caliper on the steering knuckle using new "patch-lock" cap screws. Tighten to 20 ft-lb.
5. Tighten the axle nut to 200 ft-lb; then install and spread a new cotter pin making sure each side of the pin is flush to the hub nut. If necessary, turn the axle nut clockwise to align the cotter pin after tightening to 200 ft-lb.



CD027

6. Install the wheels and using a crisscross pattern, tighten the wheel nuts in 20 ft-lb increments to a final torque of 40 ft-lb (steel wheel), 60 ft-lb (aluminium wheel w/black nuts), or 80 ft-lb (aluminum wheel w/chrome nuts).
7. Remove the vehicle from the support stand.
8. Check the front differential lubricant level and add lubricant as necessary.




PR065A

Rear Gear Case

REMOVING

■NOTE: Release the cargo box latch and allow the cargo box to tilt back; then remove the cargo box lift support by removing the cap screw and nut securing the lower lift support to the frame. The cargo box will tilt fully rearward.

1. Drain the lubricant from the rear gear case; then remove both rear drive axles.
2. Remove the boot clamps on the rear driveline boot.
3. Remove the two cap screws and lock nuts securing the rear gear case to the frame; then remove the gear case through the upper left-side of the frame and lift out the top.



PR207

AT THIS POINT

For servicing the input shaft, pinion gear, needle bearing, and axle seal, see Front Differential in this section.

RING GEAR/THRUST BUTTON

Removing

1. Remove the cap screws securing the gear case cover to the gear case; then remove the ring gear.
2. Remove the thrust button from the gear case cover (left-hand threads). Account for a shim.

Inspecting


1. Inspect the ring gear for excessive wear, missing or chipped teeth, or discoloration.
2. Inspect the thrust button for excessive wear or discoloration.
3. Inspect the bearings for discoloration, roughness, or excessive wear.

■NOTE: For servicing bearings or seals, see Front Differential in this section.

Installing/Shimming

■NOTE: Ring gear clearance must be adjusted prior to selecting shim for the thrust button.

1. Install the thrust button with shim into the gear case cover and tighten securely (left-hand threads).



2. Place the ring gear with selected shim into the cover and measure the ring gear to thrust button clearance with a thickness gauge. Clearance should be 0.002-0.004 in.



3. If clearance is as specified, remove the ring gear and thrust button; then place a drop of red Loctite #271 on the threads and tighten to 8 ft-lb (left-hand threads).
4. If clearance is not as specified, repeat steps 1 and 2 using thicker (clearance too great) or thinner (clearance too small) until correct specification is reached.



REAR DRIVE INPUT SHAFT/ HOUSING

Removing/Disassembling

1. Remove the cap screws securing the rear drive input shaft/housing to the rear gear case; then remove the input housing assembly.




2. On the 1000 model, remove the clutch pack from the clutch basket; then remove the snap ring securing the clutch basket (A) to the input shaft (B) and remove the clutch basket.




3. Remove the input shaft from the input housing; then remove the oil seal.



GZ180



GZ178A



GZ182A

4. Remove the snap ring retaining the input bearing and using an appropriate bearing driver, press the bearing from the housing.



GZ184A

Cleaning and Inspecting

1. Wash all parts in parts cleaning solvent and dry with compressed air.

WARNING

Always wear safety glasses when working with compressed air.

2. Clean all gasket material and sealant from mating surfaces.
3. Inspect bearings, shafts, and housing for excessive wear, cracks, or discoloration.
4. Inspect the clutch basket (1000) for wear in splines or cracks in the housing.

5. Inspect the clutch pack (1000) for signs of discoloration.

■NOTE: The clutch pack is not a serviceable component. If worn, discolored, or damaged in any way, it must be replaced.


Assembling/Installing

1. Install a new bearing into the input housing and secure with the snap ring (flat side directed away from bearing).




GZ184

2. Using a suitable seal driver, install a new oil seal into the front of the input housing until the seal is flush with the housing.




GZ182A

3. Apply grease to the lips of the oil seal; then install the input shaft into the input bearing and housing.



4. Install the clutch basket (1000) onto the input shaft and secure with the snap ring (flat side directed outward); then install the clutch pack into the basket.



5. Using a new gasket, install the assembled rear drive input shaft/housing onto the rear drive gear case and secure with the three cap screws. Tighten to 23 ft-lb.

AT THIS POINT

For servicing the input shaft, pinion gear, needle bearing, and axle seal, see Front Differential in this section.

INSTALLING

1. Slide the gear case into position down through the upper-left side of the frame; then align the driveline splines to the differential input coupler and engage the driveshaft and differential.
2. Pack the driveline boot with the appropriate grease; then secure with the boot clamps using CV Boot Clamp Tool.
3. Secure the differential to the frame with two through-bolts and secure with lock nuts and flat washers. Tighten to 38 ft-lb.
4. Install the rear drive axles (see Drive Axles in this section).
5. Install the brake caliper and tighten the new “patch-lock” cap screws to 20 ft-lb.
6. Fill the gear case with the appropriate lubricant.

Hub

REMOVING

1. Secure the vehicle on a support stand to elevate the wheel; then remove the wheel.


■NOTE: Removing or tightening of the hub nuts requires the axles be locked. To lock the rear axle, place the vehicle in park. To lock the front axle, turn the ignition switch to ON, select LOCK on the drive select switch; then place the vehicle in park and turn the ignition switch to OFF.

WARNING

Make sure the vehicle is solidly supported on the support stand to avoid injury.


2. Remove the cotter pin from the axle.

■NOTE: During assembly, new cotter pins should be installed.



3. Remove the hub nut securing the hub.


4. Remove the brake caliper.



5. Remove the hub assembly.

6. Remove the four cap screws securing the brake disc.

■NOTE: Applying heat to the head of each cap screw will aid in removal.



PR254A


■**NOTE:** Heating the head of each cap screw with a torch will aid in the removal.

CLEANING AND INSPECTING

1. Clean all hub components.
2. Inspect all threads for stripping or damage.
3. Inspect the brake disc (if applicable) for cracks or warping.
4. Inspect the hub for pits, cracks, loose studs, or spline wear.


REPLACING WHEEL STUDS

1. Secure the hub in a suitable holding fixture and remove the brake disc (if applicable).
2. Drive the damaged stud out of the hub; then place the new stud into the hub and thread on an appropriate flange nut.



PR250


3. Using a socket and ratchet handle, tighten the nut until the stud is fully drawn into the hub.



PR252A

INSTALLING

1. Secure the brake disc (if applicable) to the hub with the four cap screws coated with red Loctite #271. Tighten to 15 ft-lb.
2. Apply grease to the splines in the hub.



PR254B


3. Install the hub assembly onto the axle.



PR221


4. Secure the hub assembly with the nut. Tighten to 200 ft-lb; then secure with a new cotter pin.

■**NOTE:** If the cotter pin can not be inserted due to misalignment of the hole in the axle and the slots in the nut, tighten the nut until properly aligned.



PR258

5. For front hubs, secure the brake calipers to the knuckle with two new "patch-lock" cap screws tightened to 20 ft-lb.



PR377B

6. Install the wheels and using a crisscross pattern, tighten the wheel nuts in 20 ft-lb increments to a final torque of 40 ft-lb (steel wheel), 60 ft-lb (aluminium wheel w/black nuts), or 80 ft-lb (aluminum wheel w/chrome nuts).

7. Remove the vehicle from the support stand.

Hydraulic Brake Caliper

⚠ WARNING

Arctic Cat recommends only authorized Arctic Cat ROV dealers perform hydraulic brake service. Failure to properly repair brake systems can result in loss of control causing severe injury or death.

REMOVING/DISASSEMBLING

1. Secure the vehicle on a support stand to elevate the wheel; then remove the wheel.

⚠ WARNING

Make sure the vehicle is solidly supported on the support stand to avoid injury.

⚠ WARNING

Never let brake fluid contact the eyes. Damage to the eyes will occur. Always wear appropriate protective safety goggles and latex gloves when handling brake fluid.

2. Drain the brake fluid from the caliper, hose, and master cylinder through the bleed screw by pumping the brake pedal.



PR235

CAUTION

Brake fluid is highly corrosive. Do not spill brake fluid on any surface of the vehicle and do not reuse brake fluid.

■NOTE: Whenever brake components are removed, disassembled, or repaired where brake fluid is exposed to air, drain all fluid and replace with new DOT 4 brake fluid from an unopened container. Brake fluid readily absorbs moisture from the air significantly lowering the boiling point. This increases the chance of vapor lock reducing braking power and increasing stopping distance.

3. Remove the brake hose from the caliper and close the bleed screw; then remove the caliper.
4. Compress the caliper holder against the caliper (opposite the O-ring side) and remove the outer brake pad; then remove the inner brake pad.

■NOTE: If brake pads are to be returned to service, do not allow brake fluid to contaminate them.




PR237A



PR238

5. Remove the caliper holder from the caliper and discard the O-ring.



PR239B

■**NOTE:** The O-ring is used for shipping purposes and provides no function in operation.

6. Cover the piston end of the housing with a shop towel; then keeping fingers clear of piston travel, apply compressed air to the fluid port to blow the piston free of the housing. Account for two seal rings in the housing.



PR713A



PR715

⚠ **WARNING**

Make sure to hold the towel firmly in place or the piston could be ejected from the housing causing injury.

7. Using an appropriate seal removal tool, carefully remove the seals from the brake caliper housing; then remove four O-rings from the brake caliper housing noting the location of the different sized O-rings. Discard all seals, O-rings, and crush washers.

CLEANING AND INSPECTING

1. Clean all caliper components (except the brake pads) with DOT 4 brake fluid. Do not wipe dry.
2. Inspect the brake pads for damage and excessive wear.
- NOTE: For measuring brake pads, see the Periodic Maintenance section.**
3. Inspect the brake caliper housings for scoring in the piston bores, chipped seal ring grooves, or signs of corrosion or discoloration.
4. Inspect the piston surface for scoring, discoloration, or evidence of binding or galling.
5. Inspect the caliper holder for wear or bending.

ASSEMBLING/INSTALLING


1. Install new seals into the brake caliper housing and apply a liberal amount of DOT 4 brake fluid to the cylinder bore of the housing, seals, and brake piston.

CAUTION

Make sure the seals are properly in place and did not twist or roll during installation.



PR715



PR717A

2. Press the piston into the caliper housing using hand pressure only. Completely seat the piston; then wipe off any excessive brake fluid.




PR711A



PR712


3. Apply high-temperature silicone grease (supplied with the O-ring kit) to the inside of the caliper holder bores and O-rings; then install the four O-rings into the caliper.



PR719C

4. Install the caliper onto the caliper holder making sure the caliper and holder are correctly oriented.

■NOTE: It is very important to apply silicone grease to the O-rings and caliper bores prior to assembly.



PR239C

5. Making sure brake fluid does not contact the brake pads, compress the caliper holder toward the caliper and install the inner brake pad; then install the outer pad.

CAUTION

If brake pads become contaminated with brake fluid, they must be thoroughly cleaned with brake cleaning solvent or replaced with new pads. Failure to do so will result in reduced braking and premature brake pad failure.



PR238



PR239

6. Place the brake caliper assembly into position and secure with new "patch-lock" cap screws. Tighten the caliper to 20 ft-lb.

7. Place a new crush washer on each side of the brake hose fitting and install it on the caliper. Tighten to 20 ft-lb.
8. Fill the reservoir; then bleed the brake system (see Periodic Maintenance - Hydraulic Brake System).

WARNING

Never use brake fluid from an open container or reuse brake fluid. Moisture-contaminated brake fluid could cause vapor build-up (expansion) during hard braking resulting in greatly increased stopping distance or loss of control leading to injury or death.

9. Install the wheels and using a crisscross pattern, tighten the wheel nuts in 20 ft-lb increments to a final torque of 40 ft-lb (steel wheel), 60 ft-lb (aluminium wheel w/black nuts), or 80 ft-lb (aluminum wheel w/chrome nuts).
10. Remove the vehicle from the support stand and verify brake operation.

MASTER CYLINDER ASSEMBLY


■NOTE: The master cylinder is a non-serviceable component; it must be replaced as an assembly.

Removing

1. Slide a piece of flexible tubing over one of the wheel bleeder valves and direct the other end into a container. Remove the reservoir cover; then open the bleeder valve. Allow the brake fluid to drain until the reservoir is empty.



2. Remove the banjo bolt and brake switch securing the banjo-fittings to the master cylinder.



3. Remove the cotter pin and pivot pin from the yoke; then remove two cap screws and flange nuts securing the master cylinder assembly to the frame.



4. Remove the master cylinder. Discard the three crush washers.

CAUTION

Brake fluid is highly corrosive. Do not spill brake fluid on any surface of the vehicle.

Inspecting

1. Inspect the master cylinder push rod and clevis for wear, bending, or elongation of clevis holes.
2. Inspect the push rod boot for tears or deterioration.
3. Inspect the reservoir for cracks and leakage.
4. Inspect the brake hose for cracks and deterioration and the condition of the banjo-fittings.

Installing


1. Secure the master cylinder assembly to the frame with two cap screws and two flange nuts. Tighten to 25 ft-lb.
2. Using new crush washers, secure the banjo-fittings to the master cylinder with a new banjo bolt and the existing brake switch. Tighten to 20 ft-lb.
3. Install the pivot pin and secure with a new cotter pin.
4. Fill the master cylinder and bleed the brake system (see Hydraulic Brake System in the Periodic Maintenance section).

Universal Joints (1000)



REMOVING - FRONT

■NOTE: The front universal joints can be accessed by removing the belly panel. To remove the belly panel, see Belly Panel in the Steering/Frame/Controls section.


1. Support the vehicle on suitable jack stands elevated high enough to allow working from the underside of the vehicle.
2. To aid in installing, match mark drive-line components prior to removing.



3. Remove the cap screws securing the propeller shaft flange to the yoke flange on the appropriate drive-line; then remove the propeller shaft.




4. Install U-Joint Separator Tool on the universal joint fixed yoke; then remove the bearing cup retainers.



5. Using a suitable socket and ratchet handle, rotate the jackscrew to push the bearing cup out of the yoke; then remove the tool and the bearing cup.



6. Install the separator tool on the opposite side of the yoke to push the second bearing cup from the yoke; then remove the tool and separate the universal joint.
7. Secure the separator tool in a vise and repeat steps 4-6 to remove the bearing cups from the movable yoke.




REMOVING - REAR

1. Lift the rear of the vehicle and support it with suitable jack stands.
2. Remove the driver's side rear tire.
3. To aid in installing, match mark drive-line components prior to removing the cap screws.



PR152A

4. Remove the cap screws securing the yoke flange to the output joint flange.
5. Slide the driveshaft back toward the rear gear case and pivot the yoke flange away from the output joint flange.



PR939

6. Remove the rear driveshaft assembly from the vehicle.
7. Repeat steps 4-6 in the prior section (Removing – Front) to disassemble the universal joints.


INSPECTING

1. Inspect the yoke bores for damage or signs of bearing cup looseness. If bearing cups are loose, the yoke must be replaced.



PR367B

2. Check that yoke legs are parallel.



PR367A

3. Check splines and flanges for excessive wear, thread damage, or warpage.



PR367C

INSTALLING - FRONT

1. Remove the bearing cups from the universal joint; then insert the joint into the yoke and install one bearing cup on the joint.

CAUTION

Care must be taken when installing bearing cups that the needle bearings stay in place or severe damage to the universal joint will occur.



PR368

2. Secure U-Joint Separator Tool in a vise; then place the yoke, joint, and bearing cup into position and press the cup into the yoke.




PR374

3. Install the retainer in the bearing cup; then remove the yoke from the separator tool.

■NOTE: Repeat steps 2-3 for the opposite-side bearing cup.

4. Remove the separator tool from the vise and install the universal joint, bearing cups, and movable yoke into the fixed yoke using the same procedure as steps 2-3 except the vise cannot be used.



PR355


5. Check that the universal joint can be flexed freely without binding; then apply multi-purpose grease to the splines and install the propeller shaft noting the match marks made prior to removing.



PR152A

INSTALLING - REAR

1. Slide the driveshaft back toward the rear gear case and pivot the yoke flange into the output joint flange.



PR939

2. Align the match marks then apply blue Loctite to the cap screws and secure the yoke flange to the output joint flange. Tighten to 20 ft-lb.



PR152A

3. Install the wheel and using a crisscross pattern, tighten the wheel nuts in 20 ft-lb increments to a final torque of 40 ft-lb (steel wheel), 60 ft-lb (aluminium wheel w/black nuts), or 80 ft-lb (aluminum wheel w/chrome nuts).

Troubleshooting Drive System

Problem: Power not transmitted from engine to wheels

Condition	Remedy
1. Rear axle shaft serration worn - broken	1. Replace shaft

Problem: Power not transmitted from engine to either front wheel

Condition	Remedy
1. Secondary drive - driven gear teeth broken 2. Propeller shaft serration worn - broken 3. Coupling damaged 4. Coupling joint serration worn - damaged 5. Front drive - driven bevel gears broken - damaged 6. Front differential gears/pinions broken - damaged 7. Front drive actuator not operating	1. Replace gear(s) 2. Replace shaft 3. Replace coupling 4. Replace joint 5. Replace gear(s) 6. Replace gears - pinions 7. Replace fuse - drive select switch - front drive actuator

Troubleshooting Brake System

Problem: Braking poor

Condition	Remedy
1. Pad worn 2. Brake fluid leaking 3. Master cylinder/brake cylinder seal worn	1. Replace pads 2. Repair leak(s) 3. Replace seal(s)

Problem: Brake pedal travel excessive

Condition	Remedy
1. Brake fluid low 2. Piston seal - cup worn	1. Add fluid to proper level 2. Replace seal - cup

Problem: Brake fluid leaking

Condition	Remedy
1. Fittings loose 2. Hose cracked 3. Piston seal worn	1. Tighten fittings 2. Replace hose 3. Replace seal


Problem: Brake pedal spongy

Condition	Remedy
1. Air trapped in hydraulic system 2. Brake fluid low	1. Bleed hydraulic system 2. Add brake fluid and bleed hydraulic brake system

Suspension

The following suspension system components should be inspected periodically to ensure proper operation.

- A. Shock absorber rods bent, pitted, or damaged.
- B. Rubber damper cracked, broken, or missing.
- C. Shock absorber body damaged, punctured, or leaking.
- D. Shock absorber eyelets broken, bent, or cracked.
- E. Shock absorber eyelet bushings worn, deteriorated, cracked, or missing.
- F. Shock absorber spring broken or sagging.
- G. Sway bar mountings tight and bushings secure.



PR913

4. Using a suitable spring compression stand, compress the shock absorber spring, remove the retainer, and remove the spring.

⚠ WARNING

Shock absorber springs are under high compression loads. Do not attempt to remove springs without an adequate spring compressor. Severe injury could result.

Shock Absorbers


REMOVING

1. Secure the vehicle on a support stand to elevate the wheels and to release load on the suspension.

⚠ WARNING

Make sure the vehicle is solidly supported on the support stand to avoid injury.

2. Remove the two cap screws and nuts securing each front shock absorber to the frame and upper A-arm. Account for bushings and sleeves from each.



PR911

CAUTION

Additional support stands are necessary to support the rear axle when the shock absorbers are removed or damage may occur.

3. Remove the two cap screws and nuts securing each rear shock absorber to the frame and lower A-arm. Account for bushings and sleeves from each.



AF730D

CLEANING AND INSPECTING

1. Clean all shock absorber components in parts-cleaning solvent.
2. Inspect each shock rod for nicks, pits, rust, bends, and oily residue.
3. Inspect all springs, spring retainers, shock rods, sleeves, bushings, shock bodies, and eyelets for cracks, leaks, and bends.

INSTALLING

1. Place the shock absorber spring over the shock absorber, compress the spring, and install the retainer.
2. Place bushings and sleeves (where appropriate) into shock eyelet; then install shocks with two cap screws and nuts.
3. Tighten the shock absorber cap screws to 35 ft-lb (front) or 35 ft-lb (rear - 1000) or 20 ft-lb (rear - 550/700).
4. Remove the vehicle from the support stand.

Front A-Arms


REMOVING

1. Secure the vehicle on a support stand to elevate the front wheels; then remove the wheels.


⚠ WARNING

Make sure the vehicle is solidly supported on the support stand to avoid injury.


2. Remove the cotter pin from the nut. Discard the cotter pin.



3. Remove the nut securing the hub.
4. Remove the brake caliper. Account for two cap screws.



5. Remove the hub assembly.
6. Remove the cotter pin and slotted nut securing the tie rod end to the knuckle; then remove the tie rod end from the knuckle.
7. Remove the cap screws securing the ball joints to the knuckle.




PR193

8. Tap the ball joints out of the knuckle; then remove the knuckle.
9. Remove the lower shock absorber eyelet from the upper A-arm.



PR911

10. Remove the cap screws securing the A-arms to the frame.



PR909

11. Remove the snap ring from the ball joint; then remove the ball joint from the A-arm.

CAUTION

Support the knuckle when removing the cap screws or damage to the threads will occur.



PR908

CLEANING AND INSPECTING

1. Clean all A-arm components in parts-cleaning solvent.
2. Clean the ball joint mounting hole of all residual Loctite, grease, oil, or dirt for installing purposes.
3. Inspect the A-arm for bends, cracks, and worn bushings.
4. Inspect the ball joint mounting holes for cracks or damage.
5. Inspect the frame mounts for signs of damage, wear, or weldment damage.

INSTALLING


1. Apply Loctite Primer "T" to the A-arm socket; then apply green Loctite #609 to the entire outside diameter of the ball joint. Install the ball joint into the A-arm and secure with the snap ring.
2. Install the A-arm assemblies into the frame mounts and secure with the cap screws. Only finger-tighten at this time.
3. Route the brake hose through the upper A-arm as shown.



PR908

4. Secure the lower eyelet of the shock absorber to the upper A-arm. Tighten nut to 35 ft-lb.
5. Secure the A-arm assemblies to the frame mounts (from step 2). Tighten the cap screws to 35 ft-lb.
6. Install the knuckle assembly onto the ball joints and secure with cap screws. Tighten to 35 ft-lb.

7. Install the tie rod end and secure with the nut (coated with red Loctite #271). Tighten to 30 ft-lb; then install a new cotter pin and spread the pin to secure the nut.




AF618D

8. Apply grease to the hub and drive axle splines; then install the hub assembly onto the drive axle.



PR290A


9. Secure the hub assembly with the nut. Tighten only until snug.
10. Secure the brake caliper to the knuckle with two new "patch-lock" cap screws. Tighten to 20 ft-lb.



PR377B


11. Secure the hub nut (from step 9) to the shaft/axle. Tighten to 200 ft-lb.
12. Install a new cotter pin and spread the pin to secure the nut.

■NOTE: If the cotter pin cannot be inserted due to misalignment of the hole in the axle and the slots in the nut, tighten the nut until properly aligned.



PR907

13. Install the wheels and using a crisscross pattern, tighten the wheel nuts in 20 ft-lb increments to a final torque of 40 ft-lb (steel wheel), 60 ft-lb (aluminium wheel w/black nuts), or 80 ft-lb (aluminum wheel w/chrome nuts).
14. Remove the vehicle from the support stand.



PR923A

7. Remove the cap screws and lock nuts securing the lower A-arm to the frame and knuckle; then remove the lower A-arm. Follow the same procedure to remove the upper A-arm.

CLEANING AND INSPECTING

1. Clean all A-arm components in parts-cleaning solvent.
2. Inspect the A-arm for bends, cracks, and worn bushings.
3. Inspect the frame mounts for signs of damage, wear, or weldment damage.

INSTALLING

1. Install the A-arm assemblies into the frame mounts and secure with the cap screws and new lock nuts. Finger-tighten only at this time.
2. Slide the knuckle onto the drive axle and into position on the A-arms; then secure the knuckle to the A-arms with cap screws and new lock nuts. Tighten to 35 ft-lb.
3. Tighten the hardware securing the A-arms to the frame mounts (from step 1) to 35 ft-lb.
4. Secure the shock absorber to the frame with a cap screw and new lock nut. Tighten to 35 ft-lb.
5. Secure the shock absorber to the lower A-arm with a cap screw and new lock nut. Tighten to 35 ft-lb (1000) or 20 ft-lb (550/700).
6. Install the sway bar link and tighten to show three full threads.
7. Secure the boot guard to the lower A-arm with the two cap screws. Tighten securely.
8. Install the wheels and using a crisscross pattern, tighten the wheel nuts in 20 ft-lb increments to a final torque of 40 ft-lb (steel wheel), 60 ft-lb (aluminium wheel w/black nuts), or 80 ft-lb (aluminum wheel w/chrome nuts).
9. Remove the vehicle from the support stand.

Rear A-Arms

REMOVING

1. With the vehicle in park, secure the vehicle on a support stand to elevate the wheels.

WARNING

Make sure the vehicle is solidly supported on the support stand to avoid injury.

2. Remove the wheel.
3. Secure a strap to the top of the rear knuckle and frame. This will support the knuckle and axle while the A-arms are being removed.
4. Remove the cap screws securing the boot guard to the lower A-arm.
5. Loosen and remove the sway bar link lock nut and cap screw. Account for bushings, washers, and spacer.



PR922

6. Remove the cap screws and lock nuts securing the shock absorber to the frame and lower A-arm; then remove the shock absorber. Discard the lock nuts.

Wheels and Tires

TIRE SIZE

⚠ WARNING

Use only Arctic Cat approved tires when replacing tires. Failure to do so could result in unstable vehicle operation.

The ROV models are equipped with low-pressure tubeless tires of the size and type listed in the General Information section. Do not under any circumstances substitute tires of a different type or size.

⚠ WARNING

Always use the size and type of tires specified. Always maintain proper tire inflation pressure.

⚠ WARNING

Do not mix tire tread patterns. Use the same pattern type on front and rear. Failure to heed warning could cause poor handling qualities of the vehicle and could cause excessive drive train damage not covered by warranty.

TIRE INFLATION PRESSURE

Front and rear tire inflation pressure should be 0.84-1.41 kg/cm² (12-20 psi).

REMOVING

1. Secure the vehicle on a support stand to elevate the wheels.

⚠ WARNING

Make sure the vehicle is solidly supported on the support stand to avoid injury.

2. Remove the nuts securing the wheels; then remove the wheels.

CLEANING AND INSPECTING

1. Clean the wheels and hubs with parts-cleaning solvent.
2. Clean the tires with soap and water.
3. Inspect each wheel for cracks, dents, or bends.
4. Inspect each tire for cuts, wear, missing lugs, and leaks.

INSTALLING

1. Install each wheel on its hub and secure with the existing hardware.
2. Install the wheels and using a crisscross pattern, tighten the wheel nuts in 20 ft-lb increments to a final torque of 40 ft-lb (steel wheel), 60 ft-lb (aluminium wheel w/black nuts), or 80 ft-lb (aluminum wheel w/chrome nuts).

CHECKING/INFLATING

1. Using an air pressure gauge, measure the air pressure in each tire. Adjust the air pressure as necessary to meet the recommended inflation pressure.
2. Inspect the tires for damage, wear, or punctures.

⚠ WARNING

Do not operate the vehicle if tire damage exists.

■NOTE: If repair is needed, follow the instructions found on the tire repair kit or remove the wheel and have it repaired professionally.

■NOTE: Be sure all tires are the specified size and have identical tread pattern.

Troubleshooting

Problem: Suspension too soft	
Condition	Remedy
1. Spring preload incorrect 2. Spring(s) weak 3. Shock absorber damaged	1. Adjust preload 2. Replace spring(s) 3. Replace shock absorber
Problem: Suspension too stiff	
Condition	Remedy
1. Spring preload incorrect 2. A-arm-related bushings worn	1. Adjust preload 2. Replace bushing
Problem: Suspension noisy	
Condition	Remedy
1. Cap screws (suspension system) loose 2. A-arm-related bushings worn	1. Tighten cap screws 2. Replace bushings
Problem: Vehicle pulling or steering erratic	
Condition	Remedy
1. Vehicle steering is erratic on dry, level surface 2. Vehicle pulls left or right on dry, level surface	1. Check front wheel alignment and adjust if necessary (see the Steering/Frame/Controls section) 2. Check air pressure in tires and adjust to specifications

NOTES

