

REPAIR MANUAL

4-Stroke Engine

MPE 850 OFF-ROAD

This repair manual is valid for the following engine models:

- 409135 I2 846 UTV NA-80

TD409135_RLF

Rev A

04.09.2015

en_English



Read the introductory chapter before performing the task on the engine.
Pay particular attention to the safety messages.

Textron Motors GmbH strives to make continual improvements as part of the ongoing technical development of its products. All documentation is therefore subject to technical modifications.

Reprints and translations, in whole or in part, require written permission from Textron Motors GmbH.

All rights reserved according to the copyright law.

Textron Motors GmbH

Daimlerstraße 5

88677 Markdorf

Germany

www.weber-motor.com

Table of contents

1	About this document	9
1.1	Meaning of the symbols and signal words	9
1.2	Change management	9
1.3	Finding the required information	10
2	Safety	11
2.1	Meaning of the safety alert symbol and signal words	11
2.2	Important safety messages	12
3	Basic instructions for working on the engine	15
3.1	Before you begin working	15
3.1.1	Removing engine from vehicle	15
3.2	While working	15
3.2.1	Lift and transport the engine	15
3.2.2	Secure the engine while working	15
3.2.3	Tightening torque	16
3.2.4	Cleaning	16
3.2.5	Disposal	16
3.3	After working	16
3.3.1	Updating engine control unit calibration	16
3.3.2	Checking the work carried out	16
4	Tools and accessories	17
4.1	Equipment workshop	17
4.1.1	Textron Motors special tools	17
4.1.2	Textron Motors Diagnostic Tool	18
4.1.3	Commercially available workshop equipment and standard tools	18
4.1.4	Commercially available special tools	20
4.1.5	Supplies	21
5	Overview of activities	22
010	Crankcase	22
010.01-1	Crankcase	22
Replacing crankcase	22	
Replacing welch plugs	22	
Replacing tie rod	22	
Replacing plugs	22	
010.01-2	Crankcase NA	22
Replacing cylinder liners	22	
Replacing oil seal	23	
Replacing plug	23	
010.01-3	Crankcase	23
Removing plug	23	
Installing plug	23	

Replacing plugs	23
Removing fitting	23
Installing fitting	23
Removing sensor crankshaft	23
Installing sensor crankshaft	23
Removing sensor knock	23
Installing sensor knock	23
010.02-1 Oil cooler bracket	24
Removing oil cooler bracket	24
Installing oil cooler bracket	24
010.02-2 Oil cooler bracket	24
Replacing blanking cover	24
Replacing plug	24
Sealing cover oil cooler bracket	24
010.03 Generator cover	24
Removing generator cover	24
Installing generator cover	24
Replacing generator cover	24
Replacing oil seal	25
Replacing vent plug	25
020 Crank drive	25
020.01 Crankshaft	25
Removing crank drive	25
Installing crank drive	26
Replacing crankshaft	26
Replacing balance shaft	26
Removing pistons and con rods	26
Installing pistons and con rods	27
Replacing piston	27
Replacing con rod	27
Checking con rod bearing play	27
Checking main bearing play	27
020.02 Stub shaft	27
Removing stub shaft	27
Installing stub shaft	27
020.03 Abdeckung Kurbelwelle	28
Removing crankshaft cover	28
Installing crankshaft cover	28
030 Cylinder head	28
030.01 Valve cover	28
Removing valve cover	28
Installing valve cover	28
Replacing valve cover	28
Removing ignition coils	28
Installing ignition coils	28
Removing sensor camshaft	28
Installing sensor camshaft	28
030.02 Cylinder head	29
Removing cylinder head	29
Installing cylinder head	29
Replacing cylinder head	29
Removing spark plugs	29

Installing spark plugs	30
Removing switch oil pressure	30
Installing switch oil pressure	30
Removing fitting	30
Installing fitting	30
Replacing plugs	30
040 Valve train	30
040.01 Camshaft	30
Replacing camshaft	30
Replacing timing chain	31
Checking and setting valve timing	31
Replacing chain rail	31
Replacing chain guide	31
040.02 Rocker arms	31
Replacing rocker arms	31
040.03 Valves	32
Removing valve	32
Installing valve	32
050 Cooling system	32
050.01 Thermostat housing	32
Removing thermostat housing	32
Installing thermostat housing	32
Removing fitting	32
Installing fitting	32
Replacing thermostat	33
Replacing sensor coolant temperature	33
Replacing plug thermostat housing	33
Removing closing cap thermostat housing	33
Installing closing cap thermostat housing	33
050.02 Coolant pump	33
Removing impeller	33
Installing impeller	33
Removing coolant pump	34
Installing coolant pump	34
050.03 Oil cooler	34
Removing oil cooler	34
Installing oil cooler	34
060 Exhaust system	34
060.01 Mounting exhaust manifold	34
Removing/Installing exhaust system	34
Replacing studs	34
070 Intake area	35
070.01 Intake manifold	35
Removing intake manifold	35
Installing intake manifold	35
Replacing intake manifold	35
Removing sensor intake manifold pressure/temperature	35
Installing sensor intake manifold pressure/temperature	35
Replacing cap	35
070.02 Mounting throttle body	35
Removing throttle body	35
Installing throttle body	35

Replacing throttle body	35
Replacing rubber mount	35
080 Engine management system	36
Sensor crankshaft	36
Sensor camshaft	36
Sensor coolant temperature	36
Sensor lambda	36
Sensor intake manifold pressure/temperature NA	36
Sensor knock	36
Engine control unit NA	36
Ignition coils	36
Spark plugs	36
Injectors NA	36
Throttle body	36
Switch oil pressure	36
090 Starter, Generator	36
090.01 Starter	36
Removing starter	36
Installing starter	36
Replacing starter	36
090.02 Generator	37
Removing generator	37
Installing generator	37
090.03 Voltage regulator	37
Removing/Installing voltage regulator	37
090.04 Relay starter	37
Removing/Installing relay starter	37
100 Fuel system	37
100.01 Fuel rail	37
Removing fuel rail	37
Installing fuel rail	37
Replacing injector	37
110 Lubrication system	37
110.01 Dry sump	37
Removing suction pump cover	37
Installing suction pump cover	37
Replacing suction pump cover	38
Removing oil suction pump	38
Installing oil suction pump	38
Stutzen ersetzen	38
Removing intermediate gear suction pump	38
Installing intermediate gear suction pump	38
110.02 Oil pressure pump	39
Removing oil pressure pump	39
Installing oil pressure pump	39
110.03 Oil pressure valve	39
Removing oil pressure valve	39
Installing oil pressure valve	39
110.04 Oil filter	39
Removing oil filter	39
Installing oil filter	39
Removing threaded sleeve	39

Installing threaded sleeve	40
110.05 Oil tank	40
Removing/Installing oil tank	40
120 Engine mount	40
120.01 Lifting eye	40
Removing bracket on the drive side	40
Installing bracket on the drive side	40
Removing pipe clamp	40
Installing pipe clamp	40
Removing bracket across from the drive side	40
Installing bracket across from the drive side	40
6 Working instructions, single	41
6.1 List of working instructions, single	41
Appendix	231
Overview of revisions	231
Index	232

1 About this document

This repair manual describes how to safely and correctly remove, install and replace engine components.

Observe the following information:

- Read through the service manual before performing any tasks.
- Some figures in this repair manual are general illustrations and may differ from the actual engine.

1.1 Meaning of the symbols and signal words

Item	Meaning
<i>NOTICE</i>	The signal word NOTICE indicates potential property damage.
Information	The signal word Information indicates specific features and recommendations.
	For the activity required special tools.
	For the activity additionally required spare parts.
	For the activity required supplies.
	For the activity additionally required documents.

1.2 Change management

Textron Motors GmbH strives to make continual improvements as part of the ongoing technical development of its products. You may find that descriptions in the repair manual are changed or amended. All changes are described in the chapter **Overview of revisions**.

Observe the following information:

- Always use the most current repair manual from the protected area on our web site www.weber-motor.com.
- Always print the required chapter and all chapters referred to completely and then destroy the printouts.

1.3 Finding the required information


When you planning a work on the engine, proceed as follows:

For example, you want to replace the cylinder liners **2**.

- ▶ Identify the corresponding component in the spare parts catalog..

The cylinder liners can be found in the spare parts catalog in chapter

010.01-2 Crankcase NA **1**



- ▶ Open chapter 5 **Overview of activities** in the repair manual.

- ▶ Locate the section with the same designation **010.01-2 Crankcase NA** **3**.

In this section you will find the activity **Replacing cylinder liners** **5**.

- ▶ Check whether the activity is valid for the engine model **4**.

- ▶ Perform all for the activity required working instructions **6** in the order shown.

Observe the following references:

- A list of all working instructions is located in chapter 6.1 **List of working instructions, single**.
- Each working instruction contains information on required special tools, additional required spare parts, supplies and documents.

5 Overview of activities		
Valid for	Activity	For the activity required working instructions
010.01-2 Crankcase NA		
409135	Replacing cylinder liners	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 070.01.01 Removing intake manifold ▶ 010.03.01 Removing generator cover ▶ 030.01.04 Removing ignition coils ▶ 030.01.01 Removing valve cover ▶ 030.02.01 Removing cylinder head ▶ 110.01.01 Removing suction pump cover ▶ 020.01.05 Removing pistons and con rods ▶ 010.01.2.01 Replacing cylinder liners ▶ 020.01.06 Installing pistons and con rods ▶ 110.01.02 Installing suction pump cover ▶ 030.02.02 Installing cylinder head ▶ 010.03.02 Installing generator cover ▶ 030.01.02 Installing valve cover ▶ 030.01.05 Installing ignition coils ▶ 070.01.02 Installing intake manifold
409135	Replacing oil seal	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.01 Removing generator cover ▶ 090.02.01 Removing generator ▶ 010.01.2.02 Replacing oil seal ▶ 090.02.02 Installing generator ▶ 010.03.02 Installing generator cover
409135	Replacing plug	<ul style="list-style-type: none"> ▶ 010.01.2.03 Replacing plug

2 Safety

This engine is state-of-the-art and built according to recognized safety-technical regulations. Ignoring the information in this repair manual may result in personal injury or property damage.

This repair manual is solely intended for use in a workshop authorized by Textron Motors or the vehicle manufacturer. All work on the engine must be performed by appropriately trained personnel.

Before beginning any work, trained personnel authorized to work on the engine must have access to the complete documentation of the engine. Make sure that trained personnel have read and understand all introductory chapters and in particular, the chapter on safety.

Observe all generally applicable laws and regulations in addition to the information in this repair manual:

- accident prevention
- environmental protection
- handling of hazardous materials
- personal safety equipment
- traffic laws

2.1 Meaning of the safety alert symbol and signal words

Item	Meaning
	The safety alert symbol draws your attention to possible dangers.
WARNING	The signal word WARNING indicates a potentially dangerous situation that may lead to a serious or fatal injury.
CAUTION	The signal word CAUTION indicates a potentially dangerous situation that may lead to a minor or moderately severe injury.

2.2 Important safety messages

Working instructions	You endanger the safety of personnel if you do not perform work exactly as described in this repair manual. <ul style="list-style-type: none">▶ Do not deviate from the working instructions in this repair manual.▶ Pay attention to the safety messages in the vehicle manufacturer's documentation.
Malfunctions	Engine malfunctions can cause pose a safety risk to persons. <ul style="list-style-type: none">▶ Only operate the engine in perfect condition.
Defective components	Defective engine components can cause serious engine damages and pose a safety risk to persons. <ul style="list-style-type: none">▶ Check all components before installation.▶ Always replace defective components.
Checking the work carried out	Work performed incorrectly poses a safety risk to personnel. <ul style="list-style-type: none">▶ Check the vehicle safety each time after working on the engine. (See chapter 3.3.2 Checking the work carried out.)
Spare parts	All the components in your engine have been carefully tested and fulfill strict quality and safety requirements. <ul style="list-style-type: none">▶ Textron Motors offers spare parts to the highest quality. Ensure that equivalent spare parts corresponds with this quality requirements.
Add-on parts and modifications	Engine modifications may pose a safety risk to persons. <ul style="list-style-type: none">▶ Do not install add-on parts or modify the engine.
Lift and transport the engine.	Spinal column injury due to incorrect lifting of heavy loads. <ul style="list-style-type: none">▶ Always use a workshop crane to lift and transport the engine on the brackets provided. (See chapter 3.2 Lift and transport the engine.)
Securing the engine	Crush injuries due to the engine overturning. <ul style="list-style-type: none">▶ Mount the engine to the engine stand before starting any work. (See chapter 3.2.2 Secure the engine while working.)
Tools and accessories	Unsuitable tools and accessories pose a safety risk to personnel. <ul style="list-style-type: none">▶ Always use tools listed in chapter 4 Tools and accessories.

Protective equipment	Missing protective equipment poses a safety risk to personnel. ► Attach all protective equipment after completing the tasks.
Hot engine components	Engine components become extremely hot during operation. ► Do not touch any engine components during operation. ► Switch off the engine and wait until the components have cooled.
Engine power supply	The engine must be disconnected from the power supply before any work is carried out. Leaving the engine connected to the power supply poses a risk to personnel. ► Only reconnect the power supply when prompted to do so by the vehicle manufacturer. ► Pay attention to the safety messages in the vehicle manufacturer's documentation.
Engine exhaust gases	Engine exhaust gases contain carbon monoxide (CO). Inhalation of carbon monoxide can deprive the body of oxygen and result in organ damage or death by asphyxiation. ► Never operate the engine in enclosed spaces.
Fuel, engine oil and coolant handling	Engine fluids pose a health risk. ► Always read the manufacturer's instructions. ► Always wash your hands prior to eating, smoking and using the restroom as well as at the end of the working shift when working with engine fluids.
	Engine fluids are hazardous to the environment. ► Never allow engine fluids to escape into the groundwater, water courses or sewage system. Always dispose of engine fluids according to applicable regulations.
	Danger of slipping on spilled fluids. ► Always use a filler neck or funnel when filling the engine with fluids. ► Always clean up any spilled engine fluids immediately.
Fuel	Fuel is highly flammable. Vapors may ignite and cause an explosion. ► Do not smoke in the vicinity of the engine and do not allow open flames or sparks near the engine or the fuel system. ► Always turn off the engine before fueling. ► Never fill with fuel while the engine is running. ► Do not start the engine if you smell fuel or see a fuel leak. ► Fuel on hot surfaces can cause fires. ► In the event of a fire, use foam, dry chemical or carbon dioxide fire extinguishers. Do not extinguish with water.

2 Safety

2.2 Important safety messages



Engine oil

Engine oil is flammable and can emit toxic gases.

- ▶ Do not smoke in the vicinity of the engine and do not allow open flames or sparks near the engine.
- ▶ Engine oil on hot surfaces can cause fires.
- ▶ In the event of a fire, use foam, dry chemical or carbon dioxide fire extinguishers. Do not extinguish with water.

3 Basic instructions for working on the engine**3.1 Before you begin working**

The following requirements must be met before performing any tasks:

- The engine has been removed from the vehicle.
- The engine has been disconnected from the power supply.
- There is no engine oil or coolant in the engine.
- The engine is in original factory condition. You identify the factory condition in the spare parts catalog.

3.1.1 Removing engine from vehicle


See the vehicle manufacturer's documentation.

3.2 While working**3.2.1 Lift and transport the engine**

WARNING! Spinal column injury due to incorrect lifting of heavy loads. Always lift the engine using a workshop crane.

NOTICE! Components can break. Lift the engine only using the brackets.

- Lift the engine using the brackets 1.

**3.2.2 Secure the engine while working**

WARNING! Crush injuries due to the engine overturning. Mount the engine to the engine stand before starting any work.

If not otherwise specified, mount the engine on the drive side or across from the drive side. (See chapter 000.01 Mount the engine on the engine stand.)

3.2.3 Tightening torque

For all details about tightening torque in this repair manual, observe the following information:

- If not otherwise specified, threads are dry and free of engine oil.
- For components with coated threads, the tightening torques always refer to new components.

3.2.4 Cleaning

Observe the following information:

- Before assembling components, clean all joint surfaces.
- If there is contamination in the lubrication system, cooling system or fuel unit, clean all components concerned.

3.2.5 Disposal

When disposing of operating materials, replaced parts or the whole engine, always comply with the relevant applicable national laws and guidelines.

3.3 After working

3.3.1 Updating engine control unit calibration

Update the calibration of the engine control unit when engine installed again in the vehicle.

- ▶ Update the engine control unit calibration. (See the Textron Motors Diagnostic Tool manual.)
- ▶ Clear the trouble codes. (See the Textron Motors Diagnostic Tool manual.)

3.3.2 Checking the work carried out

Check the engine when installed again in the vehicle.

- ▶ Turn the ignition on for about a minute, until the throttle body opens and closes again.
- ▶ Allow the engine to warm up as described in the service manual of the engine. You should not hear any unusual noises.
- ▶ Perform a visual inspection. No fluids should be escaping.
- ▶ Run the engine through all operating modes.

4 Tools and accessories**4.1 Equipment workshop****4.1.1 Textron Motors special tools**

Textron Motors offers a tool case that contains the following Textron Motors special tools. Visit our web site www.weber-motor.com for more information.


Figure	Description
	Locking tool crankshaft
	Chain tool
	Installation spike valve stem seal
	Remover bearing cap

Figure	Description
	TDC-adjusting tool
	Assembling kit oil seal crankshaft
	Pin punch axle intermediate gear
	Assembling kit slide ring seal

4.1.2 Textron Motors Diagnostic Tool

Textron Motors offers a diagnostic case that contains the Textron Motors Diagnostic Tool. The Textron Motors Diagnostic Tool is designed for fault diagnostics and service tasks for Textron engines using a Synerject engine management system. Visit your local vehicle dealer or our web site www.weber-motor.com for more information.



4.1.3 Commercially available workshop equipment and standard tools

In addition to the Textron Motors special tools, you will require the following tools and accessories. The figures are only examples of suitable tools. All tools and accessories are available from specialist retailers.

Abbildung	Bezeichnung
	Workshop crane with carrying strap Minimum lifting capacity 300 kg [650 lb]
	Engine stand Minimum lifting capacity 300 kg [650 lb] Mounting bolts M6 and M10
	Torque wrench 0,5 – 80 Nm [0.4 – 59 lbf ft] with extension and insert adapter
	Reversible ratchet with extension and insert adapter

Abbildung	Bezeichnung
	Torx® screwdriver T20, T30, T45
	Torx® screwdriver socket T20, T30, T45
	Hexagon screwdriver 4, 5, 6, 7, 8
	6-point socket 4, 5, 6, 7, 8

Abbildung	Bezeichnung	Abbildung	Bezeichnung
	Hexagon nut-driver 7		Lockring pliers (bore holes)
	6-point socket wrench 7, 10, 12, 14		Clamp pincer
	Open-end wrench 7, 12, 15, 19, 22, 24, 27		Pin punch 5, 7, 8
	Insert open-end wrench 7, 12, 15, 16, 19, 22, 24, 27		Protective glasses
	Bar magnet		Feeler gauge 0,05 – 2 mm
	Universal pliers		Caliper Measuring accuracy 0,05 mm
	Plastic hammer		Drip tray

4.1.4 Commercially available special tools

In addition you will require the following commercially available special tools. In the working instructions will be separately referred on these special tools. The figures are only examples of suitable tools. All tools and accessories are available from specialist retailers.

Abbildung	Bezeichnung
	12-point socket wrench 12
	Stud extractor 8, 10
	Spark plug wrench Wrench size 16 mm [5/8"] Diameter: maximum 22 mm [0.87 in]
	Angle indicator
	Crown wrench Width of pins maximum 3 mm
	Universal strap wrench

Abbildung	Bezeichnung
	Valve refacer
	Piston ring compressor
	Cylinder liner puller
	Oil seal slide hammer
	Valve spring compressor
	Precision clearance gauges 0,025 mm - 0,04 mm

4.1.5 Supplies

You need the following supplies when working on the engine. Unless otherwise specified, use the products as directed by the manufacturer.

Supplies	Recommended products
Petroleum jelly for fitting o-rings and gaskets	<ul style="list-style-type: none">– Commercial petroleum jelly for industrial applications
Lubricant for injectors o-rings	<ul style="list-style-type: none">– Mobil DTE-24, DTE-25, DTE-26– Exxon/Mobil Norpar 15
Silicone liquid seal	<ul style="list-style-type: none">– Three Bond 1227E
Anti-Seize assembly paste for lubricating threaded connections	<ul style="list-style-type: none">– Weicon Anti-Seize „High-Tech“ ASW 040 P– Loctite 8150
Thread locker, high strength	<ul style="list-style-type: none">– Loctite 272
Thread locker, medium strength	<ul style="list-style-type: none">– Loctite 243
Thread sealant	<ul style="list-style-type: none">– Loctite 542– Loctite 577
Valve grinding compound	<ul style="list-style-type: none">– Teroson valve grinding compound
Sealing surface cleaner	<ul style="list-style-type: none">– Liqui Moly brake and parts cleaner AIII

5 Overview of activities

Valid for	Activity	¹ For the activity required working instructions	
010 Crankcase			
010.01-1 Crankcase			
409135	Replacing crankcase		<ul style="list-style-type: none"> ▶ Remove the crank drive. See section 020.01 Crank drive in this chapter. ▶ 010.01-1.01 Replacing crankcase ▶ Install the crank drive. See section 020.01 Crank drive in this chapter.
409135	Replacing welch plugs	s	<ul style="list-style-type: none"> ▶ 010.01-1.02 Replacing welch plugs
409135	Replacing tie rod	s	<ul style="list-style-type: none"> ▶ 010.01-1.03 Replacing tie rod
409135	Replacing plugs	s	<ul style="list-style-type: none"> ▶ 010.01-1.04 Replacing plugs
010.01-2 Crankcase NA			
409135	Replacing cylinder liners		<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 070.01.01 Removing intake manifold ▶ 010.03.01 Removing generator cover ▶ 030.01.04 Removing ignition coils ▶ 030.01.01 Removing valve cover ▶ 030.02.01 Removing cylinder head ▶ 110.01.01 Removing suction pump cover ▶ 020.01.05 Removing pistons and con rods ▶ 010.01-2.01 Replacing cylinder liners ▶ 020.01.06 Installing pistons and con rods ▶ 110.01.02 Installing suction pump cover ▶ 030.02.02 Installing cylinder head ▶ 010.03.02 Installing generator cover ▶ 030.01.02 Installing valve cover ▶ 030.01.05 Installing ignition coils ▶ 070.01.02 Installing intake manifold

1 Activities which are marked with „s“, are not fully described in this overview of activities. Observe the references in the working instructions.

Valid for	Activity	¹ For the activity required working instructions
409135	Replacing oil seal	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.01 Removing generator cover ▶ 090.02.01 Removing generator ▶ 010.01-2.02 Replacing oil seal ▶ 090.02.02 Installing generator ▶ 010.03.02 Installing generator cover
409135	Replacing plug	<ul style="list-style-type: none"> ▶ 010.01-2.03 Replacing plug
010.01-3 Crankcase		
409135	Removing plug	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 010.01-3.01 Removing plug
409135	Installing plug	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 010.01-3.02 Installing plug
409135	Replacing plugs	<ul style="list-style-type: none"> s ▶ 010.01-3.03 Replacing plugs
409135	Removing fitting	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 010.01-3.04 Removing fitting
409135	Installing fitting	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 010.01-3.05 Installing fitting
409135	Removing sensor crankshaft	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 010.01-3.06 Removing sensor crankshaft
409135	Installing sensor crankshaft	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 010.01-3.07 Installing sensor crankshaft
409135	Removing sensor knock	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 010.01-3.08 Removing sensor knock
409135	Installing sensor knock	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 010.01-3.09 Installing sensor knock

¹ Activities which are marked with „s“, are not fully described in this overview of activities. Observe the references in the working instructions.

Valid for	Activity	¹ For the activity required working instructions
010.02-1 Oil cooler bracket		
409135	Removing oil cooler bracket	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 050.03.01 Removing oil cooler ▶ 010.02-1.01 Removing oil cooler bracket
409135	Installing oil cooler bracket	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 010.02-1.02 Installing oil cooler bracket ▶ 050.03.02 Installing oil cooler
010.02-2 Oil cooler bracket		
409135	Replacing blanking cover	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 010.02-2.01 Replacing blanking cover
409135	Replacing plug	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 010.02-2.02 Replacing plug
409135	Sealing cover oil cooler bracket	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 050.03.01 Removing oil cooler ▶ 010.02-2.03 Sealing cover oil cooler bracket ▶ 050.03.02 Installing oil cooler
010.03 Generator cover		
409135	Removing generator cover	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.01 Removing generator cover
409135	Installing generator cover	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.02 Installing generator cover
409135	Replacing generator cover	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.01 Removing generator cover ▶ 010.03.03 Replacing generator cover ▶ 010.03.02 Installing generator cover

1 Activities which are marked with „s“, are not fully described in this overview of activities. Observe the references in the working instructions.

Valid for	Activity	¹ For the activity required working instructions
409135	Replacing oil seal	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.01 Removing generator cover ▶ 010.03.04 Replacing oil seal ▶ 010.03.02 Installing generator cover
409135	Replacing vent plug	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.05 Replacing vent plug

020 Crank drive
020.01 Crankshaft

409135	Removing crank drive	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.01 Removing generator cover ▶ 090.01.01 Removing starter ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 070.01.01 Removing intake manifold ▶ 050.03.01 Removing oil cooler ▶ 010.02-1.01 Removing oil cooler bracket ▶ 050.02.01 Removing impeller ▶ 050.02.03 Removing coolant pump ▶ 020.03.01 Removing crankshaft cover ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 090.02.01 Removing generator ▶ 110.02.01 Removing oil pressure pump ▶ 110.01.01 Removing suction pump cover ▶ 030.01.04 Removing ignition coils ▶ 030.01.01 Removing valve cover ▶ 020.01.01 Removing crank drive
--------	----------------------	---

1 Activities which are marked with „s“, are not fully described in this overview of activities. Observe the references in the working instructions.

Valid for	Activity	1 For the activity required working instructions
409135	Installing crank drive	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 020.01.02 Installing crank drive ▶ 110.02.02 Installing oil pressure pump ▶ 090.02.02 Installing generator ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 020.03.02 Installing crankshaft cover ▶ 050.02.04 Installing coolant pump ▶ 050.02.02 Installing impeller ▶ 010.02-1.02 Installing oil cooler bracket ▶ 050.03.02 Installing oil cooler ▶ 110.01.02 Installing suction pump cover ▶ 070.01.02 Installing intake manifold ▶ 090.01.02 Installing starter ▶ 030.01.02 Installing valve cover ▶ 030.01.05 Installing ignition coils ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.02 Installing generator cover
409135	Replacing crankshaft	<ul style="list-style-type: none"> ▶ Remove the crank drive. See section 020.01 Crank drive in this chapter. ▶ 020.01.03 Replacing crankshaft ▶ Remove the crank drive. See section 020.01 Crank drive in this chapter.
409135	Replacing balance shaft	<ul style="list-style-type: none"> ▶ Remove the crank drive. See section 020.01 Crank drive in this chapter. ▶ 020.01.04 Replacing balance shaft ▶ Install the crank drive. See section 020.01 Crank drive in this chapter.
409135	Removing pistons and con rods	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 070.01.01 Removing intake manifold ▶ 010.03.01 Removing generator cover ▶ 110.01.01 Removing suction pump cover ▶ 030.01.04 Removing ignition coils ▶ 030.01.01 Removing valve cover ▶ 030.02.01 Removing cylinder head ▶ 020.01.05 Removing pistons and con rods

1 Activities which are marked with „s“, are not fully described in this overview of activities. Observe the references in the working instructions.

Valid for	Activity	1	For the activity required working instructions
409135	Installing pistons and con rods		<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 020.01.06 Installing pistons and con rods ▶ 030.02.02 Installing cylinder head ▶ 110.01.02 Installing suction pump cover ▶ 030.01.02 Installing valve cover ▶ 030.01.05 Installing ignition coils ▶ 010.03.02 Installing generator cover ▶ 070.01.02 Installing intake manifold
409135	Replacing piston		<ul style="list-style-type: none"> ▶ Remove the pistons and con rods. See section 020.01 Crankshaft in this chapter. ▶ 020.01.07 Replacing piston ▶ Install the pistons and con rods. See section 020.01 Kurbelwelle in this chapter.
409135	Replacing con rod		<ul style="list-style-type: none"> ▶ Remove the pistons and con rods. See section 020.01 Crankshaft in this chapter. ▶ 020.01.08 Replacing con rod ▶ Install the pistons and con rods. See section 020.01 Crankshaft in this chapter.
409135	Checking con rod bearing play	s	<ul style="list-style-type: none"> ▶ 020.01.09 Checking con rod bearing play
409135	Checking main bearing play	s	<ul style="list-style-type: none"> ▶ 020.01.10 Checking main bearing play

020.02 Stub shaft

409135	Removing stub shaft		<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.01 Removing generator cover ▶ 020.02.01 Removing stub shaft
409135	Installing stub shaft		<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 020.02.02 Installing stub shaft ▶ 010.03.02 Installing generator cover

1 Activities which are marked with „s“, are not fully described in this overview of activities. Observe the references in the working instructions.

Valid for	Activity	¹ For the activity required working instructions
020.03 Abdeckung Kurbelwelle		
409135	Removing crankshaft cover	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 020.03.01 Removing crankshaft cover
409135	Installing crankshaft cover	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 020.03.02 Installing crankshaft cover
030 Cylinder head		
030.01 Valve cover		
409135	Removing valve cover	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 030.01.04 Removing ignition coils ▶ 030.01.01 Removing valve cover
409135	Installing valve cover	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 030.01.02 Installing valve cover ▶ 030.01.05 Installing ignition coils
409135	Replacing valve cover	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 030.01.04 Removing ignition coils ▶ 030.01.06 Removing sensor camshaft ▶ 030.01.01 Removing valve cover ▶ 030.01.03 Replacing valve cover ▶ 030.01.02 Installing valve cover ▶ 030.01.07 Installing sensor camshaft ▶ 030.01.05 Installing ignition coils
409135	Removing ignition coils	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 030.01.04 Removing ignition coils
409135	Installing ignition coils	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 030.01.05 Installing ignition coils
409135	Removing sensor camshaft	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 030.01.06 Removing sensor camshaft
409135	Installing sensor camshaft	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 030.01.07 Installing sensor camshaft

1 Activities which are marked with „s“, are not fully described in this overview of activities. Observe the references in the working instructions.

Valid for	Activity	¹ For the activity required working instructions
030.02 Cylinder head		
409135	Removing cylinder head	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 070.01.01 Removing intake manifold ▶ 010.03.01 Removing generator cover ▶ 030.01.04 Removing ignition coils ▶ 030.01.01 Removing valve cover ▶ 030.02.01 Removing cylinder head
409135	Installing cylinder head	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 030.02.02 Installing cylinder head ▶ 030.01.02 Installing valve cover ▶ 030.01.04 Removing ignition coils ▶ 010.03.02 Installing generator cover ▶ 070.01.02 Installing intake manifold
409135	Replacing cylinder head	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 070.01.01 Removing intake manifold ▶ 010.03.01 Removing generator cover ▶ 030.01.04 Removing ignition coils ▶ 030.02.04 Removing spark plugs ▶ 030.01.01 Removing valve cover ▶ 030.02.01 Removing cylinder head ▶ Remove all valves: 040.03.01 Removing valve ▶ 030.02.03 Replacing cylinder head ▶ Install all valves: 040.03.02 Installing valve ▶ 030.02.02 Installing cylinder head ▶ 030.01.02 Installing valve cover ▶ 030.02.05 Installing spark plugs ▶ 030.01.05 Installing ignition coils ▶ 010.03.02 Installing generator cover ▶ 070.01.02 Installing intake manifold
409135	Removing spark plugs	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 030.01.04 Removing ignition coils ▶ 030.02.04 Removing spark plugs

¹ Activities which are marked with „s“, are not fully described in this overview of activities. Observe the references in the working instructions.

Valid for	Activity	¹ For the activity required working instructions
409135	Installing spark plugs	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 030.02.05 Installing spark plugs ▶ 030.01.05 Installing ignition coils
409135	Removing switch oil pressure	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 030.02.06 Removing switch oil pressure
409135	Installing switch oil pressure	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 030.02.07 Installing switch oil pressure
409135	Removing fitting	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 030.02.08 Removing fitting
409135	Installing fitting	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 030.02.09 Installing fitting
409135	Replacing plugs	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 030.02.10 Replacing plugs

040 Valve train

040.01 Camshaft

409135	Replacing camshaft	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 070.01.01 Removing intake manifold ▶ 010.03.01 Removing generator cover ▶ 030.01.04 Removing ignition coils ▶ 030.01.01 Removing valve cover ▶ 030.02.01 Removing cylinder head ▶ 040.01.01 Replacing camshaft ▶ 030.02.02 Installing cylinder head ▶ 030.01.02 Installing valve cover ▶ 030.01.05 Installing ignition coils ▶ 010.03.02 Installing generator cover ▶ 070.01.02 Installing intake manifold
--------	--------------------	---

1 Activities which are marked with „s“, are not fully described in this overview of activities. Observe the references in the working instructions.

Valid for	Activity	1	For the activity required working instructions
409135	Replacing timing chain		<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 030.01.04 Removing ignition coils ▶ 030.01.01 Removing valve cover ▶ 010.03.01 Removing generator cover ▶ 110.01.01 Removing suction pump cover ▶ 040.01.02 Replacing timing chain ▶ 110.01.02 Installing suction pump cover ▶ 010.03.02 Installing generator cover ▶ 030.01.02 Installing valve cover ▶ 030.01.05 Installing ignition coils
409135	Checking and setting valve timing		<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 030.01.04 Removing ignition coils ▶ 030.01.01 Removing valve cover ▶ 010.03.01 Removing generator cover ▶ 090.02.01 Removing generator ▶ 040.01.03 Checking and setting valve timing ▶ 090.02.02 Installing generator ▶ 010.03.02 Installing generator cover ▶ 030.01.02 Installing valve cover ▶ 030.01.05 Installing ignition coils
409135	Replacing chain rail	s	<ul style="list-style-type: none"> ▶ 040.01.04 Replacing chain rail
409135	Replacing chain guide	s	<ul style="list-style-type: none"> ▶ 040.01.05 Replacing chain guide
040.02 Rocker arms			
409135	Replacing rocker arms		<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 030.01.04 Removing ignition coils ▶ 030.01.01 Removing valve cover ▶ 010.03.01 Removing generator cover ▶ 040.02.01 Replacing rocker arms ▶ 010.03.02 Installing generator cover ▶ 030.01.02 Installing valve cover ▶ 030.01.05 Installing ignition coils

1 Activities which are marked with „s“, are not fully described in this overview of activities. Observe the references in the working instructions.

Valid for	Activity	¹ For the activity required working instructions
040.03 Valves		
409135	Removing valve	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 070.01.01 Removing intake manifold ▶ 010.03.01 Removing generator cover ▶ 030.01.04 Removing ignition coils ▶ 030.01.01 Removing valve cover ▶ 030.02.01 Removing cylinder head ▶ 040.03.01 Removing valve
409135	Installing valve	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 040.03.02 Installing valve ▶ 030.02.02 Installing cylinder head ▶ 030.01.02 Installing valve cover ▶ 030.01.05 Installing ignition coils ▶ 010.03.02 Installing generator cover ▶ 070.01.02 Installing intake manifold
050 Cooling system		
050.01 Thermostat housing		
409135	Removing thermostat housing	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 070.01.01 Removing intake manifold ▶ 050.01.01 Removing thermostat housing
409135	Installing thermostat housing	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 050.01.02 Installing thermostat housing ▶ 070.01.02 Installing intake manifold
409135	Removing fitting	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 070.01.01 Removing intake manifold ▶ 050.01.03 Removing fitting
409135	Installing fitting	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 050.01.04 Installing fitting ▶ 070.01.02 Installing intake manifold

¹ Activities which are marked with „s“, are not fully described in this overview of activities. Observe the references in the working instructions.

Valid for	Activity	¹ For the activity required working instructions
409135	Replacing thermostat	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 070.01.01 Removing intake manifold ▶ 050.01.03 Removing fitting ▶ 050.01.05 Replacing thermostat ▶ 050.01.04 Installing fitting ▶ 070.01.02 Installing intake manifold
409135	Replacing sensor coolant temperature	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 070.01.01 Removing intake manifold ▶ 050.01.06 Replacing sensor coolant temperature ▶ 070.01.02 Installing intake manifold
409135	Replacing plug thermostat housing	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 070.01.01 Removing intake manifold ▶ 050.01.07 Replacing plug thermostat housing ▶ 070.01.02 Installing intake manifold
409135	Removing closing cap thermostat housing	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 070.01.01 Removing intake manifold ▶ 050.01.08 Removing closing cap thermostat housing
409135	Installing closing cap thermostat housing	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 050.01.09 Installing closing cap thermostat housing ▶ 070.01.02 Installing intake manifold
050.02 Coolant pump		
409135	Removing impeller	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.01 Removing generator cover ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 050.03.01 Removing oil cooler ▶ 010.02-1.01 Removing oil cooler bracket ▶ 050.02.01 Removing impeller
409135	Installing impeller	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 050.02.02 Installing impeller ▶ 010.02-1.02 Installing oil cooler bracket ▶ 050.03.02 Installing oil cooler ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.02 Installing generator cover

1 Activities which are marked with „s“, are not fully described in this overview of activities. Observe the references in the working instructions.

Valid for	Activity	¹ For the activity required working instructions
409135	Removing coolant pump	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.01 Removing generator cover ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 050.03.01 Removing oil cooler ▶ 010.02-1.01 Removing oil cooler bracket ▶ 050.02.01 Removing impeller ▶ 050.02.03 Removing coolant pump
409135	Installing coolant pump	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 050.02.04 Installing coolant pump ▶ 050.02.02 Installing impeller ▶ 010.02-1.02 Installing oil cooler bracket ▶ 050.03.02 Installing oil cooler ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.02 Installing generator cover

050.03 Oil cooler

409135	Removing oil cooler	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 050.03.01 Removing oil cooler
409135	Installing oil cooler	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 050.03.02 Installing oil cooler

060 Exhaust system

060.01 Mounting exhaust manifold

409135	Removing/Installing exhaust system	You require the following documents: <ul style="list-style-type: none"> – Vehicle manufacturer's documentation – 060.01.01 Instructions for mounting nuts and exhaust gasket
409135	Replacing studs	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 060.01.02 Replacing studs

1 Activities which are marked with „s“, are not fully described in this overview of activities. Observe the references in the working instructions.

Valid for	Activity	¹ For the activity required working instructions
070 Intake area		
070.01 Intake manifold		
409135	Removing intake manifold	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 070.01.01 Removing intake manifold
409135	Installing intake manifold	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 070.01.02 Installing intake manifold
409135	Replacing intake manifold	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 070.01.01 Removing intake manifold ▶ 070.02.01 Removing throttle body ▶ 070.01.05 Removing sensor intake manifold pressure/temperature ▶ Replace the intake manifold. ▶ 070.01.02 Installing intake manifold ▶ 070.02.02 Installing throttle body ▶ 070.01.06 Installing sensor intake manifold pressure/temperature
409135	Removing sensor intake manifold pressure/temperature	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 070.01.05 Removing sensor intake manifold pressure/temperature
409135	Installing sensor intake manifold pressure/temperature	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 070.01.06 Installing sensor intake manifold pressure/temperature
409135	Replacing cap	<ul style="list-style-type: none"> ▶ 070.01.07 Replacing cap
070.02 Mounting throttle body		
409135	Removing throttle body	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 070.02.01 Removing throttle body
409135	Installing throttle body	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 070.02.02 Installing throttle body
409135	Replacing throttle body	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 070.02.01 Removing throttle body ▶ 070.02.03 Replacing throttle body ▶ 070.02.02 Installing throttle body
409135	Replacing rubber mount	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 070.02.01 Removing throttle body ▶ 070.02.04 Replacing rubber mount ▶ 070.02.02 Installing throttle body

1 Activities which are marked with „s“, are not fully described in this overview of activities. Observe the references in the working instructions.

Valid for	Activity	¹ For the activity required working instructions
080 Engine management system		
	Sensor crankshaft	See section 010.01-3 Crankcase in this chapter.
	Sensor camshaft	See section 030.01 Valve cover in this chapter.
	Sensor coolant temperature	See section 050.01 Thermostat housing in this chapter.
	Sensor lambda	You require the following documents: – Vehicle manufacturer's documentation
	Sensor intake manifold pressure/temperature	See section 070.01 Saugrohr in this chapter.
	NA	
	Sensor knock	See section 010.01-3 Crankcase in this chapter.
	Engine control unit NA	You require the following documents: – Vehicle manufacturer's documentation
	Information! When replacing the engine control unit, the throttle body must be recalibrated. Before putting the engine into operation again, turn the ignition on for about a minute, until the throttle body opens and closes again.	
	Ignition coils	See section 030.01 Valve cover in this chapter.
	Spark plugs	See section 030.02 Cylinder head in this chapter.
	Injectors NA	See section 100.01 Fuel rail in this chapter.
	Throttle body	See section 070.02 Mounting throttle body in this chapter.
	Switch oil pressure	See section 030.02 Cylinder head in this chapter.
090 Starter, Generator		
090.01 Starter		
409135	Removing starter	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 090.01.01 Removing starter
409135	Installing starter	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 090.01.02 Installing starter
409135	Replacing starter	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 090.01.01 Removing starter ▶ 090.01.03 Replacing starter ▶ 090.01.02 Installing starter

¹ Activities which are marked with „s“, are not fully described in this overview of activities. Observe the references in the working instructions.

Valid for	Activity	¹ For the activity required working instructions
090.02 Generator		
409135	Removing generator	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.01 Removing generator cover ▶ 090.02.01 Removing generator
409135	Installing generator	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 090.02.02 Installing generator ▶ 010.03.02 Installing generator cover
090.03 Voltage regulator		
409135	Removing/Installing voltage regulator	<p>You require the following documents:</p> <ul style="list-style-type: none"> – Vehicle manufacturer's documentation
090.04 Relay starter		
409135	Removing/Installing relay starter	<p>You require the following documents:</p> <ul style="list-style-type: none"> – Vehicle manufacturer's documentation
100 Fuel system		
100.01 Fuel rail		
409135	Removing fuel rail	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 100.01.01 Removing fuel rail
409135	Installing fuel rail	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 100.01.02 Installing fuel rail
409135	Replacing injector	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 100.01.01 Removing fuel rail ▶ 100.01.03 Replacing injector ▶ 100.01.02 Installing fuel rail
110 Lubrication system		
110.01 Dry sump		
409135	Removing suction pump cover	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.01 Removing generator cover ▶ 110.01.01 Removing suction pump cover
409135	Installing suction pump cover	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 110.01.02 Installing suction pump cover ▶ 010.03.02 Installing generator cover

1 Activities which are marked with „s“, are not fully described in this overview of activities. Observe the references in the working instructions.

Valid for	Activity	¹ For the activity required working instructions
409135	Replacing suction pump cover	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.01 Removing generator cover ▶ 110.01.01 Removing suction pump cover ▶ 110.01.04 Removing oil suction pump ▶ 110.01.03 Replacing suction pump cover ▶ 110.01.05 Installing oil suction pump ▶ 110.01.02 Installing suction pump cover ▶ 010.03.02 Installing generator cover
409135	Removing oil suction pump	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.01 Removing generator cover ▶ 110.01.01 Removing suction pump cover ▶ 110.01.04 Removing oil suction pump
409135	Installing oil suction pump	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 110.01.05 Installing oil suction pump ▶ 110.01.02 Installing suction pump cover ▶ 010.03.02 Installing generator cover
409135	Stutzen ersetzen	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 110.01.06 Stutzen ersetzen
409135	Removing intermediate gear suction pump	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.01 Removing generator cover ▶ 110.01.01 Removing suction pump cover ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 110.01.07 Removing intermediate gear suction pump
409135	Installing intermediate gear suction pump	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 110.01.08 Installing intermediate gear suction pump ▶ 110.01.02 Installing suction pump cover ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.02 Installing generator cover

¹ Activities which are marked with „s“, are not fully described in this overview of activities. Observe the references in the working instructions.

Valid for	Activity	¹ For the activity required working instructions
110.02 Oil pressure pump		
409135	Removing oil pressure pump	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.01 Removing generator cover ▶ 090.02.01 Removing generator ▶ 110.02.01 Removing oil pressure pump
409135	Installing oil pressure pump	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 110.02.02 Installing oil pressure pump ▶ 090.02.02 Installing generator ▶ 010.03.02 Installing generator cover
110.03 Oil pressure valve		
409135	Removing oil pressure valve	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 010.03.01 Removing generator cover ▶ 110.01.01 Removing suction pump cover ▶ 110.03.01 Removing oil pressure valve
409135	Installing oil pressure valve	<ul style="list-style-type: none"> ▶ 000.01.02 Mount the engine across from the drive side of the engine stand ▶ 110.03.02 Installing oil pressure valve ▶ 110.01.02 Installing suction pump cover ▶ 010.03.02 Installing generator cover
110.04 Oil filter		
409135	Removing oil filter	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 110.04.01 Removing oil filter
409135	Installing oil filter	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 110.04.02 Installing oil filter
409135	Removing threaded sleeve	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 070.01.01 Removing intake manifold ▶ 110.04.01 Removing oil filter ▶ 110.04.03 Removing threaded sleeve

¹ Activities which are marked with „s“, are not fully described in this overview of activities. Observe the references in the working instructions.

Valid for	Activity	¹ For the activity required working instructions
409135	Installing threaded sleeve	<ul style="list-style-type: none"> ▶ 000.01.01 Mount the engine on the drive side of the engine stand ▶ 110.04.04 Installing threaded sleeve ▶ 110.04.02 Installing oil filter ▶ 070.01.02 Installing intake manifold
110.05 Oil tank		
409135	Removing/Installing oil tank	<p>You require the following documents:</p> <ul style="list-style-type: none"> – Vehicle manufacturer's documentation
120 Engine mount		
120.01 Lifting eye		
409135	Removing bracket on the drive side	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 120.01.01 Removing bracket on the drive side
409135	Installing bracket on the drive side	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 120.01.02 Installing bracket on the drive side
409135	Removing pipe clamp	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 120.01.03 Removing pipe clamp
409135	Installing pipe clamp	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 120.01.04 Installing pipe clamp
409135	Removing bracket across from the drive side	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 120.01.05 Removing bracket across from the drive side
409135	Installing bracket across from the drive side	<ul style="list-style-type: none"> ▶ 000.01 Mount the engine on the engine stand ▶ 120.01.06 Installing bracket across from the drive side

1 Activities which are marked with „s“, are not fully described in this overview of activities. Observe the references in the working instructions.

6 Working instructions, single

Observe that the single working instructions do not constitute a complete description of the activity. Always perform the activities, as described in chapter 5 **Overview of activities**.

6.1 List of working instructions, single

000.01	Mount the engine on the engine stand	44	010.03.04	Replacing oil seal.....	86
000.01.01	Mount the engine on the drive side of the engine stand.....	45	010.03.05	Replacing vent plug	87
000.01.02	Mount the engine across from the drive side of the engine stand	46	020.01.01	Removing crank drive.	88
010.01-1.01	Replacing crankcase	47	020.01.02	Installing crank drive.	93
010.01-1.02	Replacing welch plugs.....	58	020.01.03	Replacing crankshaft	107
010.01-1.03	Replacing tie rod.....	59	020.01.04	Replacing balance shaft.....	108
010.01-1.04	Replacing plugs	60	020.01.05	Removing pistons and con rods....	109
010.01-2.01	Replacing cylinder liners.....	62	020.01.06	Installing pistons and con rods.....	111
010.01-2.02	Replacing oil seal.....	63	020.01.07	Replacing piston	113
010.01-2.03	Replacing plug	65	020.01.08	Replacing con rod.....	116
010.01-3.01	Removing plug.....	66	020.01.09	Checking con rod bearing play	118
010.01-3.02	Installing plug.....	66	020.01.10	Checking main bearing play.....	121
010.01-3.03	Replacing plugs	67	020.02.01	Removing stub shaft	128
010.01-3.04	Removing fitting	69	020.02.02	Installing stub shaft	129
010.01-3.05	Installing fitting	69	020.03.01	Removing crankshaft cover	131
010.01-3.06	Removing sensor crankshaft.....	70	020.03.02	Installing crankshaft cover	131
010.01-3.07	Installing sensor crankshaft.....	70	030.01.01	Removing valve cover.....	132
010.01-3.08	Removing sensor knock	71	030.01.02	Installing valve cover.....	133
010.01-3.09	Installing sensor knock	71	030.01.03	Replacing valve cover.....	134
010.02-1.01	Removing oil cooler bracket	72	030.01.04	Removing ignition coils	135
010.02-1.02	Installing oil cooler bracket	74	030.01.05	Installing ignition coils	135
010.02-2.01	Replacing blanking cover.....	76	030.01.06	Removing sensor camshaft	136
010.02-2.02	Replacing plug	77	030.01.07	Installing sensor camshaft	136
010.02-2.03	Sealing cover oil cooler bracket....	78	030.02.01	Removing cylinder head	137
010.03.01	Removing generator cover.....	81	030.02.02	Installing cylinder head	139
010.03.02	Installing generator cover.....	82	030.02.03	Replacing cylinder head.....	143
010.03.03	Replacing generator cover.....	85	030.02.04	Removing spark plugs	151
			030.02.05	Installing spark plugs	151

6 Working instructions, single

6.1 List of working instructions, single



030.02.06	Removing switch oil pressure	152	070.01.05	Removing sensor intake manifold pressure/temperature	195
030.02.07	Installing switch oil pressure	152	070.01.06	Installing sensor intake manifold pressure/temperature	195
030.02.08	Removing fitting	153	070.01.07	Replacing cap	196
030.02.09	Installing fitting	153	070.02.01	Removing throttle body	197
030.02.10	Replacing plugs	154	070.02.02	Installing throttle body	198
040.01.01	Replacing camshaft	156	070.02.03	Replacing throttle body	199
040.01.02	Replacing timing chain	160	070.02.04	Replacing rubber mount	200
040.01.03	Checking and setting valve timing ..	164	090.01.01	Removing starter	201
040.01.04	Replacing chain rail	166	090.01.02	Installing starter	202
040.01.05	Replacing chain guide	167	090.01.03	Replacing starter	203
040.02.01	Replacing rocker arms	168	090.02.01	Removing generator	204
040.03.01	Removing valve	171	090.02.02	Installing generator	206
040.03.02	Installing valve	173	100.01.01	Removing fuel rail	209
050.01.01	Removing thermostat housing	176	100.01.02	Installing fuel rail	210
050.01.02	Installing thermostat housing	177	100.01.03	Replacing injector	211
050.01.03	Removing fitting	179	110.01.01	Removing suction pump cover	213
050.01.04	Installing fitting	179	110.01.02	Installing suction pump cover	214
050.01.05	Replacing thermostat	180	110.01.03	Replacing suction pump cover	216
050.01.06	Replacing sensor coolant temperature		110.01.04	Removing oil suction pump	217
	181		110.01.05	Installing oil suction pump	218
050.01.07	Replacing plug thermostat housing	182	110.01.06	Replacing fitting	219
050.01.08	Removing closing cap thermostat housing	183	110.01.07	Removing intermediate gear suction pump	220
050.01.09	Installing closing cap thermostat housing	183	110.01.08	Installing intermediate gear suction pump	221
050.02.01	Removing impeller	184	110.02.01	Removing oil pressure pump	222
050.02.02	Installing impeller	185	110.02.02	Installing oil pressure pump	223
050.02.03	Removing coolant pump	186	110.03.01	Removing oil pressure valve	224
050.02.04	Installing coolant pump	187	110.03.02	Installing oil pressure valve	225
050.03.01	Removing oil cooler	190	110.04.01	Removing oil filter	226
050.03.02	Installing oil cooler	191	110.04.02	Installing oil filter	226
060.01.01	Instructions for mounting nuts and exhaust gasket	192	110.04.03	Removing threaded sleeve	227
060.01.02	Replacing studs	192	110.04.04	Installing threaded sleeve	227
070.01.01	Removing intake manifold	193	120.01.01	Removing bracket on the drive side	
070.01.02	Installing intake manifold	194			228

120.01.02	Installing bracket on the drive side	228
120.01.03	Removing pipe clamp	229
120.01.04	Installing pipe clamp	229
120.01.05	Removing bracket across from the drive side	230
120.01.06	Installing bracket across from the drive side.....	230


000.01 Mount the engine on the engine stand

WARNING! Crush injuries due to the engine overturning. Mount the engine to the engine stand before starting any work.


If not otherwise specified in the chapter, mount the engine on the drive side or across from the drive side.

- ▶ Mount the engine on the drive side **1** of the engine stand. (See chapter 000.01.01 Mount the engine on the drive side of the engine stand.)

or



- ▶ Mount the engine across from the drive side **2** of the engine stand. (See chapter 000.01.02 Mount the engine across from the drive side of the engine stand.)




000.01.01 Mount the engine on the drive side of the engine stand

WARNING! Spinal column injury due to incorrect lifting of heavy loads. Always lift the engine using a workshop crane.

NOTICE! Breakage. Lift the engine only using the brackets.

- Lift the engine using the brackets **1**.




- Mount the engine on the engine stand.

Suitable mounting points M10:

- Depth of thread **2** 30 mm
- Depth of thread **3** 44 mm
- Depth of thread **4** 46 mm

or




- Mount the engine on the engine stand.

Suitable mounting points M10:

- Depth of thread **5** 30 mm

Suitable mounting points M6 **6**




000.01.02 Mount the engine across from the drive side of the engine stand

WARNING! Spinal column injury due to incorrect lifting of heavy loads. Always lift the engine using a workshop crane.

NOTICE! Breakage. Lift the engine only using the brackets.

- ▶ Lift the engine using the brackets **1**.




- ▶ Mount the engine on the engine stand.

Suitable mounting points M10:

- Depth of thread **2** 40 mm
- Depth of thread **3** 30 mm


or



- ▶ Mount the engine on the engine stand.

Suitable mounting points M10:

- Depth of thread **4** 30 mm



010.01-1.01 Replacing crankcase



- Pin punch axle intermediate gear
- Universal strap wrench
- Crown wrench
- Cylinder liner puller




- Thread sealant
- Silicone liquid seal




- 7 plugs M18x1.5
- 1 plug M10x1
- 1 Oil filter
- 1 Seal 8x12x1 Al
- 1 O-ring sensor crankshaft
- 1 Seal 18x22x1.5 Al
- 4 O-rings cylinder liner


- ▶ Unscrew the bolt **1**.
- ▶ Pull the sensor crankshaft **2** out.




- ▶ Unscrew the fitting **3**.




- ▶ Turn the lower case 180°.
- ▶ Remove the sleeves **4**.




► Unscrew the plug **5**.




► Punch the axle **7** out using the pin punch axle intermediate gear **6** and plastic hammer.




► Remove the intermediate gear suction pump **8**.




► Remove the sleeves **9**.




- ▶ Unscrew the bolts **10**.
- ▶ Remove the chain rail **11**.



- ▶ Turn the upper case 180°.
- ▶ Unscrew the oil filter **13** using a universal strap wrench.
- ▶ Unscrew the threaded sleeve **12** using a crown wrench.




- ▶ Unscrew 10 bolts **14**.




The thermostat housing is caulked with a silicone liquid seal.


- ▶ Remove the thermostat housing **15**.




- Remove the sleeve **16**.



- Unscrew the bolt **17**.
- Remove the chain rail **18**.



- Remove the cylinder liners **19** using a cylinder liner puller.




Prepare the new crankcase

- Replace the crankcase.
- Screw in a new plug **20**.

Tightening torque:


20 Nm +4 Nm [14.8 lbf ft +3 lbf ft]



- ▶ Screw in new plugs **21**.

Tightening torque:

20 Nm +4 Nm [14.8 lbf ft +3 lbf ft]

21


- ▶ Screw in a new plug **22**.

Tightening torque:

9 Nm +2 Nm [6.6 lbf ft +1.5 lbf ft]


22
23
23

- ▶ Insert the sleeves **23**.

- ▶ Screw in new plugs **24**.

Tightening torque:

20 Nm +4 Nm [14.8 lbf ft +3 lbf ft]

24
24
24



Two threaded holes M18 **25** remain open.

Use new plugs **26**.

- ▶ Coat the threads on the plugs with thread sealant.
- ▶ Screw in plugs.

Tightening torque:

20 Nm +4 Nm [14.8 lbf ft +3 lbf ft]

25
26
27


- ▶ Insert the sleeve **27**.


WARNING! Crush injuries due to a dropped crankcase.

- ▶ Lift the crankcase using a carrying strap.
- ▶ Mount the crankcase on the engine stand.

Suitable mounting points M10 **28**:

- Depth of thread 30 mm


Suitable mounting points M6 **29**:




- ▶ Screw in the threaded sleeve **30** using a crown wrench.

Tightening torque:

17 Nm +3 Nm [12.5 lbf ft +2.2 lbf ft]




- ▶ Clean the sealing surface **32** with sealing surface cleaner.
- ▶ Use a new oil filter **31**.
- ▶ Coat the oil filter seal **33** lightly with engine oil.




► Screw in the oil filter **34** by hand.


Tightening torque:
10 Nm [7.4 lbf ft]




► Clean the sealing surface **35** with sealing surface cleaner.




► Clean the sealing surface **36** with sealing surface cleaner.



► Apply the silicone liquid seal **37** without gaps as illustrated.




► Hold the thermostat housing **38** in position.



► Screw in 10 bolts **39**.

Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]




► Replace the seal **40**.


► Screw in the fitting **41**.

Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]




- ▶ Replace the o-ring **42** on the sensor crankshaft **43**.
- ▶ Coat the o-ring lightly with petroleum jelly.
- ▶ Slide on the o-ring as illustrated.




- ▶ Insert the sensor crankshaft **45**.
- ▶ Screw in the bolt **44**.

Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]




- ▶ Turn the crankcase 180°.
- ▶ Hold the intermediate gear suction pump **46** in position.
- ▶ Slide in the axle **47**. Observe the position of the bevel **48**.




- ▶ Replace the seal **49**.
- ▶ Screw in the plug **50**.

Tightening torque:


20 Nm +4 Nm [14.8 lbf ft +3 lbf ft]




- ▶ Insert the sleeves **51**.



- ▶ Unscrew the bolt **52**.
- ▶ Remove the lower case **53**.




- ▶ Check if the welch plugs **54** are installed.



- Insert the chain guide **56**.
- Screw in the bolts **55**.

Tightening torque:


8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]




- Turn the upper case 180°.
- Insert the chain rail **58**.
- Screw in the bolt **57**.

Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]




- Replace the o-rings **60**.
- Coat the o-rings lightly with petroleum jelly.
- Insert the cylinder liners **59**.



010.01-1.02 Replacing welch plugs

The upper case is disconnected from the crankcase.

- Welch plug 1 **1**
- Welch plug 2 **2**




- Unscrew the banjo bolt **3**.
- Remove the welch plug **4**.



- Replace the welch plug **6**.
- Hold the welch plug in position.
- Screw in the banjo bolt **5**.

Tightening torque:
20 Nm +2 Nm [14.8 lbf ft +1.5 lbf ft]



010.01-1.03 Replacing tie rod


– Stud extractor




– Anti-Seize assembly paste

The lower case is disconnected from the crankcase.

- ▶ Unscrew the tie rod **1** using a stud extractor.
- ▶ Replace tie rod.
- ▶ Apply Anti-Seize assembly paste to all threads **2**.
- ▶ Screw in the tie rod using a stud extractor.


Tightening torque:

18 Nm +2 Nm [13.3 lbf ft +1.5 lbf ft]



010.01-1.04 Replacing plugs

- Plug 1 **1**
- Plug 2 **2**
- Plug 3 **3**




Replacing plug 1

- Unscrew the plug **1**.
- Replace the plug.
- Screw in the plug.

Tightening torque:

20 Nm +4 Nm [14.8 lbf ft +3 lbf ft]




Replacing plug 2

The generator cover and rotor are removed.

- Unscrew the plug **1**.
- Replace the plug.
- Screw in the plug.

Tightening torque:

20 Nm +4 Nm [14.8 lbf ft +3 lbf ft]




Replacing plug 3

The generator cover and generator are removed.

- Unscrew the plug **1**.
- Replace the plug.
- Screw in the plug.

Tightening torque:

9 Nm +2 Nm [6.6 lbf ft +1.5 lbf ft]




010.01-2.01 Replacing cylinder liners



– Cylinder liner puller


- ▶ Remove the cylinder liners **1** using a cylinder liner puller.
- ▶ Replace the cylinder liners.
- ▶ Coat the o-rings **1** lightly with petroleum jelly.
- ▶ Insert the cylinder liners.




010.01-2.02 Replacing oil seal


- Oil seal slide hammer
- Assembling kit oil seal crankshaft

- ▶ Pull the oil seal **1** out using the oil seal slide hammer.




- ▶ Replace the oil seal **2**.
- ▶ Coat the inside of the oil seal **4** lightly with petroleum jelly.
- ▶ Slide the oil seal onto guide sleeve **3**.



- ▶ Slide the guiding sleeve **5** onto crankshaft **6**.

Use the M10x1x35 bolts you removed on the rotor.


- ▶ Screw in the bolts **7**.




- ▶ Hold the sliding sleeve **8** in position on the oil seal **9**.

Use the M10x1x35 bolts you removed on the rotor.


- ▶ Screw in the bolt **10**.




- ▶ Screw in the bolt **11** until the oil seal is flush with the crankcase.



- ▶ Unscrew the bolt **13**.
- ▶ Remove the sliding sleeve **12**.



- ▶ Unscrew the bolts **16**.
- ▶ Remove the guiding sleeve **14**.
- ▶ Check if the oil seal **15** is tilted.
- ▶ If the oil seal is tilted, it must be replaced.




010.01-2.03 Replacing plug

- Unscrew the plug **1**.
- Replace the plug.
- Screw in the plug.


Tightening torque:

20 Nm +4 Nm [14.8 lbf ft +3 lbf ft]



010.01-3.01 Removing plug

- Unscrew the plug **1**.




010.01-3.02 Installing plug

- – 1 Seal 18x22x1.5 Al

- Replace the seal **1**.
- Screw in the plug **2**.


Tightening torque:

20 Nm +4 Nm [14.8 lbf ft +3 lbf ft]



010.01-3.03 Replacing plugs

- Plugs 1 **1**
- Plug 2 **2**
- Plug 3 **3**


Replacing plugs 1


The oil cooler bracket is removed.

Two threaded holes M18 **1** remain open.

- Unscrew the plugs **2**.
- Replace the plugs.
- Coat the threads on the plugs with thread sealant.
- Screw in the plugs.

Tightening torque:

20 Nm +4 Nm [14.8 lbf ft +3 lbf ft]




Replacing plug 2

- Unscrew the plug **1**.
- Replace the plug.
- Screw in the plug.

Tightening torque:

20 Nm +4 Nm [14.8 lbf ft +3 lbf ft]




Replacing plug 3

- Unscrew the plug **1**.
- Replace the plug.
- Screw in the plug.


Tightening torque:

20 Nm +4 Nm [14.8 lbf ft +3 lbf ft]



010.01-3.04 Removing fitting

► Unscrew the fitting **1**.


**010.01-3.05 Installing fitting**

 – 1 Seal 8x12x1 Al

► Replace the seal **1**.
► Screw in the fitting **2**.


Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]



010.01-3.06 Removing sensor crankshaft


- Unscrew the bolt **1**.
- Pull the sensor crankshaft **2** out.



010.01-3.07 Installing sensor crankshaft

- 1 O-ring sensor crankshaft

- Replace the o-ring **2** on the sensor crankshaft **1**.
- Coat the o-ring lightly with petroleum jelly.
- Slide on the o-ring as illustrated.




- Insert the sensor crankshaft **4**.

- Screw in the bolt **3**.


Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]



010.01-3.08 Removing sensor knock


- Unscrew the bolt **2**.
- Remove the sensor knock **1**.

**010.01-3.09 Installing sensor knock**

- Hold the sensor knock **1** in position.
- Screw in the bolt **2**.


Tightening torque:

20 Nm +4 Nm [14.8 lbf ft +3 lbf ft]




010.02-1.01 Removing oil cooler bracket


- Unscrew 15 bolts **1**.



- Remove the oil cooler bracket **2**.



► Remove the sleeve **3**.




010.02-1.02 Installing oil cooler bracket




– 1 Gasket oil cooler bracket

- ▶ Replace the gasket **1**.
- ▶ Insert the gasket into the groove and lightly coat with petroleum jelly.
- ▶ Insert the sleeve **2**.



- ▶ Hold the oil cooler bracket **3** in position.



► Screw in 1 bolt M6x30 **A**.


Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]

► Screw in 14 bolts M6x20 **B**.

Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]




010.02-2.01 Replacing blanking cover




- 1 O-ring blanking cover

WARNING! Serious eye injuries due to a flying circlip. Wear protective glasses.

- Remove the circlip **3** using a lockring pliers.
- Remove the clamp ring **2**.
- Remove the blanking cover **1**.




- Replace the blanking cover **4** and the o-ring **5**.
- Coat the o-ring lightly with petroleum jelly.



- Insert the blanking cover **6**.
- Insert the clamp ring **7**.

WARNING! Serious eye injuries due to a flying circlip. Wear protective glasses.

- Install the circlip **8** using a lockring pliers.



010.02-2.02 Replacing plug




– 1 Seal 14x18x1.5 Al

- Unscrew the plug **2**.
- Replace the plug.
- Replace the seal **1**.
- Screw in the plug.

Tightening torque:

14 Nm +2 Nm [10.3 lbf ft +1.5 lbf ft]




010.02-2.03 Sealing cover oil cooler bracket



– Silicone liquid seal


Information! The cover oil cooler bracket should only be removed if it leaks. Textron Motors recommends replacing the entire oil cooler bracket.

- Unscrew 14 bolts **1**.




The cover oil cooler bracket is caulked with a silicone liquid seal.


- Remove the cover oil cooler bracket **2**.




- ▶ Clean the sealing surfaces **3** with sealing surface cleaner.



- ▶ Apply the silicone liquid seal **4** without gaps as illustrated.



- ▶ Hold the cover oil cooler bracket **5** in position.



- ▶ Screw in the bolt **6**.


Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]

- ▶ Screw in 13 bolts **7**.


Tightening torque:

5 Nm +1 Nm [3.7 lbf ft +0.7 lbf ft]




010.03.01 Removing generator cover

- Unscrew 10 bolts **1**.




- Unscrew 2 bolts **2**.



The generator cover is caulked with a silicone liquid seal.

- Remove the generator cover **3**.



010.03.02 Installing generator cover




- 1 Oil seal generator cover
- 1 Seal 10x16x1 Al




- Silicone liquid seal


- Check if the sleeves **1** are installed.




- Replace the oil seal **2**.
- Push the oil seal into the generator cover **3**.




- Coat the inside of the oil seal **4** lightly with petroleum jelly.




- ▶ Clean the sealing surface **5** with sealing surface cleaner.



- ▶ Clean the sealing surface **6** with sealing surface cleaner.
- ▶ Apply the silicone liquid seal **7** without gaps as illustrated.




- ▶ Hold the generator cover **8** in position.



► Screw in 10 bolts **9**.

Tightening torque:


8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]



► Screw in 2 bolts **10**.

Tightening torque:

40 Nm +8 Nm [29.5 lbf ft +5.9 lbf ft]



► Unscrew the vent plug **11**.

If too much engine oil has been filled, engine oil may leak at the plug.


► Fill in 40 ml [0.04 qt (US)] engine oil.

► Replace the seal **12**.

► Screw in the vent plug.

Tightening torque:

9 Nm +2 Nm [6.7 lbf ft +1.5 lbf ft]




010.03.03 Replacing generator cover

– 1 Seal 10x16x1 Al

- ▶ Replace the generator cover **3**.
- ▶ Remove the plug from the old generator cover.
- ▶ Replace the seal **2**.
- ▶ Screw in the plug **1**.


Tightening torque:

9 Nm +2 Nm [6.7 lbf ft +1.5 lbf ft]



010.03.04 Replacing oil seal

- ▶ Pull the oil seal **1** out.
- ▶ Replace the oil seal.
- ▶ Push the oil seal into the generator cover **2**.




010.03.05 Replacing vent plug

– 1 Seal 10x16x1 Al

- Unscrew the vent plug **1**.
- Replace the vent plug.
- Replace the seal **2**.
- Screw in the vent plug.

Tightening torque:

9 Nm +2 Nm [6.7 lbf ft +1.5 lbf ft]



020.01.01 Removing crank drive.



- Chain tool
- Stud extractor
- 12-point socket wrench 12



- Anti-Seize assembly paste



- Instruction manual chain tool


NOTICE

Bearing damage, increased wear and leaks due to installing components swapped over.


All components in the crank drive are inserted together. If the components are installed swapped over, they no longer fit together well.

- ▶ When removing the components, mark the cylinder assignment and installation position.
- ▶ Install all components back into the place from which they were removed.


- ▶ Unscrew the chain tensioner **1**.



- ▶ Mark the running direction of the timing chain **2**.
- ▶ Open the timing chain. (See the instruction manual of the chain tool.)




- ▶ Turn the engine 180°.
- ▶ Remove the timing chain **3**.




- ▶ Unscrew the nuts **4** in the sequence as illustrated **5**.

The rocker arm and cross bars are no longer firmly attached to the cylinder head. Do not turn the cylinder head.




► Remove the cylinder head **6**.




► Turn the engine 180°.

Unscrew all bolts in the sequence as illustrated **7**.

- Unscrew 4 bolts M6 **1** – **4**.
- Unscrew 5 bolts M8 **5** – **9**.



► Pull the oil pressure valve **8** out using a bar magnet.




The crankcase is caulked with a silicone liquid seal.


- ▶ Remove the lower case **9**.
- ▶ If the screw connection of a tie rod **10** has loosened unscrew the tie rod using a stud extractor.
- ▶ Apply Anti-Seize assembly paste to all threads.
- ▶ Screw in the tie rod using a stud extractor.

Tightening torque:


18 Nm +2 Nm [13.3 lbf ft +1.5 lbf ft]




- ▶ Turn the crankshaft **11** 180°.




- ▶ Mark the cylinder assignment and installation position on the piston, con rod, con rod cover and bearing shells.
- ▶ Unscrew the con-rod bolts **12**.
- ▶ Remove the con-rod cover **13**.




- ▶ Pull the pistons **14** out.



- ▶ Remove the balance shaft **15**.



- ▶ Remove the crankshaft **16**.
- ▶ Remove the oil seal **17**.



020.01.02 Installing crank drive.



- Piston ring compressor
- 12-point socket wrench 12
- Assembling kit oil seal crankshaft
- TDC-Adjusting tool
- Chain tool

- Service manual of the engine
- Instruction manual chain tool



- 4 Con rod bolts
- 1 Cylinder head gasket
- 1 Oil seal crankshaft
- 1 Chain tensioner
- 1 Chain link




- Silicone liquid seal

NOTICE**Bearing damage, increased wear and leaks due to installing components swapped over.**


All components in the crank drive are inserted together. If the components are installed swapped over, they no longer fit together well.

- ▶ When removing the components, mark the cylinder assignment and installation position.
- ▶ Install all components back into the place from which they were removed.


- ▶ Clean the crankcase sealing surfaces **1**
2 with sealing surface cleaner.



- ▶ Check if the main bearing shells **3** and bearing shells balance shaft **4** are installed.




- ▶ When replacing a piston, continue with chapter 020.01.07 **Replacing piston**.
- ▶ When replacing a con rod, continue with chapter 020.01.08 **Replacing con rod**.
- ▶ Coat the con rod bearing shells **5** lightly with engine oil.
- ▶ Insert con rod bearing shells in con rod and con rod cover. Observe the installation instructions for the con rod bearing.




Installation instructions for the con rod bearings

NOTICE! Serious damage to bearings due to con rod bearing shells being installed incorrectly.


- ▶ Insert the con rod bearing shells **6** centered on the con rod.
- ▶ Measure whether the dimensions “=” **7** are equal.




- Displace the ring joints **8** of the three piston rings 120°.



- Turn the engine 180°.
- Coat the pistons **9** lightly with engine oil.
- Slide in the pistons using a piston ring compressor.



- Turn the engine 180°.
- When replacing the crankshaft, check the main bearing play and con rod bearing play. (See chapter 020.01.09 Checking con rod bearing play.) (See chapter 020.01.10 Checking main bearing play.)
- When replacing the crankcase, check the main bearing play. (See chapter 020.01.10 Checking main bearing play.)
- Insert the crankshaft **10**.




- ▶ Insert con-rod covers **12**.
- ▶ Replace the con-rod bolts **11**.
- ▶ Tighten the con-rod bolts in three stages.

Tightening torque:


First stage 10 Nm [7.4 lbf ft]

Second stage 20 Nm [14.8 lbf ft]


Third stage +115°



- ▶ Observe the marking **13**.
- The marking ends flush with the crankcase.




- ▶ When replacing the balance shaft **14**, replace the bearing shells balance shaft.
- ▶ Insert the balance shaft.




Aligning the balance shaft to the crankshaft


- ▶ Observe the marking **15**.
The marking ends flush with the crankcase.




- ▶ Turn the crankshaft **16** 180°.



- ▶ Check if the centering pins **17** are installed.





- Apply the silicone liquid seal **18** without gaps as illustrated.




Checking the alignment of the balance shaft / crankshaft

- Check the markings **19**.
Both markings appear as shown.
- Put the lower case **20** on.




- ▶ Assemble the oil pressure valve in the sequence as illustrated **21**.

21



- ▶ Insert the oil pressure valve **22**.

22



Screw in all bolts in the sequence as illustrated **23**.

- ▶ Screw in 5 bolts M8 ① – ⑤.

Tightening torque:


9 Nm +1 Nm [6.6 lbf ft +0.7 lbf ft]

- ▶ Screw in 4 bolts M6 ⑥ – ⑨.


Tightening torque:

Maximum 5 Nm [3.7 lbf ft]

23




- ▶ Turn the engine 180°.
- ▶ Check if the centering pins **24** are installed.



- ▶ Replace the cylinder head gasket **25**.
- ▶ Put the cylinder head gasket on.

Observe the installation position:


- Exhaust side **26**
- Inscription **27**
- Centering pins **28**
- Starter **29**



- ▶ Put the cylinder head **30** on.

Observe the installation position:

- Exhaust side **31**
- Starter **32**



- ▶ Lubricate the nuts **33** with engine oil.
- ▶ Screw on the nuts by hand. Do not tighten.
- ▶ Tighten the nuts in the sequence as illustrated **34** in three stages.

Tightening torque:

First stage


20 Nm ± 3 Nm [14.8 lbf ft ± 2.2 lbf ft]

Second stage

40 Nm ± 3 Nm [29.5 lbf ft ± 2.2 lbf ft]

Third stage

180° ± 4 °



- ▶ Turn the engine 180°.
- Tighten all bolts in the sequence as illustrated **35**.

- ▶ Tighten 5 bolts M8 **1** – **5**.


Tightening torque:

23 Nm $+2$ Nm [17 lbf ft $+1.5$ lbf ft]

- ▶ Tighten 4 bolts M6 **6** – **9**.

Tightening torque:


8 Nm $+2$ Nm [5.9 lbf ft $+1.5$ lbf ft]




- ▶ Lift the engine. (See chapter 3.2.1 Lift and transport the engine.)
- ▶ Remove the engine from the engine stand.
- ▶ Turn the engine and mount on the engine stand.

Suitable mounting points M10 **36**:

- Depth of thread 30 mm.




- ▶ Replace the oil seal **37**.
- ▶ Coat the inside of the oil seal **39** lightly with petroleum jelly.
- ▶ Slide the oil seal onto guiding sleeve **38**.



- ▶ Slide the guiding sleeve **40** onto crankshaft **41**.

Use the M10x1x35 bolts you removed on the rotor.


- ▶ Screw in the bolts **42**.




- ▶ Hold the sliding sleeve **43** in position on the oil seal **44**.

Use a M10x1x35 bolt that you removed from the rotor.


- ▶ Screw in the bolt **45**.




- ▶ Screw in the bolt **46** until the oil seal is flush with the crankcase.



- ▶ Unscrew the bolt **48**.
- ▶ Remove the sliding sleeve **47**.



- ▶ Unscrew the bolts **51**.
- ▶ Remove the guiding sleeve **49**.
- ▶ Check if the oil seal **50** is tilted.
- ▶ If the oil seal is tilted, it must be replaced.




Setting valve timing

- ▶ Check whether the camshaft is at the crossing point.

The position of the camshaft is as illustrated **53**.

The marking **52** ends flush with the cross bar.


- ▶ If the camshaft does not appear as shown, turn it.



- ▶ Hold the TDC-adjusting tool **55** in position. Observe the positioning pin and positioning bore **54**.


Use the M10x1x35 bolts you removed on the rotor.

- ▶ Screw in the bolts **56**.



Use a hexagon screwdriver socket 8 and reversible ratchet.


- ▶ Turn the crankshaft on the TDC-adjusting tool **58** in the direction shown **57** until the marking **60** ends flush with the crankcase halves **59**.




- ▶ Turn the engine 180°.

If not installing a new timing chain, observe the running direction marked.

- ▶ Insert the timing chain **61** as illustrated.




- ▶ Insert the chain link **62** on the open ends of the timing chain.
- ▶ Turn the engine 180°.
- ▶ Close the timing chain. (See the instruction manual of the chain tool.)



- ▶ Replace the chain tensioner **63**.
- ▶ Screw in the chain tensioner.

Tightening torque:

40 Nm +5 Nm [29.5 lbf ft +3.7 lbf ft]




Checking the alignment of the balance shaft / crankshaft

Use a hexagon screwdriver socket 8 and reversible ratchet.

- ▶ Turn the crankshaft on the TDC-adjusting tool **65** several times in the direction shown **64**.

The crankshaft can be turned.


- ▶ If the crankshaft does not turn, check the alignment of the balance shaft / crankshaft.




Checking valve timing

Use a hexagon screwdriver socket 8 and reversible ratchet.


- ▶ Turn the crankshaft on the TDC-adjusting tool **67** in the direction shown **66** until the marking **69** ends flush with the crankcase halves **68**.



- ▶ Check whether the camshaft is at the crossing point.
The position of the camshaft is as illustrated **71**.
The marking **70** ends flush with the cross bar.
- ▶ If the camshaft does not appear as shown, set the valve timing again.
or
- ▶ If the camshaft does not appear as shown several times, replace the timing chain. (See chapter 040.01.02 Replacing timing chain.)




- ▶ Unscrew the bolts **73**.
- ▶ Remove the TDC-adjusting tool **72**.
- ▶ Check the valve lash. (See the service manual of the engine.)



020.01.03 Replacing crankshaft

- 020.01.10 Checking main bearing play
- 020.01.09 Checking con rod bearing play

- ▶ Replace the crankshaft **1**.
- ▶ Check the main bearing play. (See chapter 020.01.10 Checking main bearing play.)
- ▶ Check the con rod bearing play. (See chapter 020.01.09 Checking con rod bearing play.)




020.01.04 Replacing balance shaft



– 8 Bearing shell balance shaft

- ▶ Replace the bearing shells balance shaft **1**.
- ▶ Coat the bearing shells balance shaft lightly with engine oil.
- ▶ Insert the main bearing shells in crankcase.
- ▶ Replace the balance shaft **2**.
- ▶ Insert the balance shaft.



020.01.05 Removing pistons and con rods



- 12-point socket wrench 12


NOTICE

Bearing damage, increased wear and leaks due to installing components swapped over.


All components in the crank drive are inserted together. If the components are installed swapped over, they no longer fit together well.

- ▶ When removing the components, mark the cylinder assignment and installation position.
- ▶ Install all components back into the place from which they were removed.


- ▶ Turn the engine 180°.
- ▶ Turn the crankshaft on a bolt **2** in the direction shown **1** until the crankshaft stops at BDC (Bottom Dead Center).



- ▶ Mark the cylinder assignment and installation position on the piston, con rod, con rod cover and bearing shells.
- ▶ Unscrew the con-rod bolts **3**.
- ▶ Remove the con-rod cover **4**.



- ▶ Pull the pistons **5** out.



020.01.06 Installing pistons and con rods


– Piston ring compressor
 – 12-point socket wrench 12



– 4 Con rod bolts


NOTICE

Bearing damage, increased wear and leaks due to installing components swapped over.

All components in the crank drive are inserted together. If the components are installed swapped over, they no longer fit together well.


- ▶ When removing the components, mark the cylinder assignment and installation position.
- ▶ Install all components back into the place from which they were removed.

- ▶ Coat the con rod bearing shells **1** lightly with engine oil.
- ▶ Insert con rod bearing shells in con rod and con rod cover. Observe the installation instructions for the con rod bearing.



Installation instructions for the con rod bearings

NOTICE! Serious damage to bearings due to con rod bearing shells being installed incorrectly.

- ▶ Insert the con rod bearing shells **2** centered on the con rod.
- ▶ Measure whether the dimensions “=” **3** are equal.



- Displace the ring joints **4** of the three piston rings 120°.



- Turn the engine 180°.
- Coat the pistons **5** lightly with engine oil.
- Slide in the pistons using a piston ring compressor.




- Turn the engine 180°.
- Insert con-rod covers **7**.
- Replace the con-rod bolts **6**.
- Tighten the con-rod bolts in three stages.

Tightening torque:

First stage 10 Nm [7.4 lbf ft]

Second stage 20 Nm [14.8 lbf ft]

Third stage +115°



020.01.07 Replacing piston

WARNING**Serious eye injuries due to a flying circlip.**

When installing or removing the circlip, it can be thrown at great speed and cause serious eye injuries.

- Wear protective glasses, along with any bystanders.


NOTICE**Bearing damage, increased wear and leaks due to installing components swapped over.**

All components in the crank drive are inserted together. If the components are installed swapped over, they no longer fit together well.


- When removing the components, mark the cylinder assignment and installation position.
- Install all components back into the place from which they were removed.

The piston and con rod are removed.

- Install the circlip **2** using a litte screwdriver.
- Pull the piston pin **1** out.
- Remove the piston **3**.





- ▶ Replace the piston **5**.
- ▶ Install the circlip **7** using a little screwdriver.
- ▶ Pull the piston pin **6** out.
- ▶ Hold the con rod **4** in position. Observe the piston's installation position.



Installation position piston

Arrow on top **8** and inside arrow **9** in the direction of the chain tensioner **10** and starter **11**.



- ▶ Coat the piston pin **13** lightly with engine oil.
- ▶ Slide in the piston pin.
- ▶ Install the circlip **12** using a litte screwdriver.



020.01.08 Replacing con rod



- 020.01.09 Checking con rod bearing play

! WARNING**Serious eye injuries due to a flying circlip.**

When installing or removing the circlip, it can be thrown at great speed and cause serious eye injuries.

- Wear protective glasses, along with any bystanders.


NOTICE**Bearing damage, increased wear and leaks due to installing components swapped over.**

All components in the crank drive are inserted together. If the components are installed swapped over, they no longer fit together well.


- When removing the components, mark the cylinder assignment and installation position.
- Install all components back into the place from which they were removed.

The crankshaft, piston and con rod are removed.

- Install the circlip **2** using a litte screwdriver.
- Pull the piston pin **1** out.
- Remove the piston **3**.



- ▶ Replace the con rod **4**.
- ▶ Hold the con rod in position.
- ▶ Coat the piston pin **5** lightly with engine oil.
- ▶ Slide in the piston pin.
- ▶ Install the circlip **6** using a little screwdriver.
- ▶ Check the con rod bearing play. (See chapter 020.01.09 Checking con rod bearing play.)



020.01.09 Checking con rod bearing play



– Precision clearance gauges



– Con rod bearing shells in different thicknesses

Information! Con rod bolts are extension bolt and must be replaced after removal. However, when measuring the con rod bearing play, you can use the removed con rod bolts.

NOTICE**Bearing damage, increased wear and leaks due to installing components swapped over.**

All components in the crank drive are inserted together. If the components are installed swapped over, they no longer fit together well.

- ▶ When removing the components, mark the cylinder assignment and installation position.
- ▶ Install all components back into the place from which they were removed.


The crankshaft, piston and con rod are removed.

NOTICE! Bearing damage due to incorrect con rod bearing play. When replacing a con rod or the crankshaft, the con rod bearing play must be checked.

- ▶ Unscrew the con-rod bolts **1**.

Use the removed con rod bearing shells.


- ▶ Coat the con rod bearing shells **2** lightly with engine oil.
- ▶ Insert con rod bearing shells **2** in con rod and con rod cover. Observe the installation instructions for the con rod bearing.




Installation instructions for the con rod bearings

NOT/CE! Serious damage to bearings due to con rod bearing shells being installed incorrectly.

- ▶ Insert the con rod bearing shells **3** centered on the con rod.
- ▶ Measure whether the dimensions “=” **4** are equal.



- ▶ Affix the precision clearance gauges to the bearing positions of the crankshaft **5** (a) or (b) according to the manufacturer's instructions.



- ▶ Hold the con rod **6** in position.
- ▶ Tighten the con-rod bolts **7** in three stages.


Tightening torque:

First stage 10 Nm [7.4 lbf ft]

Second stage 20 Nm [14.8 lbf ft]

Third stage +115°

- ▶ Unscrew the con-rod bolts.
- ▶ Remove the con rod.




- ▶ Read con rod bearing play "A" **8** on the precision clearance gauges according to the manufacturer's instructions.

Required con rod bearing play:

0,025 – 0,040 mm

The thicknesses of the upper and lower con rod bearing shell may differ.


- ▶ If the con rod bearing play is incorrect, repeat the process using another con rod bearing shell thickness.
- ▶ Clean the bearing positions carefully.



The con rod bearing shells are marked on the side **9** in color. Each color represent a specific thickness of the con rod bearing shell.

Available thicknesses con rod bearing shells:

- Red 1,721 mm
- Yellow 1,726 mm
- Blue 1,731 mm
- Green 1,736 mm
- Brown 1,741 mm



020.01.10 Checking main bearing play



– Precision clearance gauges



– Main bearing shells in different thicknesses

NOTICE**Bearing damage, increased wear and leaks due to installing components swapped over.**

All components in the crank drive are inserted together. If the components are installed swapped over, they no longer fit together well.


- ▶ When removing the components, mark the cylinder assignment and installation position.
- ▶ Install all components back into the place from which they were removed.

The crankshaft, piston and con rod are removed.


NOTICE! Bearing damage due to incorrect con rod bearing play. When replacing the crankcase or crankshaft, the main bearing play must be checked.

Use the removed main bearing shells.


- ▶ Insert main bearing shells **1** in crankcase.




- ▶ Affix the precision clearance gauges to all bearing positions of the crankshaft **2** (a) according to the manufacturer's instructions.




- ▶ Insert the crankshaft **4**.
- ▶ Put the lower case **3** on.



- ▶ Assemble the oil pressure valve in the sequence as illustrated **5**.



- ▶ Insert the oil pressure valve **6**.



Screw in all bolts in the sequence as illustrated **7**.

- ▶ Screw in 5 bolts M8 **1** – **5**.

Tightening torque:


9 Nm +1 Nm [6.6 lbf ft +0.7 lbf ft]

- ▶ Screw in 4 bolts M6 **6** – **9**.

Tightening torque:

Maximum 5 Nm [3.7 lbf ft]

- ▶ Turn the engine 180°.




Information! The cylinder head gasket must be replaced after removal. However, when measuring the main bearing play, you can use the removed cylinder head gasket.

- ▶ Put the cylinder head gasket **8** on.

Observe the installation position:


- Exhaust side **9**
- Inscription **10**
- Centering pins **11**
- Starter side **12**



- ▶ Put the cylinder head **13** on.

Observe the installation position:

- Exhaust side **14**
- Starter side **15**



- ▶ Lubricate the nuts **16** with engine oil.
- ▶ Screw on the nuts by hand. Do not tighten.
- ▶ Tighten the nuts in the sequence as illustrated **17** in three stages.

Tightening torque:

First stage


20 Nm \pm 3 Nm [14.8 lbf ft \pm 2.2 lbf ft]

Second stage

40 Nm \pm 3 Nm [29.5 lbf ft \pm 2.2 lbf ft]

Third stage

$180^\circ \pm 4^\circ$



- ▶ Turn the engine 180° .

Tighten all bolts in the sequence as illustrated **18**.

- ▶ Tighten 5 bolts M8 **1** – **5**.


Tightening torque:

23 Nm \pm 2 Nm [17 lbf ft \pm 1.5 lbf ft]

- ▶ Tighten 4 bolts M6 **6** – **9**.


Tightening torque:

8 Nm \pm 2 Nm [5.9 lbf ft \pm 1.5 lbf ft]




- Turn the engine 180°.
- Unscrew the nuts **19** in the sequence as illustrated **20**.

The rocker arm and cross bars are no longer firmly attached to the cylinder head. Do not turn the cylinder head.




- Remove the cylinder head **21**.




- Turn the engine 180°.

Unscrew all bolts in the sequence as illustrated **22**.


- Unscrew 4 bolts M6 **1** – **4**.
- Unscrew 5 bolts M8 **5** – **9**.



- ▶ Pull the oil pressure valve **23** out using a bar magnet.

23

- ▶ Remove the lower case **24**.

24


- ▶ Read main bearing play "B" **25** on the precision clearance gauges according to the manufacturer's instructions.

Required main bearing play:

0,04 – 0,06 mm

The thicknesses of the upper and lower main bearing shell may differ.


- ▶ If the main bearing play is incorrect, repeat the process using another main bearing shell thickness.
- ▶ Clean the bearing positions carefully.

25

The main bearing shells are marked on the side **26** in color. Each color represent a specific thickness of the main bearing shells.

Available thicknesses main bearing shells:

- Red 1,990 mm
- Yellow 1,995 mm
- Blue 2,000 mm
- Green 2,005 mm
- Brown 2,010 mm




020.02.01 Removing stub shaft




– Locking tool crankshaft


- ▶ Hold the locking tool crankshaft **1** on rotor.
- ▶ Screw in the bolt **2** and washer.



- ▶ Unscrew the bolts **3**.
- ▶ Remove the locking tool crankshaft **4**.



- ▶ Remove the rotor **5**.
- ▶ Remove the stub shaft **6**.



020.02.02 Installing stub shaft



– Locking tool crankshaft




– 6 Bolts M10x1x35

NOTICE**Leaks due to damage to the coating on the bolts.**


The threads of the 6 bolts on the rotor have a micro encapsulated coating. During fastening the bolt, the microcapsules will burst and the contained adhesive and curing agent are released and mixed. The coating begins to cure within a short time. If the bolts are moved again later, the coating becomes ineffective and engine oil can escape.

- ▶ Replace the bolts after removing.
- ▶ After inserting the bolts by hand, continue the task quickly until the bolts are tight.
- ▶ Never tighten the bolts again later.


- ▶ Hold the stub shaft **1** in position.
- ▶ Slide on the rotor **2**.




- ▶ Replace the bolts **3**.
- ▶ Screw in the bolts by hand. Do not tighten.



- ▶ Hold the locking tool crankshaft **4** on rotor.
- ▶ Screw in the bolt **5** and washer.




- ▶ Tighten the bolts **6**.
Tightening torque:
60 Nm +10 Nm [44.3 lbf ft +7.4 lbf ft]
- ▶ Remove the locking tool crankshaft **7**.




020.03.01 Removing crankshaft cover

- Unscrew the bolt **2**.
- Remove the cover **1**.


020.03.02 Installing crankshaft cover

 – 1 Gasket crankshaft cover


- Replace the gasket **1**.
- Coat the gasket lightly with petroleum jelly.



- Insert the cover **2**.
- Screw in the bolt **3**.


Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]



030.01.01 Removing valve cover

- Unscrew the bolts **1**.
- Remove the valve cover **2**.



030.01.02 Installing valve cover




– 1 Sealing kit valve cover




– Anti-Seize assembly paste

- ▶ Replace the valve cover seals **1**.




- ▶ Clean the sealing surface **2** with sealing surface cleaner.



- ▶ Put the valve cover **3** on.
- ▶ Apply Anti-Seize assembly paste to all bolts **4**.
- ▶ Screw in the bolts in the sequence as illustrated **5**.


Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]




030.01.03 Replacing valve cover

- ▶ Replace the valve cover **1**.
- ▶ Affix the engine badge **2** included with the valve cover.



030.01.04 Removing ignition coils

- Unscrew the bolts **1**.
- Pull the ignition coils **2** out.



030.01.05 Installing ignition coils




- 2 Serrated lock washers

- Insert the ignition coils **3**.
- Replace the serrated lock washers **1**.
- Screw in the bolts **2**. Observe the arrangement of the serrated lock washers and washers.


Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]



030.01.06 Removing sensor camshaft

- Unscrew the bolt **1**.
- Pull the sensor camshaft **2** out.



030.01.07 Installing sensor camshaft

- Coat the o-ring **1** lightly with petroleum jelly.




- Insert the sensor camshaft **3**.

- Screw in the bolt **2**.

Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]



030.02.01 Removing cylinder head



– Chain tool



– Instruction manual chain tool


NOTICE
Engine damage from small components in the engine or cylinder head.

Operating the engine when there are small components in the crankcase and cylinder head can result in serious damage and cause the crank drive to seize.


- When removing small components, always cover the chain channel.

Setting valve timing


- Turn the crankshaft on a bolt **2** in the direction shown **1** until the camshaft stops as shown in the following figure.




- Check whether the camshaft is at the crossing point.
The position of the camshaft is as illustrated **4**.
The marking **3** ends flush with the cross bar.



- ▶ Mark the position of the rotor **5** to the crankcase **6**.




- ▶ Unscrew the chain tensioner **7**.
- ▶ Open the timing chain. (See the instruction manual of the chain tool.)
- ▶ Secure the ends of the timing chain.




- ▶ Unscrew the nuts **8** in the sequence as illustrated **9**.

The rocker arm and cross bars are no longer firmly attached to the cylinder head. Do not turn the cylinder head.



- ▶ Remove the cylinder head **10**.



030.02.02 Installing cylinder head


- Chain tool
- 12-point socket wrench 12
- Instruction manual chain tool
- Service manual of the engine




- 1 Cylinder head gasket
- 1 Chain tensioner
- 1 Chain link


NOTICE
Engine damage from small components in the engine or cylinder head.

Operating the engine when there are small components in the crankcase and cylinder head can result in serious damage and cause the crank drive to seize.

- When removing small components, always cover the chain channel.


- Check if the centering pins **1** are installed.



- Replace the cylinder head gasket **2**.
- Put the cylinder head gasket on.

Observe the installation position:


- Exhaust side **3**
- Inscription **4**
- Centering pins **5**
- Starter **6**



- ▶ Put the cylinder head **7** on.

Observe the installation position:

- Exhaust side **8**
- Starter **9**



- ▶ Lubricate the nuts **10** with engine oil.
- ▶ Screw on the nuts by hand. Do not tighten.
- ▶ Tighten the nuts in the sequence as illustrated **11** in three stages.

Tightening torque:

First stage


20 Nm \pm 3 Nm [14.8 lbf ft \pm 2.2 lbf ft]

Second stage

40 Nm \pm 3 Nm [29.5 lbf ft \pm 2.2 lbf ft]


Third stage

180° \pm 4°




Setting valve timing

- ▶ Check whether the camshaft is at the crossing point.
The position of the camshaft is as illustrated **13**.
The marking **12** ends flush with the cross bar.
- ▶ If the camshaft does not appear as shown, turn it.




- ▶ Check whether the crankshaft is at TDC (Top Dead Center).
The markings **15** fit together.
- ▶ If the markings do not line up, turn the rotor **14**.



- ▶ Close the timing chain. (See the instruction manual of the chain tool.)
- ▶ Replace the chain tensioner **16**.
- ▶ Screw in the chain tensioner.


Tightening torque:

40 Nm +5 Nm [29.5 lbf ft +3.7 lbf ft]




Checking valve timing


- ▶ Turn the crankshaft on a bolt **18** several times in the direction shown **17**.



- ▶ Turn the crankshaft on a bolt in the direction shown until the crankshaft is at TDC (Top Dead Center).
The markings **19** fit together.



- ▶ Check whether the camshaft is at the crossing point.
The position of the camshaft is as illustrated **21**.
The marking **20** ends flush with the cross bar.
- ▶ If the camshaft does not appear as shown, set the valve timing again.
or
- ▶ If the camshaft does not appear as shown several times, replace the timing chain. (See chapter 040.01.02 Replacing timing chain.)
- ▶ Check the valve lash. (See the service manual of the engine.)



030.02.03 Replacing cylinder head



- Remover bearing cap
- Stud extractor




- Lubricant for injectors o-rings
- Thread sealant


- Unscrew the bolts **1**.
- Remove the bracket **2**.




- 1 Seal 8x12x1 Al
- 1 Plug M8x1
- 1 Plug M10x1




- Unscrew the switch oil pressure **3**.




- Unscrew the bolt **5**.
- Remove the bracket **4**.
- Unscrew the fitting **6**.




- Unscrew the studs **7** using a stud extractor.




- Unscrew the bolts **8**.




- Remove the fuel rail **9**.




- Remove the sleeves **10**.



- Unscrew the bolt **12**.
- Remove the sensor knock **11**.




- Unscrew the bolts **13**.




The hole in the remover bearing cap is provided for mounting a slide hammer.


- Remove the bearing cap **15** using the remover bearing cap **14**.




- Remove the camshaft **16**.
- Replace the cylinder head **17**.



- Unscrew the bolts **18**.
- Remove the bearing cap **19**.
- Check if the sleeves **20** are installed.



- Coat the camshaft on the bearing surfaces **21** lightly with engine oil.




► Insert the camshaft.

The camshaft is marked at the 1st cylinder end only.

Observe the installation position:


- Inscription **22**
- Exhaust side **23**



NOT/CE! Bearing damage due to the bearing cap being installed incorrectly. The bearing surfaces for supporting the camshaft in the cylinder head and in the bearing cap are processed together. Therefore, only use the bearing cap originally installed. Observe the markings **24** during installation.

► Insert the bearing cap **25**.


Observe the installation position.



► Screw in the bolts **26**.

Tightening torque:


8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]




- ▶ Hold the sensor knock **27** in position.
- ▶ Screw in the bolt **28**.

Tightening torque:


20 Nm +4 Nm [14.8 lbf ft +3 lbf ft]



- ▶ Insert the sleeves **29**.




- ▶ Coat the o-rings **31** lightly with lubricant.
- ▶ Insert the fuel rail **30**.



- ▶ Screw in the bolts **32**.

Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]


32


- ▶ Apply Anti-Seize assembly paste to all studs **33**.

- ▶ Screw in the studs using a stud extractor.

Tightening torque:

16 Nm +4 Nm [11.8 lbf ft +3 lbf ft]

33


- ▶ Hold the bracket **34** in position as illustrated.
- ▶ Coat the thread on the bolt **35** with high strength thread locker.
- ▶ Screw in the bolt.

Tightening torque:


8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]

34
35

- ▶ Replace the seal **38**.
- ▶ Screw in the fitting **37**.

Tightening torque:


8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]

36
37


- ▶ Coat the thread on the switch oil pressure **38** with thread sealant.
- ▶ Screw in the switch oil pressure.

Tightening torque:

9 Nm +2 Nm [6.6 lbf ft +1.5 lbf ft]



- ▶ Screw in a new plug **39**.


Tightening torque:

6 Nm +2 Nm [4.4 lbf ft +1.5 lbf ft]

- ▶ Screw in a new plug **40**.

Tightening torque:

9 Nm +2 Nm [6.6 lbf ft +1.5 lbf ft]




- ▶ Hold the bracket **41** in position.

- ▶ Screw in the bolts **42**.


Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]



030.02.04 Removing spark plugs

► Unscrew the spark plugs **1** using a spark plug wrench.

**030.02.05 Installing spark plugs**

– Spark plug wrench size 16 mm




– Service manual of the engine

► Check the spark plugs. (See the service manual of the engine.)

► Screw in the spark plugs **1** using a spark plug wrench.


Tightening torque:

22 Nm +10 Nm [16.2 lbf ft +7.4 lbf ft]



030.02.06 Removing switch oil pressure

- Unscrew the switch oil pressure **1**.




030.02.07 Installing switch oil pressure

- Thread sealant

- Coat the thread on the switch oil pressure **1** with thread sealant.
- Screw in the switch oil pressure.


Tightening torque:

9 Nm +2 Nm [6.6 lbf ft +1.5 lbf ft]



030.02.08 Removing fitting

► Unscrew the fitting **1**.


**030.02.09 Installing fitting**

– 1 Seal 8x12x1 Al

► Replace the seal **1**.
► Screw in the fitting **2**.


Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]



030.02.10 Replacing plugs

- Plugs 1 **1**
- Plug 2 **2**
- Plug 3 **3**




Replacing plugs 1

- Unscrew the plugs **1**.
- Replace the plugs.
- Screw in the plugs.

Tightening torque:

6 Nm +2 Nm [4.4 lbf ft +1.5 lbf ft]




Replacing plug 2

- Unscrew the plug **1**.
- Replace the plug.
- Screw in the plug.

Tightening torque:

6 Nm +2 Nm [4.4 lbf ft +1.5 lbf ft]




Replacing plug 3

- Unscrew the plug **1**.
- Replace the plug.
- Screw in the plug.

Tightening torque:

9 Nm +2 Nm [6.6 lbf ft +1.5 lbf ft]

1



040.01.01 Replacing camshaft



- Remover bearing cap


NOTICE

Increased wear and leaks due to installing components swapped over.


All components in the valve train are inserted together. If the components are installed swapped over, they no longer fit together well.

- ▶ Install all components back into the place from which they were removed.


- ▶ Remove the rocker arms and cross bars **1**.
- ▶ Remove the valve adjustment shims **2** using a bar magnet.




- ▶ Unscrew the bolts **3**.



- ▶ Remove the bearing cap **5** using the remover bearing cap **4**.



- ▶ Remove the camshaft **6**.
- ▶ Replace the camshaft.
- ▶ Coat the camshaft on the bearing surfaces **7** lightly with engine oil.




- ▶ Insert the camshaft.

The camshaft is marked at the 1st cylinder end only.

Observe the installation position.

- Inscription **8**
- Intake side **9**




NOTICE! Bearing damage due to the bearing cap being installed incorrectly. The bearing surfaces for supporting the camshaft in the cylinder head and in the bearing cap are processed together. Therefore, only use the bearing cap originally installed.

Observe the markings **10** during installation.

- ▶ Insert the bearing cap **11**.


Observe the installation position.




- ▶ Screw in the bolts **12**.

Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]




- ▶ Insert the valve adjustment shims **14**.
- ▶ Insert the rocker arms and cross bars **13**.
Observe the installation instructions for rocker arms and cross bars.




Installation instructions for rocker arms and cross bars

Observe the installation position:

- Counterbore **15**



- Fuel rail **16**
- Rocker arm short **17** **19** with cam spike
- Rocker arm long **18** **20**



040.01.02 Replacing timing chain



– Chain tool



– Instruction manual chain tool




– 1 Chain tensioner

– 1 Chain link

Setting valve timing


- ▶ Turn the crankshaft on a bolt **2** in the direction shown **1** until the camshaft stops as shown in the following figure.




- ▶ Check whether the camshaft is at the crossing point.

The position of the camshaft is as illustrated **4**.

The marking **3** ends flush with the cross bar.




- ▶ Mark the position of the rotor **5** to the crankcase **6**.




Replacing timing chain


- Unscrew the chain tensioner **7**.
- Open the timing chain. (See the instruction manual of the chain tool.)



- Turn the engine 180°.
- Remove the timing chain **8**.
- Replace the timing chain.
- Insert the timing chain as illustrated.




- ▶ Insert the chain link **9** on the open ends of the timing chain.
- ▶ Turn the engine 180°.



Setting valve timing



- ▶ Check whether the camshaft is at the crossing point.
The position of the camshaft is as illustrated **11**.
The marking **10** ends flush with the cross bar.
- ▶ If the camshaft does not appear as shown, turn it.
- ▶ Check whether the crankshaft is at TDC (Top Dead Center).
The markings **13** fit together.
- ▶ If the markings do not line up, turn the rotor **12**.



- ▶ Close the timing chain. (See the instruction manual of the chain tool.)
- ▶ Replace the chain tensioner **14**.
- ▶ Screw in the chain tensioner.


Tightening torque:

40 Nm +5 Nm [29.5 lbf ft +3.7 lbf ft]




Checking valve timing

- Turn the crankshaft on a bolt **16** several times in the direction shown **15**.




- Turn the crankshaft on a bolt in the direction shown until the crankshaft is at TDC (Top Dead Center).

The markings **17** fit together.



- Check whether the camshaft is at the crossing point.
The position of the camshaft is as illustrated **19**.
The marking **18** ends flush with the cross bar.
- If the camshaft does not appear as shown, set the valve timing again.



040.01.03 Checking and setting valve timing



– TDC-Adjusting tool

– Chain tool



– Instruction manual chain tool




– 1 Chain tensioner

– 1 Chain link

- ▶ Hold the TDC-adjusting tool **2** in position. Observe the positioning pin and positioning bore **1**.

Use the M10x1x35 bolts you removed on the rotor.


- ▶ Screw in the bolts **3**.




Checking valve timing

Use a hexagon screwdriver socket 8 and reversible ratchet.


- ▶ Turn the crankshaft on the TDC-adjusting tool **5** in the direction shown **4** until the marking **7** ends flush with the crankcase halves **6**.




- ▶ Check whether the camshaft is at the crossing point.
The position of the camshaft is as illustrated **9**.
The marking **8** ends flush with the cross bar.
- ▶ If the camshaft does not appear as shown, continue with section **Setting valve timing**.




- Unscrew the bolts **11**.
- Remove the TDC-adjusting tool **10**.


Setting valve timing

- Unscrew the chain tensioner **12**.
- Open the timing chain. (See the instruction manual of the chain tool.)
- Secure the ends of the timing chain.




- Turn the camshaft until the position of the camshaft is as illustrated **14**.
- The marking **13** ends flush with the cross bar.



- Close the timing chain. (See the instruction manual of the chain tool.)
- Replace the chain tensioner **15**.
- Screw in the chain tensioner.

Tightening torque:

40 Nm +5 Nm [29.5 lbf ft +3.7 lbf ft]



- Turn the crankshaft on the TDC-adjusting tool several times in the direction shown.
- Check the valve timing again


040.01.04 Replacing chain rail

The cylinder head is removed.

- Unscrew the bolt **1**.
- Remove the chain rail **2**.
- Replace the chain rail.
- Insert the chain rail.
- Screw in the bolt.

Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]




040.01.05 Replacing chain guide

The upper case is disconnected from the lower case.

- Unscrew the bolts **1**.
- Remove the chain guide **2**.
- Replace the chain guide.
- Insert the chain guide.
- Screw in the bolts.

Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]



040.02.01 Replacing rocker arms



- Service manual of the engine

NOTICE

Increased wear and leaks due to installing components swapped over.

All components in the valve train are inserted together. If the components are installed swapped over, they no longer fit together well.

- ▶ Install all components back into the place from which they were removed.

NOTICE


Engine damage from small components in the engine or cylinder head.

Operating the engine when there are small components in the crankcase and cylinder head can result in serious damage and cause the crank drive to seize.

- ▶ When removing small components, always cover the chain channel.


Replacing a rocker arm on the 1st cylinder

- ▶ Turn the crankshaft on a bolt **2** in the direction shown **1** until the camshaft stops as shown in the following figure.




The camshaft is marked at the 1st cylinder end only.

- ▶ Check whether the camshaft is at the crossing point.
 The position of the camshaft is as illustrated.
 The marking **3** ends flush with the cross bar.
 All rocker arms **4** on the cylinder have a certain amount of play.
- ▶ Continue with the section **Replacing a rocker arm**.




Replacing a rocker arm on the 2nd cylinder

- ▶ Turn the crankshaft on a bolt **6** in the direction shown **5** until the camshaft stops as shown in the following figure.




The camshaft is marked at the 1st cylinder end only.

- ▶ Check whether the camshaft is at the crossing point.
 The position of the camshaft is as illustrated.
 The inscription **7** is not visible.
 All rocker arms **8** on the cylinder have a certain amount of play.
- ▶ Continue with the section **Replacing a rocker arm**.




Replacing a rocker arm

- Remove the rocker axle **9** using a universal pliers.




- Remove the rocker arm **10**.



- Replace the rocker arm **11**.
- Hold the rocker arm in position.
- Check if the circlip **13** is installed.
- Slide in the rocker axle **12**.

NOTICE! Valve breakage due to insufficient valve lash.

- Check the valve lash. (See the service manual of the engine.)



040.03.01 Removing valve



– Valve spring compressor

Information! The following chapter describes how to remove one valve. If you want to remove several valves, apply the procedure for any number of valves.


NOTICE**Increased wear and leaks due to installing components swapped over.**

All components in the valve train are inserted together. If the components are installed swapped over, they no longer fit together well.


- ▶ Install all components back into the place from which they were removed.

The cylinder head is removed.


- ▶ Remove the rocker arms and cross bars **1**.
- ▶ Remove the valve adjustment shim **2** using a bar magnet.




- ▶ Install the valve spring compressor according to the manufacturer's instructions.
- ▶ Press the valve spring **4** together using the valve spring compressor according to the manufacturer's instructions.
- ▶ Remove the collet valves **3** using a bar magnet.
- ▶ Remove the valve spring compressor.




- Remove the spring cup **5**, valve spring **6** and spring pad **7**.



- Pull the valve **8** out.



- Remove the valve stem seal **9**.



040.03.02 Installing valve



- Piston ring compressor
- Valve spring compressor



- 1 Valve stem for each removed valve



- Valve grinding compound


Information! The following chapter describes how to install a valve. If you want to install several valves, apply the procedure for any number of valves.

NOTICE**Increased wear and leaks due to installing components swapped over.**


All components in the valve train are inserted together. If the components are installed swapped over, they no longer fit together well.

- ▶ Install all components back into the place from which they were removed.

- ▶ Replace the valve stem seal **2**.
- ▶ Install the valve stem seal using a installation spike valve stem seal **1**.




- ▶ Coat the valve stem **3** lightly with engine oil.
- ▶ Slide in the valve.
- ▶ Insert the valve using the valve refacer.




Valve springs are sidewise color-coded. If you replace valve springs, all installed valve springs must have the same color-code.


- ▶ Insert the spring pad **6**, valve spring **5** and spring cup **4**.



- ▶ Install the valve spring compressor according to the manufacturer's instructions.
- ▶ Press the valve spring **8** together using the valve spring compressor according to the manufacturer's instructions.
- ▶ Insert the collet valves **7**.
- ▶ Remove the valve spring compressor.




- ▶ Insert the valve adjustment shims **10**.
- ▶ Insert the rocker arms and cross bars **9**. Observe the installation instructions for rocker arms and cross bars.




Installation instructions for rocker arms and cross bars

Observe the installation position:

- Counterbore **11**




- Fuel rail **12**
- Rocker arm short **13** **15** with cam spike
- Rocker arm long **14** **16**




050.01.01 Removing thermostat housing

- Unscrew 10 bolts **1**.



The thermostat housing is caulked with a silicone liquid seal.


- Remove the thermostat housing **2**.




050.01.02 Installing thermostat housing

– Silicone liquid seal


- ▶ Clean the sealing surface **1** with sealing surface cleaner.




- ▶ Clean the sealing surface **2** with sealing surface cleaner.



- ▶ Apply the silicone liquid seal **3** without gaps as illustrated.




► Hold the thermostat housing **4** in position.



► Screw in 10 bolts **5**.


Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]




050.01.03 Removing fitting

- Unscrew 2 bolts **1**.




- Remove the fitting **2**.


050.01.04 Installing fitting

- 1 O-ring fitting thermostat housing


- Replace the o-ring **1**.
- Coat the o-ring lightly with petroleum jelly.
- Insert the fitting **2**.



- Screw in 2 bolts **3**.

Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]




050.01.05 Replacing thermostat




- 1 Distance washer

- Remove the thermostat **1** and distance washer **2**.




- Replace the thermostat **3**.
- Replace the distance washer **4**.
- Put the distance washer on thermostat.



Observe the installation position:

- Locating tab **5** at thermostat
- Insert the thermostat **6**.




050.01.06 Replacing sensor coolant temperature

– Thread sealant

- ▶ Unscrew the sensor coolant temperature **1**.
- ▶ Replace the sensor coolant temperature.
- ▶ Coat the thread on the sensor coolant temperature with thread sealant.
- ▶ Screw in the sensor coolant temperature.

Tightening torque:

18 Nm +7 Nm [13.3 lbf ft +5.2 lbf ft]



050.01.07 Replacing plug thermostat housing




– Thread sealant

- ▶ Unscrew the plug **1**.
- ▶ Replace the plug.
- ▶ Coat the thread on the plug with thread sealant.
- ▶ Screw in the plug.


Tightening torque:

14 Nm +2 Nm [10.3 lbf ft +1.5 lbf ft]



050.01.08 Removing closing cap thermostat housing


- Open the hose clamp **2**.
- Remove the closing cap **1**.

**050.01.09 Installing closing cap thermostat housing**

- Insert the closing cap **1**.
- Close the hose clamp **2**.

Tightening torque:

3 Nm +0,5 Nm [2.2 lbf ft +0.4 lbf ft]




050.02.01 Removing impeller




– Locking tool crankshaft

- ▶ Hold the locking tool crankshaft **1** on rotor.
- ▶ Screw in the bolt **2** and washer.



- ▶ Unscrew the nut **3**.
- ▶ Remove the impeller **4**.



050.02.02 Installing impeller



– Locking tool crankshaft




– Thread locker, medium strength

The locking tool crankshaft is still installed.


- ▶ Insert the impeller **1**.
- ▶ Coat the thread on the water pump axle **2** with medium strength thread locker.
- ▶ Screw on the nut **3**.

Tightening torque:

6 Nm +2 Nm [4.4 lbf ft +1.5 lbf ft]



- ▶ Remove the locking tool crankshaft **4**.




050.02.03 Removing coolant pump



– Locking tool crankshaft

The locking tool crankshaft is still installed.

- Unscrew the water pump axle **1** using a open-end wrench.



050.02.04 Installing coolant pump




- Locking tool crankshaft
- Assembling kit slide ring seal




- 1 Repair kit slide ring seal

The locking tool crankshaft is still installed.


- Replace the water pump axle **1**.
- Screw in the water pump axle using a open-end wrench. Avoid damaging the water pump axle when doing so.




- Replace the sealing bracket **2**.
- Coat the gasket **3** and o-ring **4** lightly with petroleum jelly.
- Coat the inside of the oil seal **5** lightly with petroleum jelly.




- Insert the sealing bracket **6**.




- ▶ Screw in the guide **7** using a open-end wrench.



- ▶ Replace the slide ring seal **8**.
- ▶ Slide the slide ring seal onto guide.



- ▶ Hold the sliding sleeve **9** in position.
- ▶ Screw on the nut **10**.




- ▶ Screw in the nut **11** using a open-end wrench until the slide ring seal is inserted completely.

Tightening torque:


10 Nm +1 Nm [7.4 lbf ft +0.7 lbf ft]



- ▶ Unscrew the nut **13**.
- ▶ Remove the sliding sleeve **12**.




- ▶ Unscrew the guide **14** using a open-end wrench.




050.03.01 Removing oil cooler

- Unscrew the bolts **1**.




- Remove the oil cooler **2**.



050.03.02 Installing oil cooler

– 4 Gaskets oil cooler


- ▶ Replace the gaskets **1**.
- ▶ Insert the gaskets into the grooves and lightly coat with petroleum jelly.



- ▶ Hold the oil cooler **2** in position.
- ▶ Screw in the bolts **3**.

Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]



060.01.01 Instructions for mounting nuts and exhaust gasket



– 8 Nuts
– 2 Exhaust gaskets




– Anti-Seize assembly paste


- ▶ Replace the nuts **1**.
- ▶ Apply Anti-Seize assembly paste thoroughly to all studs **2**.
- ▶ Screw on the nuts.

Tightening torque:

22 Nm +4 Nm [16.2 lbf ft +3 lbf ft]



- ▶ Replace the exhaust gaskets **3**.



060.01.02 Replacing studs



– Stud extractor




– Anti-Seize assembly paste

- ▶ Unscrew the studs **1** using a stud extractor.
- ▶ Replace the studs.
- ▶ Apply Anti-Seize assembly paste to all studs.
- ▶ Screw in the studs using a stud extractor.


Tightening torque:

16 Nm +4 Nm [11.8 lbf ft +3 lbf ft]




070.01.01 Removing intake manifold


► Unscrew 4 bolts **1**.



► Unscrew the bolts **2**.



► Remove the intake manifold **3**.




070.01.02 Installing intake manifold




- 2 O-rings intake manifold

- ▶ Replace the o-rings **2**.
- ▶ Insert the o-rings into the grooves **1** and lightly coat with petroleum jelly.



- ▶ Hold the intake manifold **3** in position.
- ▶ Screw in the bolts **4** lightly. Do not tighten.



- ▶ Screw in 4 bolts **5**.

Tightening torque:


8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]



- ▶ Tighten the bolts **6**.


Tightening torque:

20 Nm +4 Nm [14.8 lbf ft +3 lbf ft]



070.01.05 Removing sensor intake manifold pressure/temperature

- Unscrew the bolt **1**.
- Pull the sensor intake manifold pressure/temperature **2** out.



070.01.06 Installing sensor intake manifold pressure/temperature


- Coat the o-ring **1** lightly with petroleum jelly.



- Insert the sensor intake manifold pressure/temperature **3**.
- Screw in the bolt **2**.

Tightening torque:

4,5 Nm +1 Nm [3.3 lbf ft +0.7 lbf ft]



070.01.07 Replacing cap




– Clamp pincer



– 1 Hose clamp 8.8-10.5/5


The hose clamp will be destroyed during removal.

- ▶ Remove the hose clamp **1**.
- ▶ Remove the cap **2**.
- ▶ Replace the cap.
- ▶ Insert the cap.
- ▶ Replace the hose clamp.
- ▶ Close the hose clamp using a clamp pincer.




070.02.01 Removing throttle body

- ▶ Open the hose clamp **1**.




- ▶ Remove the throttle body **2**.



070.02.02 Installing throttle body


- ▶ Insert the hose clamp **2** and throttle body **1**.



- ▶ Close the hose clamp **3**.

Tightening torque:


3 Nm +0,5 Nm [2.2 lbf ft +0.4 lbf ft]w



070.02.03 Replacing throttle body

Information! When replacing the throttle body, it must be recalibrated. Before putting the engine into operation again, turn the ignition on for about a minute, until the throttle body opens and closes again.

- Unscrew the bolts **1**.
- Remove the rubber mount **2**.




- Replace the throttle body **4**.
- Hold the rubber mount **5** in position.


Observe the orientation of the throttle body to the rubber mount. Screw in the bolts evenly crosswise.

- Screw in the bolts **3** by hand. Do not tighten.
- Tighten the bolts.

Tightening torque:
8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]




- Observe the orientation of the throttle body to the rubber mount.
A regular edge **6** is visible.



070.02.04 Replacing rubber mount

- Unscrew the bolts **1**.
- Remove the rubber mount **2**.




- Replace the rubber mount **5**.
- Hold the rubber mount in position.

Observe the orientation of the throttle body **4** to the rubber mount. Screw in the bolts evenly crosswise.

- Screw in the bolts **3** by hand. Do not tighten.
- Tighten the bolts.


Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]




- Observe the orientation of the throttle body to the rubber mount.

A regular edge **6** is visible.




090.01.01 Removing starter

- Unscrew 2 bolts **1**.



- Unscrew the bolt **3**.
- Remove the starter **2**.




090.01.02 Installing starter




- 1 O-ring starter

- Replace the o-ring **1**.
- Coat the o-ring lightly with petroleum jelly.




- Hold the starter **2** in position.
- Screw in the bolt **3** lightly. Do not tighten.



- Screw in 2 bolts **4**.

Tightening torque:


40 Nm +8 Nm [29.5 lbf ft +5.9 lbf ft]



- Tighten the bolt **5**.


Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]



090.01.03 Replacing starter


- Unscrew the bolt **2**.
- Remove the bracket **1**.



- Replace the **3** starter.
- Hold the bracket **4** in position.
- Screw in the bolt **5**.

Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]




090.02.01 Removing generator




– Locking tool crankshaft


- ▶ Hold the locking tool crankshaft **1** on rotor.
- ▶ Screw in the bolt **2** and washer.




- ▶ Unscrew the bolts **3**.
- ▶ Remove the locking tool crankshaft **4**.



- Remove the rotor **5**.
- Remove the stub shaft **6**.




- Unscrew the bolts **7**.



The connector plug of the stator is not shown.

- Disconnect the connector plug of the stator.
- Remove the stator **8**.
- Remove the distance washer **9**.



090.02.02 Installing generator



– Locking tool crankshaft



– 6 Bolts M10x1x35




– Thread locker, medium strength

NOTICE**Leaks due to damage to the coating on the bolts.**


The threads of the six bolts on the rotor have a micro encapsulated coating. During fastening the bolt, the microcapsules will burst and the contained adhesive and curing agent are released and mixed. The coating begins to cure within a short time. If the bolts are moved again later, the coating becomes ineffective and engine oil can escape.

- ▶ Replace the bolts after removing.
- ▶ After inserting the bolts by hand, continue the task quickly until the bolts are tight.
- ▶ Never tighten the bolts again later.

- ▶ Check if the sleeves **1** are installed.



- ▶ Insert the distance washer **2**.
- ▶ Hold the stator **3** in position.




- ▶ Coat the thread on the bolts **4** with medium strength thread locker.
- ▶ Screw in the bolts.

Tightening torque:


7 Nm +1 Nm [5.2 lbf ft +0.7 lbf ft]

The connector plug of the stator is not shown.


- ▶ Connect the connector plug of the stator.




- ▶ Hold the stub shaft **5** in position.
- ▶ Slide on the rotor **6**.




- ▶ Replace the bolts **7**.
- ▶ Screw in the bolts by hand. Do not tighten.



- ▶ Hold the locking tool crankshaft **8** on rotor.
- ▶ Screw in the bolt **9** and washer.



- ▶ Tighten the bolts **10**.
 - Tightening torque:
60 Nm +10 Nm [44.3 lbf ft +7.4 lbf ft]
- ▶ Remove the locking tool crankshaft **11**.




100.01.01 Removing fuel rail

⚠ WARNING**Burn injuries due to ignited fuel.**


Fuel is highly flammable. Leaks in the fuel system can lead to burns and vapors may ignite and cause an explosion.

- ▶ When working on the fuel system, observe the safety messages in chapter 2.2 **Important safety messages**.
- ▶ Only remove the fuel rail if absolutely necessary.
- ▶ If you find that the fuel rail or injectors are defective, replace them immediately,
- ▶ If you find that o-rings are defective, replace the injector immediately.
- ▶ After the repair, always ensure that the fuel system has no leaks.

▶ Unscrew the bolts **1**.



▶ Remove the fuel rail **2**.



100.01.02 Installing fuel rail




- Lubricant for injectors o-rings

! WARNING**Burn injuries due to ignited fuel.**

Fuel is highly flammable. Leaks in the fuel system can lead to burns and vapors may ignite and cause an explosion.

- ▶ When working on the fuel system, observe the safety messages in chapter 2.2 **Important safety messages**.
- ▶ Only remove the fuel rail if absolutely necessary.
- ▶ If you find that the fuel rail or injectors are defective, replace them immediately,
- ▶ If you find that o-rings are defective, replace the injector immediately.
- ▶ After the repair, always ensure that the fuel system has no leaks.


- ▶ Coat the o-rings **2** lightly with lubricant for injectors o-rings.
- ▶ Insert the fuel rail **1**.



- ▶ Screw in the bolts **3**.

Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]



100.01.03 Replacing injector



- Lubricant for injectors o-rings


⚠ WARNING**Burn injuries due to ignited fuel.**

Fuel is highly flammable. Leaks in the fuel system can lead to burns and vapors may ignite and cause an explosion.


- ▶ When working on the fuel system, observe the safety messages in chapter 2.2 **Important safety messages**.
- ▶ Only remove the injectors if you have to replace them.
- ▶ If you find that the fuel rail or injectors are defective, replace them immediately,
- ▶ If you find that o-rings are defective, replace the injector immediately.
- ▶ After the repair, always ensure that the fuel system has no leaks.

WARNING! Serious eye injuries due to a flying bracket. Wear protective glasses.


- ▶ Carefully push apart the brackets **1**.




- ▶ Pull the injector **2** out.



- ▶ Replace the injector **4**.
- ▶ Coat the o-ring **3** lightly with lubricant for injectors o-rings.
- ▶ Insert the injector until it engages in the bracket.




- ▶ Check that the injector is engaged in the bracket **5**.




110.01.01 Removing suction pump cover

- Turn the engine 180°.
- Unscrew 14 bolts **1**.




The suction pump cover is caulked with a silicone liquid seal.

- Prize off the suction pump cover using the grooves **2**.



- Remove the suction pump cover **3**.




110.01.02 Installing suction pump cover




– Silicone liquid seal


- ▶ Clean the sealing surface **1** with sealing surface cleaner.




- ▶ Clean the sealing surface **2** with sealing surface cleaner.




- ▶ Check if the sleeves **3** are installed.



- ▶ Apply the silicone liquid seal **4** without gaps as illustrated.



- ▶ Put the suction pump cover **5** on.



- ▶ Screw in 7 bolts M6x20 **A**.

Tightening torque:


8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]

- ▶ Screw in 7 bolts M6x30 **B**.

Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]

- ▶ Turn the engine 180°.



110.01.03 Replacing suction pump cover



– 1 Seal 18x22x1.5 Al




– Thread sealant

- ▶ Replace the suction pump cover **1**.
- ▶ Replace the seals **2**.
- ▶ Coat the thread on the fittings **3** with thread sealant.
- ▶ Screw in the fittings.


Tightening torque:

10 Nm +2 Nm [7.4 lbf ft +1.5 lbf ft]




110.01.04 Removing oil suction pump

- ▶ Unscrew the bolts **1**.
- ▶ Remove the oil screen **2**.



- ▶ Unscrew the bolts **3**.
- ▶ Remove the oil suction pump **4**.




110.01.05 Installing oil suction pump

- ▶ Insert the oil suction pump **2**.
- ▶ Screw in the bolts **1**.

Tightening torque:


8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]



- ▶ Insert the oil screen **4**.
- ▶ Screw in the bolts **3**.

Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]



110.01.06 Replacing fitting

– 1 Seal 18x22x1.5 Al




– Thread sealant

- ▶ Turn the engine 180°.
- ▶ Unscrew the fitting **1**.
- ▶ Replace the fitting.
- ▶ Replace the seal **2**.
- ▶ Coat the thread on the fitting with thread sealant.
- ▶ Screw in the fitting.

Tightening torque:

10 Nm +2 Nm [7.4 lbf ft +1.5 lbf ft]

- ▶ Turn the engine 180°.




110.01.07 Removing intermediate gear suction pump




- Pin punch axle intermediate gear


- Unscrew the plug **1**.



- Punch the axle **3** out using the pin punch axle intermediate gear **2** and plastic hammer.



- Remove the intermediate gear suction pump **4**.




110.01.08 Installing intermediate gear suction pump



- 1 Seal 18x22x1.5 Al


- ▶ Hold the intermediate gear suction pump **1** in position.
- ▶ Slide in the axle **2**. Observe the position of the bevel **3**.



- ▶ Replace the seal **4**.
- ▶ Screw in the plug **5**.

Tightening torque:


20 Nm +4 Nm [14.8 lbf ft +3 lbf ft]




110.02.01 Removing oil pressure pump

WARNING! Serious eye injuries due to a flying circlip. Wear protective glasses.


- ▶ Remove the circlip **1** using a lockring pliers.
- ▶ Remove the oil pump cover **2** using a universal pliers.



- ▶ Remove the outer rotor **3** of the oil pressure pump.
- ▶ Remove the inner rotor **4** of the oil pressure pump.
- ▶ Remove the key **5**.



- ▶ Remove the timing insert **6**.




110.02.02 Installing oil pressure pump



- 4 O-rings oil pump cover

NOTICE! Engine damage due to the lack of lubrication. If the timing insert is installed in reverse, the engine cannot build up any oil pressure. Insert the side with centering pin **1** first.

- Insert the timing insert **2**. Observe the installation position.




NOTICE! Engine damage due to the lack of lubrication. If the key **3** is not installed, the engine cannot build up any oil pressure. Always install the key.

- Replace the key.

- Insert the key.

- Insert the inner rotor **4** of the oil pressure pump.

- Insert the outer rotor **5** of the oil pressure pump.




- Replace the o-rings **6**.

- Coat the o-rings lightly with petroleum jelly.

- Insert the oil pump cover **7**.


WARNING! Serious eye injuries due to a flying circlip. Wear protective glasses.

- Install the circlip **8** using a lockring pliers.




110.03.01 Removing oil pressure valve

- Unscrew the bolt **1**.




- Pull the oil pressure valve **2** out using a bar magnet.




110.03.02 Installing oil pressure valve

► Assemble the oil pressure valve in the sequence as illustrated **1**.




► Insert the oil pressure valve **2**.



► Screw in the bolt **3**.

Tightening torque:

23 Nm +2 Nm [17 lbf ft +1.5 lbf ft]




110.04.01 Removing oil filter



– Universal strap wrench

- Unscrew the oil filter **1** using a universal strap wrench.




110.04.02 Installing oil filter



– 1 Oil filter


- Replace the oil filter **1**.
- Clean the sealing surface **2** with sealing surface cleaner.
- Coat the oil filter seal **3** lightly with engine oil.



- Screw in the oil filter **4** by hand.

Tightening torque:


10 Nm [7.4 lbf ft]



110.04.03 Removing threaded sleeve

– Crown wrench

- Unscrew the threaded sleeve **1** using a crown wrench.


**110.04.04 Installing threaded sleeve**

– Crown wrench

- Screw in the threaded sleeve **1** using a crown wrench.


Tightening torque:

17 Nm +3 Nm [12.5 lbf ft +2.2 lbf ft]



120.01.01 Removing bracket on the drive side

- Unscrew the bolt **2**.
- Remove the bracket **1**.




120.01.02 Installing bracket on the drive side

 – Thread locker, high strength


- Hold the bracket **1** in position as illustrated.
- Coat the thread on the bolt **2** with high strength thread locker.
- Screw in the bolt.

Tightening torque:
8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]



120.01.03 Removing pipe clamp

- Unscrew the bolt **2**.
- Remove the pipe clamp **1**.




120.01.04 Installing pipe clamp

- Hold the pipe clamp **1** in position.
- Screw in the bolt **2**.


Tightening torque:

8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]



120.01.05 Removing bracket across from the drive side


- Unscrew the bolts **2**.
- Remove the bracket **1**.



120.01.06 Installing bracket across from the drive side

- Hold the bracket **1** in position.
- Screw in the bolts **2**.

Tightening torque:
8 Nm +2 Nm [5.9 lbf ft +1.5 lbf ft]



Appendix**Overview of revisions**

Revision	Date	Chapter	Description	Note
Rev 1.0	04.09.2015	–	1st edition repair manual	–

Index**B**

Balance shaft, replace 108
Blanking cover, replace 76
Bracket 120.01, install 228, 230
Bracket 120.01, remove 228, 230

C

Camshaft, replace 156
Cap, replace 196
Chain guide, replace 167
Chain rail, replace 166
Closing cap, install 183
Closing cap, remove 183
Con rod bearing play, check 118
Con rod, install 111
Con rod, remove 109
Con rod, replace 116
Coolant pump, install 187
Coolant pump, remove 186
Cover oil cooler bracket, seal 78
Crankcase, replace 47
Crank drive, install 93
Crank drive, remove 88
Crankshaft cover, remove 131
Crankshaft, replace 107
Cylinder head, install 139
Cylinder head, remove 137
Cylinder head, replace 143
Cylinder liners, replace 62

E

Exhaust gaskets, replace 192

F

Fitting 010.01-3, install 69
Fitting 010.01-3, remove 69
Fitting 030.02, install 153
Fitting 030.02, remove 153
Fitting 050.01, install 179
Fitting 050.01, remove 179
Fitting 110.01, replace 219
Fuel rail, install 210
Fuel rail, remove 209

G

Generator cover, install 82
Generator cover, remove 81

Generator cover, replace 85
Generator, install 206
Generator, remove 204

I

Ignition coils, remove 135
Impeller, install 185
Impeller, remove 184
Injector, replace 211
Intake manifold, install 194
Intake manifold, remove 193
Intermediate gear suction pump, install 221
Intermediate gear suction pump, remove 220

M

Main bearing play, check 121

N

Nuts 062.01, replace 192

O

Oil cooler bracket, install 74
Oil cooler bracket, remove 72
Oil cooler, install 191
Oil cooler, remove 190
Oil filter, install 226
Oil filter, remove 226
Oil pressure pump, install 223
Oil pressure pump, remove 222
Oil pressure valve, install 225
Oil pressure valve, remove 224
Oil seal 010.01-2, replace 63
Oil seal 010.03, replace 86
Oil suction pump, install 218
Oil suction pump, remove 217

P

Pipe clamp, install 229
Pipe clamp, remove 229
Piston, install 111
Piston, remove 109
Piston, replace 113
Plug 010.01-1, replace 60
Plug 010.01-2, replace 65
Plug 010.01-3, install 66
Plug 010.01-3, remove 66
Plug 010.01-3, replace 67
Plug 010.02-2, replace 77

Plug 030.02, replace 154
Plug 050.01, replace 182

R

Rocker arm, replace 168
Rubber mount, replace 200

S

Sensor camshaft, remove 136
Sensor coolant temperature, replace 181
Sensor crankshaft, install 70
Sensor crankshaft, remove 70
Sensor intake manifold pressure/temperature, install 195
Sensor intake manifold pressure/temperature, remove 195
Sensor knock, install 71
Sensor knock, remove 71
Spark plugs, install 151
Spark plugs, remove 151
Special tools, overview 17
Starter, install 202
Starter, remove 201
Starter, replace 203
Stub shaft, install 129
Stub shaft, remove 128
Studs, replace 192
Suction pump cover, install 214
Suction pump cover, remove 213
Suction pump cover, replace 216
Switch oil pressure, install 152
Switch oil pressure, remove 152

T

Thermostat housing, install 177
Thermostat housing, remove 176
Thermostat, remove 180
Threaded sleeve, install 227
Threaded sleeve, remove 227
Throttle body, install 198
Throttle body, remove 197
Throttle body, replace 199
Tie rod, replace 59
Timing chain, replace 160
Tool case, overview 17

V

Valve cover, install 133
Valve cover, remove 132
Valve cover, replace 134
Valve, install 173

Valve, remove 171
Valve timing, check 164
Vent plug, replace 87

W

Welch plug, replace 58