

Arctic Cat® Prowler

Installation Instructions - Accessory Kit

VXC Glass Windshield Kit

(p/n 1436-648)



■ NOTE: Read these Installation Instructions thoroughly before beginning the installation process. Retain these Installation Instructions for future reference.

Kit includes:

Ref. No.	p/n	QTY	DESCRIPTION
1	N/A	1	Windshield
2	2441-224	8	Rubber Clamp
3	N/A	8	Machine Screw
4	N/A	8	Flat Washer
5	N/A	8	Nut
6	N/A	1	Adhesive Foam
1436-0453-845	1	1	Hardware Kit
		1	Instructions

Tools Needed: T30 Torx and a 10 mm socket.

1. Thoroughly clean the installation area on the vehicle.
2. Apply Adhesive Foam (6) along the inside perimeter of the Windshield (1); then align windshield with the hood and front ROPS tubes. See Fig. 1.

3. Place eight Rubber Clamps (2) on the forward-most section of the ROPS making sure the flat side of the clamp is facing toward the front of the vehicle.
4. Secure the windshield to the ROPS using eight Machine Screws (3), eight Flat Washers (4), and eight Nuts (5).

CAUTION

Do not over-tighten the nuts. Damage to the windshield may occur.

Fig. 1

