

Arctic Cat® ROV/ATV Installation Instructions

Black Magic Wheels/Trailfinder Tires Kit (1436-681)



■ **NOTE:** Read these Installation Instructions thoroughly before beginning the installation process. Retain these Installation Instructions for future reference.

Kit includes:

p/n	QTY	DESCRIPTION
1436-620	2	Front Wheel (14 x 6.5)
1436-621	2	Rear Wheel (14 x 8)
1436-750	2	Front Tire (26 x 10 x R14)
1436-762	2	Rear Tire (26 x 12 x R14)
0423-618	16	Lug Nut
2441-293	4	Wheel Cap
0402-064	4	Valve Stem
0453-847	1	Instructions

■ **NOTE:** It is very important to use the proper tools when repairing or replacing tires to prevent damage to the tire bead or wheel rims. If proper tools and related items are not available, have this maintenance performed by an authorized Arctic Cat dealer or a qualified tire repair station.

1. Park the vehicle on level ground and engage the parking brake and the differential lock.
2. Loosen the lug nuts on the wheel to be removed.
3. Elevate the vehicle.
4. Remove the lug nuts; then remove and discard the wheel and tire.
5. Install new Wheel and tire and install with new Lug Nuts. Using a crisscross pattern, tighten the wheel nuts in 20 ft-lb increments to a final torque factor of 80 ft-lb.
6. Remove the vehicle from the jack. Repeat for other three wheel/tires.

