



ARCTIC CAT®
www.ace.ag

DVX 400

STREET-LEGAL



2006

Illustrated Parts Manual

TABLE OF CONTENTS

2006 ATV DVX 400 Street Legal

Red - (Model No. A2006DVI2AUSR)

Black-Red - (Model No. A2006DVI2AUSD)

Black-Cat Green - (Model No. A2006DVI2AUSE)

Tony Stewart Edition - (Model No. A2006DVI2AUSX)


BODY PANEL ASSEMBLY	1
HEADLIGHT AND TAILLIGHT ASSEMBLIES	2
DECALS	3
DECALS (Tony Stewart Edition)	4
SEAT ASSEMBLY	5
CYLINDER HEAD COVER	6
CYLINDER HEAD ASSEMBLY	7
CYLINDER ASSEMBLY	8
CRANKCASE ASSEMBLY	9
CRANKCASE COVER ASSEMBLY	10
CRANKSHAFT ASSEMBLY	11
STARTER CLUTCH ASSEMBLY	12
CRANK BALANCER ASSEMBLY	13
CAMSHAFT/VALVE ASSEMBLY	14
CAM CHAIN ASSEMBLY	15
CARBURETOR ASSEMBLY	16
AIR CLEANER ASSEMBLY	17
EXHAUST ASSEMBLY	18
OIL PUMP ASSEMBLY	19
OIL TANK AND HOSE ASSEMBLY	20
WATER PUMP ASSEMBLY	21
RADIATOR ASSEMBLY	22
RADIATOR HOSE ASSEMBLY	23
CLUTCH ASSEMBLY	24
TRANSMISSION ASSEMBLY	25
GEAR SHIFTING ASSEMBLY	26
STARTER MOTOR ASSEMBLY	27
MAGNETO ASSEMBLY	28
ELECTRICAL ASSEMBLY	29
BATTERY ASSEMBLY	30
INDICATOR LIGHT ASSEMBLY	31
WIRING HARNESS ASSEMBLY	32
FRAME ASSEMBLY	33
REAR BRAKE PEDAL ASSEMBLY	34
FOOTREST ASSEMBLY	35
GAS TANK ASSEMBLY	36
HANDLEBAR ASSEMBLY	37
REVERSE LOCK ASSEMBLY	38
CONTROLS	39
TIE ROD ASSEMBLY	40
STEERING POST ASSEMBLY	41
FRONT SUSPENSION ASSEMBLY	42
FRONT WHEEL ASSEMBLY	43
FRONT BRAKE ASSEMBLY	44
FRONT BRAKE HOSE ASSEMBLY	45
FRONT MASTER CYLINDER ASSEMBLY	46
SWING ARM ASSEMBLY	47
REAR SUSPENSION ASSEMBLY	48
RIGHT REAR WHEEL ASSEMBLY	49
LEFT REAR WHEEL ASSEMBLY	50
REAR BRAKE ASSEMBLY	51
REAR MASTER CYLINDER ASSEMBLY	52
RELATED ITEMS	Back Cover

■ **NOTE:** The illustrations used in this Parts Manual are for reference to replacement part numbers only and are not to be used for assembly. For assembly procedures, use an Arctic Cat Service Manual. Underlined part numbers are new for the 2006 model

2006 Arctic Cat AG

Printed March 2006



®™ Trademarks of Arctic Cat Inc., Thief River Falls, MN 56701



BODY PANEL ASSEMBLY

0740-380R


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	1406-445	1	Panel, Body - Red		1406-491	1	Panel, Trim - Left - Cat Green (Black-Cat Green)
	1406-486	1	Panel, Body - Black (Black-Red/Black-Cat Green)	14	0423-489	10	Nut, Stamped
	<u>2406-126</u>	1	Panel, Body - TS Orange	15	1406-449	1	Fender, Front - Right - Red
2	0423-494	2	Rivet, Reinstallable		1406-450	1	Fender, Front - Left - Red
3	1406-451	1	Fender, Rear - Right - Red		1406-492	1	Fender, Front - Right - Cat Green (Black-Cat Green)
	1406-452	1	Fender, Rear - Left - Red		1406-493	1	Fender, Front - Left - Cat Green (Black-Cat Green)
	1406-494	1	Fender, Rear - Right - Cat Green (Black-Cat Green)		<u>2406-128</u>	1	Fender, Front - Right - TS Orange
	1406-495	1	Fender, Rear - Left - Cat Green (Black-Cat Green)		<u>2406-129</u>	1	Fender, Front - Left - TS Orange
	<u>2406-130</u>	1	Fender, Rear - Right - TS Orange	16	1506-301	1	Bracket, Mounting - Front Fender - Right
	<u>2406-131</u>	1	Fender, Rear - Left - TS Orange		1506-302	1	Bracket, Mounting - Front Fender - Left
4	0423-459	4	Clip, Mounting	17	0623-269	2	Clip, Retaining
5	8476-616	12	Screw, Machine	18	AC006-009	1	Cover, Tank - Red
6	8050-212	12	Washer		AC006-010	1	Cover, Tank - Black (Black-Red/Black-Cat Green)
7	0624-250	12	Nut, Lock		<u>2406-127</u>	1	Cover, Tank - TS Orange
8	1506-306	1	Bracket, Mounting - Rear Fender - Right	19	8424-502	1	Nut, Lock
	1506-305	1	Bracket, Mounting - Rear Fender - Left	20	1506-413	1	Bracket, Mounting - Reverse Switch
9	0423-357	4	Nut, Stamped	21	8424-602	2	Nut, Lock
10	1506-410	4	Clamp, Foot Guard	22	0423-068	1	Screw, Machine
11	0423-419	8	Screw, Machine	23	AC008-006	1	Bracket Indicator Rear Left DVX
12	1506-411	1	Guard, Foot - Right	24	AC008-007	1	Bracket Indicator Rear Right DVX
	1506-412	1	Guard, Foot - Left	25	AC008-008	1	Bracket Indicator Front Left DVX
13	1406-447	1	Panel, Trim - Right - Black	26	AC008-009	1	Bracket Indicator Front Right DVX
	1406-448	1	Panel, Trim - Left - Black	27	AC008-010	1	Bracket Number Plate DVX
	1406-488	1	Panel, Trim - Right - Red (Black-Red)	28	AC008-139	2	Reflector
	1406-489	1	Panel, Trim - Left - Red (Black-Red)	29	AC008-793	1	Anti Theft Device
	1406-490	1	Panel, Trim - Right - Cat Green (Black-Cat Green)	30	AC008-793	1	Bracket Anti Theft Device
				31	AC008-791	1	Clamp Anti Theft Device



HEADLIGHT AND TAILLIGHT ASSEMBLIES

0739-273


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	0509-023	1	Housing, Headlight	16	0509-022	1	Taillight Assembly (inc. 17-19)
2	0609-252	1	Bulb, Headlight - Low Beam	17	0509-025	1	ø Housing, Taillight
3	0409-055	2	Bulb, Headlight - High Beam	18	0409-056	1	ø Bulb, Taillight
4	0423-488	1	Bolt, Carriage	19	0409-057	1	ø Socket, Taillight
5	0486-146	1	Harness, Adapter - Headlight	20	1406-790	4	Pad, Taillight
6	1406-480	1	Bracket, Mounting - Headlight	21	0486-138	1	Harness, Adapter - Taillight
7	0423-357	2	Nut - Stamped	22	AC003-003	1	Headlight Assy. DVX
8	0423-501	2	Screw, Self-Tapping		AC003-246	1	Headlight High Beam DVX
9	0123-802	2	Washer		AC003-247	1	Headlight Low Beam DVX
10	0423-447	2	Grommet		AC008-005	1	Bracket Headlight DVX
11	0423-487	2	Washer, Shoulder		AC006-001	1	Orifice Headlight DVX
12	0423-060	1	Clip, Tinerman	23	AC003-079	1	Taillight New
13	8424-502	1	Nut, Lock	24	AC003-145	2	Indicator, Left
14	0623-301	1	Screw, Self-Tapping	25	AC003-146	2	Indicator, Right
15	8408-616	2	Screw, Cap	26	AC008-013	1	Holder Panel DVX



DECALS

0740-383


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	<u>1411-003</u>	1	Decal, Graphic - Front	6	0411-762	1	Decal, "Arctic Cat"
	<u>1411-013</u>	1	Decal, Graphic - Front (Black-Red)	7	0411-696	1	Decal, Warning - Tire Pressure/Passenger
	<u>1411-012</u>	1	Decal, Graphic - Front (Black-Cat Green)	8	0411-746	1	Reflector, Rear - Red - Right
2	<u>0411-996</u>	1	Decal, Graphic - Front Fender - Right		0411-747	1	Reflector, Rear - Red - Left
	<u>0411-997</u>	1	Decal, Graphic - Front Fender - Left	9	0411-218	1	Decal, Warning - General
	<u>1411-006</u>	1	Decal, Graphic - Front Fender - Right (Black-Cat Green)	10	<u>0411-998</u>	1	Decal, Graphic - Side - Right
	<u>1411-007</u>	1	Decal, Graphic - Front Fender - Left (Black-Cat Green)		<u>0411-999</u>	1	Decal, Graphic - Side - Left
3	0411-744	1	Reflector, Front - Amber - Right		<u>1411-010</u>	1	Decal, Graphic - Side - Right (Black-Red)
	0411-745	1	Reflector, Front - Amber - Left		<u>1411-011</u>	1	Decal, Graphic - Side - Left (Black-Red)
4	0411-759	1	Decal, Warning - Pre Ride		<u>1411-008</u>	1	Decal, Graphic - Side - Right (Black-Cat Green)
5	<u>0411-994</u>	1	Decal, Graphic - Rear Fender - Right		<u>1411-009</u>	1	Decal, Graphic - Side - Left (Black-Cat Green)
	<u>0411-995</u>	1	Decal, Graphic - Rear Fender - Left				
	<u>1411-004</u>	1	Decal, Graphic - Rear Fender - Right (Black-Cat Green)				
	<u>1411-005</u>	1	Decal, Graphic - Rear Fender - Left (Black-Cat Green)				



DECALS (Tony Stewart Edition)

0740-689

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	<u>1411-175</u>	1	Decal, Graphic - Front	6	0411-762	1	Decal, "Arctic Cat"
2	<u>1411-166</u>	1	Decal, Graphic - Front Fender - Right	7	0411-696	1	Decal, Warning - Tire Pressure/Passenger
	<u>1411-167</u>	1	Decal, Graphic - Front Fender - Left	8	0411-746	1	Reflector, Rear - Red - Right
3	0411-744	1	Reflector, Front - Amber - Right		0411-747	1	Reflector, Rear - Red - Left
	0411-745	1	Reflector, Front - Amber - Left	9	0411-218	1	Decal, Warning - General
4	0411-759	1	Decal, Warning - Pre-Ride	10	<u>1411-170</u>	1	Decal, Graphic - Side - Right
5	<u>1411-168</u>	1	Decal, Graphic - Rear Fender - Right		<u>1411-171</u>	1	Decal, Graphic - Side - Left
	<u>1411-169</u>	1	Decal, Graphic - Rear Fender - Left	11	<u>1411-172</u>	2	Decal, Graphic - Tank - Upper




SEAT ASSEMBLY


(Complete Seat Assembly p/n 1506-300)

0740-389

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	1506-297	1	Cover, Seat	5	0406-877	3	ä Bumper, Seat
2	1506-298	1	Foam, Seat	6	0624-528	AR	Staple - 5/16 in.
3	1506-359	1	Latch, Seat	7	0624-094	AR	Staple - 1/4 in.
4	1506-299	1	Base, Seat (inc. 5)				



Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3423-646	2	Bolt	4	3423-560	1	Cushion
2	3423-680	2	Washer	5	3403-016	1	Cover, Cylinder Head
3	3423-647	1	Bolt	6	3402-843	1	Gasket




CYLINDER HEAD ASSEMBLY

0739-184

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3402-839	1	Head, Cylinder - Assembly (inc. 2-4)	13	3423-558	1	Bolt
2	3423-043	4	ø Pin	14	3423-559	1	Washer
3	3423-611	6	ø Bolt	15	0217-708	1	Spark Plug (NGK CR7E)
4	3423-764	2	ø Bolt	16	3413-024	1	Cover, Thermostat
5	3402-840	4	Guide, Valve	17	3413-025	1	Thermostat
6	3402-841	1	Gasket, Cylinder Head	18	3423-328	2	Bolt
7	3423-088	2	Pin, Dowel	19	3470-030	1	Pipe, Intake
8	3423-429	2	Bolt	20	3402-235	1	Clamp, Intake Pipe
9	3423-637	4	Bolt	21	3402-916	1	Clamp, Intake Pipe
10	3423-675	4	Washer	22	3423-635	1	Bolt
11	3004-339	1	Plug, Oil Gallery	23	3423-457	1	Nut
12	3003-290	1	Gasket				

8




CRANKCASE ASSEMBLY

ELT400K (Complete Engine p/n 0462-039)

0739-188


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3502-028	1	Crankcase Set (inc. 2-11)	12	3402-897	1	Plug, Oil Drain
2	3423-088	2	ø Pin, Dowel	13	3402-011	1	Gasket
3	3423-098	7	ø Bolt	14	3446-391	1	Pipe, Oil - Inner - No. 1
4	3423-097	8	ø Bolt	15	3446-356	1	Pipe, Oil - Inner - No. 2
5	3423-706	1	ø Plug, Oil Gallery	16	3423-709	3	O-Ring
6	3402-894	1	ø Gasket	17	3423-710	1	O-Ring
7	3402-918	1	ø Jet, Oil Gallery	18	3005-514	1	Bolt
8	3423-051	1	ø O-Ring	19	3423-391	1	Bolt
9	3402-919	1	ø Separator, Oil - No. 1	20	3423-737	2	Spacer, Engine Mounting
10	3402-920	1	ø Separator, Oil - No. 2	21	3423-457	2	Nut
11	3423-435	4	ø Screw, Separator				



CRANKCASE COVER ASSEMBLY

0739-206

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3403-017	1	Cover, Clutch	14	3409-042	1	Cover, Magneto
2	3446-357	1	Gasket, Clutch Cover	15	3409-023	1	Gasket, Magneto Cover
3	3423-540	1	Plug, Oil Gallery	16	3402-898	1	Plug, Crank Hole
4	3402-436	1	Gasket, Oil Gallery Plug	17	3423-061	1	O-Ring
5	3423-610	4	Pin	18	3402-012	1	Gasket
6	3423-162	16	Bolt	19	3423-111	1	Plug
7	3003-290	2	Gasket	20	3409-022	1	Cover, Starter Idle Gear
8	3423-098	4	Bolt	21	3423-713	1	O-Ring
9	3423-112	1	Plug, Oil Gallery	22	3423-328	3	Bolt
10	3402-011	1	Gasket	23	3435-098	1	Cover, Engine Sprocket
11	3423-705	1	Plug, Oil Gallery	24	3006-094	2	Bolt
12	3004-339	1	Bolt, Oil Level	25	3423-672	2	Washer
13	3402-009	1	Gasket	26	3402-962	1	Plate, Chain Guide




CRANKSHAFT ASSEMBLY

0739-207

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3502-029	1	Crankshaft Assembly (inc. 2-6)	12	3004-552	1	Screw
2	3502-012	1	ø Rod, Connecting	13	3502-030	1	Sprocket, Cam Chain Drive
3	3502-014	1	ø Pin	14	3406-140	1	Gear, Primary Drive
4	3406-139	1	ø Bearing	15	3423-253	1	Nut
5	3402-922	1	ø Crankshaft - Right	16	3423-684	1	Washer
6	3402-923	1	ø Crankshaft - Left	17	3006-890	1	Key, Gear
7	3402-926	1	Gear, Balancer Drive	18	3402-846	1	Piston
8	3423-047	1	Pin	19	3502-011	1	Ring Set, Piston
9	3402-904	2	Bearing	20	3402-847	1	Pin, Piston
10	3402-910	1	Seal, Oil - Right	21	3003-439	2	Circlip
11	3402-952	1	Retainer, Oil Seal - Right				


12



CRANK BALANCER ASSEMBLY

0739-185


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3423-666	1	Nut	6	3402-090	4	Spring, Driven Gear
2	3423-698	1	Washer	7	3402-900	2	Bearing
3	3406-137	1	Gear, Driven	8	3423-047	1	Pin, Inner Driven Gear Race
4	3406-138	1	Race, Driven Gear - Inner	9	3402-925	1	Balancer, Crank
5	3423-106	2	Pin, Driven Gear				



CAMSHAFT/VALVE ASSEMBLY

0739-208


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3502-015	1	Camshaft, Intake	3402-860	AR		Shim, Tappet - 2.70 mm
2	3502-031	1	Camshaft, Exhaust	3402-861	AR		Shim, Tappet - 2.75 mm
3	3402-877	2	Valve, Intake	3402-862	AR		Shim, Tappet - 2.80 mm
4	3402-878	2	Valve, Exhaust	3402-863	AR		Shim, Tappet - 2.85 mm
5	3402-726	4	Spring, Valve	3402-864	AR		Shim, Tappet - 2.90 mm
6	3402-934	4	Retainer, Spring	3402-865	AR		Shim, Tappet - 2.95 mm
7	3402-879	8	Cotter, Valve	3402-866	AR		Shim, Tappet - 3.00 mm
8	3402-880	4	Seat, Spring	3402-867	AR		Shim, Tappet - 3.05 mm
9	3402-078	4	Seal, Oil	3402-868	AR		Shim, Tappet - 3.10 mm
10	3402-851	4	Tappet	3402-869	AR		Shim, Tappet - 3.15 mm
11	3402-852	AR	Shim, Tappet - 2.30 mm	3402-870	AR		Shim, Tappet - 3.20 mm
	3402-853	AR	Shim, Tappet - 2.35 mm	3402-871	AR		Shim, Tappet - 3.25 mm
	3402-854	AR	Shim, Tappet - 2.40 mm	3402-872	AR		Shim, Tappet - 3.30 mm
	3402-855	AR	Shim, Tappet - 2.45 mm	3402-873	AR		Shim, Tappet - 3.35 mm
	3402-856	AR	Shim, Tappet - 2.50 mm	3402-874	AR		Shim, Tappet - 3.40 mm
	3402-857	AR	Shim, Tappet - 2.55 mm	3402-875	AR		Shim, Tappet - 3.45 mm
	3402-858	AR	Shim, Tappet - 2.60 mm	3402-876	AR		Shim, Tappet - 3.50 mm
	3402-859	AR	Shim, Tappet - 2.65 mm				



CAM CHAIN ASSEMBLY

0739-210


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3502-032	1	Chain, Camshaft Drive	8	3402-850	1	ø Gasket
2	3402-848	1	Guide, Cam Chain - No. 1	9	3402-933	1	ø Plug
3	3402-930	1	Guide, Cam Chain - No. 2	10	3402-932	1	ø Spring
4	3402-849	1	Tensioner, Cam Chain	11	3402-137	1	Gasket, Adjuster
5	3423-561	1	Bolt	12	3004-475	2	Bolt
6	3423-142	1	Washer	13	3402-929	1	Retainer, Cam Chain Guide No.1
7	3502-019	1	Adjuster, Tensioner - Assembly (inc. 8-10)	14	3423-018	1	Screw



CARBURETOR ASSEMBLY

0740-390


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3470-031	1	Carburetor Assembly (inc. 2-58)	32	4505-144	1	ø Diaphragm Assembly
2	3423-567	1	ø Washer	33	4505-129	1	ø Cover Assembly
3	4505-118	1	ø Ring	34	4505-125	1	ø Spring
4	4505-119	1	ø E-Ring	35	3423-570	2	ø Screw
5	4505-145	1	ø Spring	36	3423-564	2	ø Screw
6	3423-709	1	ø O-Ring	37	4505-133	4	ø Screw
7	4505-123	1	ø Holder	38	3423-563	1	ø Screw
8	4505-130	1	ø Diaphragm	39	0694-025	1	ø Screw
9	4505-126	1	ø Valve, Piston	40	3423-571	1	ø Screw
10	4505-146	1	ø Ring	41	4505-109	1	ø Float Assembly
11	4505-124	1	ø Spring	42	4505-135	1	ø Pilot Jet - 22.5
12	4505-143	1	ø Washer	43	4505-142	1	ø Pipe
13	4505-117	1	ø Jet Needle 5E26-1	44	3004-645	3	ø Screw
14	3423-568	1	ø O-Ring	45	4505-148	1	ø O-Ring
15	3423-566	1	ø Washer	46	4505-127	1	ø Cover
16	4505-152	1	ø Adjuster	47	3423-572	1	ø Nut
17	4505-113	1	ø Spring	48	4505-134	1	ø Main Jet - 60
18	4505-071	1	ø Main Jet - 130	49	4505-150	1	ø Hose
19	4505-140	1	ø Ring	50	4505-112	1	ø Spring
20	4505-141	1	ø Holder, Jet	51	3423-573	1	ø Washer
21	4505-136	1	ø Jet	52	4505-137	1	ø Screw, Adjust - Assembly
22	4505-110	1	ø Pin	53	4505-151	1	ø Screw
23	4505-116	1	ø Needle Valve Assembly	54	4505-147	1	ø Guide, Cable
24	4505-111	1	ø O-Ring	55	3423-569	1	ø O-Ring
25	4505-114	1	ø Needle Jet P-0M	56	4505-149	1	ø Hose
26	4505-120	1	ø Starter Plunger Assembly	57	0693-784	1	ø Hose
27	4505-121	1	ø Spring	58	4505-154	1	ø Plug
28	3423-565	1	ø O-Ring	59	4505-155	1	Sensor Assembly
29	3470-011	1	ø Cap	60	4505-156	1	Screw
30	4505-122	1	ø Holder, Guide	61	3004-787	1	Clamp, Drain Hose
31	4505-153	1	ø Cover, Diaphragm				



AIR CLEANER ASSEMBLY

0739-212


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3470-032	1	Cleaner, Air - Assembly (inc. 2-17)	11	3423-726	1	ø Clamp, Tube
2	3470-014	1	ø Filter	12	3470-017	1	ø Trap, Flame
3	3470-015	1	ø Holder	13	3470-012	1	ø Cap, Air Cleaner (inc. 14)
4	3470-016	1	ø Stopper, Holder	14	3470-013	1	ø ø Gasket
5	0693-505	1	ø Screw	15	3470-027	1	ø Joint, Inlet
6	3470-026	1	ø Tube, Outlet	16	3470-028	1	ø Duct, Inlet
7	3470-025	1	ø Fitting, Elbow	17	3423-503	1	ø Clamp
8	3402-334	1	ø Plug, Breather	18	3004-377	1	Bolt, Air Cleaner - Right
9	3423-313	2	ø Clip	19	3004-507	2	Bolt, Air Cleaner - Left
10	3423-727	1	ø Clamp, Tube				



EXHAUST ASSEMBLY

0739-213


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3512-005	1	Pipe, Exhaust	12	3412-005	1	ø Gasket
2	3412-003	1	Gasket, Exhaust Pipe	13	3423-613	3	ø Bolt
3	3004-301	2	Bolt, Stud	14	0694-024	2	Washer
4	3423-176	2	Nut	15	3423-694	2	Spacer
5	3412-006	1	Cover, Exhaust Pipe	16	3423-718	2	Cushion
6	3412-004	1	Connector, Muffler	17	3423-715	3	Cushion, Exhaust Pipe Cover
7	3512-006	1	Body, Muffler (inc. 8-12 and one No. 13)	18	3423-661	3	Screw
8	3423-740	1	ø Clamp	19	3423-574	3	Washer
9	3423-739	1	ø Spacer	20	3423-575	3	Spacer, Exhaust Pipe Cover
10	3423-645	3	ø Bolt	21	AC004-704	1	Exhaust ACE 4 (DVX) Stainless Steel
11	3412-009	1	ø Arrester				



OIL PUMP ASSEMBLY

0739-215


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3502-020	1	Pump, Oil - Assembly	12	3402-885	1	Cap, Oil Filter
2	3402-881	1	Gear, Driven	13	3423-277	1	O-Ring
3	3423-046	2	Pin	14	3402-238	1	Spring
4	3423-443	1	Washer	15	3423-328	3	Bolt
5	3423-184	1	Circlip	16	3402-917	1	Spring
6	3004-520	3	Screw	17	3402-891	1	Ball
7	3502-022	1	Rotor Set, Oil Pump	18	3402-883	1	Seat, Oil Check Valve
8	3502-023	1	Strainer, Oil Pump	19	3402-935	1	Gear, Idle - Oil Pump
9	3004-376	2	Bolt	20	3402-936	1	Shaft
10	3470-008	1	Filter, Oil	21	3423-358	2	Circlip
11	3423-270	1	O-Ring				



OIL TANK AND HOSE ASSEMBLY

0739-216


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3410-019	1	Hose, Oil Tank - Right	12	3423-055	1	O-Ring, Oil Level Gauge
2	3410-020	1	Hose, Oil Tank - Left	13	3004-705	1	Plug, Oil Drain
3	3423-720	1	Bolt, Union	14	3402-436	1	Gasket, Oil Drain Plug
4	3006-113	2	Gasket, Oil Hose Union	15	3502-021	1	Tank, Oil
5	3004-512	3	Bolt	16	3423-657	2	Bolt, Oil Tank
6	3423-744	2	Cushion, Oil Tank	17	3423-716	2	Cushion, Oil Tank
7	3423-711	3	O-Ring, Oil Hose	18	3423-692	2	Spacer, Oil Tank
8	3008-199	3	Pin, Oil Tank Hose	19	3406-074	1	Decal, Oil Level
9	3410-018	1	Hose, Oil Overflow	20	3402-882	1	Protector, Oil Tank
10	3423-723	2	Clamp, Hose	21	3423-423	2	Clip
11	3470-009	1	Gauge, Oil Level				



WATER PUMP ASSEMBLY

0740-401


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3413-036	1	Pump, Water (inc. 2-12)	10	3406-144	1	ø O-Ring
2	3406-141	1	ø Gasket	11	3005-909	1	ø Seal, Water Pump Shaft
3	3423-769	3	ø Bolt	12	3413-037	1	ø Impeller/Shaft
4	3423-770	2	ø Screw	13	3423-629	3	Bolt
5	3423-771	1	ø Pin	14	3423-630	1	Bolt
6	3406-142	1	ø O-Ring	15	3004-521	1	O-Ring
7	3406-143	1	ø Seal, Oil	16	3423-184	1	Circlip
8	3423-772	1	ø Washer	17	3413-021	1	Gear, Water Pump Driven
9	3423-773	1	ø Pin				



RADIATOR ASSEMBLY

0739-218

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3413-030	1	Radiator	7	3423-576	1	ø O-Ring
2	3413-029	1	Cover, Radiator	8	3413-035	1	Fan, Radiator
3	3423-657	3	Bolt	9	3423-741	3	Nut
4	3423-692	3	Spacer	10	3004-339	3	Bolt
5	3423-716	3	Cushion	11	3409-035	1	Switch, Temperature
6	3409-024	1	Switch, Radiator Fan (inc. 7)	12	3402-937	1	Boot, Radiator Fan




RADIATOR HOSE ASSEMBLY

0739-224

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3413-029	1	Hose, Radiator Inlet	6	3423-654	2	Screw
2	3413-030	1	Hose, Radiator Outlet	7	3413-034	1	Hose, Inlet
3	3006-324	4	Clamp	8	3423-480	2	Clip
4	3413-031	1	Tank, Reservoir (inc. 5)	9	3413-033	1	Hose, Overflow
5	3413-032	1	Cap, Reservoir Tank	10	3413-027	1	Cap, Radiator


24



TRANSMISSION ASSEMBLY

0739-226


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3402-942	1	Countershaft	24	3402-195	1	Washer
2	3402-943	1	Gear, 2nd Drive - 18T	25	3423-421	1	Washer
3	3446-362	1	Gear, 3rd Drive - 21T	26	3402-903	1	Bearing, Driveshaft - Left
4	3446-363	1	Gear, 4th Drive - 23T	27	3402-912	1	Seal, Oil - Driveshaft
5	3446-364	1	Gear, 5th Drive - 26T	28	3402-915	1	Bushing, 1st Driven Gear
6	3423-689	1	Washer	29	3402-230	1	Bushing, 2nd Driven Gear
7	3423-702	2	Washer	30	3446-377	1	Sprocket, Driveshaft - 14T
8	3402-382	2	Washer	31	3446-416	1	Chain Assembly (inc. 32)
9	3402-975	1	Bearing, Countershaft - Left	32	3446-417	1	ø Joint Set
10	3423-066	5	Circlip	33	3446-367	1	Retainer, Countershaft - Right
11	3402-976	1	Bearing, Countershaft - Right	34	3423-018	2	Screw
12	3435-099	1	Driveshaft	35	3446-368	1	Retainer, Driveshaft Oil Seal
13	3446-365	1	Gear, 1st Driven - 33T	36	3423-659	2	Bolt, Retainer
14	3446-366	1	Gear, 2nd Driven - 30T	37	3402-947	1	Shaft, Reverse Idle
15	3402-944	1	Gear, 3rd Driven - 26T	38	3402-948	1	Gear, Reverse Idle - 24T
16	3402-945	1	Gear, 4th Driven - 23T	39	3402-949	1	Bushing, Reverse Idle Gear
17	3402-946	1	Gear, 5th Driven - 22T	40	3402-209	1	Washer
18	3402-950	1	Gear, Reverse Driven - 28T	41	3423-701	1	Washer
19	3402-951	1	Dog, Reverse	42	3423-686	1	Washer, Wave
20	3446-380	1	Bushing, 3rd Driven Gear	43	3423-518	1	Circlip
21	3423-036	2	Washer	44	3423-651	2	Bolt
22	3446-273	1	Bushing, Reverse Driven Gear	45	3402-961	1	Plate, Sprocket
23	3003-320	1	Bearing, Driveshaft - Right				



GEAR SHIFTING ASSEMBLY

0739-227

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3446-397	1	Fork, Gear Shift - No. 1	23	3402-956	1	Stopper, Shift Cam
2	3446-398	1	Fork, Gear Shift - No. 2	24	3402-957	1	Plate, Shift Cam Stopper
3	3446-399	1	Fork, Gear Shift - No. 3	25	3423-652	1	Bolt, Cam Stopper Arm
4	3402-958	1	Shaft, Gear Fork - No. 1	26	3446-374	1	Spring, Shift Cam
5	3446-031	2	Retainer, Shift Cam Bearing	27	3423-615	1	Washer, Shift Cam
6	3402-953	1	Cam, Gear Shift (inc. 7)	28	3402-959	1	Shaft, Gear Shift
7	3423-114	1	ø Pin, Shift Cam	29	3402-960	1	Stopper, Gear Shift Arm
8	3446-369	1	Pin, Shift	30	3402-068	1	Seal, Oil - Gear Shift Shaft
9	3446-370	1	Shaft, Reverse Lock	31	3446-390	1	Spring, Gear Shift Shaft Return
10	3402-954	1	Shifter, Gear Shift Cam	32	3423-700	1	Washer, Gear Shaft
11	3446-371	1	Pawl, Gear Shift - No. 1	33	3423-546	2	Circlip, Gear Shaft
12	3446-372	1	Pawl, Gear Shift - No. 2	34	3423-678	1	Washer
13	3446-373	1	Spring, Reverse Lock	35	3402-385	1	Bearing
14	3402-955	1	Lifter, Gear Shift Pawl	36	3423-695	2	Spacer
15	3402-132	1	Roller, Gear Cam Shifter	37	3446-418	1	Lever, Gear Shift (inc. 38)
16	3423-708	2	Pin, Shift Pawl	38	3446-376	1	ø Rubber, Gear Shift Lever
17	3402-907	1	Bearing, Shift Cam - Left	39	3004-341	1	Bolt, Gear Shift Lever
18	3402-911	1	Seal, Reverse Lock	40	3509-006	1	Base Assembly
19	3446-389	2	Spring, Shift Pawl Return	41	3423-044	2	Contact
20	3423-435	2	Screw, Shift Cam Bearing	42	3423-273	1	O-Ring
21	3423-018	2	Screw, Shift Pawl Lifter	43	3402-087	2	Spring
22	3402-186	1	Bearing, Shift Cam - Right	44	3423-418	2	Bolt




STARTER MOTOR ASSEMBLY

0739-228

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3445-033	1	Motor, Starter (inc. 2-10)	7	3008-099	1	ø Washer Set
2	3402-671	1	ø Brush Terminal Set	8	3423-536	2	ø Through-Bolt (inc. 9)
3	3008-164	1	ø O-Ring	9	3423-496	2	ø ø O-Ring
4	3402-672	1	ø Brush Holder Set	10	3423-272	1	ø O-Ring
5	3008-551	2	ø Brush Spring	11	3004-756	2	Bolt
6	3423-497	2	ø O-Ring	12	3423-195	1	Nut

28




ELECTRICAL ASSEMBLY

0740-399

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3409-025	1	Relay, Starter (inc. 2-3)	8	3530-027	1	Coil, Ignition
2	3409-038	1	ø Cover, Starter Relay	9	3004-377	1	Bolt
3	3530-044	1	ø Fuse - 20 Amp	10	3409-029	1	Cap, Spark Plug
4	3423-020	2	Bolt, Starter Motor	11	3409-030	1	Seal, Spark Plug Cap
5	3409-027	1	Rectifier	12	3430-009	1	Seal, High Tension Lead
6	0693-982	2	Bolt	13	3409-031	1	Cover, Spark Plug Cap
7	3409-043	1	CDI				



Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3445-034	1	Battery	6	3445-039	1	Cable, Starter Motor/Starter Relay (inc. 7)
2	3406-003	2	Protector	7	3545-018	1	ø Cap, Terminal
3	3445-036	2	Protector	8	3445-040	1	Cable, Battery/Starter Relay (inc. 9)
4	3445-037	2	Protector	9	3545-019	1	ø Cap, Terminal
5	3445-035	1	Protector, Battery	10	3445-041	1	Cable, Battery/Ground




INDICATOR LIGHT ASSEMBLY

0739-232

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3420-008	1	Light, Indicator - Assembly (inc. 2-7)	7	3420-009	3	ø Bulb, Indicator Light
2	3409-034	3	ø Socket	8	AC005-001	1	Speedo Assy. DVX (inc. 9)
3	3409-039	3	ø Ring	9	AC008-029	1	Sensor DVX
4	3420-005	1	ø Lens, Neutral - Green	10	AC003-158	1	Horn
5	3420-006	1	ø Lens, Reverse - Red	11	AC008-400	1	Bracket Sensor DVX
6	3420-007	1	ø Lens, Water Temperature - Red				



Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3509-007	1	Harness, Main	11	3409-040	1	Fuse Box - Cooling Fan (inc. 12)
2	3423-731	1	Clamp	12	3530-043	2	ã Fuse - 10 Amp
3	3402-237	1	Clamp	13	3409-007	1	Key, Blank (Type C)
4	3423-732	3	Clamp		3409-011	1	Key, Blank (Type D)
5	0693-564	1	Clamp		3409-012	1	Key, Blank (Type E)
6	3423-733	2	Clamp		3409-013	1	Key, Blank (Type F)
7	3008-044	3	Clamp	14	0409-013	1	Cover, Key
8	3509-004	1	Switch, Ignition	15	3423-777	1	Clamp
9	3409-036	1	Switch, Brakelight	16	3423-778	1	Clamp
10	3423-736	1	Spring	17	AC003-225	1	Harness DVX




FRAME ASSEMBLY

0739-234

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3406-004	1	Frame - Gray	10	3406-006	1	Protector, Engine
2	3406-005	1	Rail, Seat - Silver	11	3423-653	2	Bolt
3	3423-633	2	Bolt	12	3406-104	1	Plate, Battery
4	3423-638	2	Bolt	13	3004-377	2	Bolt
5	3406-105	1	Plate, Mounting - Engine - Right	14	3446-381	1	Roller, Chain Control
6	3406-106	1	Plate, Mounting - Engine - Left	15	3423-631	1	Bolt
7	3006-544	4	Bolt	16	3423-696	2	Washer
8	3406-107	1	Plate, Mounting - Engine - Upper	17	3406-013	2	Cap, Seat Rail
9	3004-630	4	Bolt	18	3406-016	2	Cushion, Seat Mount - Front






FOOTREST ASSEMBLY

0739-239


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3406-009	1	Footrest - Right	10	3006-544	4	Bolt
2	3406-010	1	Footrest - Left	11	3406-070	1	Guard, Foot - Right - Black
3	3423-636	4	Bolt		3406-071	1	Guard, Foot - Left - Black
4	3406-011	1	Support, Mudguard - Right	12	3423-661	8	Bolt
5	3406-012	1	Support, Mudguard - Left	13	3423-690	8	Washer
6	3423-633	2	Bolt	14	3436-017	1	Kit, Tool
7	3406-148	1	Grip, Front	15	3436-019	1	Wrench, Spanner
8	3004-630	4	Bolt	16	3436-020	1	Gauge, Air Pressure
9	3406-149	1	Grip, Rear	17	3436-018	1	Wrench, Hex



GAS TANK ASSEMBLY

0739-240


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3570-005	1	Tank, Gas	11	3423-743	2	Cushion, Rear
2	3470-018	1	Cap, Gas Tank	12	3423-693	2	Spacer
3	3470-022	1	Hose, Breather	13	3423-655	2	Bolt
4	3470-033	1	Hose, Breather	14	3470-019	1	Valve, Shut-Off - Assembly
5	3406-109	1	Cushion, Front	15	3470-020	1	Hose, Gasline
6	3406-110	2	Cushion, Side	16	3423-722	2	Clamp, Hose
7	3003-787	2	Clamp	17	3423-328	2	Bolt
8	3423-673	1	Washer, Seat Hook	18	3006-599	2	Gasket
9	3423-691	1	Spacer	19	3470-029	1	Cover, Air Cleaner Inlet Duct
10	3423-096	1	Screw				




HANDLEBAR ASSEMBLY

0739-241

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3405-024	1	Handlebar	16	3423-714	1	Washer
2	3405-041	1	Cover, Steering Head	17	3406-113	1	Guide, Cable
3	3423-735	2	Clip	18	3423-627	2	Bolt
4	3405-032	1	Bracket, Mounting - Right	19	3487-004	1	Cable, Parking Brake
5	3405-033	1	Bracket, Mounting - Left	20	3406-114	1	Guide, Parking Brake Cable
6	3405-026	2	Balancer Set, Handlebar (inc. 7-12)	21	3423-730	1	Clamp
7	3423-660	2	Ø Screw	22	3406-115	1	Stopper, Cable
8	3405-029	2	Ø Expander	23	3423-780	1	Clamp
9	3423-672	2	Ø Washer	24	3423-729	1	Clamp
10	3405-030	2	Ø Expander	25	3008-044	3	Clamp, Cable
11	3405-031	2	Ø Spacer	26	AC008-403	1	Mirror Adapter DVX
12	3423-668	2	Ø Nut	27	AC008-408	1	Support Brake Cable DVX
13	3487-005	1	Cable, Clutch	28	AC008-409	1	Counter Part DVX
14	3487-006	1	Cable, Throttle				
15	3445-038	1	Cable, Starter Plunger				
	AC008-411	1	Cable, Choke DVX Street				




Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3502-026	1	Knob, Reverse Lock - Assembly	5	3406-020	1	Bracket, Knob
2	3423-605	1	Screw	6	3423-734	2	Clip
3	3423-603	1	Screw	7	3406-150	1	Bracket, Reverse Cable
4	3006-700	1	Nut	8	3423-604	1	Bolt



CONTROLS

0739-243


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3405-037	2	Grip, Handlebar	24	3423-746	1	Washer
2	3405-042	1	Case, Throttle (inc. 3-9)	25	3423-623	2	Nut
3	3405-035	1	Cap	26	3502-025	1	Holder
4	3423-582	1	Gasket	27	3004-507	2	Bolt
5	3423-581	3	Screw	28	3402-963	2	Nut, Adjuster
6	3405-036	1	Holder	29	3423-749	2	Bolt, Adjuster
7	3423-580	2	Bolt	30	3402-968	1	Lock, Parking Brake
8	3004-853	1	Nut	31	3423-745	1	Bolt, Parking Brake Lock
9	1691-018	1	Screw	32	3423-747	1	Washer
10	3402-886	1	Lever, Front Brake	33	3402-965	1	Spacer
11	3423-583	1	Bolt, Pivot	34	3402-966	1	Spring, Return
12	3423-748	1	Nut	35	3402-967	1	Knob, Parking Brake Lock
13	3409-037	1	Switch, Stop (inc. 14)	36	3423-753	1	Screw, Parking Brake Lock Knob
14	3423-750	1	Screw	37	3423-752	1	Washer
15	3509-010	1	Switch, Control Assembly (inc. 16-19)	38	3406-019	1	Cover, Clutch Lever
16	3409-009	1	Lever, Choke	39	AC003-018	1	Switch Combined
17	3409-010	1	Cover, Choke	40	AC008-410	1	Lever Choke DVX
18	3423-196	1	Screw	41	AC002-003	1	Brake Lever DVX Assy.
19	3423-197	1	Screw	42	AC002-001	1	Brake Twin Lever DVX
20	3446-419	1	Lever, Clutch Assembly (inc. 21-37)	43	AC008-751	1	Mirror Left
21	3409-041	1	Switch, Clutch	44	AC008-752	1	Mirror Right
22	3402-964	1	Lever	45	AC008-753	1	Mirror Mounting Left
23	3423-751	1	Bolt, Pivot				



TIE ROD ASSEMBLY

0740-391


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3405-009	2	Tie Rod	8	3423-620	4	Nut
2	3405-043	1	Knuckle, Steering - Right	9	3423-664	2	Nut, Tie Rod - Left
	3405-044	1	Knuckle, Steering - Left	10	3423-607	4	Pin, Cotter
3	3423-681	4	Washer, Rod End Lock	11	3004-417	4	Washer
4	3405-045	2	End, Knuckle - Upper	12	3423-681	4	Washer, Wave
5	3405-007	2	Ball Joint - Right	13	3423-620	4	Nut
6	3405-008	2	Ball Joint - Left	14	3423-607	4	Pin, Cotter
7	3423-665	2	Nut, Tie Rod - Right	15	3423-193	2	Circlip




STEERING POST ASSEMBLY

0740-656

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	<u>3405-046</u>	1	Post, Steering	10	3423-624	1	Nut
2	3405-014	2	Seal, Dust - Steering Post Holder	11	3423-607	1	Pin, Cotter
3	3405-013	2	Holder, Steering Post	12	<u>3405-049</u>	2	Clamp, Handlebar - Lower
4	3423-602	2	Bolt	13	3423-781	2	Bolt, Handlebar Clamp - Lower
5	3423-055	1	O-Ring	14	3423-782	2	Washer
6	3405-038	1	Bushing, Steering Post	15	3423-341	2	Nut
7	<u>3405-047</u>	1	Seal, Dust - Steering Post -Upper	16	<u>3405-050</u>	2	Clamp, Handlebar - Upper
8	<u>3405-048</u>	1	Seal, Dust - Steering Post - Lower	17	3004-498	4	Bolt, Handlebar Clamp - Upper
9	3423-676	1	Washer	18	3423-682	4	Washer




Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	<u>3405-051</u>	2	Shock Assembly - Front - Silver	8	3406-094	4	Bearing
2	3423-641	2	Bolt	9	3405-020	8	Seal, Dust - Lower A-Arm
3	3423-640	2	Bolt	10	3406-101	16	Seal, Dust - Inner
4	3423-457	4	Nut	11	3406-112	4	Spacer
5	<u>3405-052</u>	1	A-Arm - Lower Right	12	3406-111	8	Spacer
	<u>3405-053</u>	1	A-Arm - Lower Left	13	3423-634	8	Bolt
6	<u>3405-054</u>	1	A-Arm - Upper Right	14	3423-457	8	Nut
	<u>3405-055</u>	1	A-Arm - Upper Left	15	3423-617	8	Washer
7	3406-093	4	Bearing				



FRONT WHEEL ASSEMBLY

0739-247


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3405-021	2	Hub, Wheel - Gray	11	3423-608	2	Pin, Cotter
2	3402-893	2	Bearing, Wheel Hub - Inner	12	3402-895	2	Spacer, Front Axle
3	3402-899	2	Bearing, Wheel Hub - Outer	13	3402-896	2	Spacer, Front Axle
4	3402-914	2	Seal, Dust - Inner	14	3406-028	2	Disc, Brake
5	3402-913	2	Seal, Dust - Outer	15	3423-649	6	Bolt, Brake Disc
6	3405-023	2	Spacer, Wheel Hub Bearing	16	3406-152	2	Cover, Brake Disc
7	3406-151	2	Rim, Front Wheel	17	3423-455	6	Bolt
8	3423-783	8	Nut	18	3406-017	2	Tire
9	3003-156	2	Washer	19	3406-008	2	Valve Assembly
10	3423-622	2	Nut, Wheel Hub	20	3405-022	2	Plate, Wheel Hub



FRONT BRAKE ASSEMBLY

0739-248

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3406-023	1	Caliper, Brake - Right (inc. 2-15)	11	3406-033	2	ø Boot
	3406-030	1	Caliper, Brake - Left (inc. 2-15)	12	3406-037	4	ø Pin
2	3406-021	2	ø Piston Set (inc. 3)	13	3406-027	1	ø Bracket - Right
3	3406-022	2	ø ø Seal Set, Piston		3406-040	1	ø Bracket - Left
4	3406-036	2	ø Spring, Pad	14	3406-025	2	ø Valve, Bleed
5	3406-043	2	ø Boot	15	3406-026	2	ø Cap, Bleed Valve
6	3423-584	2	ø Pin	16	3406-031	1	Pad, Brake - Set - Right (inc. 17)
7	3406-035	2	ø Washer		3406-032	1	Pad, Brake - Set - Left (inc. 17)
8	3406-024	2	ø Pin, Slide	17	3406-041	1	ø Shim - Right
9	3406-034	2	ø Spring		3406-082	1	ø Shim - Left
10	3406-042	2	ø Plug, Dust	18	3423-784	4	Bolt




FRONT BRAKE HOSE ASSEMBLY

0739-249

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3423-719	3	Bolt	7	3004-339	2	Bolt
2	3006-112	6	Washer	8	3406-155	1	Brakeline, Front
3	3406-153	1	Hose, Front Brake - No. 1	9	3423-112	1	Bolt
4	3406-154	1	Hose, Front Brake - No. 2	10	3423-728	1	Clamp, Front Brakeline
5	3423-754	1	Clamp, Hose No. 2 - Right	11	3406-119	1	Cover, Front Brakeline
6	3423-755	1	Clamp, Hose No. 2 - Left				


46



SWING ARM ASSEMBLY

0740-393


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3406-156	1	Arm, Swing (inc. 2-3)	17	3423-757	1	Nut, Chain Adjuster
2	3406-133	2	ø Bearing	18	3423-643	2	Bolt
3	3406-053	2	ø Bushing	19	3423-644	2	Bolt
4	3406-102	4	Seal, Bearing	20	3423-677	4	Washer
5	3406-052	2	Spacer	21	3423-586	1	Plate
6	3406-054	2	Cover, Dust	22	3423-587	1	Plate
7	3423-618	2	Washer, Thrust	23	3406-056	1	Guard, Swing Arm - Assembly (inc. 24-27)
8	3406-051	1	Shaft, Pivot	24	3406-057	1	ø Guard, Swing Arm
9	3423-785	1	Nut	25	3406-058	1	ø Slide, Chain - Swing Arm Guard
10	3423-786	1	Washer	26	3423-671	3	ø Washer
11	3406-055	1	Slide, Chain	27	3423-704	3	ø Rivet
12	3423-656	3	Bolt	28	3423-756	3	Bolt
13	3446-383	1	Plate, Chain Adjuster	29	3423-648	2	Bolt
14	3423-650	1	Bolt, Chain Adjuster	30	3004-278	2	Washer
15	3423-679	1	Washer, Chain Adjuster Nut	31	3406-123	1	Cap, Swing Arm
16	3423-190	1	Circlip	32	3406-124	1	Boot, Chain Adjuster Bolt



REAR SUSPENSION ASSEMBLY

0739-252


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3406-061	1	Arm, Front (inc. 2 and four No. 3)	13	3406-068	1	Spacer, Rear
2	3406-095	1	ø Bearing	14	3406-067	1	Guard, Front Arm
3	3406-096	6	ø Bearing	15	3423-662	2	Screw
4	3423-626	3	Fitting, Grease	16	3406-062	1	Arm, Rear (inc. two No. 3)
5	3406-060	1	Spacer	17	3406-064	1	Spacer
6	3406-063	6	Seal, Dust	18	3423-589	1	Bolt
7	3423-591	1	Bolt	19	3423-457	1	Nut
8	3423-670	3	Nut	20	3423-588	1	Bolt
9	3406-065	1	Spacer	21	3406-125	1	Shock Assembly - Rear - Silver
10	3406-066	6	Spacer	22	3423-669	1	Nut, Lower
11	3423-590	1	Bolt	23	3423-639	1	Bolt, Lower
12	3406-100	2	Seal				



RIGHT REAR WHEEL ASSEMBLY

0739-257


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3406-159	1	Hub, Wheel - Gray	9	3406-134	1	Housing, Rear Axle Bearing
2	3406-160	1	Wheel, Rear	10	3406-127	1	Spacer, Rear Axle Bearing
3	3423-788	4	Nut	11	3406-092	2	Bearing, Rear Axle
4	3423-685	1	Washer	12	3406-099	2	Seal, Dust
5	3423-667	1	Nut, Hub	13	3406-079	1	Disc, Brake
6	3423-609	1	Pin, Cotter	14	3423-649	4	Bolt
7	3446-420	1	Axle, Rear	15	3406-072	1	Tire, Rear
8	3423-759	1	Nut, Rear Axle	16	3406-008	1	Valve Assembly



LEFT REAR WHEEL ASSEMBLY

0739-258


Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3406-159	1	Hub, Wheel - Gray	8	3423-687	2	Washer
2	3406-160	1	Wheel, Rear	9	3446-421	1	Hub, Rear Sprocket
3	3423-788	4	Nut	10	3446-422	1	Sprocket, Rear - 40T
4	3423-685	1	Washer	11	3423-642	4	Bolt
5	3423-667	1	Nut, Hub	12	3423-683	4	Washer
6	3423-609	1	Pin, Cotter	13	3406-072	1	Tire, Rear
7	3423-758	1	Nut, Rear Axle	14	3406-008	1	Valve Assembly



REAR BRAKE ASSEMBLY

0739-255

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3406-076	1	Caliper Assembly, Rear (inc. 2-24)	14	3406-025	1	ø Valve, Bleed
2	3406-078	1	ø Piston Set (inc. 3)	15	3406-026	1	ø Cap, Bleed Valve
3	3406-077	1	ø ø Seal Set	16	3406-129	1	ø Actuator, Parking Brake
4	3406-036	1	ø Spring, Pad	17	3406-080	1	ø Gasket
5	3406-043	1	ø Boot	18	3423-763	2	ø Bolt
6	3423-584	1	ø Bolt	19	3423-592	1	ø O-Ring
7	3406-035	1	ø Washer	20	3406-081	1	ø Boot
8	3423-762	1	ø Pin	21	3406-130	1	ø Arm
9	3406-033	2	ø Boot	22	3423-760	1	ø Bolt
10	3406-034	1	ø Spring	23	3423-593	1	ø Nut
11	3406-128	1	ø Bracket	24	3423-595	1	ø Spring
12	3406-038	2	ø Pin	25	3406-075	1	Pad Set
13	3406-039	1	ø Washer	26	3423-789	2	Bolt



REAR MASTER CYLINDER ASSEMBLY

0739-261

Ref.	Part No.	Qty.	Description	Ref.	Part No.	Qty.	Description
1	3406-083	1	Master Cylinder Assembly (inc. 2-9)	14	3406-087	1	ø Cap
2	3406-084	1	ø Piston Set (inc. 3)	15	3423-112	1	Bolt
3	3402-887	1	ø ø Boot	16	3410-015	1	Hose - Reservoir/Master Cylinder
4	3406-089	1	ø Rod, Push	17	3004-193	2	Clamp, Hose
5	3402-970	1	ø Yoke	18	3402-969	1	Hose, Brake
6	3423-599	2	ø Nut	19	3423-719	2	Bolt, Union
7	3406-090	1	ø Fitting, Elbow	20	3006-112	4	Washer
8	3423-596	1	ø Circlip	21	3423-703	1	Pin
9	3423-597	1	ø O-Ring	22	0693-556	1	Washer
10	3423-628	2	Bolt	23	3423-606	1	Pin, Cotter
11	3406-132	1	Reservoir (inc. 12-14)	24	3423-790	1	Clamp, Brake Hose
12	3406-085	1	ø Diaphragm	25	3423-600	1	Bolt
13	3406-086	1	ø Plate	26	3406-091	1	Guide, Hose

RELATED ITEMS

2006 ATV DVX 400 Street Legal

Red - (Model No. A2006DVI2AUSR)

Black-Red - (Model No. A2006DVI2AUSD)

Black-Cat Green - (Model No. A2006DVI2AUSE)

Tony Stewart Edition - (Model No. A2006DVI2AUSX)

0436-541	A-Arm Guard Kit
0436-544	Bars Kit - Nerf/Black Web
0436-540	Bumper Kit (Front)
0436-014	Flag Kit
0436-545	Frame Guard Kit (Side)
0436-722	Handguard Kit - Black
0436-720	Handguard Kit - Green
0436-721	Handguard Kit - Red
0436-724	Headlight Cover - Chrome
0436-723	Headlight Cover - Smoke
2257-537	Illustrated Parts Manual

2257-370	Manuel d'utilisation (F)
0436-005	Oil - 10W-40
0436-003	Oil - 5W-30
2257-310	Operator's Manual (E)
0436-690	Shock Cover - Green
0436-689	Shock Cover - Red
0436-542	Skid Plate Kit (Center)
0436-543	Skid Plate Kit (Rear)
0436-042	Tire Repair Kit - Deluxe
0436-685	Trailerable Cover

■ **NOTE:** For a complete list of related items, refer to the current accessory catalog.