

PRB8

ROCKER SWITCH CABLE

STOP SW

SWITCH ACCESSORY



FAN MOTOR

2X 4X ACTUATOR ASM

FUEL INJ.

SENSOR ANGLE DETECT

REG. RECT. ASSY

2WD/4WD SW

COMB SW

TMAP SENSOR (T-MAP)

THROTTLE POSITION SENSOR (TPS)

IDLE SPEED CONTROL (ISC)

ENG TEMP (ETC)

GEAR CHANGE SW

WINKER RELAY

REAR STOP SW

START MAG

12V 18AH BATTERY

STARTER MOTOR

RH RR WINKER 12V 10W

TAIL/STOP LIGHT 12V 5/21W

LICENCE LIGHT 12V 5W

RH RR WINKER 12V 10W

TAIL/STOP LIGHT 12V 5/21W

REAR ACCESSORY

HEAD LIGHT 12V 35W/35W

RH FR WINKER 12V 10W

FR POSITION 12V 5W

GAUGE LCD

HORN

HEAD LIGHT 12V 35W/35W

RH FR WINKER 12V 10W

WINCH

SOLENOID

FUEL PUMP LEVEL SENSOR

EFI ECU (M3 C) 48P

L/W	B	GR/G	R/Y
1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18	19	20

