

- 1 HORN, 12V
- 2 CONTROLS, LH
- 3 SWITCH, 2WD/4WD/DIFFERENTIAL LOCK
- 4 GAUGE, LCD
- 5 SWITCH, KEY
- 6 SWITCH, HAND BRAKE
- 7 ELEMENT, LEFT HANDWARMER
- 8 SWITCH, HANDWARMER/THUMBWARMER
- 9 ELEMENT, THUMBWARMER
- 10 ELEMENT, RIGHT HANDWARMER
- 11 CONNECTOR, DIAGNOSTICS
- 12 ECU
- 13 COIL, FRONT IGNITION
- 14 COIL, REAR IGNITION
- 15 SENSOR, FUEL LEVEL/PUMP, FUEL
- 16 INJECTOR, FRONT FUEL
- 17 INJECTOR, REAR FUEL
- 18 SENSOR, SPEEDOMETER
- 19 SOLENOID, STARTER
- 20 BATTERY, 12V
- 21 MOTOR, STARTER
- 22 CONNECTOR, ENGINE/BATTERY GROUND
- 23 CONNECTOR, REAR ACCESSORY
- 24 LIGHT, REAR RIGHT TURN
- 25 TAILLIGHT, RIGHT
- 26 LIGHT, LICENSE PLATE
- 27 TAILLIGHT, LEFT
- 28 LIGHT, REAR RIGHT TURN
- 29 HARNESS, PASSENGER SEATBASE
- 30 ELEMENT, LEFT PASSENGER HANDWARMER
- 31 SWITCH, PASSENGER HANDWARMER
- 32 ELEMENT, RIGHT PASSENGER HANDWARMER
- 33 REGULATOR/RECTIFIER
- 34 MAGNETO
- 35 SENSOR, CRANKSHAFT POSITION
- 36 SENSOR, AIR TEMPERATURE
- 37 SENSOR, MANIFOLD ABSOLUTE PRESSURE
- 38 SENSOR, COOLANT TEMPERATURE
- 39 SENSOR, TILT
- 40 CONTROL, IDLE SPEED
- 41 SENSOR, THROTTLE POSITION
- 42 SWITCH, FOOT BRAKE
- 43 PDM
- 44 SWITCH, GEAR SHIFT POSITION
- 45 FLASHER
- 46 MOTOR, FAN
- 47 ACTUATOR, 2WD/4WD
- 48 LIGHT, LEFT POSITION
- 49 SIGNAL, FRONT LH TURN
- 50 HEADLIGHT, LH
- 51 CONNECTOR, FRONT SWITCHED ACCESSORY
- 52 CONNECTOR, REAR SWITCHED ACCESSORY
- 53 CONNECTOR, FRONT ACCESSORY
- 54 HEADLIGHT, RH
- 55 SIGNAL, FRONT RH TURN
- 56 LIGHT, RIGHT POSITION
- 57 CONNECTOR, REVERSE LIMIT-HIGH
- 58 CONNECTOR, REVERSE LIMIT-LOW
- 59 CONNECTOR, REVERSE LIMIT

NOTES

1. CONNECTORS VIEWED FROM MATING SURFACE SIDE.

2. ● MOLDED CONNECTOR MALE PIN TERMINAL
○ MOLDED CONNECTOR FEMALE RECEPTACLE TERMINAL